

Altera SoC Embedded Design Suite User Guide



Subscribe



Send Feedback

ug-1137
2016.02.17

101 Innovation Drive
San Jose, CA 95134
www.altera.com

ALTERA
now part of Intel®

Contents

Introduction to SoC Embedded Design Suite.....	1-1
Overview.....	1-1
Linux Device Tree Binary.....	1-2
Hardware and Software Development Roles.....	1-3
Hardware Engineer.....	1-3
Bare-Metal and RTOS Developer.....	1-4
Linux Kernel and Driver Developer.....	1-4
Linux Application Developer.....	1-4
Hardware – Software Development Flow.....	1-5
SoC EDS Introduction Document Revision History.....	1-6
 Installing the Altera SoC Embedded Design Suite.....	 2-1
Installation Folders.....	2-1
Installing the SoC EDS.....	2-1
Installing the ARM DS-5 Altera Edition Toolkit.....	2-2
Installing Altera SoC Embedded Design Suite Document Revision History.....	2-2
 Licensing.....	 3-1
Getting the License.....	3-1
Activating the License.....	3-2
SoC EDS Licensing Document Revision History.....	3-8
 Embedded Command Shell.....	 4-1
Embedded Command Shell Document Revision History.....	4-1
 Getting Started Guides.....	 5-1
Getting Started Guides Document Revision History.....	5-1
 ARM DS-5 AE.....	 6-1
Starting Eclipse ARM DS-5 AE.....	6-1
Bare-Metal Project Management.....	6-2
Bare-Metal Project Management Using Makefiles.....	6-2
GCC-Based Bare-Metal Project Management.....	6-5
ARM Compiler Bare-Metal Project Management.....	6-9
Debugging.....	6-18
Accessing Debug Configurations.....	6-19
Creating a New Debug Configuration.....	6-19
Debug Configuration Options.....	6-21
DTSL Options.....	6-31

ARM DS-5 AE Document Revision History.....	6-36
Boot Tools User Guide.....	7-1
Introduction.....	7-1
Second Stage Bootloader Support Package Generator.....	7-2
BSP Generation Flow.....	7-2
BSP Generator Graphical User Interface.....	7-4
BSP Generator Command Line Interface.....	7-5
BSP Files and Folders.....	7-9
BSP Settings.....	7-9
Second Stage Bootloader Image Tool (mkpimage).....	7-20
Operation.....	7-21
Header File Format.....	7-21
Tool Usage.....	7-23
Output Image Layout.....	7-24
U-Boot Image Tool (mkimage).....	7-25
Tool Options.....	7-26
Usage Examples.....	7-27
Building the Second Stage Bootloader.....	7-27
Building the Cyclone V and Arria V Preloader.....	7-27
Building the Arria 10 Bootloader.....	7-28
Boot Tools User Guide Document Revision History.....	7-29
Hardware Library.....	8-1
Feature Description.....	8-2
SoC Abstraction Layer (SoCAL).....	8-2
Hardware Manager (HW Manager).....	8-2
Hardware Library Reference Documentation.....	8-3
System Memory Map.....	8-3
Hardware Library Document Revision History.....	8-4
HPS Flash Programmer User Guide.....	9-1
HPS Flash Programmer Command-Line Utility.....	9-1
How the HPS Flash Programmer Works.....	9-2
Using the Flash Programmer from the Command Line.....	9-2
HPS Flash Programmer.....	9-2
HPS Flash Programmer Command Line Examples.....	9-4
Supported Memory Devices.....	9-6
HPS Flash Programmer User Guide Document Revision History.....	9-7
Bare-Metal Compiler.....	10-1
Bare Metal Compiler Document Revision History.....	10-2
SD Card Boot Utility.....	11-1
Usage Scenarios.....	11-1

Tool Options.....	11-2
SD Card Boot Utility Document Revision History.....	11-3
 Linux Software Development Tools.....	 12-1
Linux Compiler.....	12-1
Linux Device Tree Generator.....	12-2
Linux Software Development Tools Document Revision History.....	12-2
 Support and Feedback.....	 13-1
Support and Feedback Document Revision History.....	13-1

2016.02.17

ug-1137



Subscribe



Send Feedback

The Altera® system on a chip (SoC) Embedded Design Suite (EDS) provides the tools needed to develop embedded software for Altera's SoC devices.

The Altera SoC EDS is a comprehensive tool suite for embedded software development on Altera SoC devices. The Altera SoC EDS contains development tools, utility programs, run-time software, and application examples that enable firmware and application software development on the Altera SoC hardware platform.

Overview

The Altera SoC EDS enables you to perform all required software development tasks targeting the Altera SoCs, including:

- Board bring-up
- Device driver development
- Operating system (OS) porting
- Bare-metal application development and debugging
- OS- and Linux-based application development and debugging
- Debug systems running symmetric multiprocessing (SMP)
- Debug software targeting soft IP residing on the FPGA portion of the device

The major components of the SoC EDS include:

- ARM® Development Studio 5 (DS-5™) AE (AE) Toolkit
- Compiler tool chains:
 - Bare-metal GNU Compiler Collection (GCC) tool chain from Mentor Graphics®
 - Bare-metal compiler
 - Linux GCC compiler tool chain from Linaro®
- Pre-built Linux package including:
 - Linux kernel executable
 - U-boot image
 - Bootloader Device Tree —Device tree blob consumed by u-boot for A10
 - Linux Device Tree—Device tree blob consumed by Linux
 - Secure Digital (SD) card image
 - Script to download Linux source code from the GitHub repository⁽¹⁾
- SoC Hardware Library (HWLIB)

© 2016 Altera Corporation. All rights reserved. ALTERA, ARRIA, CYCLONE, ENPIRION, MAX, MEGACORE, NIOS, QUARTUS and STRATIX words and logos are trademarks of Altera Corporation and registered in the U.S. Patent and Trademark Office and in other countries. All other words and logos identified as trademarks or service marks are the property of their respective holders as described at www.altera.com/common/legal.html. Altera warrants performance of its semiconductor products to current specifications in accordance with Altera's standard warranty, but reserves the right to make changes to any products and services at any time without notice. Altera assumes no responsibility or liability arising out of the application or use of any information, product, or service described herein except as expressly agreed to in writing by Altera. Altera customers are advised to obtain the latest version of device specifications before relying on any published information and before placing orders for products or services.

ISO
9001:2008
Registered

ALTERA
now part of Intel

- Hardware-to-software interface utilities:
 - Second stage bootloader generator
 - Linux device tree generator
- Sample applications
- Golden Hardware Reference Designs (GHRD) including:
 - FPGA hardware project
 - FPGA hardware SRAM Object File (.sof) file
 - Precompiled Second Stage Bootloaders
 - Preloader for Arria V and Cyclone V
 - Bootloader for Arria 10
- Embedded command shell allowing easy invocation of the included tools
- SD Card Boot Utility
- Quartus® Prime Programmer and SignalTap II

Note: The Linux package included in the SoC EDS is not an official release and is intended to be used only as an example. Use the official Linux release described in the *Golden System Reference Design (GSRD) User Manual* available on the Rocketboards website or a specific release from the Git trees located on the GitHub repository for development.

Note: The SoC EDS is tested only with the Linux release that comes with it. Newer Linux releases may not be fully compatible with this release of SoC EDS.

Note: The Golden Hardware Reference Design (GHRD) included with the SoC EDS is not an official release and is intended to be used only as an example. For development purposes, use the official GHRD release described in the *GSRD User Manual* available on the Rocketboards website.

Related Information

- [Golden System Reference Design User Manual](#)
- [GitHub Repository](#)

Linux Device Tree Binary

There are two different Linux device tree binary (DTB) file versions delivered as part of the SoC EDS:

- The version from the **prebuilt_images** folder: **socfpga_cyclone5.dtb** and **socfpga_arria10.dtb** are generic DTB files which do not have any dependency on soft IP. FPGA programming and bridge releasing are not required before Linux starts running using this DTB.

This DTB file is intended for customers interested in bringing up a new board or just wanting to simplify their boot flow until they get to the Linux prompt. If what is being developed or debugged does not involve the FPGA, it is better to remove the FPGA complexities.

- The version from the hardware design folder: **soc_system.dtb**, **ghrd_5astfd5k3.dtb**, and **ghrd_10as066n2.dtb** are based on the GHRD design, which is part of the GSRD. Since the GHRD does contain soft IPs, these DTB file versions notify Linux to load the soft IP drivers. Therefore, the FPGA needs to be programmed and the bridges released before booting Linux.

⁽¹⁾ The script downloads the sources corresponding to the pre-built Linux package.

Hardware and Software Development Roles

Depending on your role in hardware or software development, you need a different subset of the SoC EDS toolkit. The following table lists some typical engineering development roles and indicates the tools that each role typically requires.

For more information about each of these tools, refer to the **SoC Embedded Design Suite** page.

Table 1-1: Hardware and Software Development Roles

This table lists typical tool usage, but your actual requirements depend on your specific project and organization.

Tool	Hardware Engineer	Bare-Metal Developer	RTOS Developer	Linux Kernel and Driver Developer	Linux Application Developer
ARM DS-5 Debugging	√	√	√	√	√
ARM DS-5 Tracing		√	√	√	
ARM DS-5 Cross Triggering		√	√	√	
Hardware Libraries		√	√	√	
Second Stage Bootloader Generator	√	√	√	√	
Flash Programmer		√	√	√	√
Bare-Metal Compiler	√	√	√	√	
Linux Compiler				√	√
Linux Device Tree Generator				√	

Hardware Engineer

As a hardware engineer, you typically design the FPGA hardware in Qsys. You can use the debugger of ARM DS-5 AE to connect to the ARM cores and test the hardware. A convenient feature of the DS-5 debugger is the soft IP register visibility, using Cortex Microcontroller Software Interface Standard (CMSIS) System View Description (.svd) files. With this feature, you can easily read and modify the soft IP registers from the ARM side.

As a hardware engineer, you may generate the Preloader for your hardware configuration. The Preloader is a piece of software that configures the HPS component according to the hardware design.

As a hardware engineer, you may also perform the board bring-up. You can use ARM DS-5 debugger to verify that they can connect to the ARM and the board is working correctly.

These tasks require JTAG debugging, which is enabled only in the Subscription Edition. For more information, see the *Licensing* section.

Related Information

- [Licensing](#) on page 3-1
- [Hardware – Software Development Flow](#) on page 1-5

For more information about `.svd` files, refer to the Hardware - Software Development Flow section.

Bare-Metal and RTOS Developer

As either a bare-metal or a RTOS developer, you need JTAG debugging and low-level visibility into the system.

Use the bare-metal compiler to compile your code and the SoC Hardware Library to control the hardware in a convenient and consistent way.

Use the Flash Programmer to program the flash memory on the target board.

These tasks require JTAG debugging, which is enabled only in the Subscription Edition. For more information, see the *Licensing* section.

Related Information

[Licensing](#) on page 3-1

Linux Kernel and Driver Developer

As a Linux kernel or driver developer, you may use the same tools the RTOS developers use, because you need low-level access and visibility into the system. However, you must use the Linux compiler instead of the bare-metal compiler. You can use the Linux device tree generator (DTG) to generate Linux device trees.

These tasks require JTAG debugging, which is enabled only in the Subscription Edition.

For more information, see the "Licensing" chapter.

Related Information

[Licensing](#) on page 3-1

Linux Application Developer

As a Linux application developer, you write code that targets the Linux OS running on the board. Because the OS provides drivers for all the hardware, you do not need low-level visibility over JTAG. DS-5 offers a very detailed view of the OS, showing information such as which threads are running and which drivers are loaded.

These tasks do not require JTAG debugging. You can perform them both in the Web and Subscription editions. For more information, see the *Licensing* section.


Related Information

[Licensing](#) on page 3-1

Hardware – Software Development Flow

The Altera hardware-to-software handoff utilities allow hardware and software teams to work independently and follow their respective familiar design flows.

Figure 1-1: Altera Hardware-to-Software Handoff



The following handoff files are created when the hardware project is compiled:

- **Handoff** folder – contains information about how the HPS component is configured, including things like which peripherals are enabled, the pin MUXing and IOCSR settings, and memory parameters
- **.svd** file – contains descriptions of the HPS registers and of the soft IP registers on FPGA side implemented in the FPGA portion of the device
- **.sopcinfo** file – contains a description of the entire system

The handoff folder is used by the second stage bootloader generator to create the preloader.

For more information about the handoff folder, refer to the *BSP Generation Flow* chapter.

The **.svd** file contains the description of the registers of the HPS peripheral registers and registers for soft IP components in the FPGA portion of the SoC. This file is used by the ARM DS-5 Debugger to allow these registers to be inspected and modified by the user.

The SOPC Information (**.sopcinfo**) file, containing a description of the entire system, is used by the Linux device tree generator to create the device tree used by the Linux kernel.

For more information, refer to the "Linux Device Tree Generator" chapter.

Note: The soft IP register descriptions are not generated for all soft IP cores.

Related Information

- [BSP Generation Flow](#) on page 7-2
- [Linux Device Tree Generator](#)
- [SoC Embedded Design Suite Download Page](#)

SoC EDS Introduction Document Revision History

Date	Version	Changes
February 2016	2016.02.17	Maintenance release.
August 2015	2015.08.06	Added Arria 10 support.

2016.02.17

ug-1137



Subscribe



Send Feedback

You must install the Altera SoC Embedded Design Suite (EDS) and the ARM DS-5 AE to run the SoC EDS on an Altera SoC hardware platform.

Installation Folders

The default installation folder for SoC EDS is:

- *<SoC EDS installation directory>*
 - **c:\altera\15.1\embedded** on Windows
 - **~/altera/15.1/embedded** on Linux

The default installation folder for Quartus Prime Programmer is:

- *<Quartus installation directory>*
 - **c:\altera\15.1\qprogrammer** on Windows
 - **~/altera/15.1/qprogrammer** on Linux

Note: The installation directories are defined, as follows:

- *<Altera installation directory>* to denote the location where Altera tools are installed.
- *<SoC EDS installation directory>* to denote the location where SoC EDS is installed.

Installing the SoC EDS

Perform the following steps to install the SoC EDS Tool Suite in a Windows-based system:

1. Download the latest installation program from the *SoC Embedded Design Suite Download Center* page of the Altera website.
2. Run the installer to open the **Installing SoC Embedded Design Suite (EDS)** dialog box, and click **Next** to start the **Setup Wizard**.
3. Accept the license agreement, and click **Next**.
4. Accept the default installation directory or browse to another installation directory, and click **Next**.

Note: If you have previously installed the Quartus Prime software, accept the default *<SoC EDS installation directory>* to allow the Quartus Prime software and the SoC EDS Tool Suite to operate together.

© 2016 Altera Corporation. All rights reserved. ALTERA, ARRIA, CYCLONE, ENPIRION, MAX, MEGACORE, NIOS, QUARTUS and STRATIX words and logos are trademarks of Altera Corporation and registered in the U.S. Patent and Trademark Office and in other countries. All other words and logos identified as trademarks or service marks are the property of their respective holders as described at www.altera.com/common/legal.html. Altera warrants performance of its semiconductor products to current specifications in accordance with Altera's standard warranty, but reserves the right to make changes to any products and services at any time without notice. Altera assumes no responsibility or liability arising out of the application or use of any information, product, or service described herein except as expressly agreed to in writing by Altera. Altera customers are advised to obtain the latest version of device specifications before relying on any published information and before placing orders for products or services.

ISO
9001:2008
Registered

ALTERA
now part of Intel

5. Select **All** the components to be installed, and click **Next**. The installer displays a summary of the installation.
6. Click **Next** to start the installation process. The installer displays a separate dialog box with the installation progress of the component installation.
7. When the installation is complete, turn on **Launch DS-5 Installation** to start the ARM DS-5 installation, and click **Finish**.

Note: On some Linux-based machines, you can install the SoC EDS with a setup GUI similar to the Windows-based setup GUI. Because of the variety of Linux distributions and package requirements, not all Linux machines can use the setup GUI. If the GUI is not available, use an equivalent command-line process. Download the Linux installation program from the *SoC Embedded Design Suite Download Center* page on the Altera website.

Related Information

[SoC Embedded Design Suite Download Center](#)

Installing the ARM DS-5 Altera Edition Toolkit

Before you begin

For the last step of the SoC EDS installation process, start the ARM DS-5 AE Toolkit installer.

Note: Make sure you have the proper setting to access the internet.

1. When the **Welcome** message is displayed, click **Next**.
2. Accept the license agreement and click **Next**.
3. Accept the default installation path, to ensure proper interoperability between SoC EDS and ARM DS-5 AE, and click **Next**.
4. Click **Install** to start the installation process. The progress bar is displayed.
5. When a driver installation window appears, click **Next**.
6. Accept the driver installation and click **Install**.
7. After successful installation, click **Finish**. ARM DS-5 AE installation is complete.
8. Click **Finish**.

Installing Altera SoC Embedded Design Suite Document Revision History

Date	Version	Changes
February 2016	2016.02.17	Updated the installation path to 15.1.
August 2015	2015.08.06	Added Arria 10 support.

2016.02.17

ug-1137



Subscribe



Send Feedback

The SoC EDS is available with three different licensing options:

- Subscription edition
- Free web edition
- 30-day evaluation of subscription edition

The only tool impacted by the selected licensing option is the ARM DS-5 AE. All the other tools offer the same level of features in all licensing options; for example, the second stage bootloader generator and the bare-metal compiler offer the same features no matter which licensing option is used.

The main difference between the licensing options depends on which types of debugging scenarios are enabled:

Licensing Option	Debugging Scenarios Enabled
Web edition	<ul style="list-style-type: none"> • Linux application debugging over ethernet
Subscription edition 30-day evaluation of the subscription edition	<ul style="list-style-type: none"> • JTAG-based Bare-Metal Debugging • JTAG-based Linux Kernel and Driver Debugging • Linux Application Debugging over Ethernet

Getting the License

Depending on the licensing option, it is necessary to follow the steps detailed for each option to obtain the license.

Subscription Edition - If you have purchased the SoC EDS Subscription Edition, then you have already received an ARM license serial number. This is a 15-digit alphanumeric string with two dashes in between. You will need to use this number to activate your license in DS-5, as shown in the *Activating the License* section.

Free Web Edition - For the free SoC EDS Web Edition, you will be able to use DS-5 perpetually to debug Linux applications over an Ethernet connection. Get your ARM license activation code from the SoC Embedded Design Suite download page on the Altera website and then activate your license in DS-5, as shown in the *Activating the License* section.

© 2016 Altera Corporation. All rights reserved. ALTERA, ARRIA, CYCLONE, ENPIRION, MAX, MEGACORE, NIOS, QUARTUS and STRATIX words and logos are trademarks of Altera Corporation and registered in the U.S. Patent and Trademark Office and in other countries. All other words and logos identified as trademarks or service marks are the property of their respective holders as described at www.altera.com/common/legal.html. Altera warrants performance of its semiconductor products to current specifications in accordance with Altera's standard warranty, but reserves the right to make changes to any products and services at any time without notice. Altera assumes no responsibility or liability arising out of the application or use of any information, product, or service described herein except as expressly agreed to in writing by Altera. Altera customers are advised to obtain the latest version of device specifications before relying on any published information and before placing orders for products or services.

ISO
9001:2008
Registered

ALTERA
now part of Intel

30-Day Evaluation of Subscription Edition - If you want to evaluate the SoC EDS Subscription Edition, you can get a 30-Day Evaluation activation code from the SoC Embedded Design Suite download page on the Altera website and then activate your license in DS-5, as shown in the *Activating the License* section.

Related Information

- [SoC EDS Download Page](#)
- [Activating the License](#) on page 3-2


Activating the License

This section presents the steps required for activating the license in the ARM DS-5 AE by using the serial license number or activation code that were mentioned in the "Getting the License" chapter.

Note: An active user account is required to activate the DS-5 AE license. If you do not have an active user account, it can be created on the ARM *Self-Service* page available on the ARM website.


1. The first time the ARM DS-5 is run, it notifies you that it requires a license. Click the **Open License Manager** button.

Figure 3-1: No License Found




2. If at any time it is required to change the license, select **Help > ARM License Manager** to open the **License Manager**.

Figure 3-2: Accessing ARM License Manager




3. The **License Manager - View and edit licenses** dialog box opens and shows that a license is not available. Click the **Add License** button.

Figure 3-3: ARM License Manager




4. In the **Add License - Obtain a new licenses** dialog box, select the type of license to enter. In this example, select the radio button, “**Enter a serial number or activation code to obtain a license**” to enter the choices listed, below. When done, click **Enter**.
 - a. ARM License Number for **Subscription Edition**.
 - b. ARM License Activation Code for **Web Edition** and **30-Day Evaluation**.

Figure 3-4: Add License - Obtain a New License




5. Click **Next**.
6. In the **Add License - Choose Host ID** dialog box, select the Host ID (Network Adapter MAC address) to tie the license to. If there are more than one option, select the one you desire to lock the license to, and click **Next**.

Figure 3-5: Add License - Choose host ID



7. In the **Add License - Developer account details** dialog box, enter an ARM developer (Silver) account. If you do not have an account, it can be created easily by clicking the provided link. After entering the account information, click **Finish**.

Figure 3-6: Add License - Developer Account Details



Note: The License Manager needs to be able to connect to the Internet in order to activate the license. If you do not have an Internet connection, you will need to write down your Ethernet MAC


address and generate the license directly from the *ARM Self-Service* web page on the ARM website, then select the "**Already have a license**" option in the License Manger.

Note: Only the Subscription Edition, with an associated license number can be activated this way. The Web Edition and Evaluation edition are based on activation codes, and these codes cannot be used on the *ARM Self-Service* web page on the ARM website. They need to be entered directly in the License Manager; which means an Internet connection is a requirement for licensing.

The ARM License Manager uses the Eclipse settings to connect to the Internet. The default Eclipse settings use the system-wide configuration for accessing the Internet. In case the License Manager cannot connect to the Internet, you can try to change the Proxy settings by going to **Window > Preferences > General > Network Connections**. Ensure that "HTTPS" proxy entry is configured and enabled.

8. After a few moments, the ARM DS-5 will activate the license and display it in the **License Manager**. Click **Close**.

Figure 3-7: ARM License Manager



Related Information

- [ARM website](#)
- [Getting the License](#) on page 3-1

SoC EDS Licensing Document Revision History

Date	Version	Changes
February 2016	2016.02.17	Maintenance release.
August 2015	2015.08.06	Added Arria 10 support.

2016.02.17

ug-1137



Subscribe



Send Feedback

The purpose of the embedded command shell is to provide an option for you to invoke the SoC EDS tools. It enables you to invoke the SoC EDS tools without qualifying them with the full path. Commands like 'eclipse', 'bsp-editor', or 'arm-altera-eabi-gcc' can be executed directly.

On Windows, the embedded command shell is started by running **<SoC EDS installation directory>\Embedded_Command_Shell.bat**.

On Linux, the embedded command shell is started from the **Start** menu or by running **<SoC EDS installation directory>/embedded_command_shell.sh**.

Embedded Command Shell Document Revision History

Date	Version	Changes
February 2016	2016.02.17	Maintenance release.
August 2015	2015.08.06	Added Arria 10 support.

© 2016 Altera Corporation. All rights reserved. ALTERA, ARRIA, CYCLONE, ENPIRION, MAX, MEGACORE, NIOS, QUARTUS and STRATIX words and logos are trademarks of Altera Corporation and registered in the U.S. Patent and Trademark Office and in other countries. All other words and logos identified as trademarks or service marks are the property of their respective holders as described at www.altera.com/common/legal.html. Altera warrants performance of its semiconductor products to current specifications in accordance with Altera's standard warranty, but reserves the right to make changes to any products and services at any time without notice. Altera assumes no responsibility or liability arising out of the application or use of any information, product, or service described herein except as expressly agreed to in writing by Altera. Altera customers are advised to obtain the latest version of device specifications before relying on any published information and before placing orders for products or services.

ISO
9001:2008
Registered

ALTERA
now part of Intel

2016.02.17

ug-1137



Subscribe



Send Feedback

The Getting Started Guides chapter provides instructions on how to access complete Getting Started instructions including the following:

- Board Setup
- Running Linux
- Running the Tools
- Second Stage Bootloader
- Baremetal Debugging
- Hardware Libraries (HWLibs)
- Peripheral Register Visibility
- Baremetal Project Management
- Linux Application Debugging
- Linux Kernel and Driver Debugging
- Tracing

Related Information

[SoCEDSGettingStarted Wiki Page](#)

For more information on how to access the Getting Started Guides.

Getting Started Guides Document Revision History

Date	Version	Changes
February 2016	2016.02.17	Maintenance release.
August 2015	2015.08.06	Removed content from this section and moved it to the Altera Wiki.

Related Information

[SoCEDSGettingStarted](#)

For more information about getting started, refer to the SoCEDSGettingStarted page on the Altera Wiki.

© 2016 Altera Corporation. All rights reserved. ALTERA, ARRIA, CYCLONE, ENPIRION, MAX, MEGACORE, NIOS, QUARTUS and STRATIX words and logos are trademarks of Altera Corporation and registered in the U.S. Patent and Trademark Office and in other countries. All other words and logos identified as trademarks or service marks are the property of their respective holders as described at www.altera.com/common/legal.html. Altera warrants performance of its semiconductor products to current specifications in accordance with Altera's standard warranty, but reserves the right to make changes to any products and services at any time without notice. Altera assumes no responsibility or liability arising out of the application or use of any information, product, or service described herein except as expressly agreed to in writing by Altera. Altera customers are advised to obtain the latest version of device specifications before relying on any published information and before placing orders for products or services.

ISO
9001:2008
Registered

ALTERA
now part of Intel

2016.02.17

ug-1137



Subscribe



Send Feedback

The ARM Development Studio 5 Toolkit AE (ARM DS-5 AE) is a device-specific exclusive offering from Altera.

The ARM DS-5 AE is a powerful Eclipse-based comprehensive Integrated Development Environment (IDE). Some of the most important provided features are:

- File editing, supporting syntax highlighting and source code indexing
- Build support, based on makefiles
- Bare-metal debugging
- Linux application debugging
- Linux kernel and driver debugging
- Multicore debugging
- Access to HPS peripheral registers
- Access to FPGA soft IP peripheral registers
- Tracing of program execution through Program Trace Macrocells (PTM)
- Tracing of system events through System Trace Macrocells (STM)
- Cross-triggering between HPS and FPGA
- Connecting to the target using Altera USB Blaster™ II

The ARM DS-5 AE is a complex tool with many features and options. This chapter only describes the most common features and options and provides getting started scenarios to help you get started, quickly.

You can access the ARM DS-5 AE reference material from Eclipse, by navigating to **Help > Help Contents > ARM DS-5 Documentation** or online.

Related Information

[Online ARM DS-5 Documentation](#)

The ARM DS-5 AE reference material can be accessed online on the documentation page of the ARM website.

Starting Eclipse ARM DS-5 AE

ARM DS-5 AE must be started from the Embedded Command Shell.

Eclipse needs to be started from the Embedded Command Shell so that all the utilities are added to the search path, and they can be used directly from the makefiles without the full path.

To start the Eclipse IDE that the ARM DS-5 AE uses, you must type **eclipse &** at the command line.

© 2016 Altera Corporation. All rights reserved. ALTERA, ARRIA, CYCLONE, ENPIRION, MAX, MEGACORE, NIOS, QUARTUS and STRATIX words and logos are trademarks of Altera Corporation and registered in the U.S. Patent and Trademark Office and in other countries. All other words and logos identified as trademarks or service marks are the property of their respective holders as described at www.altera.com/common/legal.html. Altera warrants performance of its semiconductor products to current specifications in accordance with Altera's standard warranty, but reserves the right to make changes to any products and services at any time without notice. Altera assumes no responsibility or liability arising out of the application or use of any information, product, or service described herein except as expressly agreed to in writing by Altera. Altera customers are advised to obtain the latest version of device specifications before relying on any published information and before placing orders for products or services.

ISO
9001:2008
Registered

ALTERA
now part of Intel

Bare-Metal Project Management

ARM DS-5 AE enables convenient project management for bare-metal projects using two different methods:

- Using Makefiles
- Using the ARM DS-5 AE graphical interface

Some users prefer Makefiles because they allow the option for the project compilation to be performed from scripts. Other users prefer to use a GUI to manage the project, and this is available for both GCC and ARM Compiler bare-metal projects.

Method	Advantages	Compiler Toolchain Support
Makefile	Scripted compilation	GCC
ARM DS-5 AE graphical interface	Multiple toolchain support	GCC, ARM Compiler

Bare-Metal Project Management Using Makefiles


The ARM DS-5 AE enables convenient project management using makefiles. The sample projects that are provided with SoC EDS use makefiles to manage the build process.

Note: This option refers to just the DS-5 specific aspects. If you are not familiar with defining and using makefiles, please use the ARM DS-5 AE GUI option detailed in the next section.

To allow ARM DS-5 AE to manage a makefile-based project, create a project, as follows:


1. Create a folder on the disk.
2. Create the project by selecting **File > New > Makefile Project with Existing Code**.

Figure 6-1: Creating a Project with Existing Code




3. Type the folder name in the **Existing Code Location** edit box and then click **Finish**.

Figure 6-2: Import Existing Code



4. Create a Makefile in that folder, and define the rules required for compiling the code. Make sure it has the **all** and the **clean** targets.
ARM DS-5 AE now offers the possibility of invoking the build process from the IDE and allows you to build your project, as shown in the following figure:

Figure 6-3: Eclipse IDE - Build Process Invoked - Building a Software Project in ARM DS-5 AE



If the compilation tools issue errors, ARM DS-5 AE parses and formats them for you and displays them in the Problems view.

5. Build a software project in ARM DS-5 AE.


GCC-Based Bare-Metal Project Management

This section shows how the Bare-metal toolchain plugin can be used to manage GCC-based projects in a GUI environment.

Creating Project


1. Start Eclipse.
2. Go to **File > New C Project**.
3. Determine if you want to create an **Executable** empty project or a **Bare-metal library** empty project.
 - a. **Bare-metal executable**
Select **Project Type** to be **Executable > Empty Project** then **Toolchain** to be **Altera Baremetal GCC** then click **Finish**.

Figure 6-4: Bare-Metal Executable Project Type

**b. Static Library**

Select **Bare-metal Library** > **Empty Project** and click Finish.


Figure 6-5: Bare-Metal Library Project Type



Build Settings


Once the project is created, the project properties can be accessed by going to **Project > Properties**.

Figure 6-6: Project Properties



Then, in the **Project Properties** window, the **Compilation** settings can be accessed by selecting **C/C++ Build > Settings**.

Figure 6-7: Project Settings



The **Build Settings** include detailed settings for all tools:

- Compiler
- Assembler
- Linker

The *Getting Started Guides* chapter in this document contains a link to complete instructions on how to create a project from scratch, compile it and run it on an Altera SoC development board.


ARM Compiler Bare-Metal Project Management

This section shows ARM DS-5 can be used to manage ARM compiler projects in a GUI environment.

Creating a Project


1. Start Eclipse.
2. Go to **File > New C Project**.
3. Select one of the following options:
 - a. Select "Project Type" as **Executable > Empty Project** and then for "Toolchains", select **ARM Compiler 5**. Click **Finish**.

Figure 6-8: Create an Empty ARM Compiler Bare-Metal Executable Project



- b. Select **Static Library > Empty Project** and then for "Toolchains", select **ARM Compiler 5**. Click **Finish**.

Figure 6-9: Create an Empty ARM Compiler Bare-metal Library Project




Linker Script

ARM DS-5 AE offers a visual tool to help create linker scripts.


1. Go to **File > New > Other...**

Figure 6-10: Creating a Linker Script




2. Select **Scatter File Editor** > **Scatter File** and press **Next**.

Figure 6-11: Creating a Scatter File




3. Select the location of the new file, type in the file name and press **Finish**.

Figure 6-12: Create a New Scatter File Resource




4. The linker script file can be edited directly as shown in the example below.

Figure 6-13: Linker Script Example



5. The file can also be edited by using the tools on the Outline view for the file.


Figure 6-14: Editing "Scatter.scat" File Using Tools on the Outline View



Build Settings


1. Once the project is created, the project properties can be accessed by going to **Project > Properties**.

Figure 6-15: Project Properties



2. Then, in the **Project Properties** window, the "Compilation" settings can be accessed by selecting **C/C++ Build > Settings**.

Figure 6-16: Project Settings



The build settings include detailed settings for all tools:

- Compiler
- Assembler
- Linker

The "Getting Started with ARM Compiler Bare Metal Project Management" contains a link to complete instructions on how to create a project from scratch, compile it and run it on an Altera SoC development board.

Related Information

[Getting Started Guides](#) on page 5-1


Debugging

The ARM DS-5 AE offers you a variety of debugging features.

Accessing Debug Configurations

The settings for a debugging session are stored in a **Debug Configuration**. The **Debug Configurations** window is accessible from the **Run > Debug Configurations** menu.


Figure 6-17: Accessing Debug Configurations



Creating a New Debug Configuration


A **Debug Configuration** is created in the **Debug Configurations** window by selecting **DS-5 Debugger** as the type of configuration in the left panel and then right-clicking with the mouse and selecting the **New** menu option.

Figure 6-18: Create New Debug Configuration



In the ARM DS-5 AE, you can assign a default name to the configuration, which you can edit.

Figure 6-19: Rename Debug Configuration



Debug Configuration Options

This section lists the **Debug Configuration** options, which allows you to specify the desired debugging options for a project:

- Connection Options
- File Options
- Debugger Options
- RTOS Awareness
- Arguments
- Environment
- Event Viewer

Related Information

- [Getting Started Guides](#)
For examples on how to use the ARM DS-5 AE debugging features.
- [Online ARM DS-5 Documentation](#)
Refer to the DS-5 reference documentation for the complete details.

Connection Options

The **Connection** tab allows the user to select the desired target. The following targets are available for the Altera platforms:

Arria 10 SoC:

- Bare Metal Debug
 - Debug Cortex-A9_0
 - Debug Cortex-A9_1
 - Debug Cortex-A9x2 SMP
- Linux Application Debug
 - Connect to already running **gdbserver**
 - Download and debug application
 - Start **gdbserver** and debug target resident application
- Linux Kernel and/or Device Driver Debug
 - Debug Cortex-A9_0
 - Debug Cortex-A9_1
 - Debug Cortex-A9x2 SMP

Arria V SoC:

- Bare Metal Debug
 - Debug Cortex-A9_0
 - Debug Cortex-A9_1
 - Debug Cortex-A9x2_SMP
- Linux Application Debug
 - Connect to already running **gdbserver**
 - Download and debug application
 - Start **dbgserver** and debug target resident application
- Linux Kernel and/or Device Driver Debug
 - Debug Cortex-A9_0
 - Debug Cortex-A9_1
 - Debug Cortex-A9x2_SMP

Cyclone V SoC (Single Core):

- Bare Metal Debug
 - Debug Cortex-A9_0
- Linux Application Debug
 - Connect to already running **gdbserver**
 - Download and debug application
 - Start **dbgserver** and debug target resident application
- Linux Kernel and/or Device Driver Debug
 - Debug Cortex-A9_0

Cyclone V SoC (Dual Core):

- Bare Metal Debug
 - Debug Cortex-A9_0
 - Debug Cortex-A9_1
 - Debug Cortex-A9x2_SMP
- Linux Application Debug
 - Connect to already running **gdbserver**
 - Download and debug application
 - Start **dbgserver** and debug target resident application
- Linux Kernel and/or Device Driver Debug
 - Debug Cortex-A9_0
 - Debug Cortex-A9_1
 - Debug Cortex-A9x2_SMP

Dual Arria V SoC (Two Dual Core SoCs):

- Bare Metal Debug
 - Debug HPS0 Cortex-A9_0
 - Debug HPS0 Cortex-A9_1
 - Debug HPS0 Cortex-A9x2_SMP
 - Debug HPS1 Cortex-A9_0
 - Debug HPS1 Cortex-A9_1
 - Debug HPS1 Cortex-A9x2_SMP
- Linux Application Debug
 - Connect to already running **gdbserver**
 - Download and debug application
 - Start **dbgserver** and debug target resident application
- Linux Kernel and/or Device Driver Debug
 - Debug HPS0 Cortex-A9_0
 - Debug HPS0 Cortex-A9_1
 - Debug HPS0 Cortex-A9x2_SMP
 - Debug HPS1 Cortex-A9_0
 - Debug HPS1 Cortex-A9_1
 - Debug HPS1 Cortex-A9x2_SMP

Dual Cyclone V SoC (Two Dual Core SoCs):



- Bare Metal Debug
 - Debug HPS0 Cortex-A9_0
 - Debug HPS0 Cortex-A9_1
 - Debug HPS0 Cortex-A9x2_SMP
 - Debug HPS1 Cortex-A9_0
 - Debug HPS1 Cortex-A9_1
 - Debug HPS1 Cortex-A9x2_SMP
- Linux Application Debug
 - Connect to already running **gdbserver**
 - Download and debug application
 - Start **dbgserver** and debug target resident application
- Linux Kernel and/or Device Driver Debug
 - Debug HPS0 Cortex-A9_0
 - Debug HPS0 Cortex-A9_1
 - Debug HPS0 Cortex-A9x2_SMP
 - Debug HPS1 Cortex-A9_0
 - Debug HPS1 Cortex-A9_1
 - Debug HPS1 Cortex-A9x2_SMP

Android Application Debug:

- Native Application/Library Debug
 - APK Native Library Debug via `gdbserver`
 - Attach to a running Android application
 - Download and debug an Android application


Linux Application Debug:

- Application Debug
 - Connections via `gdbserver`
 - Connect to already running **gdbserver**
 - Download and debug application
 - Start **dbgserver** and debug target resident application

Depending on the selected Target, the Connections panel will look different. For Bare Metal Debug and Linux Kernel and/or Device Driver Debug target types:

- A Target Connection option appears and it allows the user to select the type of connection to the target. Altera USB-Blaster and DSTREAM are two of the most common options.
- A DTSL option appears, allowing the user to configure the Debug and Traces Services Layer (detailed later).
- A Connections Browse button appears, allowing the user to browse and select either of the specific instances for the connection— Altera USB-Blaster or the DSTREAM instance.

Figure 6-20: Connection Options for Bare-metal and Linux Kernel and/or Device Driver Debug



For the **Linux Application Debug** targets, the connection parameters will be different depending on which type of connection was selected. The following two pictures illustrate the options.

Figure 6-21: Linux Application Debugging – Connect to a Running GDB Server





Figure 6-22: Linux Application Debugging – Download And Debug Application



Note: For the **Linux Application Debug**, the **Connection** needs to be configured in the **Remote System Explorer** view, as shown in *Getting Started with Linux Application Debugging*.

Related Information


- [DTSL Options](#) on page 6-31
For more information about the option on the Connections tab, refer to the DTSL Options section.
- [Debugger Options](#) on page 6-28
- [Getting Started Guides](#) on page 5-1

Files Options

The **Files** tab allows the following settings to be configured:

- **Application on host to download** – the file name of the application to be downloaded to the target. It can be entered directly in the edit box or it can be browsed for in the **Workspace** or on the **File System**.
- **Files** – contains a set of files. A file can be added to the set using the “+” button, and files can be removed from the set using the “-” button. Each file can be one of the following two types:
 - **Load symbols from file** – the debugger will use that file to load symbols from it,
 - **Add peripheral description files from directory** – the debugger to load peripheral register descriptions from the .SVD files stored in that directory. The SVD file is a result of the compilation of the hardware project.

Figure 6-23: Files Settings




Debugger Options

The **Debugger** tab offers the following configurable options

- **Run Control Options**
 - Option to connect only, debug from entry point or debug from user-defined symbol,
 - Option to run user-specified target initialization script,
 - Option to run user-specified debug initialization script,
 - Option to execute user-defined debugger commands
- **Host working directory** – used by semihosting
- **Paths** – allows the user to enter multiple paths for the debugger to search for sources. Paths can be added with “+” button and removed with “-” button.


Figure 6-24: Debugger Settings



RTOS Awareness

The **RTOS Awareness** tab allows the user to enable RTOS awareness for the debugger.

Figure 6-25: RTOS Awareness Settings



Related Information


[Keil Website](#)

For more information about RTOS Awareness, refer to the Embedded Development Tools page on the Keil™ website.

Arguments

The **Arguments** tab allows the user to enter program arguments as text.


Figure 6-26: Arguments Settings



Environment

The **Environment** tab allows the user to enter environment variables for the program to be executed.


Figure 6-27: Environment Settings



DTSL Options

The Debug and Trace Services Layer (DTSL) provides tracing features. To configure trace options, in your project's **Debug Configuration** window, in the "Connection" tab, click the **Edit** button to open the **DTSL Configuration** window.

Figure 6-28: Debug Configurations - DTSL Options - Edit




Cross Trigger Settings

The **Cross Trigger** tab allows the configuration of the cross triggering option of the SoC FPGA.

The following options are available:

- **Enable FPGA > HPS Cross Trigger** – for enabling triggers coming from FPGA to HPS
- **Enable HPS > FPGA Cross Trigger** – for enabling triggers coming from HPS to FPGA

Figure 6-29: DTSL Configuration Editor - Cross Trigger




Trace Capture Settings

The **Trace Capture** tab allows the selection of the destination of the trace information. As mentioned in the introduction, the destination can be one of the following:

- **None** – meaning the tracing is disabled
- **ETR** – using any memory buffer accessible by HPS
- **ETF** – using the 32KB on-chip trace buffer
- **DSTREAM** – using the 4GB buffer located in the DSTREAM


The DSTREAM option is available only if the **Target** connection is selected as **DSTREAM** in the **Debug Configuration**.

Figure 6-30: DTSL Configuration Editor - Trace Capture > Trace Capture Method



The **Trace Buffer** tab provides the option of selecting the timestamp frequency.

Figure 6-31: DTSL Configuration Editor - Trace Capture > Timestamp Frequency



Cortex-A9 Settings

The **Cortex-A9** tab allows the selection of the desired core tracing options.

Figure 6-32: DTSL Configuration Editor - Cortex-A9

The screenshot shows the 'Cortex-A9' tab in the DTSL Configuration Editor. The 'Enable Cortex-A9 core trace' checkbox is checked. Below it, 'Enable Cortex-A9 0 trace' and 'Enable Cortex-A9 1 trace' are checked, while 'PTM Triggers halt execution' is unchecked. 'Enable PTM Timestamps' is checked. The 'Timestamp period' is set to 4000. 'Enable PTM Context IDs' is checked, and the 'Context ID Size' is set to 32 bit. 'Cycle Accurate' and 'Trace capture range' are unchecked. The 'Start address' is 0x0 and the 'End address' is 0xFFFFFFFF.


The following **Core Tracing Options** are available:

- **Enable Cortex-A9 0 core trace** – check to enable tracing for core #0
- **Enable Cortex-A9 1 core trace** – check to enable tracing for core #1
- **PTM Triggers halt execution** – check to cause the execution to halt when tracing
- **Enable PTM Timestamps** – check to enable time stamping
- **Enable PMT Context IDs** – check to enable the context IDs to be traced
- **Context ID Size** – select 8-, 16- or 32-bit context IDs. Used only if Context IDs are enabled
- **Cycle Accurate** – check to create cycle accurate tracing
- **Trace capture range** – check to enable tracing only a certain address interval
- **Start Address, End Address** – define the tracing address interval (Used only if the Trace Capture Range is enabled)

STM Settings

The **STM** tab allows you to configure the System Trace Macrocell (STM).

Figure 6-33: DTSL Configuration Editor - STM



Only one option is available:


- **Enable STM Trace** – check to enable STM tracing.

ETR Settings

The **ETR** settings allow the configuration of the Embedded Trace Router (ETR) settings.

The Embedded Trace Router is used to direct the tracing information to a memory buffer accessible by HPS.

Figure 6-34: DTSL Configuration Editor - ETR



The following options are available:


- **Configure the system memory trace buffer** – check this if the **ETR** is selected for trace destination on the **Trace Capture** tab.
- **Start Address, Size** – define the trace buffer location in system memory and its size.
- **Enable scatter-gather mode** – use when the OS cannot guarantee a contiguous piece of physical memory. The scatter-gather table is setup by the operating system using a device driver and is read automatically by the ETR.

ETF Settings

The **ETF** tab allows the configuration of the Embedded Trace FIFO (ETF) settings.

The Embedded Trace FIFO is a 32KB buffer residing on HPS that can be used to store tracing data to be retrieved by the debugger, but also as an elastic buffer for the scenarios where the tracing data is stored in memory through ETR or on the external DSTREAM device using TPIU.

Figure 6-35: DTSL Configuration Editor - ETF



The following options are available:

- **Configure the on-chip trace buffer** – check this if ETF is selected for trace destination on the **Trace Capture** tab.
- **Size** – define the ETF size. The default size is set to 0x8000 (32KB).

ARM DS-5 AE Document Revision History

Date	Version	Changes
February 2016	2016.02.17	Updated default size in ETF Settings.
August 2015	2015.08.06	Added Arria 10 support.

2016.02.17

ug-1137



Subscribe



Send Feedback

Introduction

The boot flow for all Altera SoC devices includes the second stage bootloader (SSBL). The SSBL is usually referred to as “preloader” in the context of Cyclone V and Arria V devices, and “bootloader” in the context of Arria 10 devices.

The SSBL is loaded by the boot ROM into the on-chip RAM (OCRAM) and has the task of bringing up the SDRAM, and loading and executing the next stage in the boot process.

Figure 7-1: Cyclone V and Arria V Typical Boot Flow




Figure 7-2: Arria 10 Typical Boot Flow



For Cyclone V and Arria V devices, the OCRAM size is 64 KB, which limits the SSBL size and typically requires an additional bootloader stage, which then is used to load an operating system.

For Arria 10 devices, there is no need for an additional bootloader stage, because the OCRAM size is 256 KB and the required functionality is included in the SSBL.

This chapter presents the tools that are used to enable the SSBL management:

- **SSBL Support Package Generator** – enables the user to create and manage the SSBL
- **SSBL Image Tool (mkpimage)** – enables to user to add the boot ROM-required header on top of the SSBL
- **U-Boot Image Tool (mkimage)**: enables the user to add the SSBL-required header on top of the files loaded by SSBL

Second Stage Bootloader Support Package Generator

The Second Stage Bootloader (SSBL) Support Package Generator provides an easy, safe, and reliable way to customize the SSBL for the Altera SoC devices.

The SSBL Support Package is referred to as “BSP” and the SSBL Support Package Generator is referred to as “BSP Generator” for the remainder of this document.

The BSP Generator allows you to perform the following tasks:

- Create a new BSP
- Report BSP settings
- Modify BSP settings
- Generate BSP files

The generated BSP includes a makefile, which can be used to build the corresponding bootable Preloader or Bootloader image.

The BSP Generator functionality can be accessed from a Graphical User Interface or by using a set of command line tools, which allow complete scripting of the flow.


BSP Generation Flow

This section presents the BSP generation flow for both the Cyclone V and Arria V Preloader and Arria 10 Bootloader. While the flows are similar, there are some important differences.

Cyclone V and Arria V Flow

For Cyclone V and Arria V, the BSP Generator creates a customized BSP with preloader generic source files and board-specific SoC FPGA files. The generator consolidates the hardware settings and user inputs to create the BSP. The BSP files include a makefile to create the preloader image. The preloader image can then be downloaded to a Flash device or FPGA RAM to be used for booting HPS.

Figure 7-3: Arria V/ Cyclone V BSP Generator Flow



The hardware handoff information contains various settings that the user entered when creating the hardware design in Qsys and Quartus Prime. These include the following:

- Pin-muxing for the HPS dedicated pins
- I/O settings for the HPS dedicated pins:
 - Voltage
 - Slew rate
 - Pull up/ down
- State of HPS peripherals:
 - Enabled
 - Disabled
- Configuration of the bridges between HPS and FPGA
- Clock tree settings:
 - PLL settings
 - Clock divider settings
 - Clock gating settings
- DDR settings:
 - Technology
 - Width
 - Speed


The handoff settings are output from the Quartus Prime compilation and are located in the **<quartus project directory>/hps_isw_handoff/<hps entity name>** directory (where **<hps entity name>** is the HPS component name in Qsys).

You must update the hardware handoff files and regenerate the BSP each time a hardware change impacts the HPS, such as after pin multiplexing or pin assignment changes.

Arria 10 Flow

For Arria 10, the BSP Generator creates a customized BSP consisting of a makefile and a Bootloader Device Tree. There is no source code generated, as all customization is encapsulated in the Bootloader Device Tree and makefile settings. The makefile can be used to create the combined bootloader image, which contains both the bootloader executable and the bootloader device tree. The combined image can then be downloaded to a Flash device or FPGA RAM to be used for booting HPS.

Figure 7-4: Arria 10 SSBL Support Package Generator Flow



The hardware handoff information contains various settings that the user entered when creating the hardware design in Qsys and Quartus Prime. These include the following:

- Pin-muxing for the HPS dedicated pins
- I/O settings for the HPS dedicated pins:
 - Voltage
 - Slew rate
 - Pull up/ down
- Pin-muxing for the shared pins
- State of HPS peripherals:
 - Enabled
 - Disabled
- Configuration of the bridges between HPS and FPGA
- Clock tree settings:
 - PLL settings
 - Clock divider settings
 - Clock gating settings

The handoff settings are output from the Quartus Prime compilation and are located in the **<quartus project directory>/hps_isw_handoff** directory.

The user must run the BSP Generator and re-generate the Bootloader device tree each time a hardware change results in a change of the above parameters.

However, the user does not have to always recompile the Bootloader whenever a hardware setting is changed. The Bootloader needs to be recompiled only when changing the boot source.

BSP Generator Graphical User Interface

You must perform the following steps to use the BSP Generator GUI, **bsp -editor**:

1. Start an embedded command shell.
2. Run the **bsp -editor** command in the embedded command shell to launch the BSP Generator GUI.
3. To open and modify an existing BSP project, click **File > Open** and browse to an existing .bsp file.
4. To create a new BSP project, click **File > New HPS BSP** to open the **New BSP** dialog box. The **New BSP** dialog box includes the following settings and parameters:
 - **Preloader settings directory** – the path to the hardware handoff files. The generator inspects the handoff files to verify the validity of this path.
 - **Operating system** – Select the type of SSBL from the following two options:
 - U-Boot SPL Preloader (Cyclone V/Arria V HPS)
 - U-Boot Bootloader (Arria 10 HPS)
 - **Version** – the SSBL version to use. This release only supports the default 1.0 version.
 - **Use default locations** – checked by default, to derive the location of the BSP from the location of the hardware handoff folder. Uncheck if a custom path is desired instead.

- **BSP target directory** – the destination folder for new BSP files created by the generator. This document refers to this as < **bsp directory**>. The default directory name is “spl_bsp” for the Arria V/ Cyclone V Preloader and “uboot_bsp” for the Arria 10 Bootloader. The directory name can be modified when **Use default locations** is unchecked.
- **BSP settings file name** – the location and filename of the **.bsp** file containing the BSP settings.
- **Additional .tcl scripting** – the location and filename of a .tcl script for overriding the default BSP settings.

5. You can customize the BSP. After creating or opening a .bsp file, access the **Settings** in the **BSP Editor** dialogue box. The Settings are divided into Common and Advanced settings. When you select a group of settings, the controls for the selected settings appear on the right side of the dialogue box.

When you select a single setting, the setting name, description and value are displayed. You can edit these settings in the **BSP Editor** dialogue box.

6. Click **Generate** to generate the BSP.

7. Click **Exit** to exit the BSP Generator GUI.

Using .tcl Scripts

Instead of using the default settings, you can create a tcl script file (**.tcl**) to define custom settings during BSP creation.

set_setting is the only available **.tcl** command.

Refer to BSP Settings for a list of available settings.

The following shows example commands that are used to set parameters in the BSP settings file:

```
set_setting spl.boot.BOOT_FROM_QSPI true
set_setting spl.boot.QSPI_NEXT_BOOT_IMAGE 0x50000
```

Related Information

[BSP Settings](#) on page 7-9

BSP Generator Command Line Interface

The BSP command-line tools can be invoked from the embedded command shell, and provide all the features available in the BSP Generator GUI:

- The **bsp-create-settings** tool creates a new BSP settings file.
- The **bsp-update-settings** tool updates an existing BSP settings file.
- The **bsp-query-settings** tool reports the setting values in an existing BSP settings file.
- The **bsp-generate-files** tool generates a BSP from the BSP settings file.

Note: Help for each tool is available from the embedded command shell. To display help, type the following command: <name of tool> --help.

bsp-create-settings

The **bsp-create-settings** tool creates a new BSP settings file with default settings. You have the option to modify the BSP settings or generate the BSP files as shown in the following example.

Example 7-1: Creating a New BSP Settings File

The following example creates a new Preloader BSP settings file, based on the hardware handoff information and using the default BSP settings:

```
bsp-create-settings --type spl --bsp-dir . \
  --settings settings.bsp \
  --preloader-settings-dir ../../hps_isw_handoff/<hps_entity_name>
```

Table 7-1: User Parameters: bsp-create-settings

Option	Required	Description
<code>--type <bsp type></code>	Yes	This option specifies the type of BSP. Allowed values are "spl" for Cyclone V/Arria V Preloader, and "uboot" for Arria 10 Bootloader.
<code>--settings <filename></code>	Yes	This option specifies the path to a BSP settings file. The file is created with default settings. Altera recommends that you name the BSP settings file "settings.bsp".
<code>--preloader-settings-dir <directory></code>	Yes	This option specifies the path to the hardware handoff files.
<code>--bsp-dir <directory></code>	Yes	This option specifies the path where the BSP files are generated. When specified, bsp - create-settings generates the files after the settings file has been created. Altera recommends that you always specify this parameter with bsp - create-settings .
<code>--set <name> <value></code>	No	This option sets the BSP setting <name> to the value <value>. Multiple instances of this option can be used with the same command. Refer to BSP Settings for a complete list of available setting names and descriptions.

bsp-update-settings

The **bsp-update-settings** tool updates the settings stored in the BSP settings file, as shown in the following example.

Example 7-2: Updating a BSP Settings File

The following command changes the value of a parameter inside the file "settings.bsp":

```
bsp-update-settings --settings settings.bsp --set spl.debug.SEMIHOSTING 1
```

Table 7-2: User Parameters: bsp-update-settings

Option	Required	Description
--settings <settings-file>	Yes	This option specifies the path to an existing BSP settings file to update.
--bsp-dir <bsp-dir>	No	This option specifies the path where the BSP files are generated. When this option is specified, bsp -create-settings generates the BSP files after the settings file has been created.
--set <name> <value>	No	This option sets the BSP setting <name> to the value <value>. Multiple instances of this option can be used with the same command. Refer to BSP Settings for a complete list of available setting names and descriptions.

bsp-query-settings

The **bsp-query-settings** tool queries the settings stored in BSP settings file, as shown in the following example.

Example 7-3: Querying a BSP Settings File

The following command will retrieve all the settings from "settings.bsp" and displays the setting names and values:

```
bsp-query-settings --settings settings.bsp --get-all --show-names
```

Table 7-3: User Parameters: bsp-query-settings

Option	Required	Description
--settings <settings-file>	Yes	This option specifies the path to an existing BSP settings file.

Option	Required	Description
<code>--get <name></code>	No	This option instructs bsp - query-settings to return the value of the BSP setting <code><name></code> .
<code>--get-all</code>	No	This option shows all the BSP settings values. When using <code>--get-all</code> , you must also use <code>--show-names</code> .
<code>--show-names</code>	No	This option only takes effect when used together with <code>--get <name></code> or <code>--get-all</code> . When used with one of these options, names and values of the BSP settings are shown side-by-side.

bsp-generate-files

The **bsp-generate-files** tool generates the files and settings stored in BSP settings file, as shown in the following examples.

Example 7-4: Generating Files After BSP Creation

The following commands create a settings file based on the handoff folder, and then generate the BSP files based on those settings:

```
bsp-create-settings --type spl --bsp-dir . \
--settings settings.bsp \
--preloader-settings-dir \
../../hps_isw_handoff/<hps_entity_name>
bsp-generate-files --settings settings.bsp --bsp-dir
```

Example 7-5: Generating Files After BSP Updates

The following commands update the settings of an existing BSP settings file, and then generate the BSP files based on those settings:

```
bsp-update-settings --settings settings.bsp --set \
spl.debug.SEMIHOSTING 1
bsp-generate-files --settings settings.bsp --bsp-dir
```

Use the **bsp-generate-files** tool when BSP files need to be regenerated in one of the following conditions:

- **bsp-create-settings** created the BSP settings, but the `--bsp-dir` parameter was not specified, so BSP files were not generated.
- **bsp-update-settings** updated the BSP settings, but the `--bsp-dir` parameter was not specified, so the files were not updated.
- You want to ensure the BSP files are up-to-date.

Table 7-4: User Parameters: bsp-generate-files

Option	Required	Description
<code>--settings <settings-file></code>	Yes	This option specifies the path to an existing BSP settings file.
<code>--bsp-dir <bsp-dir></code>	Yes	This option specifies the path where the BSP files are generated.

BSP Files and Folders

The files and folders created with the BSP Generator are stored in the location you specified in **BSP target directory** in the **New BSP** dialog box.

For Cyclone V/Arria Preloader BSPs, the generated files include the following:

- **settings.bsp** – file containing all BSP settings
- **Makefile** – makefile used to compile the Preloader and create the preloader image; for more information, refer to Preloader Compilation
- **preloader.ds** – ARM DS-5 script, that can be used to download and debug the Preloader on a target device
- **generated** – folder containing files generated from the hardware handoff files

For Arria 10 Bootloader BSPs, the generated files include the following:

- **settings.bsp** – file containing all BSP settings
- **Makefile** – makefile used to compile the Bootloader, convert the Bootloader device tree file to binary, and create the combined Bootloader and Bootloader Device Tree image; for more information, refer to Preloader Compilation
- **config.mk** – makefile configuration file, containing the boot source selection and whether the Bootloader compilation is selected
- **devicetree.dts** – Bootloader device tree, containing the Bootloader customization details, derived from the handoff files and the user settings
- **uboot .ds** – ARM DS-5 script, that can be used to download and debug the Bootloader on a target device

BSP Settings

This section lists all the available BSP settings, which can be accessed from either the Graphical User Interface application (**bsp-editor**) or from the command line tools (**bsp-create-settings**, **bsp-update-settings**, **bsp-query-settings**).

The available BSP settings are different between Cyclone V and Arria V SSBL (Preloader) and Arria 10 SSBL (Bootloader).

Cyclone V and Arria V BSP Settings

Table 7-5: Cyclone V and Arria V BSP Settings

BSP Setting	Type	Default Value	Description
<code>spl.PRELOADER_TGZ</code>	String	"<SoC EDS installation directory>/host_tools/altera/preloader/uboot-socfpga.tar.gz"	This setting specifies the path to archive file containing the preloader source files.
<code>spl.CROSS_COMPILE</code>	String	"arm-altera-eabi-"	This setting specifies the cross compilation tool chain for use.
<code>spl.boot.BOOT_FROM_QSPI</code>	Boolean	False	Select the source for the subsequent boot image. Note that only one source can be active at a time. When using bsp-create-settings or bsp-update-settings , you must turn off the boot option that is currently turned on before you can turn on a different boot option.
<code>spl.boot.BOOT_FROM_SDMMC</code>	Boolean	True	
<code>spl.boot.BOOT_FROM_RAM</code>	Boolean	False	
<code>spl.boot.BOOT_FROM_NAND</code>	Boolean	False	
<code>spl.boot.QSPI_NEXT_BOOT_IMAGE</code>	Hexadecimal	0x60000	This setting specifies the location of the subsequent boot image in QSPI.
<code>spl.boot.SDMMC_NEXT_BOOT_IMAGE</code>	Hexadecimal	0x40000	This setting specifies the location of the subsequent boot image in SD/MMC.
<code>spl.boot.NAND_NEXT_BOOT_IMAGE</code>	Hexadecimal	0xC0000	This setting specifies the location of the subsequent boot image in NAND.
<code>spl.boot.FAT_SUPPORT</code>	Boolean	False	Enable FAT partition support when booting from SD/MMC.
<code>spl.boot.FAT_BOOT_PARTITION</code>	Decimal-Number	1	When FAT partition support is enabled, this specifies the FAT partition where the boot image is located.
<code>spl.boot.FAT_LOAD_PAYLOAD_NAME</code>	String	"u-boot.img"	When FAT partition supported is enabled, this specifies the boot image filename to be used.

BSP Setting	Type	Default Value	Description
<code>spl.boot.WATCHDOG_ENABLE</code>	Boolean	True	This setting enables the watchdog during the preloader execution phase. The watchdog remains enabled after the preloader exits.
<code>spl.boot.CHECKSUM_NEXT_IMAGE</code>	Boolean	True	This setting enables the preloader to validate the checksum in the subsequent boot image header information.
<code>spl.boot.EXE_ON_FPGA</code>	Boolean	False	This setting executes the preloader on the FPGA. Select <code>spl.boot.EXE_ON_FPGA</code> when the preloader is configured to boot from the FPGA.
<code>spl.boot.STATE_REG_ENABLE</code>	Boolean	True	This setting enables writing the magic value to the INITSWSTATE register in the system manager when the preloader exists; this indicates to the boot ROM that the preloader has run successfully.
<code>spl.boot.BOOTROM_HANDSHAKE_CFGIO</code>	Boolean	True	This setting enables handshake with boot ROM when configuring the IOCSR and pin multiplexing. If <code>spl.boot.BOOTROM_HANDSHAKE_CFGIO</code> is enabled and warm reset occurs when the preloader is configuring IOCSR and pin multiplexing, the boot ROM will reconfigure IOCSR and pin multiplexing again. This option is enabled by default.
<code>spl.boot.WARMRST_SKIP_CFGIO</code>	Boolean	True	This setting enables the preloader to skip IOCSR and pin multiplexing configuration during warm reset. <code>spl.boot.WARMRST_SKIP_CFGIO</code> is only applicable if the boot ROM has skipped IOCSR and pin multiplexing configuration.
<code>spl.boot.SDRAM_INITIALIZATION</code>	Boolean	False	Initialize the SDRAM to initialize the ECC bits.

BSP Setting	Type	Default Value	Description
<code>spl.boot.SDRAM_ECC_INIT_BOOT_REGION_START</code>	Hexadecimal	0x1000000	The start address of the memory region within the SDRAM to be initialized.
<code>spl.boot.SDRAM_ECC_INIT_BOOT_REGION_END</code>	Hexadecimal	0x2000000	The end address of the memory region within SDRAM to be initialized.
<code>spl.boot.SDRAM_ECC_INIT_REMAIN_REGION</code>	Boolean	True	Initialize the remaining SDRAM, during the flash accesses to load the image.
<code>spl.debug.DEBUG_MEMORY_WRITE</code>	Boolean	False	This setting enables the preloader to write debug information to memory for debugging, useful when UART is not available. The address is specified by <code>spl.debug.DEBUG_MEMORY_ADDR</code> .
<code>spl.debug.SEMIHOSTING</code>	Boolean	False	This setting enables semihosting support in the preloader, for use with a debugger tool. <code>spl.debug.SEMIHOSTING</code> is useful when UART is unavailable.
<code>spl.debug.SKIP_SDRAM</code>	Boolean	False	The preloader skips SDRAM initialization and calibration when this setting is enabled.
<code>spl.performance.SERIAL_SUPPORT</code>	Boolean	True	This setting enables UART print out support, enabling preloader code to call <code>printf()</code> at runtime with debugging information. <code>stdout</code> output from <code>printf()</code> is directed to the UART. You can view this debugging information by connecting a terminal program to the UART specified peripheral.

BSP Setting	Type	Default Value	Description
<code>spl.reset_assert.DMA</code>	Boolean	False	When enabled, this setting will force the corresponding peripheral to remain in reset. You must ensure the debugger does not read registers from these components.
<code>spl.reset_assert.GPIO0</code>	Boolean	False	
<code>spl.reset_assert.GPIO1</code>	Boolean	False	
<code>spl.reset_assert.GPIO2</code>	Boolean	False	
<code>spl.reset_assert.L4WD1</code>	Boolean	False	
<code>spl.reset_assert.OSC1TIMER1</code>	Boolean	False	
<code>spl.reset_assert.SDR</code>	Boolean	False	
<code>spl.reset_assert.SPTIMER0</code>	Boolean	False	
<code>spl.reset_assert.SPTIMER1</code>	Boolean	False	
<code>spl.warm_reset_handshake.FPGA</code>	Boolean	True	This setting enables the reset manager to perform handshake with the FPGA before asserting a warm reset.
<code>spl.warm_reset_handshake.ETR</code>	Boolean	True	This setting enables the reset manager to request that the Embedded Trace Router (ETR) stalls the Advanced eXtensible Interface (AXI) master and waits for the ETR to finish any outstanding AXI transactions before asserting a warm reset of the L3 interconnect or a debug reset of the ETR.

BSP Setting	Type	Default Value	Description
<code>spl.warm_reset_</code> <code>handshake.SDRAM</code>	Boolean	False	<p>This option allows the SDRAM contents to be preserved accros warm resets.</p> <p>Note: When using this option, the SDRAM controller is not completely re-initialized when coming back from warm reset. This may be a problem whenever the warm reset is generated by the Watchdog as a consequence of an SDRAM controller failure.</p> <p>Note: Also the SDRAM PLL is not re-initialized when this option is enabled and the system comes out of the warm reset.</p>
<code>spl.boot.FPGA_MAX_SIZE</code>	Hexadecimal	0x10000	This setting specifies the maximum code (.text and .rodata) size that can fit within the FPGA. If the code build is bigger than the specified size, a build error is triggered.
<code>spl.boot.FPGA_DATA_BASE</code>	Hexadecimal	0xFFFF0000	This setting specifies the base location for the data region (.data , .bss , heap and stack) when execute on FPGA is enabled.
<code>spl.boot.FPGA_DATA_MAX_SIZE</code>	Hexadecimal	0x10000	This setting specifies the maximum data (.data , .bss , heap and stack) size that can fit within FPGA. If the code build is bigger than the specified size, a build error is triggered.
<code>spl.debug.DEBUG_MEMORY_ADDR</code>	Hexadecimal	0xFFFFFD00	This setting specifies the base address for storing preloader debug information enabled with the <code>spl.debug.DEBUG_MEMORY_WRITE</code> setting.

BSP Setting	Type	Default Value	Description
<code>spl.debug.DEBUG_MEMORY_SIZE</code>	Hexadecimal	0x200	This setting specifies the maximum size used for storing preloader debug information.
<code>spl.debug.DEBUG_MEMORY_ADDR</code>	Hexadecimal	0xFFFFFD00	This setting specifies the base address for storing preloader debug information enabled with the <code>spl.debug.DEBUG_MEMORY_WRITE</code> setting.
<code>spl.debug.HARDWARE_DIAGNOSTIC</code>	Boolean	False	Enable hardware diagnostic support. To enable this, at least 1GB of memory is needed, otherwise hardware diagnostic will fail to run properly.
<code>spl.boot.RAMBOOT_PLRESET</code>	Boolean	True	Execute RAM Boot PLL reset code on warm reset when CSEL = 00. This option is required to enable correct warm reset functionality when using CSEL = 00. When enabling this option, the upper 4 KB of OCRAM are reserved and must not be modified by the user software. Note: Enabling this feature with CSEL != 00 does not have any effect, as the impacted code checks for this.

Arria 10 BSP Settings

The Arria 10 BSP Settings are divided in four different groups:

- Main Group
- MPU Firewall
- L3 Firewall Group
- F2S Firewall Group

The following table presents the settings prefix to be added in front of the setting name for each of the groups. They are presented in a table to make the rest of this section more readable.

Table 7-6: Arria 10 BSP Firewall Setting Prefixes

Settings Group	Setting Group Prefix
Main Group	N/A
MPU Firewall	<code>mpu_m0.noc_fw_ddr_mpu_fpga2sdram_ddr_scr.*</code>

Settings Group	Setting Group Prefix
L3 Firewall Group	mpu_m0.noc_fw_ddr_l3_ddr_scr.*
F2S Firewall Group	mpu_m0.noc_fw_ddr_mpu_fpga2sdram_ddr_scr.*

Arria 10 Main BSP Settings Group

Table 7-7: Arria 10 Main BSP Settings Group

BSP Setting	Type	Default Value	Description
uboot.boot_device	String	"SD/MMC"	Select the source for the boot image. Possible values are SD/MMC and QSPI.
uboot.model	String	"SOCFPGA Arria10 Dev Kit"	Name of the board to be displayed when bootloader starts.
uboot.external_fpga_config	Boolean	False	Configure Uboot to wait early on in the boot sequence to allow the FPGA to be brought to user mode by either a JTAG download or an externally connected flash.
uboot.rbf_filename	String	socfpga.rbf	Full FPGA .rbf filename. This setting is ignored when the uboot.external_fpga_config setting is enabled.
uboot.rbf_offset	Hexadecimal	0x720000	RBF offset address in QSPI Flash.
uboot.disable_uboot_build	Boolean	False	Can be used to disable building Uboot, and just generate the Bootloader Device Tree file.
uboot.secureboot.enable_bootloader_encryption	Boolean	0	Encrypt Bootloader using key file specified.
uboot.secureboot.enable_bootloader_signing	Boolean	0	Sign Bootloader using the key pair file specified.
uboot.secureboot.encryption_key_file	String	encrypt.key	Key file used for Bootloader encryption.
uboot.secureboot.encryption_key_name	String	key1	Key Name to use within Key File for Bootloader Encryption.
uboot.secureboot.signing_key_fpga_offset	Hexadecimal	0x0	Offset from H2F Bridge Base Address (0xc0000000) to location of root-public-key.

BSP Setting	Type	Default Value	Description
uboot.secureboot.signing_key_pair_file	String	root_key.pem	Key Pair File to use when signing is enabled. You can generate this file with the command: 'make generate-signing-key-pair-file'.
uboot.secureboot.signing_key_type	String	user	Sign Bootloader using key pair file specified.

Arria 10 Bootloader MPU Firewall BSP Settings Group

Table 7-8: Arria 10 Bootloader MPU Firewall BSP Settings Group

BSP Setting	Type	Default Value	Description
enable.mpuregion0enable	Boolean	True	Enable MPU Firewall Regions
enable.mpuregion1enable		False	
enable.mpuregion2enable		False	
enable.mpuregion3enable		False	
mpuregion0addr.base	Hexadecimal	0x0	MPU Firewall region bases
mpuregion1addr.base			
mpuregion2addr.base			
mpuregion3addr.base			
mpuregion0addr.limit	Hexadecimal	0xffff	MPU Firewall region limits
mpuregion1addr.limit			
mpuregion2addr.limit			
mpuregion3addr.limit			

Arria 10 Bootloader L3 Firewall BSP Settings Group

Table 7-9: Arria 10 Bootloader L3 Firewall BSP Settings Group

BSP Setting	Type	Default Value	Description
enable.hpsregion0enable	Boolean	True	Enable L3 Firewall regions
enable.hpsregion1enable		False	
enable.hpsregion2enable		False	
enable.hpsregion3enable		False	
enable.hpsregion4enable		False	
enable.hpsregion5enable		False	
enable.hpsregion6enable		False	
enable.hpsregion7enable		False	
hpsregion0addr.base	Hexadecimal	0x0	L3 Firewall region bases
hpsregion1addr.base			
hpsregion2addr.base			
hpsregion3addr.base			
hpsregion4addr.base			
hpsregion5addr.base			
hpsregion6addr.base			
hpsregion7addr.base			
hpsregion0addr.limit	Hexadecimal	0xffff	L3 Firewall region limits
hpsregion1addr.limit			
hpsregion2addr.limit			
hpsregion3addr.limit			
hpsregion4addr.limit			
hpsregion5addr.limit			
hpsregion6addr.limit			
hpsregion7addr.limit			

Arria 10 Bootloader F2S Firewall BSP Settings Group

Table 7-10: Arria 10 Bootloader F2S Firewall BSP Settings Group

BSP Setting	Type	Default Value	Description
<code>enable.fpga2sdram0region0</code>	Boolean	True	Enable F2S Firewall regions
<code>enable.fpga2sdram0region1</code>		True	
<code>enable.fpga2sdram0region2</code>		True	
<code>enable.fpga2sdram0region3</code>		False	
<code>enable.fpga2sdram1region0</code>		False	
<code>enable.fpga2sdram1region1</code>		False	
<code>enable.fpga2sdram1region2</code>		False	
<code>enable.fpga2sdram1region3</code>		False	
<code>enable.fpga2sdram2region0</code>		False	
<code>enable.fpga2sdram2region1</code>		False	
<code>enable.fpga2sdram2region2</code>		False	
<code>enable.fpga2sdram2region3</code>		False	
<code>fpga2sdram0region0addr.base</code>	Hexadecimal	0x0	F2S Firewall region bases
<code>fpga2sdram0region1addr.base</code>			
<code>fpga2sdram0region2addr.base</code>			
<code>fpga2sdram0region3addr.base</code>			
<code>fpga2sdram1region0addr.base</code>			
<code>fpga2sdram1region1addr.base</code>			
<code>fpga2sdram1region2addr.base</code>			
<code>fpga2sdram1region3addr.base</code>			
<code>fpga2sdram2region0addr.base</code>			
<code>fpga2sdram2region1addr.base</code>			
<code>fpga2sdram2region2addr.base</code>			
<code>fpga2sdram2region3addr.base</code>			

BSP Setting	Type	Default Value	Description
fpga2sdram0region0addr.limit	Hexadecimal	0xffff	F2S Firewall region limits
fpga2sdram0region1addr.limit			
fpga2sdram0region2addr.limit			
fpga2sdram0region3addr.limit			
fpga2sdram1region0addr.limit			
fpga2sdram1region1addr.limit			
fpga2sdram1region2addr.limit			
fpga2sdram1region3addr.limit			
fpga2sdram2region0addr.limit			
fpga2sdram2region1addr.limit			
fpga2sdram2region2addr.limit			
fpga2sdram2region3addr.limit			


Second Stage Bootloader Image Tool (mkpimage)

The Second Stage Bootloader (SSBL) Image Tool (mkpimage) creates an Altera BootROM-compatible image of the Arria V and Cyclone V Preloader or Arria 10 Bootloader. The tool can also decode the header of previously generated images.

The mkpimage tool makes the following assumptions:

- The input file format is raw binary. You must use the **objcopy** utility provided with the GNU Compiler Collection (GCC) tool chain from the Mentor Graphics website to convert other file formats, such as Executable and Linking Format File (**.elf**), Hexadecimal (Intel-Format) File (**.hex**), or S-Record File (**.srec**), to a binary format.
- The output file format is binary.
- The tool always creates the output image at the beginning of the binary file. If the image must be programmed at a specific base address, you must supply the address information to the flash programming tool.
- The output file contains only Preloader or Bootloader images. Other images such as Linux, SRAM Object File (**.sof**) and user data are programmed separately using a flash programming tool or related utilities in the U-boot on the target system.

Figure 7-5: Basic Operation of the mkpimage Tool



Operation

The mkpimage tool runs on a host machine. The tool generates the header and CRC checksum and inserts them into the output image with the SSBL program image and its exception vector.

For certain flash memory tools, the position of the SSBL images must be aligned to a specific block size; the mkpimage tool generates any padding data that may be required.

The mkpimage tool optionally decodes and validates header information when given a pre-generated SSBL image.

As illustrated, the binary SSBL image is an input to the mkpimage tool. The compiler leaves an empty space between the SSBL exception vector and the program. The mkpimage tool overwrites this empty region with header information and calculates a checksum for the whole image.

When necessary, the mkpimage tool appends the padding data to the output image.

The mkpimage tool can operate with either one or four input files. Operation on four input files consists in processing each file individually, then concatenating the four resulted images.

Header File Format

The mkpimage header file format has two versions:

- Version 0, used for Cyclone V and Arria V SSBL (Preloader)
- Version 1, used for Arria 10 SSBL (Bootloader)

For Version 0, used for Cyclone V and Arria V Preloader, the header includes the following:

- Validation word (0x31305341)
- Version field (set to 0x0)
- Flags field (set to 0x0)
- Program length measured by the number of 32 bit words in the Preloader program
- 16-bit checksum of the header contents (0x40 – 0x49)

Table 7-11: Header Format Version 0

0x4A	Header checksum
0x48	Reserved (0x0)
0x46	Program length in 32-bit words (n)
0x45	Flags
0x44	Version
0x40	Validation word (0x31305341)

Figure 7-6: Header Format Version 0

0x4A	Header Checksum
0x48	Reserved (0x0)
0x46	Program length in 32-bit words
0x45	Flags
0x44	Version
0x40	Validation word (0x31305341)

For Version 1, used for Arria 10 Bootloader, the header includes the following:

- Validation word (0x31305341).
- Version field (set to 0x1).
- Flags field (set to 0x0).
- Header length, in bytes, set to 0x14 (20 bytes).
- Total program length (including the exception vectors and the CRC field) in bytes. For an image to be valid, length must be a minimum of 0x5C (92 bytes) and a maximum of 0x32000 (200KiB).
- Program entry offset relative to the start of header (0x40) and should be 32-bit word-aligned. Default is 0x14, any value smaller than that is invalid.
- 16-bit checksum of the header contents (0x40 – 0x51):

Figure 7-7: Header Format Version 1

0x52	Header checksum
0x50	Reserved (0x0)
0x4C	Program entry offset
0x48	Program length in bytes
0x46	Header length in bytes
0x45	Flags
0x44	Version
0x40	Validation word (0x31305341)

Table 7-12: Header Format Version 1

0x52	Header checksum
0x50	Reserved (0x0)
0x4c	Program entry offset (x)
0x48	Program length in bytes (n)
0x46	Header length in bytes
0x45	Flags
0x44	Version
0x40	Validation word (0x31305341)

The header checksum for both versions of the mkpimage header is the CRC checksum of the byte value from offset 0x0 to (n*4)-4 bytes where n is the program length.

The CRC is a standard CRC32 with the polynomial:

$$x^{32} + x^{26} + x^{23} + x^{22} + x^{16} + x^{12} + x^{11} + x^{10} + x^8 + x^7 + x^5 + x^4 + x^2 + x + 1$$

. There is no reflection of the bits and the initial value of the remainder is 0xFFFFFFFF and the final value is exclusive OR-ed with 0xFFFFFFFF.

Tool Usage

The mkimage tool has three usage models:

- Single image creation
- Quad image creation
- Single or quad image decoding

If an error is found during the make image process, the tool stops and reports the error. Possible error conditions include:

- For Cyclone V and Arria V Preloaders: input image is smaller than 81 bytes or larger than 60 KB.
- For Arria 10 Bootloaders: input image is smaller than 92 bytes or larger than 200 KB.

mkpimage invokes the tool; invoking the tool with the `--help` option provides a tool description and tool usage and option information.

```
$ mkpimage --help
mkpimage version 15.1 (build 189)
```

Description: This tool creates an Altera BootROM-compatible image of Second Stage Boot Loader (SSBL). The input and output files are in binary format. It can also decode and check the validity of previously generated image.

Usage:

```
Create quad image:
    mkpimage [options] -hv <num> -o <outfile> <infile> <infile> <infile> <infile>
Create single image:
    mkpimage [options] -hv <num> -o <outfile> <infile>
Decode single/quad image:
    mkpimage -d [-a <num>] <infile>
```

Options:

```
-a (--alignment) <num>      : Address alignment in kilobytes for output image
                             (64, 128, 256, etc.), default to 64 for header
                             version 0 and 256 for header version 1,
                             override if the NAND flash has a different
                             block size. If outputting a single image, value
                             of '0' is permitted to specify no flash block
                             padding (needed for SSBL image encryption).

-d (--decode)               : Flag to decode the header information from
                             input file and display it

-f (--force)                : Flag to force decoding even if the input file
                             is an unpadded image

-h (--help)                 : Display this help message and exit

-hv (--header-version) <num> : Header version to be created (Arria/Cyclone V =
                             0, Arria 10 = 1)

-o (--output) <outfile>     : Output file, relative and absolute path
                             supported

-off (--offset) <num>       : Program entry offset relative to start of
                             header (0x40), default to 0x14. Used for header
                             version 1 only

-v (--version)              : Display version and exit
```

Output Image Layout

Base Address

The bootable SSBL image must be placed at 0x0 for NAND and QSPI flash. For SD/MMC the image can also be placed at 0x0, but typically the image is placed at offset 0x0 in a custom partition of type 0xA2. The custom partition does not have a filesystem on it. The boot ROM is able to locate the partition using the MBR (Master Boot Record) located at 0x0 on the SD/MMC card.

The mkpimage tool always places the output image at the start of the output binary file, regardless of the target flash memory type. The flash programming tool is responsible for placing the image at the desired location on the flash memory device.

Size

For Cyclone V and Arria V, a single Preloader has a maximum 60 KB image size. You can store up to four preloader images in flash. If the boot ROM does not find a valid preloader image at the first location, it attempts to read an image from the next location and so on. To take advantage of this feature, program four preloader images in flash.

For Arria 10, a single Bootloader has a maximum 200 KB image size. You can store up to four Bootloader images in flash. If the boot ROM does not find a valid Bootloader image at the first location, it attempts to read the next one and so on. To take advantage of this feature, program four Bootloader images in flash.

Address Alignment

For Cyclone V and Arria V, every Preloader image has to be aligned to a 64KB boundary, except for NAND devices. For NAND devices, each Preloader image has to be aligned to the greater of 64 KB or NAND block size.

For Arria 10, every Bootloader image has to be aligned to a 256 KB boundary, except for NAND devices. For NAND devices, each Bootloader image has to be aligned to the greater of 256 KB or NAND block size.

The following tables present typical image layouts, that are used for QSPI, SD/MMC and NAND devices with block size equal or less to 64 KB (for Cyclone V/Arria V) or 256 KB (for Arria 10).

Table 7-13: Typical Arria V/Cyclone V Preloader Image Layout

Offset	Image
0x30000	Preloader Image 3
0x20000	Preloader Image 2
0x10000	Preloader Image 1
0x00000	Preloader Image 0

Table 7-14: Typical Arria 10 Bootloader Image Layout

Offset	Image
0xC0000	Bootloader Image 3

Offset	Image
0x80000	Bootloader Image 2
0x40000	Bootloader Image 1
0x00000	Bootloader Image 0

The mkpimage tool is unaware of the target flash memory type. If you do not specify the block size, the default is 64 KB.

NAND Flash

Each Preloader or Bootloader image occupies an integer number of blocks. A block is the smallest entity that can be erased, so updates to a particular boot image do not impact the other images.

For example for Cyclone V and Arria V, a single Preloader image has a maximum size of 64 KB. But if the NAND block is 128 KB, then the Preloader images will need to be located at 128 KB intervals.

Serial NOR Flash

Each QSPI boot image occupies an integer number of sectors unless subsector erase is supported; this ensures that updating one image does not affect other images.

SD/MMC

The master boot record, located at the first 512 bytes of the device memory, contains partition address and size information. The Preloader and Bootloader images are stored in partitions of type 0xA2. Other items may be stored in other partition types according to the target file system format.

You can use the fdisk tool to set up and manage the master boot record. When the fdisk tool partitions an SD/MMC device, the tool creates the master boot record at the first sector, with partition address and size information for each partition on the SD/MMC.

Padding

The mkimage tool inserts a CRC checksum in the unused region of the image. Padding fills the remaining unused regions. The contents of the padded and unused regions of the image are undefined.

Related Information

- [Arria V Hard Processor System Technical Reference Manual](#)
For more information, please refer to the Booting and Configuration chapter.
- [Cyclone V Hard Processor System Technical Reference Manual](#)
For more information, please refer to the Booting and Configuration chapter.
- [Arria 10 Hard Processor System Technical Reference Manual](#)
For more information, please refer to the Booting and Configuration chapter.

U-Boot Image Tool (mkimage)

Both the Preloader (for Arria V/ Cyclone V) and the Bootloader (for Arria 10) require the presence of the U-Boot image header at the beginning of the next stage boot image. Depending on usage scenario, other

items that are loaded by either Preloader or Bootloader may also require the presence of the U-Boot image header.

The mkimage utility is delivered with SoC EDS and can be used to append the U-Boot image header to the next stage boot image or any other required files.

Figure 7-8: mkimage Header

0x0040	Input File
0x0000	mkimage Signature Header

The header consists of the following items:

- Image magic number - determines if the image is a valid boot image
- Image data size - the length of the image to be copied
- Data load address - the entry point of the boot image (not used for items that are not bootable images)
- Operating system - determines the type of image
- Image name - the name of the boot image
- Image CRC - the checksum value of the boot image

Figure 7-9: mkimage Header Layout

0x0040	Image Name						
0x0030							
0x0020							
0x0010	Data Load Address	Entrypoint	Image CRC	O	A	T	C
0x0000	Magic Number	Header CRC	Timestamp	Image Data Size			
	0x4	0x8	0xC				

O – Operating System **A** – Architecture **T** – Type **C** – Compression

Tool Options

mkimage invokes the mkimage tool and the --help option provides the tool description and option information.

```
$ mkimage --help
Usage: mkimage -l image
      -l ==> list image header information
mkimage [-x] -A arch -O os -T type -C comp -a addr -e ep -n name -d
data_file[:data_file...] image
      -A ==> set architecture to 'arch'
      -O ==> set operating system to 'os'
      -T ==> set image type to 'type'
      -C ==> set compression type 'comp'
      -a ==> set load address to 'addr' (hex)
      -e ==> set entry point to 'ep' (hex)
      -n ==> set image name to 'name'
      -d ==> use image data from 'datafile'
      -x ==> set XIP (execute in place)
mkimage [-D dtc_options] [-f fit-image.its|-F] fit-image
      -D => set options for device tree compiler
      -f => input filename for FIT source
Signing / verified boot not supported (CONFIG_FIT_SIGNATURE undefined)
mkimage -V ==> print version information and exit
```

Usage Examples

Example 7-6: Creating a U-boot Image

```
mkimage -A arm -T firmware -C none -O u-boot -a 0x08000040 -e 0 -n "U-Boot  
2014.10 for SOCFGPA board" -d u-boot.bin u-boot.img
```

Example 7-7: Creating a Bare-metal Application Image

```
mkimage -A arm -O u-boot -T standalone -C none -a 0x02100000 -e 0 -n  
"baremetal image" -d hello_world.bin hello_world.img
```


Building the Second Stage Bootloader

This section presents the details of how the bootable SSBL image is created, with the aid of the generated Makefile, for both Cyclone V and Arria V Preloader, and Arria 10 Bootloader.

Building the Cyclone V and Arria V Preloader

The following figure presents the Cyclone V and Arria V Preloader build flow, as performed by the generated Makefile when invoking **make**. In order to keep the illustration simple, the generated Makefile itself is not shown.

Figure 7-10: Cyclone V/Arria V Preloader Build Flow



The makefile performs the following tasks:

- Copies the generic preloader source code into < bsp directory>/ uboot-socfpga
- Copies the generated BSP files and hardware handoff files to the source directory in < bsp_directory >/ uboot-socfpga /board/ altera / socfpga _<device>
- Configures the compiler tools to target an SoC FPGA
- Compiles the source files in < bsp directory>/ uboot-socfpga with the user-specified cross compiler (specified in the BSP settings) and stores the generated preloader binary files in < bsp_directory >/ uboot - socfpga / spl
- Converts the preloader binary file to a preloader image, < bsp_directory >/preloader- mkpimage.bin, with the mkpimage tool


The makefile contains the following targets:

- make all – compiles the preloader
- make clean – deletes preloader-mkpimage.bin from the <bsp directory>
- make clean-all – deletes <bsp directory>, including the source files in the directory

Building the Arria 10 Bootloader

The following figure presents the Arria 10 Bootloader build flow, as performed by the generated Makefile when invoking **make**. In order to keep the illustration simple, the generated Makefile itself is not shown.

Figure 7-11: Arria 10 Bootloader Build Flow



Warning: For this release of the tools, the Bootloader compilation is only supported on Linux host machines. The Bootloader compilation It is not supported on Windows host machines. The rest of the flow is supported on both Linux and Windows host machines.

Note: The Bootloader needs to be recompiled only when the boot source is changed (SD/MMC and QSPI are currently supported). The Bootloader does not need to be recompiled when other settings are changed, as those settings are encapsulated in the Bootloader Device Tree.

The makefile performs the following tasks:

- Copies the bootloader source code into **< bsp directory>/ uboot-socfpga**
- Configures the bootloader to target the Arria 10 SoC
- Compiles the source files in **< bsp directory>/ uboot-socfpga** and creates the Bootloader binary **< bsp directory>/ uboot-socfpga /u- boot .bin**
- Creates the bootloader device tree file based on the hardware handoff information and user settings into **< bsp directory>/ devicetree.dts**
- Compiles the bootloader device tree source file by using **dtc** (Device Tree Compiler) into **< bsp directory>/ devicetree.dtb**
- Concatenates the bootloader device tree binary and the bootloader binary files into a combined binary file **< bsp directory>/ u- boot_w_dtb.bin**
- Converts the combined binary file to a bootable combined image, **< bsp directory>/ uboot_w_dtb-mkpimage.bin**, with the **mkpimage** tool

The makefile contains the following targets:

- **make all** – builds everything
- **make src** – copies the bootloader source code folder
- **make uboot** – builds the bootloader binary
- **make dtb** – compiles the bootloader device tree source to device tree binary
- **make clean** – deletes all built files
- **make clean-all** – deletes all built files, and the bootloader source code folder

Boot Tools User Guide Document Revision History

Date	Version	Changes
February 2016	2016.02.17	<ul style="list-style-type: none">• Updated the help definition for mkpimage in the "Tools Usage" and "Tool Options" sections.• Updated the Arria 10 Main BSP Settings Group table.
August 2015	2015.08.06	Added Arria 10 support.

2016.02.17

ug-1137




Subscribe



Send Feedback

The Altera SoC FPGA Hardware Library (HWLIB) was created to address the needs of low-level software programmers who require full access to the configuration and control facilities of SoC FPGA hardware. An additional purpose of the HWLIB is to mitigate the complexities of managing the operation of a sophisticated, multi-core application processor and its integration with hardened IP peripheral blocks and programmable logic in a SoC architecture.

Figure 8-1: HW Library



Within the context of the SoC HW/SW ecosystem, the HWLIB is capable of supporting software development in conjunction with full featured operating systems or standalone bare-metal programming environments. The relationship of the HWLIB within a complete SoC HW/SW environment is illustrated in the above figure.

The HWLIB provides a symbolic register abstraction layer known as the SoC Abstraction Layer (SoCAL) that enables direct access and control of HPS device registers within the address space. This layer is necessary for enabling several key stakeholders (boot loader developers, driver developers, board support package developers, debug agent developers, and board bring-up engineers) requiring a precise degree of access and control of the hardware resources.

© 2016 Altera Corporation. All rights reserved. ALTERA, ARRIA, CYCLONE, ENPIRION, MAX, MEGACORE, NIOS, QUARTUS and STRATIX words and logos are trademarks of Altera Corporation and registered in the U.S. Patent and Trademark Office and in other countries. All other words and logos identified as trademarks or service marks are the property of their respective holders as described at www.altera.com/common/legal.html. Altera warrants performance of its semiconductor products to current specifications in accordance with Altera's standard warranty, but reserves the right to make changes to any products and services at any time without notice. Altera assumes no responsibility or liability arising out of the application or use of any information, product, or service described herein except as expressly agreed to in writing by Altera. Altera customers are advised to obtain the latest version of device specifications before relying on any published information and before placing orders for products or services.

ISO
9001:2008
Registered

The HWLIB also deploys a set of Hardware Manager (HW Manager) APIs that provides more complex functionality and drivers for higher level use case scenarios.

The HWLIB has been developed as a source code distribution. The intent of this model is to provide a useful set of out-of-the-box functionality and to serve as a source code reference implementation that a user can tailor accordingly to meet their target system requirements.

The capabilities of the HWLIB are expected to evolve and expand over time particularly as common use case patterns become apparent from practical application in actual systems.

In general, the HWLIB assumes to be part of the system software that is executing on the Hard Processor System (HPS) in privileged supervisor mode and in the secure state.

The anticipated HWLIB clients include:

- Bare-Metal application developers
- Custom preloader and boot loader software developers
- Board support package developers
- Diagnostic tool developers
- Software driver developers
- Debug agent developers
- Board bring-up engineers
- Other developers requiring full access to SoC FPGA hardware capabilities

Feature Description

This section provides a description of the operational features and functional capabilities present in the HWLIB. An overview and brief description of the HWLIB architecture is also presented.

The HWLIB is a software library architecturally comprised of two major functional components:

- SoC Abstraction Layer (SoCAL)
- Hardware Manager (HW Manager)

SoC Abstraction Layer (SoCAL)

The SoC Abstraction Layer (SoCAL) presents the software API closest to the actual HPS hardware. Its purpose is to provide a logical interface abstraction and decoupling layer to the physical devices and registers that comprise the hardware interface of the HPS.

The SoCAL provides the benefits of:

- A logical interface abstraction to the HPS physical devices and registers including the bit-fields comprising them.
- A loosely coupled software interface to the underlying hardware that promotes software isolation from hardware changes in the system address map and device register bit field layouts.

Hardware Manager (HW Manager)

The Hardware Manager (HW Manager) component provides a group of functional APIs that address more complex configuration and operational control aspects of selected HPS resources.

The HW Manager functions have the following characteristics:

- Functions employ a combination of low level device operations provided by the SoCAL executed in a specific sequence to effect a desired operation.
- Functions may employ cross functional (such as from different IP blocks) device operations to implement a desired effect.
- Functions may have to satisfy specific timing constraints for the application of operations and validation of expected device responses.
- Functions provide a level of user protection and error diagnostics through parameter constraint and validation checks.

The HW Manager functions are implemented using elemental operations provided by the SoCAL API to implement more complex functional capabilities and services. The HW Manager functions may also be implemented by the compound application of other functions in the HW Manager API to build more complex operations (for example, software controlled configuration of the FPGA).

Hardware Library Reference Documentation

Reference documentation for the SoCAL API and HW Manager API is distributed as part of the SoCEDs Toolkit. This reference documentation is provided as online HTML accessible from any web browser.

The locations of the online SoC FPGA Hardware Library (HWLIB) Reference Documentation are:

- SoC Abstraction Layer (SoCAL) API Reference Documentation:
 - Cyclone V and Arria V: <SoC EDS installation directory>/ip/altera/hps/altera_hps/doc/soc_cv_av/socal/html/index.html
 - Arria 10: <SoC EDS installation directory>/ip/altera/hps/altera_hps/doc/soc_a10/socal/html/index.html
- Hardware Manager (HW Manager) API Reference Documentation: <SoC EDS installation directory>/ip/altera/hps/altera_hps/doc/hwmgr/html/index.html

System Memory Map

The addresses of the HPS hard IP modules are accessible through the provided SoCAL macros. SoCAL also provides macros for accessing the individual registers and register fields of the HPS hard IP modules.

For the FPGA IP modules, the macros for accessing IP registers and register fields are usually part of the IP deliverables. However, the actual IP modules-based addresses are often changed at system integration time, in the Qsys tool.

The tool "sopc-create-header-files" can be used to create a C include file with the bases addresses of all the IP modules residing in the FPGA fabric.

Note: The tool is part of Quartus Prime, and not of SoC EDS. The tool can be invoked from the SoC EDS Embedded Command Shell once Quartus Prime is installed.

The basic usage of the tool is to invoke it with the .sopcinfo file as a single parameter. For example, in order to generate the include files for the Arria 10 GHRD, the following command can be executed in that folder: `sopc-create-header-files ghrd_10as066n2.sopcinfo`.

The tool creates a separate include file for each of the masters in the system, showing the system addresses from that master's point of view. Use the file <hps_component_name>_a9_0.h for HPS software development, as it shows the system addresses from the HPS point of view.

The following example demonstrates how to use the tool to generate only the file that shows the HPS A9 Core 0 point of view:

```
sopc-create-header-files ghrd_10as066n2.sopcinfo --module\  
arria10_hps_0_arm_a9_0 --single arria10_hps_0_arm_a9_0.h
```

This creates just one file, called "arria10_hps_0_arm_a9_0.h".

You can also run "sopc-create-header-files --help" for more details about the tool, or refer to Quartus Prime documentation.

Hardware Library Document Revision History

Date	Version	Changes
February 2016	2016.02.17	<ul style="list-style-type: none">Updated the HW Library figure.Added a new section called "System Memory Map".
August 2015	2015.08.06	Added Arria 10 support.

2016.02.17

ug-1137



Subscribe



Send Feedback

The Altera Quartus Prime software and Quartus Prime Programmer include the HPS flash programmer. Hardware designs, such as HPS, incorporate flash memory on the board to store FPGA configuration data or HPS program data. The HPS flash programmer programs the data into a flash memory device connected to an Altera SoC. The programmer sends file contents over an Altera download cable, such as the USB-Blaster™ II, to the HPS and instructs the HPS to write the data to the flash memory.

The HPS flash programmer programs the following content types to flash memory:

- HPS software executable files — Many systems use flash memory to store non-volatile program code or firmware. HPS systems can boot from flash memory.

Note: The HPS Flash Programmer is mainly intended to be used for programming the Preloader image to QSPI or NAND flash. Because of the low speed of operation, it is not recommended to be used for programming large files.

- FPGA configuration data — At system power-up, the FPGA configuration controller on the board or HPS read FPGA configuration data from the flash memory to program the FPGA. The configuration controller or HPS may be able to choose between multiple FPGA configuration files stored in flash memory.
- Other arbitrary data files — The HPS flash programmer programs a binary file to any location in a flash memory for any purpose. For example, a HPS program can use this data as a coefficient table or a sine lookup table.

The HPS flash programmer programs the following memory types:

- Quad serial peripheral interface (QSPI) Flash
- Open NAND Flash Interface (ONFI) compliant NAND Flash

HPS Flash Programmer Command-Line Utility

You can run the HPS flash programmer directly from the command line. For the Quartus Prime software, the HPS flash programmer is located in *<Altera installation directory>/quartus/bin*. For the Quartus Prime Programmer, the HPS flash programmer is located in *<Altera installation directory>/qprogrammer/bin*.

© 2016 Altera Corporation. All rights reserved. ALTERA, ARRIA, CYCLONE, ENPIRION, MAX, MEGACORE, NIOS, QUARTUS and STRATIX words and logos are trademarks of Altera Corporation and registered in the U.S. Patent and Trademark Office and in other countries. All other words and logos identified as trademarks or service marks are the property of their respective holders as described at www.altera.com/common/legal.html. Altera warrants performance of its semiconductor products to current specifications in accordance with Altera's standard warranty, but reserves the right to make changes to any products and services at any time without notice. Altera assumes no responsibility or liability arising out of the application or use of any information, product, or service described herein except as expressly agreed to in writing by Altera. Altera customers are advised to obtain the latest version of device specifications before relying on any published information and before placing orders for products or services.


ISO
9001:2008
Registered

ALTERA
now part of Intel

How the HPS Flash Programmer Works

The HPS flash programmer is divided into a host and a target. The host portion runs on your computer and sends flash programming files and programming instructions over a download cable to the target. The target portion is the HPS in the SoC. The target accepts the programming data flash content and required information about the target flash memory device sent by the host. The target writes the data to the flash memory device.

Figure 9-1: HPS Flash Programmer



The HPS flash programmer determines the type of flash to program by sampling the boot select (BSEL) pins during cold reset; you do not need to specify the type of flash to program.

Using the Flash Programmer from the Command Line

HPS Flash Programmer

The HPS flash programmer utility can erase, blank-check, program, verify, and examine the flash. The utility accepts a Binary File with a required ".bin" extension.

The HPS flash programmer command-line syntax is:

```
quartus_hps <options> <file.bin>
```

Note: The HPS flash programmer uses byte addressing.

Table 9-1: HPS Flash Programmer Parameters

Option	Short Option	Required	Description
--cable	-c	Yes	<p>This option specifies what download cable to use.</p> <p>To obtain the list of programming cables, run the command "jtagconfig". It will list the available cables, like in the following example:</p> <pre>jtagconfig 1) USB-Blaster [USB-0] 2) USB-Blaster [USB-1] 3) USB-Blaster [USB-2]</pre> <p>The "-c" parameter can be the number of the programming cable, or its name. The following are valid examples for the above case:</p> <pre>-c 1 -c "USB-Blaster [USB-2]"</pre>
--device	-d	Yes (if there are multiple HPS devices in the chain)	<p>This option specifies the index of the HPS device. The tool will automatically detect the chain and determine the position of the HPS device; however, if there are multiple HPS devices in the chain, the targeted device index must be specified.</p>

Option	Short Option	Required	Description
--operation	-o	Yes	<p>This option specifies the operation to be performed. The following operations are supported:</p> <ul style="list-style-type: none"> I: Read IDCODE of SOC device and discover Access Port S: Read Silicon ID of the flash E: Erase flash B: Blank-check flash P: Program flash V: Verify flash EB: Erase and blank-check flash BP: Program <BlankCheck> flash PV: Program and verify flash BPV: Program (blank-check) and verify flash X: Examine flash <p>Note: The program begins with erasing the flash operation before programming the flash by default.</p>
--addr	-a	Yes (if the start address is not 0)	This option specifies the start address of the operation to be performed.
--size	-s	No	This option specifies the number of bytes of data to be performed by the operation. <i>size</i> is optional.
--repeat	-t	No	<p>These options must be used together. The HPS BOOT flow supports up to four images where each image is identical and these options duplicate the operation data; therefore you do not need eSW to create a large file containing duplicate images.</p> <p><i>repeat</i> specifies the number of duplicate images for the operation to perform.</p> <p><i>interval</i> specifies the repeated address. The default value is 64 kilobytes (KB).</p> <p><i>repeat</i> and <i>interval</i> are optional.</p>
--interval	-i		

HPS Flash Programmer Command Line Examples

Type `quartus_hps --help` to obtain information about usage. You can also type `quartus_hps --help=<option>` to obtain more details about each option. For example "`quartus_hps --help=o`".

Example 9-1: Program File to Address 0 of Flash

`quartus_hps -c 1 -o P input.bin` programs the input file (**input.bin**) into the flash, starting at flash address 0 using a cable *M*.

Example 9-2: Program First 500 Bytes of File to Flash (Decimal)

`quartus_hps -c 1 -o PV -a 1024 -s 500 input.bin` programs the first 500 bytes of the input file (**input.bin**) into the flash, starting at flash address 1024, followed by a verification using a cable *M*.

Note: Without the prefix 0x for the flash address, the tool assumes it is decimal.

Example 9-3: Program First 500 Bytes of File to Flash (Hexadecimal)

`quartus_hps -c 1 -o PV -a 0x400 -s 500 input.bin` programs the first 500 bytes of the input file (**input.bin**) into the flash, starting at flash address 1024, followed by a verification using a cable *M*.

Note: With the prefix 0x, the tool assumes it is hexadecimal.

Example 9-4: Program File to Flash Repeating Twice at Every 1 MB

`quartus_hps -c 1 -o BPV -t 2 -i 0x100000 input.bin` programs the input file (**input.bin**) into the flash, using a cable *M*. The operation repeats itself twice at every 1 megabyte (MB) of the flash address. Before the program operation, the tool ensures the flash is blank. After the program operation, the tool verifies the data programmed.

Example 9-5: Erase Flash on the Flash Addresses

`quartus_hps -c 1 -o EB input.bin` erases the flash on the flash addresses where the input file (**input.bin**) resides, followed by a blank-check using a cable *M*.

Example 9-6: Erase Full Chip

`quartus_hps -c 1 -o E` erases the full chip, using a cable *M*. When no input file (**input.bin**) is specified, it will erase all the flash contents.

Example 9-7: Erase Specified Memory Contents of Flash

`quartus_hps -c 1 -o E -a 0x100000 -s 0x400000` erases specified memory contents of the flash. For example, 4 MB worth of memory content residing in the flash address, starting at 1 MB, are erased using a cable *M*.

Example 9-8: Examine Data from Flash

`quartus_hps -c 1 -o X -a 0x98679 -s 56789 output.bin` examines 56789 bytes of data from the flash with a 0x98679 flash start address, using a cable *M*.

Supported Memory Devices

Table 9-2: QSPI Flash

Flash Device	Mode	Device ID	DIE #	Density (Mb)
N25Q128A	Micron	0x18BA20	1	128
N25Q256	Micron	0x19BA20	1	256
N25Q512	Micron	0x20BA20	2	512
N25Q00	Micron	0x21BA20	4	1024
N25Q128A	Micron	0x18BB20	1	128
N25Q256	Micron	0x19BB20	1	256
N25Q512	Micron	0x20BB20	2	512
N25Q00	Micron	0x21BB20	4	1024
	Micron	0x132020	1	
S25FL128S	Spansion	0x182001	1	128 (Sector size of 64 KB)
S25FL128S	Spansion	0x182001	1	128 (Sector size of 256 KB)
S25FL256S	Spansion	0x190201	1	256 (Sector size of 64 KB)
S25FL256S	Spansion	0x190201	1	256 (Sector size of 256 KB)
S25FL512S	Spansion	0x200201	1	512

Table 9-3: ONFI Compliant NAND Flash

Manufacturer	MFC ID	Device ID	Density (Gb)
Micron	0x2C	0x68	32
Micron	0x2C	0x48	16

Manufacturer	MFC ID	Device ID	Density (Gb)
Micron	0x2C	0xA1	8
Micron	0x2C	0xF1	8

Note: The HPS Flash Programmer supports all ONFI compliant NAND flash devices that are supported by the HPS QSPI Flash Controller.

Note: The HPS Flash Programmer supports the Cyclone V, Arria V and Arria 10 SoC devices.

HPS Flash Programmer User Guide Document Revision History

Date	Version	Changes
February 2016	2016.02.17	Added QSPI Flash part number to the QSPI Flash table in the "Supported Memory Devices" chapter.
August 2015	2015.08.06	Added Arria 10 support.

2016.02.17

ug-1137



Subscribe



Send Feedback

The bare-metal compiler that is shipped with the SoC EDS is the Mentor Graphics Sourcery™ CodeBench Lite Edition, version 4.9.2.

For more information on the Sourcery CodeBench Lite Edition and to download the latest version of the tools, refer to the Mentor Graphics website.

The compiler is a GCC-based **arm-altera-eabi** port. It targets the ARM processor, it assumes bare-metal operation, and it uses the standard ARM embedded-application binary interface (EABI) conventions.

The bare-metal compiler is installed as part of the SoC EDS installation in the following folder: *<SoC EDS installation directory>/host_tools/mentor/gnu/arm/baremetal*.

The Embedded Command Shell, opened by running the script from the *SoC EDS installation directory*, sets the correct environment PATH variables for the bare-metal compilation tools to be invoked. After starting the shell, commands like **arm-altera-eabi-gcc** can be invoked directly. When the ARM DS-5 AE environment is started from the embedded command shell, it inherits the environment settings, and it can call these compilation tools directly.

Alternatively, the full path to the compilation tools can be used: *<SoC EDS installation directory>/host_tools/mentor/gnu/arm/baremetal/bin*.

The bare-metal compiler comes with full documentation, located at *<SoC EDS installation directory>/host_tools/mentor/gnu/arm/baremetal/share/doc/sourceryg++-arm-altera-eabi*. The documentation is offered in four different formats to accommodate various user preferences:

- HTML files
- Info files
- Man pages
- PDF files

Among the provided documents are:

- Compiler manual
- Assembler manual
- Linker manual
- Binutils manual
- GDB manual
- Getting Started Guides⁽²⁾
- Libraries Manual

⁽²⁾ The Getting Started Guides are located on the **SoCEDSGettingStarted** page on the Altera Wiki.

Related Information

- [Mentor Graphics](#)
- [SoC EDS Getting Started Guides](#)

Bare Metal Compiler Document Revision History

Date	Version	Changes
February 2016	2016.02.17	Updated the compiler version for Mentor Graphics® Sourcery CodeBench Lite Edition.
August 2015	2015.08.06	Added Arria 10 support.

2016.02.17

ug-1137



Subscribe



Send Feedback

The SoC EDS SD card boot utility is a tool for updating the boot software on an SD card.

The Preloader is typically stored in a custom partition (with type = 0xA2) on the SD card. Optionally the next boot stage (usually the Bootloader) can also be stored on the same custom partition.

Since it is a custom partition, without a file-system, the Preloader and/or Bootloader cannot be updated by copying the new file to the card; and a software tool is needed.

The SD card boot utility allows the user to update the Preloader and/or Bootloader on a physical SD card or a disk image file. The utility is not intended to create a new bootable SD card or disk image file from scratch. In order to do that, it is recommended to use fdisk on a Linux host OS.

Related Information

[Linux Software Development Tools](#) on page 12-1

Usage Scenarios

This utility is intended to update boot software on that resides on an existing:

- Existing SD card
- Existing disk image file

The tool supports updating the following:

- Cyclone V and Arria V Preloader
- Cyclone V and Arria V Bootloader
- Arria 10 Bootloader

Note: For Cyclone V and Arria V, the Preloader file needs to have the mkpimage header, as required by the boot ROM, and the Bootloader file needs to have the mkimage header, as required by the Preloader.

Note: For Arria 10, the Bootloader needs to have the mkpimage header, as required by BootROM.

Note: Both mkpimage and mkimage tools are delivered as part of SoC EDS.

The tool only updates the custom partition that stores the Altera SoC boot code. The rest of the SD card or disk image file is not touched. This includes the Master Boot Record (MBR) and any other partitions (FAT, EXT3 etc) and free space.

© 2016 Altera Corporation. All rights reserved. ALTERA, ARRIA, CYCLONE, ENPIRION, MAX, MEGACORE, NIOS, QUARTUS and STRATIX words and logos are trademarks of Altera Corporation and registered in the U.S. Patent and Trademark Office and in other countries. All other words and logos identified as trademarks or service marks are the property of their respective holders as described at www.altera.com/common/legal.html. Altera warrants performance of its semiconductor products to current specifications in accordance with Altera's standard warranty, but reserves the right to make changes to any products and services at any time without notice. Altera assumes no responsibility or liability arising out of the application or use of any information, product, or service described herein except as expressly agreed to in writing by Altera. Altera customers are advised to obtain the latest version of device specifications before relying on any published information and before placing orders for products or services.

ISO
9001:2008
Registered

ALTERA
now part of Intel

Warning: The users of this tool need administrative or root access to their computer to use this tool to write to physical SD cards. These rights are not required when only working with disk image files. Please contact the IT department if you do not have the proper rights on your PC.

Tool Options

The utility is a command line program. The table describes all the command line options; and the figure shows the `--help` output from the tool.

Table 11-1: Command Line Options

Command line Argument	Required?	Description
-p filename	Optional	Specifies Preloader file to write
-b filename	Optional	Specifies Cyclone V or Arria V Bootloader file to write
-B filename	Optional	Specifies Arria 10 Bootloader file to write
-a write	Required	Specifies action to take. Only "write" action is supported. Example: "-a write"
disk_file	Required(unless -d option is used)	Specifies disk image file or physical disk to write to. A disk image file is a file that contains all the data for a storage volume including the partition table. This can be written to a physical disk later with another tool. For physical disks in Linux, just specify the device file. For example: /dev/mmcblk0 For physical disks in Windows, specify the physical drive path such as \\.\physicaldrive2 or use the drive letter option(-d) to specify a drive letter. The drive letter option is the easiest method in Windows
-d	Optional	specify disk drive letter to write to. Example: "-d E". When using this option, the disk_file option cannot be specified.
-h	Optional	Displays help message and exits
--version	Optional	Displays script version number and exits

Sample Output from Utility

```
$ alt-boot-disk-util --help
Altera Boot Disk Utility
Copyright (C) 1991-2014 Altera Corporation

Usage:
#write preloader to disk
    alt-boot-disk-util -p preloader -a write disk_file

#write bootloader to disk
```

```
alt-boot-disk-util -b bootloader -a write disk_file

#write BOOTloader and PREloader to disk
alt-boot-disk-util -p preloader -b bootloader -a write disk_file

#write Arria10 Bootloader to disk
alt-boot-disk-util -B al0bootloader -a write disk_file

#write BOOTloader and PREloader to disk drive 'E'
alt-boot-disk-util -p preloader -b bootloader -a write -d E
```

Options:

```
--version          show program's version number and exit
-h, --help         show this help message and exit
-b FILE, --bootloader=FILE
                   bootloader image file'
-p FILE, --preloader=FILE
                   preloader image file'
-a ACTION, --action=ACTION
                   only supports 'write' action'
-B FILE, --al0-bootloader=FILE
                   arria10 bootloader image file
-d DRIVE, --drive=DRIVE
                   specify disk drive letter to write to
```

SD Card Boot Utility Document Revision History

Date	Version	Changes
February 2016	2016.02.17	Maintenance release.
August 2015	2015.08.06	Added Arria 10 support.



2016.02.17

ug-1137



Subscribe



Send Feedback

The Linux software development tools are listed below. The Linux compiler and the linux device tree generator are described in the following sections of this chapter.

- Linux compiler
- SD card boot utility
- Linux device tree generator (DTG)

[Linux Compiler](#) on page 12-1

[Linux Device Tree Generator](#) on page 12-2

[Linux Software Development Tools Document Revision History](#) on page 12-2

Related Information

[SD Card Boot Utility](#) on page 11-1

Linux Compiler

The Linaro Linux compiler, version 4.8.3, is shipped with the SoC EDS.

For more information about the Linux compiler and to download the latest version of the tools, refer to the download page at the Linaro website.

The compiler is a GCC-based **arm-linux-gnueabi** port. It targets the ARM processor, it assumes the target platform is running Linux, and it uses the GNU embedded-application binary interface (EABI) hard-float (HF) conventions.

The Linux compiler is installed as part of the ARM DS-5 AE, which is installed as part of the SoC EDS. The compilation tools are located at *<SoC EDS installation directory>/ds-5/bin*.

The Linux compiler comes with full documentation, located at *<SoC EDS installation directory>/ds-5/documents/gcc*. The documents are provided as HTML files. Some of the provided documents are:

- Compiler manual
- Assembler manual
- Linker manual
- Binutils manual
- GDB manual
- Getting Started Guide

© 2016 Altera Corporation. All rights reserved. ALTERA, ARRIA, CYCLONE, ENPIRION, MAX, MEGACORE, NIOS, QUARTUS and STRATIX words and logos are trademarks of Altera Corporation and registered in the U.S. Patent and Trademark Office and in other countries. All other words and logos identified as trademarks or service marks are the property of their respective holders as described at www.altera.com/common/legal.html. Altera warrants performance of its semiconductor products to current specifications in accordance with Altera's standard warranty, but reserves the right to make changes to any products and services at any time without notice. Altera assumes no responsibility or liability arising out of the application or use of any information, product, or service described herein except as expressly agreed to in writing by Altera. Altera customers are advised to obtain the latest version of device specifications before relying on any published information and before placing orders for products or services.

ISO
9001:2008
Registered

ALTERA
now part of Intel

Related Information[Linaro Website](#)

Linux Device Tree Generator

A device tree is a data structure that describes the underlying hardware to an operating system - primarily Linux. By passing this data structure to the OS kernel, a single OS binary may be able to support many variations of hardware. This flexibility is particularly important when the hardware includes an FPGA.

The Linux Device Tree Generator (DTG) tool is part of Altera SoC EDS and is used to create linux device trees for SoC systems that contain FPGA designs created using Qsys. The generated device tree describes the HPS peripherals, selected FPGA Soft IP, and peripherals that are board dependent.

Note: The Arria 10 Bootloader also has an associated Device Tree called Bootloader Device Tree that is created and managed by the BSP Editor tool.

Related Information

- [Altera Wiki](#)
For more information about the Linux DTG, refer to the Altera Wiki website.
- [Linux Device Tree Generator User Guide](#)
For more details, navigate to the **Device Tree Generator User Guide** located on the **Device Tree Generator Documentation** page on the Rocketboards website.

Linux Software Development Tools Document Revision History

Date	Version	Changes
February 2016	2016.02.17	Maintenance release.
August 2015	2015.08.06	Added Arria 10 support.

Support and Feedback 13

2016.02.17

ug-1137



Subscribe



Send Feedback

Altera values your feedback. Please contact your Altera TSFAE or submit a service request at myAltera to report software bugs, potential enhancements, or obtain any additional information.

Related Information

[myAltera Account Sign In](#)

Support and Feedback Document Revision History

Date	Version	Changes
February 2016	2016.02.17	Maintenance release.
August 2015	2015.08.06	Added Arria 10 support.

© 2016 Altera Corporation. All rights reserved. ALTERA, ARRIA, CYCLONE, ENPIRION, MAX, MEGACORE, NIOS, QUARTUS and STRATIX words and logos are trademarks of Altera Corporation and registered in the U.S. Patent and Trademark Office and in other countries. All other words and logos identified as trademarks or service marks are the property of their respective holders as described at www.altera.com/common/legal.html. Altera warrants performance of its semiconductor products to current specifications in accordance with Altera's standard warranty, but reserves the right to make changes to any products and services at any time without notice. Altera assumes no responsibility or liability arising out of the application or use of any information, product, or service described herein except as expressly agreed to in writing by Altera. Altera customers are advised to obtain the latest version of device specifications before relying on any published information and before placing orders for products or services.

ISO
9001:2008
Registered