

IC Compiler Variables

Version C-2009.06, June 2009

SYNOPSYS®

Copyright Notice and Proprietary Information

Copyright © 2009 Synopsys, Inc. All rights reserved. This software and documentation contain confidential and proprietary information that is the property of Synopsys, Inc. The software and documentation are furnished under a license agreement and may be used or copied only in accordance with the terms of the license agreement. No part of the software and documentation may be reproduced, transmitted, or translated, in any form or by any means, electronic, mechanical, manual, optical, or otherwise, without prior written permission of Synopsys, Inc., or as expressly provided by the license agreement.

Right to Copy Documentation

The license agreement with Synopsys permits licensee to make copies of the documentation for its internal use only. Each copy shall include all copyrights, trademarks, service marks, and proprietary rights notices, if any. Licensee must assign sequential numbers to all copies. These copies shall contain the following legend on the cover page:

“This document is duplicated with the permission of Synopsys, Inc., for the exclusive use of _____ and its employees. This is copy number _____.”

Destination Control Statement

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the reader's responsibility to determine the applicable regulations and to comply with them.

Disclaimer

SYNOPSYS, INC., AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Registered Trademarks (®)

Synopsys, AMPS, Astro, Behavior Extracting Synthesis Technology, Cadabra, CATS, Certify, CHIPit, Design Compiler, DesignWare, Formality, HDL Analyst, HSIM, HSPICE, Identify, iN-Phase, Leda, MAST, ModelTools, NanoSim, OpenVera, PathMill, Physical Compiler, PrimeTime, SCOPE, Simply Better Results, SiVL, SNUG, SolvNet, Syndicated, Synplicity, Synplify, Synplify Pro, Synthesis Constraints Optimization Environment, TetraMAX, the Synplicity logo, UMRBus, VCS, Vera, and YIELDirector are registered trademarks of Synopsys, Inc.

Trademarks (™)

AFGen, Apollo, Astro-Rail, Astro-Xtalk, Aurora, AvanWaves, BEST, Columbia, Columbia-CE, Confirma, Cosmos, CosmosLE, CosmosScope, CRITIC, CustomSim, DC Expert, DC Professional, DC Ultra, Design Analyzer, Design Vision, DesignerHDL, DesignPower, DFTMAX, Direct Silicon Access, Discovery, Eclipse, Encore, EPIC, Galaxy, Galaxy Custom Designer, HANEX, HAPS, HapsTrak, HDL Compiler, Hercules, Hierarchical Optimization Technology, High-performance

ASIC Prototyping System, HSIM^{plus}, i-Virtual Stepper, IICE, in-Sync, iN-Tandem, Jupiter, Jupiter-DP, JupiterXT, JupiterXT-ASIC, Liberty, Libra-Passport, Library Compiler, Magellan, Mars, Mars-Rail, Mars-Xtalk, Milkyway, ModelSource, Module Compiler, MultiPoint, Physical Analyst, Planet, Planet-PL, Polaris, Power Compiler, Raphael, Saturn, Scirocco, Scirocco-i, Star-RCXT, Star-SimXT, System Compiler, System Designer, Taurus, TotalRecall, TSUPREM-4, VCS Express, VCSi, VHDL Compiler, VirSim, and VMC are trademarks of Synopsys, Inc.

Service Marks (SM)

MAP-in, SVP Café, and TAP-in are service marks of Synopsys, Inc.

SystemC is a trademark of the Open SystemC Initiative and is used under license.

ARM and AMBA are registered trademarks of ARM Limited.

Saber is a registered trademark of SabreMark Limited Partnership and is used under license.

All other product or company names may be trademarks of their respective owners.

Table of Contents

access_internal_pins	1
acs_compile_attributes	2
acs_variables	5
alib_library_analysis_path	9
attributes	10
auto_insert_level_shifters	38
auto_insert_level_shifters_on_clocks	39
auto_link_disable	40
auto_link_options	41
auto_ungroup_preserve_constraints	42
bind_unused_hierarchical_pins	43
blockPlace_addChannelBlockages	44
blockPlace_adjustMacroLocations	45
blockPlace_avoidPowerGrid	46
blockPlace_distanceToPowerGrid	47
blockPlace_keepTopLevelTogether	48
blockPlace_minChannelSize	49
blockPlace_preserveAbutment	50
blockPlace_utilSlack	51
bound_attributes	52
bsd_variables	56
budget_generate_critical_range	58
budget_map_clock_gating_cells	59
bus_inference_descending_sort	60

bus_inference_style	62
bus_minus_style.	64
bus_multiple_separator_style.	65
bus_naming_style.	66
bus_range_separator_style	69
cache_dir_chmod_octal	70
cache_file_chmod_octal.	71
case_analysis_log_file	72
case_analysis_propagate_through_icg	73
case_analysis_with_logic_constants	74
cell_attributes	75
cell_site_attributes	81
change_names_bit_blast_negative_index	83
change_names_dont_change_bus_members	84
check_design_allow_non_tri_drivers_on_tri_bus.	85
check_design_allow_unknown_wired_logic_type	86
check_error_list	87
clock_attributes.	88
collection_result_display_limit	90
command_log_file	91
company.	92
compatibility_version	93
compile_clock_gating_through_hierarchy	94
compile_dont_use_dedicated_scanout	95
compile_instance_name_prefix	96
compile_instance_name_suffix	97
compile_keep_original_for_external_references	98
compile_log_format	99
compile_power_domain_boundary_optimization	105
compile_retime_exception_registers	106
compile_seqmap_identify_shift_registers.	107
compile_ultra_ungroup_small_hierarchies.	109
compile_use_fast_delay_mode	110
compile_variables.	111
complete_mixed_mode_extraction.	116
context_check_status.	117
core_area_attributes.	118
cp_full_abut_cts_region_aware	120

cp_in_full_abut_mode	121
cts_blockage_aware.	122
cts_clock_opt_batch_mode	123
cts_clock_source_is_exclude_pin	124
cts_do_characterization	125
cts_enable_clock_at_hierarchical_pin	126
cts_enable_rc_constraints	127
cts_fix_clock_tree_sinks.	128
cts_fix_drc_beyond_exceptions	129
cts_force_user_constraints.	130
cts_instance_name_prefix	131
cts_move_clock_gate.	132
cts_net_name_prefix	133
cts_prechts_upsize_gates	134
cts_push_down_buffer	135
cts_rc_relax_factor.	136
cts_region_aware.	137
cts_target_cap	138
cts_target_transition.	139
cts_traverse_dont_touch_subtrees	140
cts_use_debug_mode	141
cts_use_lib_max_fanout.	142
cts_use_sdc_max_fanout.	143
current_design	144
db_load_ccs_data	145
dct_placement_ignore_scan.	146
ddc_allow_unknown_packed_commands	147
default_input_delay	148
default_name_rules	149
default_output_delay	150
default_port_connection_class.	151
default_schematic_options.	152
design_attributes	153
die_area_attributes.	159
disable_auto_time_borrow	161
disable_case_analysis	162
disable_library_transition_degradation.	163
do_operand_isolation	164

dont_touch_nets_with_size_only_cells	165
dpcm_variables	166
droute_advRouteLoop	169
droute_advancedRouteLoops	170
droute_areaSrLoop.	171
droute_autoSaveInterval	172
droute_autoSrLoop.	173
droute_connBrokenNet.	174
droute_connTieRail	176
droute_doMaxCapConx	178
droute_doMaxTransConx.	180
droute_doProbeConx	182
droute_doSelectedNetAntennaConx	184
droute_doXtalkConx.	186
droute_ecoListToFile	188
droute_ecoMode.	190
droute_ecoScope	192
droute_ecoSrLoop	194
droute_enable_one_pass_partitioning	195
droute_expandFillTracks	196
droute_fillDataType	198
droute_fillEndByMinSpcPercent.	199
droute_fillMetalCloseToMinDensityValue.	200
droute_fillMetalUniformly	202
droute_fillViaDataType	204
droute_fixMinEdgeLengthByFilling.	205
droute_followPolyTrkForPolyFill.	207
droute_groupSrLoop.	209
droute_lowSkewClkRoute	210
droute_maxOffGridTrack	212
droute_maxTieOffDistance.	215
droute_metalFillDensityIncrement	216
droute_minLengthCheckCutMode	217
droute_minShieldLength.	219
droute_numCPUs.	220
droute_offGridCost.	221
droute_offsetFillTrack.	222
droute_optDelaySlackTarget	224

droute_optDelaySrLoop	225
droute_optSetup	226
droute_optSrLoop	228
droute_optViaHoldTimeThreshold	229
droute_optViaSetupSlackThreshold	230
droute_optViaSrLoop	231
droute_optViaTimingDriven	232
droute_optimizeRouteGroup	234
droute_parallelLengthMode	236
droute_pinTaperLengthLimit	238
droute_pinTaperMode	239
droute_reportLimit	241
droute_rerouteUserWire	242
droute_rerunDRC	244
droute_resetMinMaxLayer	246
droute_shieldLimitSboxExt	248
droute_shieldRerouteSignalNets	250
droute_shieldSkipNotShieldedSboxes	252
droute_shieldViaMinSpacing	254
droute_smallJogMinLength	256
droute_srLoop	257
droute_stopIfNoLicense	258
droute_timeLimit	260
droute_timingDriven	261
droute_timingSpace	263
droute_treatTiedFillAsFillToFillSpacing	265
droute_trimUserAntenna	267
droute_ultraWideWireMode	269
droute_wireWidenForceWrongWay	271
droute_wireWidenIgnoreMinEdgeLengthVio	273
droute_wireWidenPieceWise	275
droute_wireWidenSrLoop	277
droute_wireWidenTimingDriven	278
droute_wireWidenWidthScheme	280
droute_wrongWayExtraCost	281
duplicate_ports	282
echo_include_commands	283
edif_variables	284

enable_cell_based_verilog_reader.	297
enable_instances_in_report_net	298
enable_page_mode	299
enable_recovery_removal_arcs	300
enable_slew_degradation.	301
enable_special_level_shifter_naming.	303
estimate_io_latency	304
exit_delete_command_log_file.	305
exit_delete_filename_log_file	306
filename_log_file.	307
find_allow_only_non_hier_ports.	308
find_converts_name_lists.	309
find_ignore_case	310
floorplan_data_attributes	311
focalopt_endpoint_margin	313
fsm_auto_inferring	314
fsm_enable_state_minimization.	315
fsm_export_formality_state_info.	316
fsm_variables	317
gen_bussing_exact_implicit	319
gen_cell_pin_name_separator	320
gen_create_netlist_busses.	321
gen_dont_show_single_bit_busses	322
gen_match_ripper_wire_widths	323
gen_max_compound_name_length.	324
gen_max_ports_on_symbol_side.	325
gen_open_name_postfix	326
gen_open_name_prefix	327
gen_show_created_busses	328
gen_show_created_symbols	329
gen_single_osc_per_name	330
generic_symbol_library.	331
groute_VABoundaryToLSWeight	332
groute_avoidCouplingUser.	333
groute_avoidXtalk.	334
groute_blncdToSkewCntrlRatio	335
groute_blockEdgeAccess.	336
groute_brokenNetsThresholdPercent.	337

groute_clockBalanced	338
groute_clockComb	339
groute_combDistance.	340
groute_combMaxConnections	341
groute_compactMode.	342
groute_congestionWeight.	343
groute_densityDriven	344
groute_detourLimitMinNetLen	345
groute_extraCostsApplyPercent.	346
groute_extraWireLengthOpt.	347
groute_forceUpperLayersForCritNets	348
groute_horReserveTracks	349
groute_ignoreViaBlockage	350
groute_incremental.	351
groute_macroBndryDir	352
groute_macroBndryTrkUtil	353
groute_macroBndryWidth.	354
groute_macroCornerTrkUtil	355
groute_mapOnly.	356
groute_maxDetourPercent	357
groute_netCriticality	358
groute_noTopLevelBusFeedThroughs.	359
groute_paEqPinNetMaxPort.	360
groute_powerDriven	361
groute_rcOptByLength	362
groute_reportDemandOnly.	363
groute_reportEffectiveOverflow	364
groute_reportGCellDensity.	365
groute_reportNetOrdering	366
groute_reserveTracksForPowerFile	367
groute_skewControl	368
groute_skewControlWeight	369
groute_speed	370
groute_timingDriven	371
groute_timingWeight.	372
groute_turboMode	373
groute_verReserveTracks	374
groute_xtalkWeight.	375

hdl_variables	376
hdlin_auto_save_templates	384
hdlin_enable_assertions.....	385
hdlin_mux_size_only	387
hdlin_optimize_pla_effort	388
hdlin_reporting_level	389
hdlin_sv_ieee_assignment_patterns	391
hdlin_sv_packages.....	392
hercules_home_dir.....	394
hier_dont_trace_ungroup	395
high_fanout_net_pin_capacitance	396
high_fanout_net_threshold.....	397
icc_magnetpl_stop_after_seq_cell.....	398
icc_snapshot_storage_location	399
ignore_guardband	400
ilm_enable_power_calculation.....	401
ilm_preserve_core_constraints.....	402
initial_target_library	406
insert_dft_clean_up	407
insert_dft_variables	408
insert_test_design_naming_style.....	412
insert_test_variables.....	413
io_variables	414
layer_attributes.....	418
lbo_cells_in_regions.....	423
level_shifter_naming_prefix	424
lib_thresholds_per_lib.....	425
lib_use_thresholds_per_pin	426
library_attributes.....	428
library_cell_attributes	432
link_force_case.....	434
link_library	435
links_to_layout_variables	436
ltl_obstruction_type.....	439
mcmm_enable_high_capacity_flow	440
mcmm_high_capacity_effort_level.....	441
monitor_cpu_memory.....	442
mpc_disable_macro_fitting.....	444

mpc_disable_pad_legalization	445
mpc_dont_cut_pnet_over_macros	446
multibit_variables	447
mux_auto_inferring_effort.	448
mv_allow_ls_on_leaf_pin_boundary	449
mw_allow_rect_and_polygon_in_def	450
mw_attr_value_extra_braces	451
mw_attr_value_no_space.	452
mw_cell_name	454
mw_design_library	455
mw_disable_escape_char	456
mw_hdl_bus_dir_for_undef_cell.	457
mw_hdl_expand_cell_with_no_instance	458
mw_hdl_verilogel_variables	459
mw_hvo_variables	461
mw_logic0_net	463
mw_logic1_net	464
mw_reference_library.	465
mw_site_name_mapping	466
mwdc_allow_higher_mem_usage	467
net_attributes	468
optimize_reg_always_insert_sequential.	470
optimize_reg_max_time_borrow	471
optimize_reg_retime_clock_gating_latches	472
physical_bus_attributes	473
physopt_area_critical_range	474
physopt_change_list.	475
physopt_check_site_array_overlap	476
physopt_checkpoint_stage.	477
physopt_cpu_limit.	478
physopt_create_missing_physical_libcells.	479
physopt_delete_unloaded_cells.	480
physopt_enable_extractor_rc	481
physopt_enable_power_optimization	482
physopt_enable_router_process	483
physopt_enable_rp_in_xg_mode	484
physopt_enable_tlu_plus	485
physopt_enable_tlu_plus_process	486

physopt_enable_via_res_support	487
physopt_hard_keepout_distance	488
physopt_heterogeneous_site_array	489
physopt_ignore_lpin_fanout	490
physopt_ignore_structure	491
physopt_macro_cell_height_threshold	492
physopt_mw_checkpoint_filename	493
physopt_new_fix_constants	494
physopt_pin_based_pad	495
physopt_power_critical_range	496
physopt_ref_pdef_loaded	497
physopt_row_overlap_threshold	498
physopt_rp_enable_orient_opt	499
physopt_tie_const_cells	500
physopt_tie_spare_cells	501
physopt_ultra_high_area_effort	502
pin_attributes	503
pin_shape_attributes	506
placement_blockage_attributes	510
placer_disable_auto_bound_for_gated_clock	513
placer_disable_macro_placement_timeout	514
placer_dont_error_out_on_conflicting_bounds	515
placer_enable_enhanced_router	516
placer_gated_register_area_multiplier	517
placer_max_cell_density_threshold	518
placer_run_in_separate_process	519
placer_soft_keepout_channel_width	520
plan_group_attributes	521
plot_variables	526
port_attributes	528
port_complement_naming_style	533
power_attributes	534
power_cg_all_registers	537
power_cg_balance_stages	538
power_cg_cell_naming_style	539
power_cg_derive_related_clock	540
power_cg_designware	541
power_cg_enable_alternative_algorithm	542

power_cg_flatten	543
power_cg_gated_clock_net_naming_style.	544
power_cg_ignore_setup_condition.	545
power_cg_inherit_timing_exceptions	546
power_cg_module_naming_style.	547
power_cg_print_enable_conditions	548
power_cg_print_enable_conditions_max_terms	549
power_cg_reconfig_stages.	550
power_default_static_probability	551
power_default_toggle_rate.	553
power_default_toggle_rate_type	555
power_do_not_size_icg_cells.	557
power_driven_clock_gating	558
power_enable_one_pass_power_gating	559
power_enable_power_gating	561
power_fix_sdpd_annotation	562
power_fix_sdpd_annotation_verbose.	564
power_hdlc_do_not_split_cg_cells.	565
power_keep_license_after_power_commands	566
power_lib2saif_rise_fall_pd	567
power_min_internal_power_threshold	568
power_model_preference.	569
power_opto_extra_high_dynamic_power_effort.	570
power_preserve_rtl_hier_names	571
power_rclock_inputs_use_clocks_fanout.	572
power_rclock_unrelated_use_fastest.	573
power_rclock_use_asynch_inputs	574
power_remove_redundant_clock_gates.	575
power_rtl_saif_file.	576
power_sa_propagation_effort.	577
power_sa_propagation_verbose	578
power_same_switching_activity_on_connected_objects.	579
power_sdpd_message_tolerance.	580
power_sdpd_saif_file	581
power_variables	582
preview_scan_variables	585
psyn_onroute_disable_cap_drc	586
psyn_onroute_disable_fanout_drc	587

psyn_onroute_disable_hold_fix	588
psyn_onroute_disable_netlength_drc.	589
psyn_onroute_disable_trans_drc	590
psyn_stress_map	591
psynopt_high_fanout_legality_limit.	592
rc_degrade_min_slew_when_rd_less_than_rnet.	593
rc_driver_model_mode.	594
rc_input_threshold_pct_fall.	595
rc_input_threshold_pct_rise	597
rc_noise_model_mode.	599
rc_output_threshold_pct_fall	600
rc_output_threshold_pct_rise	602
rc_receiver_model_mode.	604
rc_slew_derate_from_library	606
rc_slew_lower_threshold_pct_fall.	608
rc_slew_lower_threshold_pct_rise	610
rc_slew_upper_threshold_pct_fall	612
rc_slew_upper_threshold_pct_rise.	614
read_only_attributes.	616
read_translate_msff	618
reference_attributes	619
register_duplicate	621
report_default_significant_digits.	623
rom_auto_inferring	625
route_guide_attributes	626
route_layerExtraCostByRC	629
routeopt_allow_min_buffer_with_size_only	630
routeopt_checkpoint.	631
routeopt_density_limit.	632
routeopt_disable_cpulimit.	633
routeopt_drc_over_timing.	634
routeopt_preserve_routes	635
routeopt_skip_report_qor	636
routeopt_xtalk_reduction_setup_threshold.	637
rp_shift_column_for_fixed_cells	638
schematic_variables.	639
sdc_write_unambiguous_names	643
search_path	644

sh_command_log_file.	645
sh_enable_line_editing.	646
sh_line_editing_mode.	648
sh_source_uses_search_path	649
shape_attributes.	650
si_use_partial_grounding_for_min_analysis	655
si_variables.	656
si_xtalk_reselect_delta_and_slack.	657
si_xtalk_reselect_delta_delay.	658
si_xtalk_reselect_delta_delay_ratio	659
si_xtalk_reselect_max_mode_slack.	660
si_xtalk_reselect_min_mode_slack	661
single_group_per_sheet.	662
site_info_file	663
site_row_attributes	664
skew_opt_skip_clock_balancing	666
skew_opt_skip_ideal_clocks	667
skew_opt_skip_propagated_clocks	668
sort_outputs	669
suffix_variables.	670
suppress_errors	671
symbol_library	672
synlib_variables	673
syntax_check_status	676
synthetic_library	677
system_variables	678
systemcout_debug_mode	682
systemcout_levelize	685
target_library.	686
template_naming_style.	687
template_parameter_style	688
template_separator_style	690
terminal_attributes	692
test_variables	698
text_attributes.	701
timing_ccs_load_on_demand.	705
timing_check_defaults	706
timing_clock_gating_propagate_enable.	707

timing_crpr_remove_clock_to_data_crpr	708
timing_crpr_threshold_ps	709
timing_disable_cond_default_arcs	710
timing_edge_specific_source_latency	711
timing_enable_multiple_clocks_per_reg	712
timing_enable_non_sequential_checks	713
timing_gclock_source_network_num_master_registers	714
timing_input_port_default_clock	715
timing_remove_clock_reconvergence_pessimism	716
timing_report_attributes	717
timing_self_loops_no_skew	718
timing_separate_clock_gating_group	719
timing_use_clock_specific_transition	720
timing_use_driver_arc_transition_at_clock_source	721
timing_use_enhanced_capacitance_modeling	722
timing_variables	723
trackAssign_XTalkParam	726
trackAssign_densityDriven	727
trackAssign_evenSpaceAdjustment	729
trackAssign_minimizeJog	731
trackAssign_noOffGridRouting	733
trackAssign_noiseThreshold	735
trackAssign_parallelLimit	736
trackAssign_parallelLimitMode	737
trackAssign_runTimingMode	739
trackAssign_runXTalkIter	741
trackAssign_runXTalkMode	742
trackAssign_timingCost	744
trackAssign_tryGlobalLayerFirst	745
trackAssign_tryGlobalLayerOnly	747
trackAssign_variableWidthAdjustment	749
track_attributes	752
ungroup_keep_original_design	755
uniquify_keep_original_design	756
uniquify_naming_style	757
upf_extension	758
use_port_name_for_oscs	759
verbose_messages	760

verilogout_equation	761
verilogout_higher_designs_first	762
verilogout_ignore_case	763
verilogout_include_files	764
verilogout_no_tri	765
verilogout_show_unconnected_pins	766
verilogout_single_bit	767
verilogout_unconnected_prefix	768
vhdlio_variables	769
vhdliout_local_attributes	775
via_attributes	776
view_arch_types	781
view_background	782
view_command_log_file	783
view_execute_script_suffix	784
view_read_file_suffix	785
view_report_append	786
view_report_interactive	787
view_report_output2file	788
view_variables	789
view_write_file_suffix	793
voltage_area_attributes	794
wildcards	797
write_name_nets_same_as_ports	800
write_sdc_output_lumped_net_capacitance	801
write_sdc_output_net_resistance	802
write_test_variables	803

access_internal_pins

Controls the creation, deletion, and user access of internal pins.

TYPE

Boolean

DEFAULT

true

GROUP

system_variables

DESCRIPTION

The **access_internal_pins** variable controls the creation and deletion of internal pins and the access of users to internal pins. Internal pins have to do with internal design inside a library cell. Because of the source of internal pins, they are created or deleted during link time, depending on the setting of this variable. Use the **find** command and **get_pins** command to show internal pins, if such pins exist. Certain timing commands can also set constraints on internal pins. When the **access_internal_pins** variable is set to *false* (the default), after the creation of internal pins, the tool deletes the pins immediately and the constraints on the pins are lost.

SEE ALSO

get_pins(2)
link(2)

acs_compile_attributes

Customize the Automated Chip Synthesis compile strategy.

DESCRIPTION

Automated Chip Synthesis provides attributes that can customize the compile strategy. To set these attributes, use the **set_attribute** command to set the attribute on the reference design for the compile partition (or on the top-level design).

Each chip-level compile command (`acs_compile_design`, `acs_refine_design`, and `acs_recompile_design`) performs a two-step compile. The `acs_compile_design` and `acs_recompile_design` commands perform a full compile followed by a boundary compile. The `acs_refine_design` command performs an incremental compile followed by a boundary compile. The Automated Chip Synthesis compile attributes control both the effort and the strategy used in each of the steps.

These attributes affect the compile scripts generated by the **write_compile_script** command (and therefore the compile scripts generated by the chip-level compile commands). Some attributes add commands to the script before the compile command; others modify the compile command options.

Automated Chip Synthesis ignores these compile attributes if a custom compile strategy or custom compile script exists in the directory defined for the `user_compile_strategy_script` or `user_override_script` directories (default directory is `$acs_work_dir/scripts/dest_dir`).

The following attributes control the effort used in each compile step (full, incremental, and boundary):

- FullCompile

Valid values are none, low, medium, and high.
Default value is medium.

- IncrementalCompile

Valid values are none, low, medium, and high.
Default value is high.

- BoundaryCompile

Valid values are none, low, medium, high, and top.
Default value is top.

The following attributes modify the compile strategy for each compile step:

- OptimizationPriorities (all modes)

Valid values are area, area_timing, timing, and timing_area.
Default value is timing_area.

- CanFlatten (full compile mode only)

Valid values are true and false.

Default value is false.

- CompileVerify (full and incremental compile modes only)

Valid values are true and false.

Default value is false.

- HasArithmetic (full compile mode only)

Valid values are true and false.

Default value is false.

(Deprecated: You will get better QoR for datapathes with just UltraOptimization enabled.)

- PartitionDP (full compile mode only)

Valid values are duplicate, dont_split and false.

Default value is false.

(Deprecated: You will get better QoR for datapathes with just UltraOptimization enabled.)

- AutoUngroup (full compile mode only)

This is a composite attribute with one string value with the syntax: <mode> [<numCells>]

Valid values for the required mode are area, delay and false.

Default value is false.

Valid values for the optional numCells are integer numbers >0.

Default value is unset.

- MaxArea (full and incremental compile modes only)

Valid values are floating point numbers greater than or equal to 0.0.

Default value is 0.0.

- PreserveBoundaries (full and incremental compile modes only)

Valid values are true and false.

Default value is true.

- TestReadyCompile (full and incremental compile modes only)

Valid values are true and false.

Default value is false.

- UltraOptimization (all compile modes)

Valid values are true and false.

Default value is false.

For details about the impact of each attribute on the compile script, see the *Automated Chip Synthesis User Guide*.

SEE ALSO

compile(2)
get_license(2)
remove_license(2)
set_cost_priority(2)
set_flatten(2)
set_max_area(2)
set_minimize_tree_delay(2)
set_resource_allocation(2)
set_resource_implementation(2)
set_structure(2)
transform_csa(2)
uniquify(2)
write_compile_script(2)
compile_auto_ungroup_area_num_cells(3)
compile_auto_ungroup_delay_num_cells(3)
compile_auto_ungroup_override_wlm(3)
compile_implementation_selection(3)
compile_limit_down_sizing(3)
compile_map_low_drive(3)
compile_new_Boolean_structure(3)
compile_top_all_paths(3)
current_design(3)

acs_variables

Specify various Automated Chip Synthesis controls.

SYNTAX

```
string acs_dc_exec                $SYNOPSYS/sparcOS5/syn/bin/dc_shell
list   acs_exclude_extensions      {}
list   acs_exclude_list             {}
list   acs_hdl_source              {}
string acs_num_parallel_jobs        1
string acs_user_budgeting_script    "budget.scr"
string acs_user_compile_strategy_script_suffix "compile"
list   acs_user_dir(path)          {}
list   acs_verilog_extensions      {".v"}
list   acs_vhdl_extensions        {".vhdl"}
string acs_work_dir                "[pwd]"
list   check_error_list            {}
string ilm_preserve_core_constraints "false"
string acs_read_hdl_use_read_file_for_vhdl "true"
```

DESCRIPTION

These variables directly affect Automated Chip Synthesis and are used only in dc_shell-t (Tcl mode of dc_shell).

To view this man page online from within dc_shell-t, type **man acs_variables**. To view an individual variable description, type **man var**, where *var* is the name of the variable. To determine the current value of a variable, type **printvar var**.

acs_area_report_suffix

Specifies the suffix for area reports generated during the automated compile process. The default is area.

acs_autopart_max_area

Used with other acs variables to control chip-level partitioning. Defines partition threshold. For use in dc_shell-t (Tcl mode of dc_shell) only.

acs_autopart_max_percent

Used with other acs variables to control chip-level partitioning. For use in dc_shell-t (Tcl mode of dc_shell) only.

acs_use_autopartition

Used with other acs variables to control chip-level partitioning. If the variable is true, the design will be partitioned automatically. For use in dc_shell-t (Tcl mode of dc_shell) only.

acs_budgeted_cstr_suffix

Specifies the suffix for constraint files generated by the **derive_partition_budgets** command. The default is con.

acs_compile_script_suffix

Specifies the default suffix for script files generated by the

write_compile_script command, sourced in the makefile generated by the **write_makefile** command, and located by the **report_pass_data** command. The default is autoscr.

acs_constraint_file_suffix

Specifies the default suffix for constraint files generated during the automated compile process. The default is con.

acs_cstr_report_suffix

Specifies the default suffix for constraint reports generated during the automated compile process. The default is cstr.

acs_db_suffix

Specifies the default suffix for .db files that are read or written during the automated compile process. The default is db.

acs_dc_exe

Specifies the location of the dc_shell executable. This variable is used by the **acs_compile_design**, **acs_refine_design**, and **acs_recompile_design** commands to generate the makefile. The default is \$SYNOPSYS/\$arch/syn/bin/dc_shell.

acs_exclude_extensions

Specifies the file endings of files that will not be analyzed. When the **acs_read_hdl** command is collecting source files from expanded wildcards or directories, it takes only files that do not end with one of the strings from this list.

acs_exclude_list

Specifies files and directories that will not be analyzed. When the **acs_read_hdl** command is expanding wildcards or traversing directories it will analyze a file only if it is not matched by any item of this list.

acs_global_user_compile_strategy_script

Specifies the file name for the user-defined default compile strategy. The default is default.compile.

acs_hdl_source

Specifies the location of the HDL source code files. The **acs_read_hdl** command expands wildcards in that list (in a Tcl-command "glob"-style manner) and analyzes all files from the list and from the specified directories.

acs_log_file_suffix

Specifies the default suffix for log files generated during the automated compile process. The default is log.

acs_makefile_name

Specifies the filename for the makefile generated by the **write_makefile** command and run by the **compile_partitions** command. The default is Makefile.

acs_num_parallel_jobs

Specifies the number of compile jobs to run in parallel when using **gmake** as the **make** utility. The default is 1.

acs_override_script_suffix

Specifies the suffix for user-defined partition compile scripts. The default

acs_variables

is scr.

acs_qor_report_suffix

Specifies the suffix for QOR reports generated during the automated compile process. The default is qor.

acs_timing_report_suffix

Specifies the suffix for timing reports generated during the automated compile process. The default is tim.

acs_lic_wait

Specifies the maximum wait time for checking out all the licenses required by a compile job. By default (acs_lic_wait = 0), the makefile generated by Automated Chip Synthesis runs the dc_shell command without "-wait #" option. If you want to ensure that all the needed features/licenses are checked out before running the compile job, set acs_lic_wait to the maximum wait time (unit is minute).

acs_user_budgeting_script

Specifies the file name for the user-defined budgeting script. The default is budget.scr.

acs_user_compile_strategy_script_suffix

Specifies the suffix for user-defined partition compile strategies. The default is compile.

acs_user_dir(path)

Specifies a customized directory structure for Automated Chip Synthesis. For use in .synopsys_dc.setup of dc_shell-t (Tcl mode of dc_shell) only.

acs_override_report_suffix

Specifies the suffix for user-defined partition report scripts. The default is report.

acs_verilog_extensions

Specifies the file endings of Verilog files. The default value is {".v"}. When the **acs_read_hdl** command is collecting Verilog source files from expanded wildcards or directories, it takes only files that end with one of the strings from this list.

acs_vhdl_extensions

Specifies the file endings of VHDL files. When the **acs_read_hdl** command is collecting VHDL source files from expanded wildcards or directories, it takes only files that end with one of the strings from this list.

acs_work_dir

Specifies the root of the Automated Chip Synthesis project directory. During startup, this variable is set to the current working directory. This value is used when locating input files for Automated Chip Synthesis commands and when generating absolute path names.

check_error_list

Specifies a list of error codes for which messages are to be checked during the current dc_shell session.

`ilm_preserve_core_constraints`

Specifies if `ilm_mode` should be turned on (value "true") or off ("false"). The `ilm_mode`, if turned on during constraint setting, helps characterizing an instance of an ILM and creating a constraint file for it that contains the constraints for the register-to-register logic of the design. The default value is "false", turning `ilm_mode` off.

`acs_read_hdl_use_read_file_for_vhdl`

If set to true, then **`acs_read_hdl -[auto_]update`** command uses the **`read_file`** command to read VHDL files. Otherwise, it uses the **`analyze`** and **`elaborate -update`** commands to read VHDL files.

SEE ALSO

`acs_compile_design(2)`
`acs_read_hdl(2)`
`acs_recompile_design(2)`
`acs_refine_design(2)`
`check_error(2)`
`compile(2)`
`compile_partitions(2)`
`create_pass_directories(2)`,
`extract_ilm(2)`
`read_partition(2)`,
`remove_pass_directories(2)`,
`report_pass_data(2)`,
`write_compile_script(2)`,
`write_makefile(2)`,
`write_partition(2)`,
`write_partition_constraints(2)`

alib_library_analysis_path

Specifies a single path, similar to a search path, for reading and writing the alib files that correspond to the target libraries.

TYPE

string

DEFAULT

"./"

DESCRIPTION

The tool loads alibs from under this path during compile. The tool stores alibs to this path when the *alib_analyze_libs* command is issued.

SEE ALSO

attributes

Lists the predefined Synopsys attributes.

DESCRIPTION

Attributes are properties assigned to objects such as nets, cells, and clocks, and describe design features to be considered during optimization.

Attributes are grouped into the following categories:

- cell
- clock
- design
- library cell
- net
- pin
- port
- read-only
- reference

Definitions for these attributes are provided in the subsections that follow.

There are a number of commands used to set attributes, however, most attributes can be set with the **set_attribute** command. If the attribute definition specifies a **set** command, use it to set the attribute. Otherwise, use **set_attribute**.

Some attributes are informational, or "read-only." You cannot set the value of these attributes. Most attribute groups contain read-only attributes; however, a complete list of these attributes is provided in the "Read Only" subsection.

Some attributes are "instance-specific", meaning they can be applied to specified objects in the design hierarchy. The following is a list of these attributes:

Certain attributes are specific to Power Compiler objects. For information on the Power Compiler attributes, refer to the **power_attributes** manual page.

- disable_timing
- load
- test_assume

To determine the value of an attribute, use the **get_attribute** command. To remove attributes, use the **remove_attribute** command.

For a more detailed explanation of attributes, refer to the man pages of the appropriate **set** command.

Note: Path groups, cell delay, net delay, external delay, point-to-point timing specification, and arrival information are not represented as attributes, therefore cannot be manipulated with **attributes** commands.

Cell Attributes

area

Specifies the area of a cell. This attribute doesn't exist on a hierarchical cell.

We calculate the attribute by the cell's boundary points.

This attribute is "read-only" and cannot be set by the user.

aspect_ratio

Specifies **height:width** ratio of a cell. This attribute doesn't exist on a hierarchical cell.

This attribute is "read-only" and cannot be set by the user.

async_set_reset_q

Establishes the value (0 or 1) that should be assigned to the q output of an inferred register if set and reset are both active at the same time. To be used with **async_set_reset_qn**. Use these attributes only if you have used the **one_hot** or **one_cold** attributes/directives in your HDL description *and* your technology library is written using pre-V3.0a syntax; *or* if your technology library does not use a consistent convention for q and qn when set and reset are both active. If a V3.0a or later syntax technology library is used, then by default if set and reset are both active at the same time Design Compiler will use the convention of the selected technology library (**target_library**). Set with **set_attribute**.

Note: If you are unsure whether or not your technology library uses V3.0a syntax, ask your ASIC vendor.

async_set_reset_qn

Establishes the value (0 or 1) that should be assigned to the qn output of an inferred register if set and reset are both active at the same time. To be used with **async_set_reset_q**. Use these attributes only if you have used the **one_hot** or **one_cold** attributes/directives in your HDL description *and* your technology library is written using pre-V3.0a syntax; *or* if your technology library does not use a consistent convention for q and qn when set and reset are both active. If a V3.0a or later syntax technology library is used, then by default if set and reset are both active at the same time Design Compiler will use the convention of the selected technology library (**target_library**). Set with **set_attribute**.

Note: If you are unsure whether or not your technology library uses V3.0a syntax, ask your ASIC vendor.

combinational_type_exact

Specifies the replacement gate to use for cells specified in the cell list. Compile attempts to convert combinational gates tagged with **set_compile_type** to the specified replacement combinational gate. Set with **set_combinational_type**.

disable_timing

Disables the timing arcs of a cell. This has the same effect on timing as not having the arc in the library. Set with **set_disable_timing**.

dont_touch

Identifies cells to be excluded from optimization. Values are *true* (the default) or *false*. Cells with the **dont_touch** attribute set to *true* are not modified or replaced during **compile**. Setting **dont_touch** on a hierarchical

cell sets the attribute on all cells below it. Set with **set_dont_touch** .

fall_delay

Specifies an offset from the falling edge of the ideal clock waveform. Affects all clock pins on this cell. Set with **set_clock_skew -fall_delay**.

flip_flop_type

Stores the name of the specified flip-flop to be converted from the **target_library.compile** automatically converts all tagged flip-flops to the specified (or one similar) type. Set with **set_register_type -flip_flop flip_flop_name [cell_list]** .

flip_flop_type_exact

Stores the name of the specified flip-flop to be converted from the **target_library.compile** automatically converts all tagged flip-flops to the exact flip-flop type. Set with **set_register_type -exact -flip_flop flip_flop_name [cell_list]** .

height

Specifies the height of a cell. This attribute doesn't exist on a hierarchical cell.

We use the cell's cell boundary to calculate its height.

This attribute is "read-only" and cannot be set by the user.

is_black_box

true if the cell's reference is not linked to a design or is linked to a design that doesn't have a functionality. This attribute is "read-only" and cannot be set by the user.

is_combinational

true if all cells of a design and all designs in its hierarchy are combinational. A cell is combinational if it is non-sequential or non-tristate and all of its outputs compute a combinational logic function. The **report_lib** command will report such a cell as not a black-box. This attribute is *read-only* and cannot be set by the user.

is_dw_subblock

true if the object (a cell, a reference, or a design) is a DW subblock that was automatically elaborated. This attribute is "read-only" and cannot be set by the user.

NOTE: DW subblocks that are manually elaborated will not have this attribute.

is_hierarchical

true if the design is not a leaf design (for example, not from a technology library). This attribute is "read-only" and cannot be set by the user.

is_mapped

true if the cell is not generic logic. This attribute is "read-only" and cannot be set by the user.

is_sequential

true if the cell is sequential. A cell is sequential if it is not combinational. This attribute is "read-only" and cannot be set by the user.

is_synlib_module

true if the object (a cell, a reference, or a design) refers to an unmapped module reference or if the object is (or refers to) a design that was automatically elaborated from a synlib module or a synlib operator. This attribute is "read-only" and cannot be set by the user.

NOTE: synlib modules that are manually elaborated will not have this attribute.

is_synlib_operator

true if the object (a cell or a reference) is a synthetic library operator reference. This attribute is "read-only" and cannot be set by the user.

is_test_circuitry

Set by **insert_dft** on the scan cells and nets added to a design during the addition of test circuitry. This attribute is "read-only" and cannot be set by the user.

is_unmapped

true if the cell is generic logic. This attribute is "read-only" and cannot be set by the user.

latch_type_exact

Stores the name of the specified latch to be converted from the **target_library.compile** automatically converts all tagged latches to the exact latch type. Set with **set_register_type -latch latch_name [cell_list]** .

macro_area_percentage

Specifies the percentage of total macro area of a soft macro,Ãs physical_area.

This attribute is "read-only" and cannot be set by the user.

map_only

When set to *true*, **compile** will attempt to map the object exactly in the target library, and will exclude the object from logic-level optimization (flattening and structuring). The default is *false*. Set with **set_map_only**.

max_fall_delay

A floating point value that specifies the maximum falling delay on ports, clocks, pins, cells, or on paths between such objects. Set with

set_max_delay.

max_metal_layer

Specifies the reserved maximum metal layer name of a soft macro or a black box.

This attribute is "read-only" and cannot be set by the user.

max_rise_delay

A floating point value that specifies the maximum rising delay on ports, clocks, pins, cells, or on paths between such objects. Set with

set_max_delay.

max_time_borrow

A floating point number that establishes an upper limit for time borrowing; that is, it prevents the use of the entire pulse width for level-sensitive latches. Units are those used in the technology library. Set with

set_max_time_borrow.

min_fall_delay

A floating point value that specifies the minimum falling delay on ports, clocks, pins, cells, or on paths between such objects. Set with **set_min_delay.**

min_metal_layer

Specifies the reserved minimum metal layer name of a soft macro or a black box.
This attribute is "read-only" and cannot be set by the user.

min_rise_delay

A floating point value that specifies the minimum rising delay on ports, clocks, pins, cells, or on paths between such objects. Set with **set_min_delay.**

minus_uncertainty

Specifies a negative uncertainty from the edges of the ideal clock waveform. Affects all clock pins on this cell. Set with **set_clock_skew - minus_uncertainty.**

number_of_black_box

Specifies the count of black boxes in a hierarchical cell or a soft macro. Whether a cell is a black box can be determined by the attribute **is_black_box.** This attribute is "read-only" and cannot be set by the user.

number_of_io_cell

Specifies the count of io cells in a hierarchical cell or a soft macro. We count cells in when its **mask_layout_type** is either **io_pad** or **corner_pad.** This attribute is "read-only" and cannot be set by the user.

number_of_macro

Specifies the count of macros in a hierarchical cell or a soft macro. We count cells in when its **mask_layout_type** is **macro.** This attribute is "read-only" and cannot be set by the user.

number_of_pinshape

Specifies the number of pin shapes of a soft macro.
This attribute is "read-only" and cannot be set by the user.

number_of_standard_cell

Specifies the count of standard cells in a hierarchical cell or a soft macro. We count cells in when its **mask_layout_type** is **std.** This attribute is "read-only" and cannot be set by the user.

physical_area

Specifies the physical area of a hierarchical cell or a soft macro.
The physical area of a hierarchical cell is the sum of its direct children's **physical_area** or **area.** If a direct child is a hierarchical cell, then **physical_area** is used, if a child is a standard cell or macro, then **area** is used, else that child is skipped.
The physical area of a soft macro is the sum of its children's **physical_area** or **area.** The children will be iterated from the sub-design file. If a child is a soft macro, then **physical_area** is used, if a child is a standard cell

attributes

or hard macro, **area** is used, otherwise that child is skipped.
This attribute is "read-only" and cannot be set by the user.

physical_area_percentage_in_top_design

Specifies the percentage of **physical_area** of a soft macro in the top design.
This attribute is "read-only" and cannot be set by the user.

plus_uncertainty

Specifies a positive uncertainty from the edges of the ideal clock waveform.
Affects all clock pins on this cell. Set with **set_clock_skew -plus_uncertainty**.

propagated_clock

Specifies that the clock edge times be delayed by propagating the values through the clock network. Affects all clock pins on this cell. If this attribute is not present, ideal clocking is assumed. Set with **set_clock_skew -propagated**.

ref_name

The reference name of a cell. This attribute is "read-only" and cannot be set by the user.

full_name

The hierarchical name of cell, pin or net. This attribute is "read-only" and cannot be set by the user.

rise_delay

Specifies an offset from the rising edge of the ideal clock waveform. Affects all clock pins on this cell. Set with **set_clock_skew -rise_delay**.

scan

When *true*, specifies that the cell is always replaced by an equivalent scan cell during **insert_dft**. When *false*, the cell is not replaced. Set with **set_scan** .

scan_chain

Includes the specified cells of the referenced design in the scan-chain whose index is the value of this attribute. Set with **set_scan_chain** .

scan_element

Determines if sequential cells in the specified designs are replaced by equivalent scan cells during **insert_scan**. When *true*, the default, **insert_scan** replaces **cell_design_ref_list** with equivalent scan cells. The scan cells are not replaced when set to *false*. Set with **set_scan_element**.

scan_latch_transparent

When *true*, makes specified cells transparent during ATPG. For hierarchical cells, the effects apply hierarchically to level-sensitive leave cells. Set with **set_scan_transparent**. Remove with **remove_attribute**.

test_isolate

Indicates that the specified sequential cells, pins, or ports are to be logically isolated and considered untestable during test design rule checking by **check_test**. When this attribute is set on a cell, it is also placed on all pins of that cell. Do not set this attribute on a hierarchical cell. Use

report_test -assertions for a report on isolated objects. Set with **set_test_isolate**.

Note: Setting this attribute suppresses the warning messages associated with the isolated objects.

test_routing_position

Specifies the preferred routing order of the scan-test signals of the identified cells. Set with **set_test_routing_order** .

ungroup

Removes a level of hierarchy by exploding the contents of the specified cell in the current design. If specified on a reference object, cells using that reference are ungrouped during **compile**. Set with **set_ungroup** .

xnf_init

A string that specifies the value of a storage element during power-on initialization and assertion of the global Set/Reset signal. For flip-flops, the two allowed string values are *S*, to define an initial Set condition; or *R*, to define an initial Reset condition. For ROM symbols, the string value is a hex character string that defines the pattern of the ROM. Setting an **xnf_init** attribute on a cell causes the Synopsys XNF writer to create an INIT attribute on that cell in the XNF netlist; the value of this INIT attribute will match the value specified for the **xnf_init** attribute.

Set this attribute with **set_attribute**, after executing **replace_fpga** and before executing **write -f xnf**.

Note: Set this attribute only on cells that are xnf primitives; **xnfmerge** will not propagate the attribute down into any child cells. In addition, Do not set this attribute on D flip-flops if any of the asynchronous pins are being used.

xnf_loc

A string that specifies the Xilinx location of a cell. No checks are performed to verify that the specified location is valid; for valid location string values, refer to the Xilinx *XC4000 Databook*. Setting an **xnf_loc** attribute on a cell causes the Synopsys XNF writer to create a LOC attribute on that cell in the XNF netlist; the value of this LOC attribute will match the value specified for the **xnf_loc** attribute.

Set this attribute with **set_attribute**, after executing **replace_fpga** and before executing **write -f xnf**.

Note: Set this attribute only on cells that are xnf primitives; **xnfmerge** will not propagate the attribute down into any child cells.

Clock Attributes

clock_fall_transition

Sets the falling transition value on the specified clock list. The **clock_fall_transition** overrides the calculated transition times on clock pins of registers and associated nets. Set using **set_clock_transition**.

clock_rise_transition

Sets the rising transition value on the specified clock list. The **clock_rise_transition** overrides the calculated transition times on clock pins of registers and associated nets. Set using **set_clock_transition**.

dont_touch_network

When a design is optimized, **compile** assigns **dont_touch** attributes to all cells and nets in the transitive fanout of **dont_touch_network** ports. The **dont_touch** assignment stops at the boundary of storage elements. An element is recognized as storage only if it has setup or hold constraints. Set with **set_dont_touch_network**.

fall_delay

Specifies an offset from the falling edge of the ideal clock waveform. Set with **set_clock_skew -fall_delay**.

fix_hold

Specifies that **compile** should attempt to fix hold violations for timing endpoints related to this clock. Set with **set_fix_hold**.

max_fall_delay

A floating point value that specifies the maximum falling delay on ports, clocks, pins, cells, or on paths between such objects. Set with **set_max_delay**.

max_rise_delay

A floating point value that specifies the maximum rising delay on ports, clocks, pins, cells, or on paths between such objects. Set with **set_max_delay**.

max_time_borrow

A floating point number that establishes an upper limit for time borrowing; that is, it prevents the use of the entire pulse width for level-sensitive latches. Units are those used in the technology library. Set with **set_max_time_borrow**.

min_fall_delay

A floating point value that specifies the minimum falling delay on ports, clocks, pins, cells, or on paths between such objects. Set with **set_min_delay**.

min_rise_delay

A floating point value that specifies the minimum rising delay on ports, clocks, pins, cells, or on paths between such objects. Set with **set_min_delay**.

minus_uncertainty

Specifies a negative uncertainty from the edges of the ideal clock waveform. Set with **set_clock_skew -minus_uncertainty**.

period

Assigns a value to the clock period. The clock period (or cycle time) is the shortest time during which the clock waveform repeats. For a simple waveform with one rising and one falling edge, the period is the difference between successive rising edges. Set with **create_clock -period_value**.

plus_uncertainty

Specifies a positive uncertainty from the edges of the ideal clock waveform. Affects all sequential cells in the transitive fanout of this port. Set with **set_clock_skew -plus_uncertainty**.

propagated_clock

Specifies that the clock edge times be delayed by propagating the values through the clock network. If this attribute is not present, ideal clocking is assumed. Set with **set_clock_skew -propagated**.

rise_delay

Specifies an offset from the rising edge of the ideal clock waveform. Set with **set_clock_skew -rise_delay**

Design Attributes

async_set_reset_q

Establishes the value (0 or 1) that should be assigned to the q output of an inferred register if set and reset are both active at the same time. To be used with **async_set_reset_qn**. Use these attributes only if you have used the **one_hot** or **one_cold** attributes/directives in your HDL description *and* your technology library is written using pre-V3.0a syntax; *or* if your technology library does not use a consistent convention for q and qn when set and reset are both active. If a V3.0a or later syntax technology library is used, then by default if set and reset are both active at the same time Design Compiler will use the convention of the selected technology library (**target_library**). Set with **set_attribute**.

Note: If you are unsure whether or not your technology library uses V3.0a syntax, ask your ASIC vendor.

async_set_reset_qn

Establishes the value (0 or 1) that should be assigned to the qn output of an inferred register if set and reset are both active at the same time. To be used with **async_set_reset_q**. Use these attributes only if you have used the **one_hot** or **one_cold** attributes/directives in your HDL description *and* your technology library is written using pre-V3.0a syntax; *or* if your technology library does not use a consistent convention for q and qn when set and reset are both active. If a V3.0a or later syntax technology library is used, then by default if set and reset are both active at the same time Design Compiler will use the convention of the selected technology library (**target_library**). Set with **set_attribute**.

Note: If you are unsure whether or not your technology library uses V3.0a syntax, ask your ASIC vendor.

balance_registers

Determines whether the registers in a design are retimed during **compile**. When *true* (the default value), **compile** invokes the **balance_registers** command, which moves registers to minimize the maximum register-to-register delay. Set this attribute to *false*, or remove it, to disable this behavior.

Set with **set_balance_registers**. **Note:** You cannot verify designs using **compile -verify** while the **balance_registers** attribute is set to *true*. In addition, if your design contains generic logic, you should ensure that all components are mapped to cells from the library before setting the **balance_registers** attribute.

boundary_optimization

Enables **compile** to optimize across hierarchical boundaries. Hierarchy is ignored during optimization for designs with this attribute set to *true*. Set with **set_boundary_optimization** .

default_flip_flop_type

Specifies the default flip-flop type for the current design. During the mapping process, **compile** tries to convert all unmapped flip-flops to this type. If **compile** is unable to use this flip-flop, it maps these cells into the smallest flip-flop possible. Set with **set_register_type -flip_flop flip_flop_name**.

default_flip_flop_type_exact

During the mapping process, **compile** converts unmapped flip-flops to the exact flip-flop type specified here. Set with **set_register_type -exact -flip_flop flip_flop_name**.

default_latch_type_exact

Specifies the exact default latch type for the **current_design**. During the mapping process, **compile** converts unmapped latches to the exact latch type specified here. Set with **set_register_type -exact -latch latch_name**.

design_type

Indicates the current state of the design and has the value *fsm* (finite state machine), *pla* (programmable logic array), *equation* (Boolean logic), or *netlist* (gates). This attribute is "read-only" and cannot be set by the user.

dont_touch

Identifies designs that are to be excluded from optimization. Values are *true* (the default) or *false*. Designs with the **dont_touch** attribute set to *true* are not modified or replaced during **compile**. Setting **dont_touch** on a design has an effect only when the design is instantiated within another design as a level of hierarchy; setting **dont_touch** on the top-level design has no effect. Set with **set_dont_touch**.

flatten

When set to *true*, determines that a design is to be flattened during **compile**. By default, a design is not flattened. Set with **set_flatten**.

flatten_effort

Defines the level of CPU effort that **compile** uses to flatten a design. Allowed values are *low* (the default), *medium*, or *high*. Set with **set_flatten**.

flatten_minimize

Defines the minimization strategy used for logic equations. Allowed values are *single_output*, *multiple_output*, or *none*. Set with **set_flatten**.

flatten_phase

When *true*, allows logic flattening to invert the phase of outputs during **compile**. By default, logic flattening does not invert the phase of outputs. Used only if the **flatten** attribute is set. Set with **set_flatten**.

implementation

The implementation for each specified instance of the specified component_type. Specifying the **-default** option removes this attribute from all instances of the component type in the current design. Set with **set_jtag_implementation**.

is_combinational

true if all cells of a design and all designs in its hierarchy are

combinational. A cell is combinational if it is non-sequential or nonthree-state and all of its outputs compute a combinational logic function. The **report_lib** command will report such a cell as not a black-box. This attribute is *read-only*; you cannot set it.

is_dw_subblock

true if the object (a cell, a reference, or a design) is a DW subblock that was automatically elaborated. This attribute is "read-only" and cannot be set by the user.

NOTE: DW subblocks that are manually elaborated will not have this attribute.

is_hierarchical

true if any of the cells of a design are not leaf cells (for example, not from a technology library). This attribute is *read-only* and cannot be set by the user.

is_mapped

true if all the non-hierarchical cells of a design are mapped to cells in a technology library. This attribute is "read-only" and cannot be set by the user.

is_sequential

true if any cells of a design or designs in its hierarchy are sequential. A cell is sequential if it is not combinational (if any of its outputs depend on previous inputs). This attribute is *read-only* and cannot be set by the user.

is_synlib_module

true if the object (a cell, a reference, or a design) refers to an unmapped module reference or if the object is (or refers to) a design that was automatically elaborated from a synlib module or a synlib operator. This attribute is "read-only" and cannot be set by the user.

NOTE: synlib modules that are manually elaborated will not have this attribute.

is_unmapped

true if any of the cells are not linked to a design or mapped to a technology library. This attribute is *read-only* and cannot be set by the user.

local_link_library

A string that contains a list of design files and libraries to be added to the beginning of the **link_library** whenever a **link** operation is performed. Set with **set_local_link_library**.

map_only

When set to *true*, **compile** will attempt to map the object exactly in the target library, and will exclude the object from logic-level optimization (flattening and structuring). The default is *false*. Set with **set_map_only**.

max_area

A floating point number that represents the target area of the design. **compile** uses it to calculate the area cost of the design. The units must be consistent with the units used from the technology library during optimization. Set with **set_max_area**.

max_capacitance

A floating point number that sets the maximum capacitance value for input, output, or bidirectional ports, or designs. The units must be consistent with those of the technology library used during optimization. Set with **set_max_capacitance**.

max_dynamic_power

A floating point number that specifies the maximum target dynamic power for the **current_design**. The units must be consistent with those of the technology library. If this attribute is specified more than once for a design, the latest value is used. Set with **set_max_dynamic_power**.

max_leakage_power

A floating point number that specifies the maximum target leakage power for the **current_design**. The units must be consistent with those of the technology library. If this attribute is specified more than once for a design, the latest value is used. Set with **set_max_leakage_power**.

max_total_power

A floating point number that specifies the maximum target total power for the **current_design**. Total power is defined as the sum of dynamic and leakage power. If this attribute is specified more than once for a design, the latest value is used. Set with **set_max_total_power**.

min_porosity

Specifies the minimum porosity of the design. **compile -routability** and **reoptimize_design** ensure that the porosity of the design is greater than the specified value. Set with **set_min_porosity**.

minimize_tree_delay

When *true* (the default value), **compile** restructures expression trees in the **current_design** or in a list of specified designs, to minimize tree delay. The value of this attribute overrides the value of **hlo_minimize_tree_delay**. Set this attribute to *false* for any designs that you do not wish to be restructured. Set with **set_minimize_tree_delay**.

model_map_effort

Specifies the relative amount of CPU time to be used by **compile** during modeling, typically for synthetic library implementations. Values are *low*, *medium*, and *high*, or 1, 2, and 3. If **model_map_effort** is not set, the value of **synlib_model_map_effort** is used. Set with **set_model_map_effort**.

model_scale

A floating point number that sets the model scale factor for the **current_design**. Set with **set_model_scale**.

optimize_registers

When *true* (the default value), **compile** automatically invokes the Behavioral Compiler **optimize_registers** command to retime the design during optimization. Setting the attribute to *false* disables this behavior. You cannot execute **compile -verify** if **optimize_registers** is set to *true* on the design; and your design cannot contain generic logic at the instant **optimize_registers** is invoked during **compile**. Set with **set_optimize_registers**.

part

A string value that specifies the Xilinx part type for a design. For valid part types, refer to the Xilinx *XC4000 Databook*. Set with **set_attribute**.

port_is_pad

Indicates specified ports are to have I/O pads attached. The I/O pads are added during **insert_pads** and automatically added during compile. Set using **set_port_is_pad**.

resource_allocation

Indicates the type of resource allocation to be used by **compile** for the **current_design**. Allowed values are *none*, indicating no resource sharing; *area_only*, indicating resource sharing with tree balancing without considering timing constraints; *area_no_tree_balancing*, indicating resource sharing without tree balancing and without considering timing constraints; and *constraint_driven* (the default), indicating resource sharing so that timing constraints are met or not worsened. The value of this attribute overrides the value of the variable **hlo_resource_allocation** for the **current_design**. Set with **set_resource_allocation**.

resource_implementation

Indicates the type of resource implementation to be used by **compile** for the **current_design**. Allowed values are *area_only*, indicating resource implementation without considering timing constraints; *constraint_driven*, indicating resource implementation so that timing constraints are met or not worsened; and *use_fastest*, indicating resource implementation using the fastest implementation initially, unless all timing constraints are met. If the fastest implementation has been selected initially later steps of the compile command will select components with smaller area later in uncritical parts of the design. The value of this attribute overrides the value of the variable **hlo_resource_implementation** for the **current_design**. Set with **set_resource_implementation**.

scan_element

Determines if sequential cells in the specified designs are replaced by equivalent scan cells or designs during **insert_scan**. Default is set to *true*. When set to *false*, sequential cells are not replaced by equivalent scan cells. Set using **set_scan_element**.

scan_latch_transparent

When set to *true*, makes specified designs transparent during ATPG. For hierarchical cells, the effects apply hierarchically to level-sensitive leaf cells. The **set_scan_transparent** command sets the attribute; the **remove_attribute** command removes it.

share_cse

When *true*, the value of the environment variable **hlo_share_common_subexpressions** is used. The value of this attribute determines whether common subexpressions are shared during compile, to reduce the cost of the design. Setting the attribute to *false* overrides the **hlo_share_common_subexpressions**. Set with **set_share_cse**.

structure

Determines if a design is to be structured during **compile**. If *true*, adds logic structure to a design by adding intermediate variables that are factored out

attributes

of the design's equations. Set with **set_structure** .

structure_boolean

Enables the use of Boolean (non-algebraic) techniques during the structuring phase of optimization. This attribute is ignored if the **structure** attribute is *false* Set with **set_structure** .

structure_timing

Enables timing constraints to be considered during the structuring phase of optimization. This attribute is ignored if the **structure** attribute is *false*. Set with **set_structure** .

ungroup

Removes a level of hierarchy from the current design by exploding the contents of the specified cell in the current design. Set with **set_ungroup** .

wired_logic_disable

When *true*, disables creation of wired OR logic during **compile**. The default is *false*; if this attribute is not set, wired OR logic will be created if appropriate. Set with **set_wired_logic_disable**.

wire_load_model_mode

Determines which wire load model to use to compute wire capacitance, resistance, and area for nets in a hierarchical design that has different wire load models at different hierarchical levels. Allowed values are *top*, which indicates to use the wire load model at the top hierarchical level; *enclosed*, which indicates to use the wire load model on the smallest design that encloses a net completely; and *segmented*, which indicates to break the net into segments, one within each hierarchical level. In the *segmented* mode, each net segment is estimated using the wire load model on the design that encloses that segment. The *segmented* mode is not supported for wire load models on clusters. If a value is not specified for this attribute, **compile** searches for a default in the first library in the link path. If none is found, *top* is the default. Set with **set_wire_load**.

xnfout_use_blknames

When *true*, the Synopsys XNF writer writes BLKNM XNF parameters into the XNF netlist for your design when **write -f xnf** is invoked. The default is *false*. The BLKNM XNF parameters convey to the Xilinx place and route tools information, previously placed on the **db_design** by **replace_fpga**, that indicates which groupings of function generators are to be packed into CLB cells. Set with **set_attribute**.

Library Cell Attributes

dont_touch

Identifies library cells to be excluded from optimization. Values are *true* (the default) or *false*. Library cells with the **dont_touch** attribute set to *true* are not modified or replaced during **compile**. Setting **dont_touch** on a hierarchical cell sets the attribute on all cells below it. Set with **set_dont_touch** .

dont_use

Disables the specified library cells so that they are not added to a design

during **compile**. Set with **set_dont_use** .

formula

The attribute of the priority parameter for implementations in synthetic libraries. The formula should evaluate to an integer between 0 and 10. Set with **set_impl_priority**.

implementation

Specifies the implementation for the specified synthetic library cell instances to use. When compile is run, the implementation you specified is used if you set this attribute. The cells instances must be defined in the synthetic library for this attribute to work. Set with **set_implementation**.

no_sequential_degenerates

When *true*, disables mapping to versions of this latch or flip flop that have some input pins connected to 0 or to 1. Set with **set_attribute**. This attribute may also be set on the library itself, and that value will apply as the default for all registers in the library which don't have the attribute set individually.

preferred

Specifies the preferred library gate to use during technology translation when there are other gates with the same function in the target library. Set with **set_prefer** .

scan

When *true*, specifies that the instances of the library cell are always replaced by equivalent scan cells during **insert_dft**. When false, instances are not replaced. Set with **set_scan**.

scan_group

A user-defined string variable that allows you to specify to DFT Compiler a preferred scan equivalent for a non-scan storage element, when a library contains multiple scan equivalents. Typical values are *low*, *medium*, and *high*, for low, medium, and high drive strengths. However, you can define any string variable, and it need not describe drive strength. The default behavior is for DFT Compiler to attempt to choose a scan element that best matches the electrical characteristics of the nonscan element; for a more detailed explanation, refer to the *DFT Compiler Scan Synthesis User Guide*. The matching of electrical characteristics works well with the standard CMOS delay model, but is not accurate with other delay models; **scan_group** provides a means for you to specify an appropriate scan equivalent. Normally, **scan_group** would be set by the ASIC vendor or library developer, but can also be set by you. Consult your ASIC vendor before attempting to set **scan_group** with **set_attribute**. For more information about **scan_group**, refer to the *DFT Compiler Scan Synthesis User Guide*.

set_id

Allows for the value for the implementations in synthetic libraries. Set with **set_impl_priorities**.
Determines if specified designs are scan replaced by **insert_scan**. Set using **set_scan_element**.

scan_latch_transparent

When *true*, makes the specified library cells transparent in ATPG. For

attributes

hierarchical cells, the effects apply hierarchically to level-sensitive leaf cells. The **set_scan_transparent** command sets the attribute; the **remove_attribute** command removes it.

sequential_bridging

When *true*, enables **Design Compiler** to take a multiplexed flip-flop and bridge (that is, connect) the output to the input to get a desired functionality. The default is *false*, so this attribute must be set in order to enable the functionality. Bridging is required for mapping in cases where there is no flip-flop with internal feedback in the target library but one is desired in the HDL. Set with **set_attribute**. This attribute may also be set on the library itself, and that value will apply as the default for all registers in the library which don't have the attribute set individually.

NOTE: Setting this attribute to *true* can result in an increase in run times and memory consumption for Design Compiler. The increased run times depend on the number of flip-flops in the target library or libraries for which this attribute has been set.

Net Attributes

actual_max_net_capacitance

actual_min_net_capacitance

A floating point number that specified the total calculated capacitance of the net. The value of these attributes is calculated upon request. These are "read-only" attributes and they cannot be set by the user.

ba_net_resistance

A floating point number that specifies the back-annotated net resistance on a net. Set with **set_resistance**.

dont_touch

Identifies nets to be excluded from optimization. Values are *true* (the default) or *false*. Nets with the **dont_touch** attribute set to *true* are not modified or replaced during **compile**. Set with **set_dont_touch**.

is_test_circuitry

Set by **insert_dft** on the scan cells and nets added to a design during the addition of test circuitry. This attribute is "read-only" and cannot be set by the user.

"load *"

A floating point number that specifies the wire load value on a net. The total load on a net is the sum of all the loads on pins, ports, and wires associated with that net. This attribute represents only the wire load; pin and port loads are not included in the attribute value unless the attribute *subtract_pin_load* is set to **true** for the same net. Set with **set_load**.

static_probability

A floating point number that specifies the percentage of time that the signal is in the logic 1 state; this information is used by **report_power**. If this attribute is not set, **report_power** will use the default value of 0.5, indicating that the signal is in the logic 1 state half the time. Set with **set_switching_activity**.

subtract_pin_load

Causes **compile** to reduce the wire load value of a net by an amount equal to its pin load. Specifies that the **load** attribute includes the capacitances of all pins on the net. If the resulting wire load is negative, it is set to zero. Set with **set_load -subtract_pin_load**.

toggle_rate

A positive floating point number that specifies the toggle rate; that is, the number of zero-to-one and one-to-zero transitions within a library time unit period. This information is used by **report_power**; if this attribute is not set, **report_power** will use the default value of $2 * (\text{static_probability}) (1 - \text{static_probability})$. The default will be scaled by any associated clock signal (if one is available). Set with **set_switching_activity**.

wired_and

One of a set of two wired logic attributes that includes **wired_or**. When present and set to *true*, **wired_and** determines that the associated net has more than one driver and implements a wired AND function. Wired logic attributes cannot be manually set by the user. To cause wired logic attributes to be added to a netlist design that contains multiply-driven nets, you have two alternatives: 1. execute **compile** or **translate** on the design; or 2. specify the wired logic types using a resolution function in the HDL file.

wired_or

One of a set of two wired logic attributes that includes **wired_and**. When present and set to *true*, **wired_or** determines that the associated net has more than one driver and implements a wired OR function. Wired logic attributes cannot be manually set by the user. To cause wired logic attributes to be added to a netlist design that contains multiply-driven nets, you have two alternatives: 1. execute **compile** or **translate** on the design; or 2. specify the wired logic types using a resolution function in the HDL file.

Pin Attributes

actual_max_net_capacitance

actual_min_net_capacitance

A floating point number that specified the total calculated capacitance of the net that is connected to the given pin. The attributes are defined only for pins of leaf cell. The value of these attributes is calculated upon request. These are "read-only" attributes and they cannot be set by the user.

disable_timing

Disables timing arcs. This has the same effect on timing as not having the arc in the library. Set with **set_disable_timing**.

fall_delay

Specifies an offset from the falling edge of the ideal clock waveform. Set with **set_clock_skew -fall_delay**.

max_slack

A floating point value representing the worst slack of **max_rise_slack** and **max_fall_slack**.

attributes

max_fall_slack

A floating point value representing the worst slack at a pin for falling maximum path delays. This attribute is valid for any pin that appears in a constrained path after timing has been updated.

max_rise_slack

A floating point value representing the worst slack at a pin for rising maximum path delays. This attribute is valid for any pin that appears in a constrained path after timing has been updated.

min_slack

A floating point value representing the worst slack of **min_rise_slack** and **min_fall_slack**.

min_fall_slack

A floating point value representing the worst slack at a pin for falling minimum path delays. This attribute is valid for any pin that appears in a constrained path after timing has been updated..

min_rise_slack

A floating point value representing the worst slack at a pin for rising minimum path delays. This attribute is valid for any pin that appears in a constrained path after timing has been updated.

max_fall_delay

A floating point value that specifies the maximum falling delay on ports, clocks, pins, cells, or on paths between such objects. Set with **set_max_delay**.

max_rise_delay

A floating point value that specifies the maximum rising delay on ports, clocks, pins, cells, or on paths between such objects. Set with **set_max_delay**.

min_fall_delay

A floating point value that specifies the minimum falling delay on ports, clocks, pins, cells, or on paths between such objects. Set with **set_min_delay**.

min_rise_delay

A floating point value that specifies the minimum rising delay on ports, clocks, pins, cells, or on paths between such objects. Set with **set_min_delay**.

minus_uncertainty

Specifies a negative uncertainty from the edges of the ideal clock waveform. Set with **set_clock_skew -minus_uncertainty**.

observe_pin

Specifies the (internal) observe pin name of an LSI Logic scan macrocell (LSI CTV only). This attribute is used by the **write_test** command. Set with **set_attribute** .

pin_direction

Specifies the direction of a pin. Allowed values are *in*, *out*, *inout*, or

unknown. This attribute is **read-only** and cannot be set by the user.

pin_properties

Lists valid EDIF property values to be attached to different versions of the output pin. The EDIF property values correspond to different output emitter-follower resistance values on the output pin. For details about the use of this attribute, refer to the *Library Compiler Reference Manual*, Chapter 6, "Defining Cells." Set with **set_attribute**.

plus_uncertainty

Specifies a positive uncertainty from the edges of the ideal clock waveform. Affects all sequential cells in the transitive fanout of this port. Set with **set_clock_skew -plus_uncertainty**.

propagated_clock

Specifies that the clock edge times be delayed by propagating the values through the clock network. If this attribute is not present, ideal clocking is assumed. Set with **set_clock_skew -propagated**.

rise_delay

Specifies an offset from the rising edge of the ideal clock waveform. Set with **set_clock_skew -rise_delay**.

set_pin

Specifies the (internal) set pin name of an LSI Logic scan macrocell (LSI CTV only). This attribute is used by the **write_test** command. Set with **set_attribute** .

signal_type

Used to indicate that a pin or port is of a special type, such as a **clocked_on_also** port in a master/slave clocking scheme, or a **test_scan_in** pin for scan-test circuitry. Set with **set_signal_type** .

static_probability

A floating point number that specifies the percentage of time that the signal is in the logic 1 state; this information is used by **report_power**. If this attribute is not set, **report_power** will use the default value of 0.5, indicating that the signal is in the logic 1 state half the time. Set with **set_switching_activity**.

test_assume

A string that represents a constant logic value to be assumed for specified pins throughout test design rule checking by **check_test**. "1", "one", or "ONE" specifies a constant value of logic one; "0", "zero", or "ZERO" specifies a constant value of logic zero. Use **report_test -assertions** for a report on objects that have the **test_assume** attribute set. Set with **set_test_assume** .

test_initial

A string that represents an initial logic value to be assumed for specified pins at the start of test design rule checking and fault simulation by **check_test**. "1", "one", or "ONE" specifies an initial value of logic one; "0", "zero", or "ZERO" specifies an initial value of logic zero. Use **report_test -assertions** for a report on objects that have the **test_initial** attribute set. Set with **set_test_initial**.

attributes

test_isolate

Indicates that the specified sequential cells, pins, or ports are to be logically isolated and considered untestable during test design rule checking by **check_test**. When this attribute is set on a cell, it is also placed on all pins of that cell. Do not set this attribute on a hierarchical cell. Use **report_test -assertions** for a report on isolated objects. Set with **set_test_isolate**.

Note: Setting this attribute suppresses the warning messages associated with the isolated objects.

test_routing_position

Specifies the preferred routing order of the scan-test signals of the identified cells. Set with **set_test_routing_order**.

toggle_rate

A positive floating point number that specifies the toggle rate; that is, the number of zero-to-one and one-to-zero transitions within a library time unit period. This information is used by **report_power**; if this attribute is not set, **report_power** will use the default value of $2 * (\text{static_probability}) (1 - \text{static_probability})$. The default will be scaled by any associated clock signal (if one is available). Set with **set_switching_activity**.

true_delay_case_analysis

Specifies a value to set all or part of an input vector for **report_timing -true** and **report_timing -justify**. Allowed values are *0*, *1*, *r* (rise, X to 1), and *f* (fall, X to 0). Set with **set_true_delay_case_analysis**.

Port Attributes

actual_max_net_capacitance

actual_min_net_capacitance

A floating point number that specified the total calculated capacitance of the net connected to the given port. The value of these attributes is calculated upon request. These are "read-only" attributes and they cannot be set by the user.

connection_class

A string that specifies the connection class label to be attached to a port or to a list of ports. **compile**, **insert_pads**, and **insert_dft** will connect only those loads and drivers that have the same connection class label. The labels must match those in the library of components for the design, and must be separated by a space. The labels *universal* and *default* are reserved; *universal* indicates that the port can connect with any other load or driver, and *default* is assigned to any ports that do not have a connection class already assigned. Set with **set_connection_class**.

dont_touch_network

When a design is optimized, **compile** assigns **dont_touch** attributes to all cells and nets in the transitive fanout of **dont_touch_network** clock objects. The **dont_touch** assignment stops at the boundary of storage elements. An element is recognized as storage only if it has setup or hold constraints. Set with **set_dont_touch_network**.

`driven_by_dont_care`

Specifies that input port are driven by `dont_care`. Compile uses this information to create smaller designs. After optimization, the port connected to `dont_care` does not drive anything inside the optimized design. Set with **`set_logic_dc`**.

`driven_by_logic_one`

Specifies that input ports are driven by logic one. **`compile`** uses this information to create smaller designs. After optimization, a port connected to logic one usually does not drive anything inside the optimized design. Set with **`set_logic_one`** .

`driven_by_logic_zero`

Specifies that input ports are driven by logic zero. **`compile`** uses this information to create smaller designs. After optimization, a port connected to logic zero usually does not drive anything inside the optimized design. Set with **`set_logic_zero`** .

`driving_cell_dont_scale`

When *true*, indicates not to scale the transition time on the port using the driving cell. Otherwise the transition time will be scaled by operating condition factors. Set with **`set_driving_cell`**.

`driving_cell_fall`

A string that names a library cell from which to copy fall drive capability to be used in fall transition calculation for the port. Set with **`set_driving_cell`**.

`driving_cell_from_pin_fall`

A string that names the `driving_cell_fall` input pin to be used to find timing arc fall drive capability. Set with **`set_driving_cell`**.

`driving_cell_from_pin_rise`

A string that names the `driving_cell_rise` input pin to be used to find timing arc rise drive capability. Set with **`set_driving_cell`**.

`driving_cell_library_fall`

A string that names the library in which to find the **`driving_cell_fall`**. Set with **`set_driving_cell`**.

`driving_cell_library_rise`

A string that names the library in which to find the **`driving_cell_rise`**. Set with **`set_driving_cell`**.

`driving_cell_multiply_by`

A floating point value by which to multiply the transition time of the port marked with this attribute. Set with **`set_driving_cell`**.

`driving_cell_pin_fall`

A string that names the `driving_cell_fall` output pin to be used to find timing arc fall drive capability. Set with **`set_driving_cell`**.

`driving_cell_pin_rise`

A string that names the `driving_cell_rise` output pin to be used to find timing arc rise drive capability. Set with **`set_driving_cell`**.

attributes

driving_cell_rise

A string that names a library cell from which to copy rise drive capability to be used in rise transition calculation for the port. Set with **set_driving_cell**.

fall_delay

Specifies an offset from the falling edge of the ideal clock waveform. Set with **set_clock_skew -fall_delay**

fall_drive

Specifies the drive value of high to low transition on input or inout ports. Set with **set_drive**.

fanout_load

Specifies the fanout load on output ports. Set with **set_fanout_load** .

load

Specifies the load value on ports. The total load on a net is the sum of all the loads on pins, ports, and wires associated with that net. Set with **set_load**.

max_capacitance

A floating point number that sets the maximum capacitance value for input, output, or bidirectional ports, and/or designs. The units must be consistent with those of the technology library used during optimization. Set with **set_max_capacitance**.

max_fall_delay

A floating point value that specifies the maximum falling delay on ports, clocks, pins, cells, or on paths between such objects. Set with **set_max_delay**.

max_fanout

Specifies the maximum fanout load for the net connected to this port. **compile** ensures that the fanout load on this net is less than the specified value. Set with **set_max_fanout** .

max_rise_delay

A floating point value that specifies the maximum rising delay on ports, clocks, pins, cells, or on paths between such objects. Set with **set_max_delay**.

max_slack

A floating point value representing the worst slack of **max_rise_slack** and **max_fall_slack**.
.XA max_fall_slack A floating point value representing the worst slack at a pin for falling maximum path delays. This attribute is valid for any pin that appears in a constrained path after timing has been updated.
.XA max_rise_slack A floating point value representing the worst slack at a pin for rising maximum path delays. This attribute is valid for any pin that appears in a constrained path after timing has been updated.

min_slack

A floating point value representing the worst slack of **min_rise_slack** and **min_fall_slack**.

.XA min_fall_slack A floating point value representing the worst slack at a pin for falling minimum path delays. This attribute is valid for any pin that appears in a constrained path after timing has been updated.

.XA min_rise_slack A floating point value representing the worst slack at a pin for rising minimum path delays. This attribute is valid for any pin that appears in a constrained path after timing has been updated.

max_time_borrow

A floating point number that establishes an upper limit for time borrowing; that is, it prevents the use of the entire pulse width for level-sensitive latches. Units are those used in the technology library. Set with **set_max_time_borrow**.

max_transition

Specifies the maximum transition time for the net connected to this port. **compile** ensures that value. Set with **set_max_transition**.

min_capacitance

A floating point number that sets the minimum capacitance value for input and/or bidirectional ports. The units must be consistent with those of the technology library used during optimization. Set with **set_min_capacitance**.

min_fall_delay

A floating point value that specifies the minimum falling delay on ports, clocks, pins, cells, or on paths between such objects. Set with **set_min_delay**.

min_rise_delay

A floating point value that specifies the minimum rising delay on ports, clocks, pins, cells, or on paths between such objects. Set with **set_min_delay**.

minus_uncertainty

Specifies a negative uncertainty from the edges of the ideal clock waveform. Affects all sequential cells in the transitive fanout of this port. Set with **set_clock_skew -minus_uncertainty**.

model_drive

A non-negative floating point number that specifies the estimated drive value on ports in terms of standard drives of the current technology library. Set with **set_model_drive**.

model_load

A non-negative floating point number that specifies the estimated load value on ports in terms of standard loads of the current technology library. Set with **set_model_load**.

op_used_in_normal_op

Specifies that a scan-out port is also used in normal operation (system mode). This attribute is used by the **insert_dft** command. Set with **set_attribute**.

output_not_used

Determines that an output port is unconnected. Used by **compile** to create smaller designs since the logic that drives an unconnected output port might not need to be maintained. After a design with an unconnected output port is

compiled, the port is usually not driven by anything inside the design. Set with **set_unconnected** .

pad_location

A string value that specifies the Xilinx pad location (pin number) to be assigned to a port. Setting a **pad_location** attribute on a port causes the Synopsys XNF writer to indicate in the XNF netlist that this port has the pad location given by the value of the **pad_location** attribute. No checks are performed to verify that the specified location is valid; for valid pad locations, refer to the Xilinx *XC4000 Databook*. Set with **set_attribute**.

plus_uncertainty

Specifies a positive uncertainty from the edges of the ideal clock waveform. Affects all sequential cells in the transitive fanout of this port. Set with **set_clock_skew -plus_uncertainty**.

port_direction

Direction of a port. Value can be *in*, *out*, *inout*, or *unknown*. This attribute is "read-only" and cannot be set by the user.

port_is_pad

Indicates specified ports are to have I/O pads attached. The I/O pads are added using **insert_pads** and automatically optimized during compile. Set using **set_port_is_pad**.

propagated_clock

Specifies that the clock edge times be delayed by propagating the values through the clock network. Affects all sequential cells in the transitive fanout of this port. If this attribute is not present, ideal clocking is assumed. Set with **set_clock_skew -propagated**.

rise_delay

Specifies an offset from the rising edge of the ideal clock waveform. Set with **set_clock_skew -rise_delay**.

rise_drive

Specifies the drive value of low to high transition on input or inout ports. Set with **set_drive**.

signal_index

Used to enumerate different ports with the same signal type (for example, scan-in ports for a design with multiple scan chains). Set with **set_signal_type** .

signal_type

Used to indicate that a port is of a "special" type, such as a "clocked_on_also" port in a master/slave clocking scheme, or a "test_scan_in" pin for scan-test circuitry. Set with **set_signal_type** .

static_probability

A floating point number that specifies the percentage of time that the signal is in the logic 1 state; this information is used by **report_power**. If this attribute is not set, **report_power** will use the default value of 0.5, indicating that the signal is in the logic 1 state half the time. Set with **set_switching_activity**.

test_hold

Specifies the fixed, constant logic value at a port during test generation. Set with **set_test_hold** .

test_isolate

Indicates that the specified sequential cells, pins, or ports are to be logically isolated and considered untestable during test design rule checking by **check_test**. When this attribute is set on a cell, it is also placed on all pins of that cell. Do not set this attribute on a hierarchical cell. Use **report_test -assertions** for a report on isolated objects. Set with **set_test_isolate**.

Note: Setting this attribute suppresses the warning messages associated with the isolated objects.

toggle_rate

A positive floating point number that specifies the toggle rate; that is, the number of zero-to-one and one-to-zero transitions within a library time unit period. This information is used by **report_power**; if this attribute is not set, **report_power** will use the default value of $2 * (\text{static_probability}) (1 - \text{static_probability})$. The default will be scaled by any associated clock signal (if one is available). Set with **set_switching_activity**.

true_delay_case_analysis

Specifies a value to set all or part of an input vector for **report_timing -true** and **report_timing -justify**. Allowed values are *0*, *1*, *r* (rise, X to 1), and *f* (fall, X to 0). Set with **set_true_delay_case_analysis**.

Read-Only Attributes

design_type

Indicates the current state of the design and has the value *fsm* (finite state machine), *pla* (programmable logic array), *equation* (Boolean logic), or *netlist* (gates). This attribute cannot be set by the user.

is_black_box

true if the reference is not yet linked to a design or is linked to a design that doesn't have a functionality. This attribute cannot be set by the user.

is_combinational

true if all cells of a design and all designs in its hierarchy are combinational. A cell is combinational if it is non-sequential or non-tristate and all of its outputs compute a combinational logic function. The **report_lib** command will report such a cell as not a black-box. This attribute is *read-only* and cannot be set by the user.

is_dw_subblock

true if the object (a cell, a reference, or a design) is a DW subblock that was automatically elaborated. This attribute is "read-only" and cannot be set by the user.

is_hierarchical

true if any of the cells of a design are not leaf cells (for example, not from a technology library). This attribute cannot be set by the user.

`is_mapped`

true if all the non-hierarchical cells of a design are mapped to cells in a technology library. This attribute cannot be set by the user.

`is_sequential`

true if any cells of a design or designs in its hierarchy are sequential. A cell is sequential if it is not combinational. This attribute cannot be set by the user.

`is_synlib_module`

true if the object (a cell, a reference, or a design) refers to an unmapped module reference or if the object is (or refers to) a design that was automatically elaborated from a synlib module or a synlib operator. This attribute is "read-only" and cannot be set by the user.

NOTE: synlib modules that are manually elaborated will not have this attribute.

`is_synlib_operator`

true if the object (a cell or a reference) is a synthetic library operator reference. This attribute is "read-only" and cannot be set by the user.

`is_test_circuitry`

Set by **insert_dft** on the scan cells and nets added to a design during the addition of test circuitry. This attribute cannot be set by the user.

`is_unmapped`

true if any of the cells are not linked to a design or mapped to a technology library. This attribute cannot be set by the user.

`pin_direction`

Direction of a pin. Value can be *in*, *out*, *inout*, or *unknown*. This attribute cannot be set by the user.

`port_direction`

Direction of a port. Value can be *in*, *out*, *inout*, or *unknown*. This attribute cannot be set by the user.

`ref_name`

The reference name of a cell. This attribute cannot be set by the user.

Reference Attributes

`dont_touch`

Specifies that designs linked to a reference with this attribute are excluded from optimization. Values are *true* (the default) or *false*. Designs linked to a reference with with the **dont_touch** attribute set to *true* are not modified or replaced during **compile**. Set with **set_dont_touch** .

`is_black_box`

true if the reference is not yet linked to a design or is linked to a design that doesn't have a functionality. This attribute is *read-only* and cannot be set by the user.

`is_combinational`

true if all the cells of the referenced design are combinational. A cell is combinational if it is non-sequential or non-tristate and all of its outputs compute a combinational logic function. The **report_lib** command will report such a cell as not a black-box. This attribute is *read-only* and cannot be set by the user.

`is_dw_subblock`

true if the object (a cell, a reference, or a design) is a DW subblock that was automatically elaborated. This attribute is *read-only* and cannot be set by the user.

NOTE: DW subblocks that are manually elaborated will not have this attribute.

`is_hierarchical`

true if the referenced design is not a leaf cell (for example, not in a technology library). This attribute is *read-only* and cannot be set by the user.

`is_mapped`

true if the reference is linked to a design, and all the non-hierarchical cells of the referenced design are mapped to cells in a technology library. This attribute is *read-only* and cannot be set by the user.

`is_sequential`

true if all the cells of the referenced design are sequential. A cell is sequential if it is not combinational (if any of its outputs depend on previous inputs). This attribute is *read-only* and cannot be set by the user.

`is_synlib_module`

true if the object (a cell, a reference, or a design) refers to an unmapped module reference or if the object is (or refers to) a design that was automatically elaborated from a synlib module or a synlib operator. This attribute is *read-only* and cannot be set by the user.

NOTE: synlib modules that are manually elaborated will not have this attribute.

`is_synlib_operator`

true if the object (a cell or a reference) is a synthetic library operator reference. This attribute is *read-only* and cannot be set by the user.

`is_unmapped`

true if any of the non-hierarchical cells of the referenced design are not mapped to cells in a technology library, or if the reference is not yet linked to a design. This attribute is *read-only* and cannot be set by the user.

`scan`

When *true*, specifies that cells of the referenced design are always replaced by equivalent scan cells during **insert_dft**. When *false*, cells of the design are not replaced. Set with **set_scan** .

`scan_chain`

Includes the specified cells of the referenced design in the scan-chain whose index is the value of this attribute. Set with **set_scan_chain** .

attributes

scan_element

Determines if specified designs are scan replaced by **insert_scan**. Set using **set_scan_element**.

scan_latch_transparent

When *true*, makes the specified references transparent in ATPG. For hierarchical cells, the effects apply hierarchically to level-sensitive leaf cells. The specified library cell cannot be overwritten. Set with **set_scan_transparent**; remove with **remove_attribute**.

ungroup

Specifies that all designs linked to a reference with this attribute are ungrouped (levels of hierarchy represented by these design cells are removed) during **compile**. Set with **set_ungroup** .

utilization

Specifies the utilization of a soft macro.

We calculate the utilization using **physical_area:area** ratio of a soft macro. This attribute is "read-only" and cannot be set by the user.

width

Specifies the width of a cell. This attribute doesn't exist on a hierarchical cell.

We use the cell's cell boundary to calculate its width.

This attribute is "read-only" and cannot be set by the user.

SEE ALSO

find (2), **get_attribute** (2), **remove_attribute** (2), **set_attribute** (2), **power_attributes** (3).

auto_insert_level_shifters

Setting this variable to false would prevent automatic level shifter insertion in commands like `compile`, `insert_dft` etc

TYPE

Boolean

DEFAULT

true

GROUP

mv

DESCRIPTION

By default this variable is true. This enables commands like `compile` to automatically insert level shifters where needed. Setting it to false disable this feature.

auto_insert_level_shifters_on_clocks

This variable is used to direct automatic level shifter insertion to insert level shifter on specified clocks

TYPE

string

DEFAULT

" "

GROUP

none

DESCRIPTION

This variable can be set to "all" or a list of clock names (delimited by space or comma). When set to "all", automatic level shifter insertion will insert level shifters on all clock nets that need level shifters.

When this variable is set to a list of clock names, automatic level shifter insertion will insert level shifters on the net of these clocks if needed.

By default automatic level shifter insertion will not insert level shifters on the nets driven by the clocks.

auto_link_disable

Specifies whether the code to perform an auto_link during any Design Compiler command should be disabled.

TYPE

Boolean

DEFAULT

false

GROUP

system_variables

DESCRIPTION

When true, specifies that the code to perform an auto_link during any Design Compiler command should be disabled, resulting in a speedup in command processing. This speedup is important in backannotation commands like **set_load**, **set_resistance**, and **set_annotated_delay** where potentially thousands of such commands are executed in sequence. Disabling the auto_link code can significantly improve the speed with which such commands get executed.

Once the sequence of time-critical commands has been completed, this variable should be reset to the value false, to revert the Design Compiler back to its normal mode of operation.

To determine the current value of this variable use **printvar auto_link_disable**. For a list of all **system** variables and their current values, use the **print_variable_group system** command.

SEE ALSO

set_load(2)
set_resistance(2)
set_annotated_delay(2)

auto_link_options

Specifies the **link** command options to be used when **link** is invoked automatically by various Design Compiler and DFT Compiler commands (for example, **create_schematic** and **compile**).

TYPE

string

DEFAULT

-all

GROUP

system_variables

DESCRIPTION

Specifies the **link** command options to be used when **link** is invoked automatically by various Design Compiler and DFT Compiler commands (for example, **create_schematic** and **compile**). The default is **-all**. To find the available options, refer to the **link** command manual page.

To determine the current value of this variable, type **printvar auto_link_options**. For a list of all **system** variables and their current values, type **print_variable_group system**.

SEE ALSO

link(2)

auto_ungroup_preserve_constraints

Preserves (when *true*) the timing constraints on the hierarchy when the hierarchy is ungrouped during the process of optimization.

TYPE

Boolean

DEFAULT

true

GROUP

timing

DESCRIPTION

Enables the ungrouping (when *true*) of hierarchies with timing constraints and preserves the timing constraints when the hierarchies are ungrouped during the process of optimization. By default, the **auto_ungroup_preserve_constraints** variable is *true*,

The constraints are preserved when executing the following commands:

```
compile -ungroup_all
```

```
set_ungroup followed by compile
```

```
compile -auto_ungroup area | delay
```

The constraints on DesignWare library hierarchical cells are also lost when the cells are ungrouped during optimization.

Set the **auto_ungroup_preserve_constraints** variable to *false* before compiling to avoid ungrouping of hierarchies with timing constraints.

Use the **printvar auto_ungroup_preserve_constraints** command to determine the current value of this variable.

SEE ALSO

set_ungroup(2)

bind_unused_hierarchical_pins

Specifies if unused input and output hierarchical pins should be connected to constant tie-off cells during compile.

TYPE

Boolean

DEFAULT

true

GROUP

compile_variables

DESCRIPTION

Design Compiler connects each undriven leaf cell input to a constant tie-off cell during compile. The tool does the same for input pins and output pins of a design hierarchy as well. If an input pin of a design hierarchy is undriven, it will be connected to a constant tie-off cell in its parent hierarchy during compile. If an output pin of a design hierarchy is undriven, it will be connected to a constant tie-off cell in the same hierarchy during compile.

To prevent unconnected pins from being tied off, set **bind_unused_hierarchical_pins** to false before linking in the design.

When commands such as **compile -boundary_optimization** are used, the optimized design may be left with hierarchical inputs and outputs that are neither driven nor loaded. These hierarchical inputs and outputs will not be connected to constant tie-offs if **bind_unused_hierarchical_pins** variable is set to false.

To determine the current value of this variable, type **printvar bind_unused_hierarchical_pins**. For a list of all **compile** variables and their current values, type **print_variable_group compile**.

SEE ALSO

blockPlace_addChannelBlockages

Enables adding placement blockages in congested channels during *shape_fp_blocks -incremental congestion_driven* .

TYPE

integer

DEFAULT

2

DESCRIPTION

shape_fp_blocks -incremental congestion_driven command will widen congested channels to alleviate congestion. However, sometimes in the subsequent placement, more cells move into those channels than were there before they were widened, adding more signals to be routed, and potentially making channels congested again. This variable controls whether we cover those channels with blockages and if so, what kind of blockages.

By default, the tool does not add placement blockages. When set to 1, the blockages will be partial, with the corresponding percentage set to allow about the same amount of cells in the channel as before the command. When set to 2, the blockages will be soft. When set to 3, the blockages will be hard.

Note that while adding these blockages helps with the congestion in the channels, it may make other areas of the design overutilized.

Use the following command to determine the current value of the variable:

```
prompt> printvar blockPlace_addChannelBlockages
```

SEE ALSO

shape_fp_blocks(2)

blockPlace_adjustMacroLocations

Adjusts macro locations during *shape_fp_blocks -incremental congestion_driven* .

TYPE

integer

DEFAULT

0

DESCRIPTION

shape_fp_blocks -incremental congestion_driven changes plan group boundaries. Frequently, these changes are minor. If this variable is set to 1, during the command, non-fixed macros will be slightly moved to to make their locations legal (for example, plan group macros will move to fit inside the new plan group boundaries, and top level macros will move to avoid plan groups), and to avoid overlaps. If this cannot be accomplished using small moves, some overlaps may remain to be handled by subsequent placement.

Use the following command to determine the current value of the variable:

```
prompt> printvar blockPlace_adjustMacroLocations
```

SEE ALSO

shape_fp_blocks(2)

blockPlace_avoidPowerGrid

Controls whether the power grid is on during channel resizing.

TYPE

integer

DEFAULT

0

DESCRIPTION

By default, the power grid is off during channel resizing.

When set to 1, the power grid is on during channel resizing and the **shape_fp_blocks** command avoids the power grid for the plan group boundaries that it moves. If a plan group is moved when the power grid is on, by default, the plan group is placed no closer than one row height to the power grid. You can change this distance by setting the **blockPlace_distanceToPowerGrid** variable.

Note that the **blockPlace_avoidPowerGrid** variable cannot be used to legalize the plan group boundaries with respect to the power grid. The tool assumes that the plan group boundaries are already away from the power grid and decides whether to move the plan group boundaries based only on the channel size requirements.

Use the following command to determine the current value of the variable:

```
prompt> printvar blockPlace_avoidPowerGrid
```

SEE ALSO

shape_fp_blocks(2)
blockPlace_distanceToPowerGrid(3)

blockPlace_distanceToPowerGrid

Specifies the minimum allowed distance between a plan group boundary and the power grid.

TYPE

integer

DEFAULT

-1

DESCRIPTION

By default, the minimum distance allowed between a plan group boundary and the power grid is one row height.

If you specify a negative value, the tool uses one row height as the minimum distance.

Use the following command to determine the current value of the variable:

```
prompt> printvar blockPlace_distanceToPowerGrid
```

SEE ALSO

```
shape_fp_blocks(2)  
blockPlace_avoidPowerGrid(3)
```

blockPlace_keepTopLevelTogether

Controls whether the top level is kept together (contiguous) during shaping.

TYPE

integer

DEFAULT

0

DESCRIPTION

This variable, when set to 1, forces the **shape_fp_blocks** command to keep top level area contiguous.

Use the following command to determine the current value of the variable:

```
prompt> printvar blockPlace_keepTopLevelTogether
```

SEE ALSO

`shape_fp_blocks(2)`

blockPlace_minChannelSize

Specifies the minimum channel size between two plan groups.

TYPE

real

DEFAULT

0

DESCRIPTION

This variable specifies the minimum channel size between two plan groups. By default, there is no minimum channel size.

Use the following command to determine the current value of the variable:

```
prompt> printvar blockPlace_minChannelSize
```

SEE ALSO

shape_fp_blocks(2)

blockPlace_preserveAbutment

Enables preserving abutment during *shape_fp_blocks -incremental target_utilization_driven* .

TYPE

integer

DEFAULT

0

DESCRIPTION

By default, *shape_fp_blocks -incremental target_utilization_driven* command is allowed to create channels between plan groups that were originally abutted. This allows for a wider solution space. If this variable is set to 1, the command will make sure that plan groups that were originally abutted remain so. Note that this may create a very strong constraint for the command.

Use the following command to determine the current value of the variable:

```
prompt> printvar blockPlace_preserveAbutment
```

SEE ALSO

shape_fp_blocks(2)

blockPlace_utilSlack

Controls how much channel resizing can exceed the target utilization.

TYPE

real

DEFAULT

0.1

DESCRIPTION

This variable control how much channel resizing can exceed the target utilization. By default, channel resizing can exceed the target utilization by 10 percent (0.1). The channel resizing will not exceed 100 percent utilization for plan groups. For black boxes, the channel resizing can exceed the target utilization.

Use the following command to determine the current value of the variable:

```
prompt> printvar blockPlace_utilSlack
```

SEE ALSO

shape_fp_blocks(2)

bound_attributes

Contains attributes related to bound.

DESCRIPTION

Contains attributes related to bound.

You can use **get_attribute** to determine value of an attribute, and use **report_attribute** to get a report of all attributes on specified object. Specified with **list_attribute -class bound -application**, the definition of attributes can be listed.

Bound Attributes

aspect_ratio

Specifies the **width:height** ratio of a bound.
The data type of **aspect_ratio** is double.
This attribute is read-only.

bbox

Specifies the bounding-box of a bound. The **bbox** is represented by a **rectangle**. The format of a *rectangle* specification is {{llx lly} {urx ury}}, which specifies the lower-left and upper-right corners of the rectangle.
The data type of **bbox** is string.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

bbox_ll

Specifies the lower-left corner of the bounding-box of a bound.
The **bbox_ll** is represented by a **point**. The format of a *point* specification is {x y}.
You can get the **bbox_ll** of a bound, by accessing the first element of its **bbox**.
The data type of **bbox_ll** is string.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

bbox_llx

Specifies x coordinate of the lower-left corner of the bounding-box of a bound.
The data type of **bbox_llx** is double.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

bbox_lly

Specifies y coordinate of the lower-left corner of the bounding-box of a bound.
The data type of **bbox_lly** is double.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

bound_attributes

bbox_ur

Specifies the upper-right corner of the bounding-box of a bound.
The **bbox_ur** is represented by a **point**. The format of a *point* specification is {x y}.
You can get the **bbox_ur** of a bound, by accessing the second element of its **bbox**.
The data type of **bbox_ur** is string.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

bbox_urx

Specifies x coordinate of the upper-right corner of the bounding-box of a bound.
The data type of **bbox_urx** is double.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

bbox_ury

Specifies y coordinate of the upper-right corner of the bounding-box of a bound.
The data type of **bbox_ury** is double.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

color

Specifies color to draw a move bound and its associated instances.
The data type of **color** is string.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

dimension

Specifies dimension of a group bound.
Its format is {width height}.
The data type of **dimension** is string.
This attribute is read-only.

effort

Specifies effort to bring cells closer inside an auto group bound.
Its valid values can be:

- **low**
- **medium**
- **high**
- **ultra**

The data type of **effort** is string.

This attribute is read-only.

name

Specifies name of a bound object.

The data type of **name** is string.

This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

number_of_hard_macro

Specifies number of hard macro cells inside a bound.

The data type of **number_of_hard_macro** is integer.

This attribute is read-only.

number_of_standard_cell

Specifies number of standard cells inside a bound.

The data type of **number_of_standard_cell** is integer.

This attribute is read-only.

object_class

Specifies object class name of a bound, which is **bound**.

The data type of **object_class** is string.

This attribute is read-only.

object_type

Specifies object type of a bound, which can be **move_bound**, **auto_group_bound**, or **group_bound**.

The data type of **object_type** is string.

This attribute is read-only.

points

Specifies point list of a move bound's boundary.

The data type of **points** is string.

This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

type

Specifies type of a move bound or a group bound.

The data type of **type** is string.

Its valid values are:

- **soft**
- **hard**
- **exclusive**

This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

bound_attributes

utilization

Specifies the ratio of total area size of associated instances to the area of a move bound.

The data type of **utilization** is double.

This attribute is read-only.

SEE ALSO

get_attribute(2),
list_attribute(2),
report_attribute(2),
set_attribute(2).

bsd_variables

SYNTAX

```
integer test_bsd_allow_tolerable_violations = FALSE
integer test_bsd_control_cell_drive_limit = 3
integer test_bsd_manufacturer_id = 0
integer test_bsd_optimize_control_cell = FALSE
integer test_bsd_part_number = 0
integer test_bsd_version_number = 0
string test_bsd1_default_suffix_name = "bsd1"
integer test_bsd1_max_line_length = 80
integer test_cc_ir_masked_bits = 0
integer test_cc_ir_value_of_masked_bits = 0
string test_user_defined_instruction_naming_style = "USER%d"
string test_user_defined_test_data_register_naming_style = "UTDR%d"
string bsd_max_in_switching_limit = 60000
string bsd_max_out_switching_limit = 60000
```

DESCRIPTION

These variables directly affect the **insert_bsd**, **optimize_bsd**, **check_bsd**, **create_bsd_patterns** and **write_bsd1** commands. Defaults are shown above, under Syntax.

For a list of **bsd** variables, type **print_variable_group bsd**. To view this manual page on-line, type **help bsd_variables**. To view an individual variable description, type **help variable-name**, where *variable-name* is the name of the variable.

test_bsd_allow_tolerable_violations

When *true*, allows **optimize_bsd** to exchange **control and observe** cells for **observe only** cells, or to remove the cells altogether, thereby allowing tolerable violations for timing-driven optimization. The default is *false*.

test_bsd_control_cell_drive_limit

An integer that specifies the number of output bits to be controlled by a single BSR controlling cell. This controls the assignment of BSR control cells during **optimize_bsd**.

test_bsd_manufacturer_id

An integer that specifies the **manufacturer id** to be part of the Device Identification Register's capture value during **insert_bsd**.

test_bsd_optimize_control_cell

When *true*, enables control cell optimization during **optimize_bsd**. The default is *false*. The number of cells controlled by a single BSR cell is controlled by the **test_bsd_control_cell_drive_limit** variable.

test_bsd_part_number

An integer that specifies the **Part Number** to be part of the Device Identification

Register's capture value during **insert_bsd**.

test_bsd_version_number

An integer that specifies the **Version Number** to be part of the Device Identification Register's capture value during **insert_bsd**.

test_bsd1_default_suffix_name

Specifies the default suffix for name of the the BSDL file generated by the **write_bsd1** command.

test_bsd1_max_line_length

An integer that specifies the maximum number of characters per line of the output BSDL file produced by the **write_bsd1** command.

test_cc_ir_masked_bits

An integer whose binary value specifies instruction register (IR) bits that are to be masked during the search for all possible implemented instructions. Bits containing a "1" value are masked.

test_cc_ir_value_of_masked_bits

An integer that specifies a value (0 or 1) to be forced into the instruction register (IR) bits masked by the **test_cc_ir_masked_bits** variable.

test_user_defined_instruction_naming_style

Specifies the naming style to be used by **check_bsd** and **write_bsd1** for the user-defined (non-standard) instructions inferred by these commands.

test_user_test_data_register_naming_style

Specifies the naming style to be used by **check_bsd** and **write_bsd1** for the user-defined (non-standard) test data registers inferred by these commands.

bsd_max_in_switching_limit

Specifies the maximum number of inputs that may switch simultaneously while generating VIL/VIH tests using the **create_bsd_patterns** command.

bsd_max_out_switching_limit

Specifies the maximum number of outputs that may switch simultaneously while generating VOL/VOH tests using the **create_bsd_patterns** command.

SEE ALSO

insert_bsd (2), **optimize_bsd** (2), **check_bsd** (2), **write_bsd1** (2), **create_bsd_patterns** (2), **test_bsd_version_number** (3), **test_bsd_manufacturer_id** (3), **test_bsd_part_number** (3), **test_bsd_optimize_control_cell** (3), **test_bsd_control_cell_drive_limit** (3), **test_bsd_allow_tolerable_violations** (3), **test_cc_ir_masked_bits** (3), **test_cc_ir_value_of_masked_bits** (3), **test_bsd1_default_suffix_name** (3), **test_bsd1_max_line_length** (3), **test_user_defined_instruction_naming_style** (3), **test_user_test_data_register_naming_style** (3).

budget_generate_critical_range

Enables automatic generation of `set_critical_range` commands by `dc_allocate_budgets` for multiply-instantiated subdesigns.

TYPE

Boolean

DEFAULT

false

GROUP

acs_variables

DESCRIPTION

When set to true, this variable will cause the **dc_allocate_budgets** command to automatically generate a **set_critical_range** command for any budgeted cells that have multiply-instantiated subdesigns. The value of `critical_range` is set to 10% of the shortest clock period in the design. If the top-level design already has a `critical_range` attribute, then that original value will be used instead.

The purpose of this is to improve QoR, since any multiple instances must be `dont_touched` after compile in a bottom-up compile flow. Using **set_critical_range** will cause any near-critical paths in these blocks to be optimized before the block is `dont_touched`.

To see the current value of this variable, type

```
dc_shell-xg-t> printvar budget_generate_critical_range
```

SEE ALSO

budget_map_clock_gating_cells

Maps integrated clock gating cells into target library during RTL budgeting.

TYPE

Boolean

DEFAULT

false

GROUP

acs_variables

DESCRIPTION

When set to true, this variable will cause the **dc_allocate_budgets -mode rtl** command to map any integrated clock gating cells into target library cells before calculating the budget. Normally, any unmapped cells would remain unmapped during budgeting when **-mode rtl** is used.

The purpose of this is to prevent incorrect **-level_sensitive** delay constraints from appearing in the budget constraint files. These may otherwise appear because unmapped integrated clock gating cells can include transparent latch elements.

To see the current value of this variable, type

```
dc_shell-xg-t> printvar budget_map_clock_gating_cells
```

SEE ALSO

bus_inference_descending_sort

Specifies that the members of that port bus are to be sorted in descending order rather than in ascending order.

TYPE

Boolean

DEFAULT

true

GROUP

edif_variables
io_variables

DESCRIPTION

Affects the **read** command except for the db, Verilog and VHDL formats. This variable is primarily used when reading in designs in the LSI/NDL format. That particular format does not support representation of busses, but, if port names follow a specific pattern (as described in the variable **bus_inference_style**), the individual bits can be "inferred" into a port bus. When true (the default value), This variable specifies that the members of that port bus are to be sorted in descending order rather than in ascending order.

For example, with the variable **bus_inference_style** set to "%s[%d]", the ports "A[1]", "A[2]", "A[3]", and "A[4]" will be "inferred" into a port bus named "A". If this variable is true, the port bus "A" will have an index from 4 to 1; if this variable is false, the port bus "A" will have an index from 1 to 4.

With the variable **bus_inference_style** set to "#d%%s", the ports "#8%cb", "#9%cb", "#10%cb", and "#11%cb" will be "inferred" into a port bus named "cb". If this variable is true, the port bus "cb" will have an index from 11 to 8; if this variable is false, the port bus "cb" will have an index from 8 to 11.

To determine the current value of this variable, type **printvar bus_inference_descending_sort**. For a list of all **edif** or **io** variables and their current values, type **print_variable_group edif** or **print_variable_group io**.

SEE ALSO

remove_bus(2)
report_bus(2)
bus_inference_style(3)
bus_minus_style(3)
bus_naming_style(3)
bus_range_separator_style(3)
edif_variables(3)

```
io_variables(3)
```

bus_inference_style

Specifies the pattern used to infer individual bits into a port bus.

TYPE

string

DEFAULT

" "

GROUP

edif_variables
io_variables

DESCRIPTION

Specifies the pattern used to infer individual bits into a port bus. This variable affects the **read** command except, for the db and VHDL formats. This variable also affects the VHDL **write** commands. The variable is used primarily when reading in designs in the LSI/NDL format. The LSI/NDL format does not support representation of buses. But if port names follow a specific pattern (as described by this variable), the individual bits can be "inferred" into a port bus. If you specify an invalid value, no port buses are inferred.

When running in tcl mode the bus_inference_style needs to be within the curly brackets and if running in eqn mode, the bus_inference_style needs to be within double quotes.

For example: eqn mode: bus_inference_style = "%s[%d]"

tcl mode: set bus_inference_style {%s[%d]}

This variable must contain one %s (percent s) and %d (percent d) character sequence. Additional characters can be used with these symbols. To use a percent sign in a name, two are needed in the variable string (%%).

In naming a port bus, the port name is substituted for %s, and the port number replaces %d. A single percent sign is substituted for %.

For example, with this variable set to "%s[%d]", the ports "A[1]", "A[2]", "A[3]", and "A[4]" will be "inferred" into a port bus named "A" either with an index from 1 to 4 or with an index from 4 to 1 (see **bus_inference_descending_sort**).

With this variable set to "%d%%s", the ports "#8%cb", "#9%cb", "#10%cb", and "#11%cb" will be "inferred" into a port bus named "cb" either with an index from 8 to 11 or with an index from 11 to 8 (see **bus_inference_descending_sort**).

To determine the current value of this variable, type **printvar bus_inference_style**.

bus_inference_style

For a list of all **edif** or **io** variables and their current values, type **print_variable_group edif** or **print_variable_group io**.

SEE ALSO

```
remove_bus(2)
report_bus(2)
bus_inference_descending_sort(3)
bus_minus_style(3)
bus_naming_style(3)
bus_range_separator_style(3)
edif_variables(3)
io_variables(3)
```

bus_minus_style

Controls the naming of individual members of bit-blasted port, instance, or net buses with negative indices.

TYPE

string

DEFAULT

-%d

GROUP

hdl_variables

DESCRIPTION

Controls the naming of individual members of bit-blasted port, instance, or net buses with negative indices. This variable affects the **read** command with the **vhdl** format option.

To determine the current value of this variable, type **printvar bus_minus_style**. For a list of all **hdl** variables and their current values, type **print_variable_group hdl**.

SEE ALSO

remove_bus(2)
report_bus(2)
bus_inference_descending_sort(3)
bus_inference_style(3)
bus_naming_style(3)
bus_range_separator_style(3)
edif_variables(3)

bus_multiple_separator_style

Determines the name of a multibit cell that implements bits that do not form a range.

TYPE

string

DEFAULT

,

GROUP

multibit_variables

DESCRIPTION

This variable affects the naming of multibit cells during multibit mapping. This variable is used to name a multibit cell that implements bits that do not form a range. The default is used if an invalid value is specified.

The **bus_range_separator_style** is used to separate the start and end bit positions of a range, while **bus_multiple_separator_style** is used to separate two ranges. The two variables are used in conjunction with the **bus_naming_style** variable to generate names for multibit cells.

Assume that **bus_range_separator_style** is set to ":", **bus_multiple_separator_style** is set to ",", and **bus_naming_style** is set to "%s[%d]" in the following examples.

For example, if cells with the names q[0], q[1], q[2], q[5], q[6], and q[7] are packed into a 6-bit wide cell, the name given to the new cell is q[0:2,5:7]. If cells q[0], q[2], q[4], and q[6] are packed into a 4-bit wide cell, the name given to the new cell is q[0,2,4,6].

To determine the current value of this variable, type **printvar bus_range_separator_style**. For a list of all **multibit** variables and their current values, type **print_variable_group multibit**.

SEE ALSO

bus_range_separator_style(3)
multibit_variables(3)

bus_naming_style

Specifies the style to use in naming an individual port member, net member, or cell instance member of an EDIF array or of a Verilog or VHDL vector.

TYPE

string

DEFAULT

%s[%d]

GROUP

edif_variables
hdl_variables
schematic_variables

DESCRIPTION

This variable affects the **read** command with the EDIF, Verilog, or VHDL format option, the **write** command with the EDIF format option, and the **create_schematic** command with the busing option.

When reading buses, this variable specifies the style to use in naming an individual port member, net member, or cell instance member of an EDIF array or of a Verilog or VHDL vector.

When running in tcl mode the bus_naming_style needs to be within the curly brackets and if running in eqn mode, the bus_naming_style needs to be within double quotes.

For example: eqn mode: bus_naming_style = "%s[%d]"

tcl mode: set bus_naming_style {%s[%d]}

When writing buses, this variable used with the variable **bus_range_separator_style** specifies the style to use in naming a port array or net array in the EDIF file. If you specify an invalid value, the array is given the name of the bus. When writing schematic nets, this variable used with the variable **bus_range_separator_style** specifies the style to use in naming a net connected to the "wire" end of a ripper in the EDIF file. If you specify an invalid value, the net is given the name of the original net.

When creating schematics, this variable used with the variable **bus_range_separator_style** specifies the style to use in naming a ripper, bused port, bused net, or net connected to the "wire" end of a ripper. If you specify an invalid value, the default is used.

This variable must contain only one %s (percent s) and one %d (percent d) character sequence. To use the % (percent sign) in the name, use two of them in the variable

bus_naming_style

string (%%). Therefore, the only characters that can follow a percent sign are %, s, or d.

When reading buses, in naming members, the name of the array is substituted for %s, and the number of the member is substituted for %d. A single percent sign is substituted for %%.

For example, if this variable is set to "%s[%d]", then the first member of the 4-bit array "A", going from 0 to 3, is named:

A[0]

If this variable is set to "%s_%%d.X", then the first member of the 8-bit array "xy", going from 9 to 16, is named:

xy_%9.X

See **bus_dimension_separator_style** for a description of how it is used in conjunction with this variable for specifying the names of the members of multi-dimensional arrays in the EDIF format or multi-dimensional vectors in the VHDL format.

See **bus_minus_style** for a description of how to specify the names of vectors with negative indices in the VHDL format.

When creating schematics or when writing buses, in naming a bused port or bused net or a port array or net array, the original bus or array name is substituted for %s. The start and end bits of the bus or array separated by the value of the variable **bus_range_separator_style** are substituted for %d. A single percent sign is substituted for each %%.

For example, if this variable is set to "%s[%d:%d]", then the 4-bit bus or array "A", going from 0 to 3, is named:

A[0:3]

If this variable is set to "%%s[%d][%d]", then the 8-bit bus or array "B", going from -4 to 3, is named:

See **edifout_multidimension_arrays** for a description of how it is used in conjunction with this variable for specifying the names of multi-dimensional arrays.

See **edifout_numerical_array_members** for a description of how it is used in conjunction with this variable for specifying the names of descending arrays.

When creating schematics or when writing schematic nets, in naming a ripper or net connected to the "wire" end of a ripper, the original net name is substituted for %s. If the net is a scalar (a single bit) net, the bit of the ripper is substituted for %d; if the net is a bused net, the start and end bits of the ripper separated by the value of the variable **bus_range_separator_style** are substituted for %d. A single percent sign is substituted for each %%.

For example, if this variable is set to "%s[%d]", then the ripper or the net connected to the "wire" end of the ripper that is ripping off the first bit of the 4-bit net array "A" going from 0 to 3, is named:

A[0]

If this variable is set to "%s_%%d.X", then the ripper or the net connected to the "wire" end of the ripper that is ripping off the first bit of the 8-bit net array "xy" going from 9 to 16, is named:

xy_%9.X

If this variable is set to "%s[%d]" and the variable **bus_range_separator_style** is set to ":", then the net connected to the "wire" end of the ripper that is ripping off the third through fifth bits of the 8-bit net array "xy" going from 9 to 16, is named:

xy[11:13]

If this variable is set to "%s_%%d.X" and the variable **bus_range_separator_style** is set to "..", then the ripper or the net connected to the "wire" end of the ripper that is ripping off the third through fourth bits of the 4-bit net array "A" going from 0 to 3, is named:

A_%2..3.X

To determine the current value of this variable, type **printvar bus_naming_style**. For a list of all **edif**, **hdl**, or **schematic** variables and their current values, type **print_variable_group edif**, **print_variable_group hdl**, or **print_variable_group schematic**.

SEE ALSO

remove_bus(2)
report_bus(2)
bus_inference_descending_sort(3)
bus_inference_style(3)
bus_minus_style(3)
bus_range_separator_style(3)
edif_variables(3)

bus_range_separator_style

Specifies the style to use in naming a net connected to the "wire" end of a ripper in the EDIF file.

TYPE

string

DEFAULT

:

GROUP

edif_variables
schematic_variables

DESCRIPTION

Specifies the style to use in naming a net connected to the "wire" end of a ripper in the EDIF file. This variable affects the **write** command with the EDIF format option and the **create_schematic** command with the busing option.

When writing buses, this variable used with the variable **bus_naming_style**, specifies the style to use in naming a port array or net array in the EDIF file. When writing schematic nets, this variable used with the variable **bus_naming_style**, specifies the style to use in naming a net connected to the "wire" end of a ripper in the EDIF file.

When creating schematics, this variable used with the variable **bus_naming_style**, specifies the style to use in naming a ripper, bused port, bused net, or net connected to the "wire" end of a ripper. If you specify an invalid value, the default is used.

See **bus_naming_style** for a description of how this variable is used in conjunction with that variable.

To determine the current value of this variable, type **printvar bus_range_separator_style**. For a list of all **edif** or **schematic** variables and their current values, type **print_variable_group edif** or **print_variable_group schematic**.

SEE ALSO

remove_bus(2)
report_bus(2)
bus_inference_descending_sort(3)
bus_inference_style(3)
bus_minus_style(3)
bus_naming_style(3)
edif_variables(3)

cache_dir_chmod_octal

Specifies the value of the mode bits for created cache directories.

TYPE

string

DEFAULT

777

GROUP

synlib_variables

DESCRIPTION

Cache directories are created with their mode bits set to the value of the **cache_dir_chmod_octal** variable. The value of this variable is a string that is translated to an octal number. There are separate variables for directories and files, to allow the sticky bit to be set.

Many UNIX systems allow a sticky bit to be set on directories (setting the sticky bit on files has a very different meaning and is not allowed for cache files). If the sticky bit on a directory is set and if the user has write permission on the directory, the user can write his or her own files in the directory but cannot delete the files of other people in that directory (see UNIX manpage on sticky(8)).

Caches are often shared among users, and the sticky bit allows users to write into the same directory without worrying that other users will overwrite their files. If your UNIX system does not have sticky bit capabilities, your system administrator should remove that bit from the cache-dir-chmod-octal default in the system **.synopsys_dc.setup** file.

SEE ALSO

cache_ls(1)
cache_file_chmod_octal(3)

cache_file_chmod_octal

Specifies the value of the mode bits for created cache files.

TYPE

string

DEFAULT

666

GROUP

synlib_variables

DESCRIPTION

Cache files are created with their mode bits set to the value of `cache_file_chmod_octal`. The value of this variable is a string which is translated to an octal number. Cache directories use a different variable to set their mode bits (`cache_dir_chmod_octal`). There are separate variables for directories and files to allow the sticky bit to be set.

SEE ALSO

`cache_ls(1)`
`cache_dir_chmod_octal(3)`

case_analysis_log_file

Specifies the name of a log file generated during propagation of constant values, from case analysis or from nets tied to logic zero or logic one. Each scenario has its proprietary log file if multiple scenarios exist.

TYPE

string

DEFAULT

" "

DESCRIPTION

Specifies the name of a log file generated during propagation of constant values, from case analysis or from nets tied to logic zero or logic one. The log file contains the list of all ports and pins that propagate constants. The constant propagation algorithm is an iterative process that propagates constants through nets and cells starting from a list of constant pins. The algorithm finishes when no more constants can be propagated. The format of the log file follows the constant propagation algorithm.

In MCMM, you need to specify the log file name in the definition of each scenario, or no log will be generated for that scenario. If you switch the active scenario, the log file used will also be switched automatically. Log file for different scenarios can have the same name.

By default, this variable is set to an empty string, and no log file is generated during constant propagation.

To determine the current value of this variable, use **printvar case_analysis_log_file**. Please note that if you switch the scenario in MCMM, the value of this variable will remain to the value last set.

SEE ALSO

```
remove_case_analysis(2)
report_case_analysis(2)
report_disable_timing(2)
set_case_analysis(2)
disable_case_analysis(3)
```

case_analysis_propagate_through_icg

Determines whether case analysis is propagated through integrated clock gating cells.

TYPE

Boolean

DEFAULT

false

DESCRIPTION

When *false* (the default), constants propagating throughout the design will stop propagating when an integrated clock gating cell is encountered. Regardless of whether the integrated clock gating cell is enabled or disabled, no logic values will propagate in the fanout of the cell.

When *true*, constants propagated throughout the design will propagate through an integrated clock gating cell provided the cell is enabled. An integrated clock gating cell is enabled when its enable pin (or test enable pin) is set to a hi logic value. If the cell is disabled, then the disable logic value for the cell is propagated in its fanout. e.g. for a latch_posedge ICG, when it is disabled, it will propagate a logic 0 in its fanout.

To activate logic propagation through all integrated clock gating cells, the user must set the following.

```
set case_analysis_propagate_through_icg true
```

To determine the current value of this variable, type **printvar case_analysis_propagate_through_icg** or **echo \$case_analysis_propagate_through_icg**.

SEE ALSO

```
set_case_analysis(2)  
remove_case_analysis(2)
```

case_analysis_with_logic_constants

When true, enables constant propagation, even if a design contains only logic constants.

TYPE

Boolean

DEFAULT

false

GROUP

timing

DESCRIPTION

When true, enables constant propagation, even if a design contains only logic constants. When false (the default), constant propagation is not performed unless a **set_case_analysis** command is specified. The variable **disable_case_analysis** overrides the variable **case_analysis_with_logic_constants**. If the **disable_case_analysis** variable is set, no constants are propagated.

To determine the current value of this variable, use **printvar case_analysis_with_logic_constants**.

SEE ALSO

remove_case_analysis(2)
report_case_analysis(2)
set_case_analysis(2)
disable_case_analysis(3)

cell_attributes

Contains attributes that can be placed on a cell.

DESCRIPTION

Contains attributes that can be placed on a cell.

There are a number of commands used to set attributes, however, most attributes can be set with the **set_attribute** command. If the attribute definition specifies a **set** command, use it to set the attribute. Otherwise, use **set_attribute**. If an attribute is read-only, you cannot set it.

To determine the value of an attribute, use the **get_attribute** command. To remove attributes, use the **remove_attribute** command.

For a more detailed explanation of an attribute, refer to the manual pages of the appropriate **set** command. For information on all attributes, refer to the **attributes** manual page.

Cell Attributes

area

Specifies the area of a cell. This attribute does not exist on a hierarchical cell.

The tool calculates the attribute by the cell's boundary points.

This attribute is read-only and cannot be modified.

aspect_ratio

Specifies the **height:width** ratio of a cell. This attribute does not exist on a hierarchical cell.

This attribute is read-only and cannot be modified.

async_set_reset_q

Establishes the value (0 or 1) that should be assigned to the q output of an inferred register if set and reset are both active at the same time. To be used with **async_set_reset_qn**. Use these attributes only if you have used the **one_hot** or **one_cold** attributes/directives in your HDL description and your technology library is written using pre-V3.0a syntax; or if your technology library does not use a consistent convention for q and qn when set and reset are both active. If a V3.0a or later syntax technology library is used, then by default if set and reset are both active at the same time Design Compiler will use the convention of the selected technology library (**target_library**). Set with **set_attribute**.

Note: If you are unsure whether or not your technology library uses V3.0a syntax, ask your ASIC vendor.

async_set_reset_qn

Establishes the value (0 or 1) that should be assigned to the qn output of an inferred register if set and reset are both active at the same time. To be used with **async_set_reset_q**. Use these attributes only if you have used the **one_hot** or **one_cold** attributes/directives in your HDL description and your technology library is written using pre-V3.0a syntax; or if your

technology library does not use a consistent convention for q and qn when set and reset are both active. If a V3.0a or later syntax technology library is used, then by default if set and reset are both active at the same time Design Compiler will use the convention of the selected technology library (**target_library**). Set with **set_attribute**.

Note: If you are unsure whether or not your technology library uses V3.0a syntax, ask your ASIC vendor.

disable_timing *

Disables the timing arcs of a cell. This has the same effect on timing as not having the arc in the library. Set with **fbset_disable_timing**.

dont_touch

Identifies cells to be excluded from optimization. Values are *true* (the default) or *false*. Cells with the **dont_touch** attribute set to *true* are not modified or replaced during **compile**. Setting **dont_touch** on a hierarchical cell sets the attribute on all cells below it. Set with **set_dont_touch**.

fall_delay

Specifies an offset from the falling edge of the ideal clock waveform. Affects all clock pins on this cell. Set with **set_clock_skew -fall_delay**.

flip_flop_type

Stores the name of the specified flip-flop to be converted from the **target_library**. The **compile** command automatically converts all tagged flip-flops to the specified (or one similar) type. Set with **set_register_type -flip_flop flip_flop_name [cell_list]**.

flip_flop_type_exact

Stores the name of the specified flip-flop to be converted from the **target_library**. The **compile** command automatically converts all tagged flip-flops to the exact flip-flop type. Set with **set_register_type -exact -flip_flop flip_flop_name [cell_list]**.

height

Specifies the height of a cell. This attribute does not exist on a hierarchical cell.

The tool uses the cell's cell boundary to calculate its height.

This attribute is read-only and cannot be modified.

is_black_box

Set to *true* if the cell's reference is not linked to a design.

This attribute is read-only and cannot be modified.

is_combinational

Set to *true* if all cells of a design and all designs in its hierarchy are combinational. A cell is combinational if it is non-sequential or non-tristate and all of its outputs compute a combinational logic function. The **report_lib** command will report such a cell as not a black-box.

This attribute is read-only and cannot be modified.

is_dw_subblock

Set to *true* if the object (a cell, a reference, or a design) is a DW subblock that was automatically elaborated.

This attribute is read-only and cannot be modified.

cell_attributes

Note: DW subblocks that are manually elaborated will not have this attribute.

is_hierarchical

Set to *true* if the design contains leaf cells or other levels of hierarchy. This attribute is read-only and cannot be modified.

is_mapped

Set to *true* if the cell is not generic logic. This attribute is read-only and cannot be modified.

is_sequential

Set to *true* if the cell is sequential. A cell is sequential if it is not combinational. This attribute is read-only and cannot be modified.

is_synlib_module

Set to *true* if the object (a cell, a reference, or a design) refers to an unmapped module reference or if the object is (or refers to) a design that was automatically elaborated from a synlib module or a synlib operator. This attribute is read-only and cannot be modified.

Note: synlib modules that are manually elaborated will not have this attribute.

is_synlib_operator

Set to *true* if the object (a cell or a reference) is a synthetic library operator reference. This attribute is read-only and cannot be modified.

is_test_circuitry

Set by **insert_dft** on the scan cells and nets added to a design during the addition of test circuitry. This attribute is read-only and cannot be modified.

is_unmapped

true if the cell is generic logic. This attribute is read-only and cannot be modified.

latch_type_exact

Stores the name of the specified latch to be converted from the **target_library**. The **compile** command automatically converts all tagged latches to the exact latch type. Set with **set_sequential_type -latch latch_name [cell_list]**.

macro_area_percentage

Specifies the percentage of total macro area of a soft macro, $\frac{\text{physical_area}}{\text{total_macro_area}}$. This attribute is read-only and cannot be modified.

map_only

When set to *true*, **compile** will attempt to map the object exactly in the target library, and will exclude the object from logic-level optimization (flattening and structuring). The default is *false*. Set with **set_map_only**.

max_fall_delay

A floating point value that specifies the maximum falling delay on ports,

clocks, pins, cells, or on paths between such objects. Set with **set_max_delay**.

max_metal_layer

Specifies the reserved maximum metal layer name of a soft macro or a black box.

This attribute is read-only and cannot be modified.

max_rise_delay

A floating point value that specifies the maximum rising delay on ports, clocks, pins, cells, or on paths between such objects. Set with

set_max_delay.

max_time_borrow

A floating point number that establishes an upper limit for time borrowing; that is, it prevents the use of the entire pulse width for level-sensitive latches. Units are those used in the technology library. Set with

set_max_time_borrow.

min_fall_delay

A floating point value that specifies the minimum falling delay on ports, clocks, pins, cells, or on paths between such objects. Set with

set_min_delay.

min_metal_layer

Specifies the reserved minimum metal layer name of a soft macro or a black box.

This attribute is read-only and cannot be modified.

min_rise_delay

A floating point value that specifies the minimum rising delay on ports, clocks, pins, cells, or on paths between such objects. Set with

set_min_delay.

minus_uncertainty

Specifies a negative uncertainty from the edges of the ideal clock waveform. Affects all clock pins on this cell. Set with **set_clock_skew -**

minus_uncertainty.

number_of_black_box

Specifies the count of black boxes in a hierarchical cell or a soft macro.

Whether a cell is a black box can be determined by the attribute **is_black_box**.

This attribute is read-only and cannot be modified.

number_of_io_cell

Specifies the count of io cells in a hierarchical cell or a soft macro.

The tool counts cells in when its **mask_layout_type** is **io_pad**, **corner_pad**, **pad_filler**, or **flip_chip_pad**.

This attribute is read-only and cannot be modified.

number_of_macro

Specifies the count of macros in a hierarchical cell or a soft macro.

The tool counts cells in when its **mask_layout_type** is **macro**.

This attribute is read-only and cannot be modified.

cell_attributes

number_of_pinshape
 Specifies the number of pin shapes of a soft macro.
 This attribute is read-only and cannot be modified.

number_of_standard_cell
 Specifies the count of standard cells in a hierarchical cell or a soft macro.
 The tool counts cells in when its **mask_layout_type** matches ***std***.
 This attribute is read-only and cannot be modified.

physical_area
 Specifies the physical area of a hierarchical cell or a soft macro.
 The physical area of a hierarchical cell is the sum of its direct children's **physical_area** or **area**. If a direct child is a hierarchical cell, then **physical_area** is used. If a child is a standard cell or macro, then **area** is used, otherwise that child is skipped.
 The physical area of a soft macro is the sum of its children's **physical_area** or **area**. The children will be iterated from the subdesign file. If a child is a soft macro, then **physical_area** is used, if a child is a standard cell or hard macro, **area** is used, otherwise that child is skipped.
 This attribute is read-only and cannot be modified.

physical_area_percentage_in_top_design
 Specifies the percentage of **physical_area** of a soft macro in the top design.
 This attribute is read-only and cannot be modified.

plus_uncertainty
 Specifies a positive uncertainty from the edges of the ideal clock waveform.
 Affects all clock pins on this cell. Set with **set_clock_skew -plus_uncertainty**.

propagated_clock
 Specifies that the clock edge times be delayed by propagating the values through the clock network. Affects all clock pins on this cell. If this attribute is not present, ideal clocking is assumed. Set with **set_clock_skew -propagated**.

ref_name
 The reference name of a cell.
 This attribute is read-only and cannot be modified.

rise_delay
 Specifies an offset from the rising edge of the ideal clock waveform. Affects all clock pins on this cell. Set with **set_clock_skew -rise_delay**.

scan
 When *true*, specifies that the cell is always replaced by an equivalent scan cell during **insert_dft**. When *false*, the cell is not replaced. Set with **set_scan**.

scan_chain
 Includes the specified cells of the referenced design in the scan-chain whose index is the value of this attribute. Set with **set_scan_chain**.

test_dont_fault
 Specifies cells not faulted during test pattern generation. If no command

options are specified, this attribute is set for both "stuck-at-0" and "stuck-at-1" faults. Set with **set_test_dont_fault**.

test_isolate

Indicates that the specified sequential cells, pins, or ports are to be logically isolated and considered untestable during test design rule checking by **check_test**. When this attribute is set on a cell, it is also placed on all pins of that cell. Do not set this attribute on a hierarchical cell. Use **report_test -assertions** for a report on isolated objects. Set with **set_test_isolate**.

Note: Setting this attribute suppresses the warning messages associated with the isolated objects.

test_routing_position

Specifies the preferred routing order of the scan-test signals of the identified cells. Set with **set_test_routing_order**.

ungroup

Removes a level of hierarchy by exploding the contents of the specified cell in the current design. If specified on a reference object, cells using that reference are ungrouped during **compile**. Set with **set_ungroup**.

utilization

Specifies the utilization of a soft macro.

The tool calculates the utilization using **physical_area:area** ratio of a soft macro.

This attribute is read-only and cannot be modified.

width

Specifies the width of a cell. This attribute does not exist on a hierarchical cell.

The tool uses the cell's cell boundary to calculate its width.

This attribute is read-only and cannot be modified.

SEE ALSO

get_attribute(2)
remove_attribute(2)
set_attribute(2)
attributes(3)

cell_site_attributes

Contains attributes related to cell site.

DESCRIPTION

Contains attributes related to cell site.

You can use **get_attribute** to determine value of an attribute, and use **report_attribute** to get a report of all attributes on specified object. Specified with **list_attribute -class cell_site -application**, the definition of attributes can be listed.

Cell Site Attributes

bbox

Specifies the bounding-box of a cell site. The **bbox** is represented by a **rectangle**.

The format of a *rectangle* specification is {{llx lly} {urx ury}}, which specifies the lower-left and upper-right corners of the rectangle.

The data type of **bbox** is string.

This attribute is read-only.

constraints

Specifies the maximum number of flip chip driver of the particular personality type that can be placed in a flip chip driver island.

The data type of **constraints** is string.

This attribute is read-only.

layer

Specifies system layer name on which cell site is.

The data type of **layer** is string.

This attribute is read-only.

object_class

Specifies object class name of a cell site, which is **cell_site**.

The data type of **object_class** is string.

This attribute is read-only.

orientations

Specifies allowable orientations of flip chip driver when placed.

The data type of **orientations** is string.

This attribute is read-only.

personality

Specifies personality types of flip-chip driver cells to be placed in a cell site.

The data type of **personality** is string.

This attribute is read-only.

reserved_slots

Specifies that certain locations pointed by the row and column indices in an flip chip driver island are reserved for a certain flip chip driver cell.

Only the specified flip chip driver can be placed in the locations.
Its format is like, {{**lib_cell_name** {**col row**}...} ...}
The data type of **reserved_slots** is string.
This attribute is read-only.

rotate_by_row

Specifies forced orientations of the drivers are set by rows.
The data type of **rotate_by_row** is boolean.
This attribute is read-only.

style

Specifies the style to place flip chip drivers.
Its valid values can be:

- **flip_chip_array**
- **flip_chip_island**
- **flip_chip_ring**
- **flip_chip_row**

The data type of **style** is string.
This attribute is read-only.

SEE ALSO

`get_attribute(2),`
`list_attribute(2),`
`report_attribute(2),`
`set_attribute(2),`
`set_flip_chip_driver_array(2),`
`set_flip_chip_driver_island(2),`
`set_flip_chip_driver_ring(2).`

change_names_bit_blast_negative_index

Bit blast the bus if any bit of it is negative.

TYPE

Boolean

DEFAULT

false

GROUP

DESCRIPTION

If this variable is set true, `change_names` will bit blast the bus if any bit is negative. Otherwise, `change_names` will shift negative range to the positive range starting 0. The default value is *false*.

To determine the current value of this variable, use **printvar** **change_names_bit_blast_negative_index**.

SEE ALSO

`change_names(2)`
`define_name_rules(2)`

change_names_dont_change_bus_members

Controls how the **change_names** command modifies the names of bus members.

TYPE

Boolean

DEFAULT

false

GROUP

system_variables

DESCRIPTION

This variable is for the **change_names** command, and affects bus members only of bussed ports or nets. When false (the default), **change_names** gives bus members the base name from their owning bus. For example, if BUS A has range 0 to 1 with the first element NET1 and the second element NET2, **change_names** changes NET1 to A[0] and NET2 to A[1]. When this variable is set to true, **change_names** does not change the names of bus members, so that NET1 and NET2 remain unchanged.

This variable also applies to **-special** rules, but has no effect if the name is changed by other rules that have higher priority than **-special** when **-special** rules are used. (For example, **-equal_ports_nets**, **-case_insensitive**.) For more information, refer to the **APPLYING NAME RULES** section of the **define_name_rules** manual page.

To determine the current value of this variable, type **printvar change_names_dont_change_bus_members**. For a list of all **system** variables and their current values, type **print_variable_group system**.

SEE ALSO

change_names(2)
define_name_rules(2)
system_variables(3)

check_design_allow_non_tri_drivers_on_tri_bus

Specifies the severity level to be applied during compile or check_design command execution, when three-state buses with non three-state driver(s) are found in the design.

TYPE

Boolean

DEFAULT

true

GROUP

none

DESCRIPTION

When true, **compile** and **check_design** will warn out when three-state buses with non three-state driver(s) exist in the design. These commands will continue execution upon warning. When false, they will report errors on three-state bus. **compile** will cease to continue execution upon encountering errors and return 0 status. **check_design** will however continue execution without any change in return status.

The default value of this variable is true.

To determine the current value of this variable use **printvar check_design_allow_non_tri_drivers_on_tri_bus**.

SEE ALSO

check_design(2)

check_design_allow_unknown_wired_logic_type

Specifies the severity level to be applied during compile or check_design command execution, when nets with multiple drivers(unknown wired-logic type) are found in the design.

TYPE

Boolean

DEFAULT

true

GROUP

none

DESCRIPTION

When true, **compile** and **check_design** will warn out when nets with multiple drivers(unknown wired-logic type) exist in the design. These commands will continue execution upon warning. When false, they will report errors on such nets. **compile** will cease to continue execution upon encountering errors and return 0 status. **check_design** will however continue execution without any change in return status.

The default value of this variable is true.

To determine the current value of this variable use **printvar check_design_allow_unknown_wired_logic_type**.

SEE ALSO

check_design(2)

check_error_list

Specifies the error codes that the **check_error** command checks for.

TYPE

list

DEFAULT

CMD-004 CMD-006 CMD-007 CMD-008 CMD-009 CMD-010 CMD-011 CMD-012 CMD-014 CMD-015 CMD-016 CMD-019 CMD-026 CMD-031 CMD-037 DB-1 DCSH-11 DES-001 ACS-193 FILE-1 FILE-2 FILE-3 FILE-4 LINK-7 LINT-7 LINT-20 LNK-023 OPT-100 OPT-101 OPT-102 OPT-114 OPT-124 OPT-127 OPT-128 OPT-155 OPT-157 OPT-181 OPT-462 UI-11 UI-14 UI-15 UI-16 UI-17 UI-19 UI-20 UI-21 UI-22 UI-23 UI-40 UI-41 UID-4 UID-6 UID-7 UID-8 UID-9 UID-13 UID-14 UID-15 UID-19 UID-20 UID-25 UID-27 UID-28 UID-29 UID-30 UID-32 UID-58 UID-87 UID-103 UID-109 UID-270 UID-272 UID-403 UID-440 UID-444 UIO-2 UIO-3 UIO-4 UIO-25 UIO-65 UIO-66 UIO-75 UIO-94 UIO-95 EQN-6 EQN-11 EQN-15 EQN-16 EQN-18 EQN-20

GROUP

acs_variables

DESCRIPTION

Specifies the error codes that the **check_error** command checks for. The **check_error** command returns a 1 if any of the specified error codes have been generated by a previous command in the current dc_shell session.

Automated Chip Synthesis uses this capability to stop batch jobs in which the specified error codes occur.

To determine the current value of this variable, use **printvar check_error_list** in DB (dcsh) mode and **printvar check_error_list** in DB (Tcl) mode.

SEE ALSO

check_error(2)

clock_attributes

Contains attributes placed on clocks.

DESCRIPTION

Contains attributes that can be placed on clocks.

To set an attribute, use the command identified in the individual description of that attribute. To determine the value of an attribute, use the **get_attribute** command. To remove attributes, use the **remove_attribute** command.

For a more detailed explanation of an attribute, refer to the manual pages of the appropriate **set** command. For information on all attributes, refer to the **attributes** manual page.

Clock Attributes

dont_touch_network

When a design is optimized, **compile** assigns **dont_touch** attributes to all cells and nets in the transitive fanout of **dont_touch_network** ports. The **dont_touch** assignment stops at the boundary of storage elements. An element is recognized as storage only if it has setup or hold constraints. Set with **set_dont_touch_network**.

fall_delay

Specifies an offset from the falling edge of the ideal clock waveform. Set with **set_clock_skew -fall_delay**

fix_hold

Specifies that **compile** should attempt to fix hold violations for timing endpoints related to this clock. Set with **set_fix_hold**.

max_fall_delay

A floating point value that specifies the maximum falling delay on ports, clocks, pins, cells, or on paths between such objects. Set with **set_max_delay**.

max_rise_delay

A floating point value that specifies the maximum rising delay on ports, clocks, pins, cells, or on paths between such objects. Set with **set_max_delay**.

max_time_borrow

A floating point number that establishes an upper limit for time borrowing; that is, it prevents the use of the entire pulse width for level-sensitive latches. Units are those used in the technology library. Set with **set_max_time_borrow**.

min_fall_delay

A floating point value that specifies the minimum falling delay on ports, clocks, pins, cells, or on paths between such objects. Set with **set_min_delay**.

clock_attributes

`min_rise_delay`

A floating point value that specifies the minimum rising delay on ports, clocks, pins, cells, or on paths between such objects. Set with **`set_min_delay`**.

`minus_uncertainty`

Specifies a negative uncertainty from the edges of the ideal clock waveform. Set with **`set_clock_skew -minus_uncertainty`**.

`period`

Assigns a value to the clock period. The clock period (or cycle time) is the shortest time during which the clock waveform repeats. For a simple waveform with one rising and one falling edge, the period is the difference between successive rising edges. Set with **`create_clock -period period_value`**.

`plus_uncertainty`

Specifies a positive uncertainty from the edges of the ideal clock waveform. Affects all sequential cells in the transitive fanout of this port. Set with **`set_clock_skew -plus_uncertainty`**.

`propagated_clock`

Specifies that the clock edge times be delayed by propagating the values through the clock network. If this attribute is not present, ideal clocking is assumed. Set with **`set_clock_skew -propagated`**.

`rise_delay`

Specifies an offset from the rising edge of the ideal clock waveform. Set with **`set_clock_skew -rise_delay`**.

SEE ALSO

`get_attribute(2)`

`remove_attribute(2)`

`attributes(3)`

collection_result_display_limit

Sets the maximum number of objects that can be displayed by any command that displays a collection.

TYPE

int

DEFAULT

100

DESCRIPTION

This variable sets the maximum number of objects that can be displayed by any command that displays a collection. The default is 100.

When a command (for example, **add_to_collection**) is issued at the command prompt, its result is implicitly queried, as though **query_objects** had been called. You can limit the number of objects displayed by setting this variable to an appropriate integer. A value of -1 displays all objects; a value of 0 displays the collection handle id instead of the names of any objects in the collection.

To determine the current value of this variable, use **printvar collection_result_display_limit**.

SEE ALSO

collections(2)
printvar(2)
query_objects(2)

command_log_file

Specifies the name of the file to which a log of the initial values of variables and commands executed is written. If the value is an empty string, a command log file is not created.

TYPE

string

DEFAULT

"./command.log"

GROUP

system_variables

DESCRIPTION

Specifies the name of the file to which a log of the initial values of variables and commands executed is written. If the value is an empty string, a command log file is not created. Also, if "-no_log" has been specified when invoking DC, then command log file is not created.

This variable is only valid in eqn mode of dc_shell. If you are running tcl mode, please use the variable sh_command_log_file.

To determine the current value of this variable use **printvar command_log_file**. For a list of all **system** variables and their current values, use the **print_variable_group system** command.

SEE ALSO

sh_command_log_file(3)
view_command_log_file(3)
view_log_file(3)

company

Specifies the name of the company where Synopsys software is installed. The company name is displayed on the schematics.

TYPE

string

DEFAULT

" "

GROUP

system_variables

DESCRIPTION

Specifies the name of the company where Synopsys software is installed. The company name is displayed on the schematics.

To determine the current value of this variable use **printvar company**. For a list of all **system** variables and their current values, use the **print_variable_group system** command.

compatibility_version

Sets the default behavior of the system to be the same as the Synopsys software version specified in the variable.

TYPE

string

DEFAULT

C-2009.06-ICC

GROUP

system_variables

DESCRIPTION

Sets the default behavior of the system to be the same as the Synopsys software version specified in the variable. This setting provides compatibility for script command files written in previous software versions. The scripts are run on the current version of the software, so results are usually better. However, the script performs the same default actions here as it did on the specified software version.

To determine the current value of this variable use **printvar compatibility_version**. For a list of all **system** variables and their current values, use the **print_variable_group system** command.

compile_clock_gating_through_hierarchy

Controls whether the **compile** or **compile_ultra** command with the **-gate_clock** option will perform clock gating through hierarchy boundaries.

TYPE

Boolean

DEFAULT

false

GROUP

compile_variables

DESCRIPTION

When true, **compile -gate_clock** and **compile_ultra -gate_clock** are allowed to use one clock gate to gate registers in different hierarchical cells. This can increase the number of clock gating opportunities and reduce the number of clock gates.

When false (the default), the clock gating will only be performed in such a way that clock gates are in the same hierarchy cell as all the registers gated by them.

To determine the current value of this variable use **printvar compile_clock_gating_through_hierarchy**. For a list of all **compile** variables and their current values, use the **print_variable_group compile** command.

SEE ALSO

compile_variables(3)

compile_dont_use_dedicated_scanout

Controls whether optimizations use a scan cell's dedicated scan-out pin for functional connections.

TYPE

integer

DEFAULT

1

GROUP

insert_dft_variables

DESCRIPTION

When 1 (the default), optimizations (**place_opt**, **clock_opt**, **route_opt** and **psynopt**) do not use a scan cell's dedicated scan-out pin for functional connections.

When 0, optimizations can use dedicated scan-out pins for functional connections.

Dedicated scan-out pins must be identified in the technology library using the **test_output_only** attribute. Contact your ASIC Vendor to ensure that dedicated scan-out pins are correctly modeled in the library that you are using.

To determine the current value of this variable, type **printvar compile_dont_use_dedicated_scanout**.

SEE ALSO

compile_instance_name_prefix

Specifies the prefix used in generating cell instance names when **compile** is executed.

TYPE

string

DEFAULT

U

GROUP

compile_variables

DESCRIPTION

Specifies the prefix used in generating cell instance names when **compile** is executed.

To determine the current value of this variable use **printvar compile_instance_name_prefix**. For a list of **compile** variables and their current values, use the **print_variable_group compile** command.

SEE ALSO

compile_variables(3)

compile_instance_name_suffix

Specifies the suffix used for generating cell instance names when **compile** is executed.

TYPE

string

DEFAULT

" "

GROUP

compile_variables

DESCRIPTION

Specifies the suffix used for generating cell instance names when **compile** is executed.

To determine the current value of this variable use **printvar compile_instance_name_suffix**. For a list of **compile** variables and their current values, use the **print_variable_group compile** command.

SEE ALSO

compile_variables(3)

compile_keep_original_for_external_references

Controls compile command to keep the original design when there is an external reference to the design.

TYPE

Boolean

DEFAULT

false

GROUP

none

DESCRIPTION

By default, **compile** will modify the original copy of the designs in the current design.

When set to true, the original design and its sub designs are copied and preserved (before doing any modifications during compile) if there is an external reference to this design.

For example, if there is an instance of design bot, U1 in the current design mid and there is an external reference from another design top which is not part of current hierarchy, then the U1 will be uniquified to a new design bot_0 before doing any modification to the design. Hence when the user changes the current_design to top and performs a link, the original design bot will be linked into the current_hierarchy.

Usually, this is needed only when you are doing a bottom compile without setting dont_touches on all the sub designs especially with boundary optimization turned on during compile.

If there is a dont_touch attribute on any of the instances of the design or in the design itself, this variable does not have effect.

SEE ALSO

compile_log_format

Controls the format of the columns to be displayed during the mapping phases of **compile** and **reoptimize_design**.

TYPE

string

DEFAULT

%elap_time %area %wns %tns %drc %endpoint

GROUP

compile_variables

DESCRIPTION

Controls the format of the columns to be displayed during the mapping phases of **compile** and **reoptimize_design**. The default specification is shown in the DEFAULT section and results in an output display format similar to Table 1. The headings and order of the columns displayed correspond to the keywords specified in the syntax. For example, "%elap_time" specifies the ELAPSED TIME column, "%area" the AREA column, and so on.

Table 1
Default compile Log Output Format

Elapsed		Worst Neg	Total Neg	Design	
Time	Area	Slack	Slack	Rule Cost	Endpoint
-----	-----	-----	-----	-----	-----
18:00:30	1498.0	4.12	32.2	0.0	U1/U2/
CURRENT_SECS_reg[4]					
18:00:30	1498.0	4.07	31.6	0.0	U1/U2/
CURRENT_SECS_reg[4]					
18:00:30	1497.0	4.07	30.6	0.0	U1/U2/
CURRENT_SECS_reg[4]					
18:00:31	1499.0	3.61	27.5	0.0	U1/U2/
CURRENT_SECS_reg[4]					
18:00:31	1499.0	3.58	26.1	0.0	U1/U2/
CURRENT_SECS_reg[4]					

By default, the columns in Table 1 are nine characters wide except for the ENDPOINT column, which is 25 characters. The default precision for the floating point data types AREA, TOTAL NET SLACK, and DESIGN RULE COST is one digit to the right of the decimal point; for WORST NEG SLACK, two digits.

There are 13 possible columns that can be displayed; only six are displayed in the default format. You can create a customized output format by specifying any number of the available columns, with their keywords and defaults. For example, specifying "%mem" displays the MBYTES column with a width of 6 characters and a precision of 1 digit to the right of the decimal point. When you specify "%mem", the following information is displayed horizontally under these column names: COLUMN HEADER, DATA TYPE, KEYWORD, WIDTH, PRECISION, and FORMAT.

```
MBYTES floating point mem 6 1 f
```

See the section "DEFINITIONS OF COLUMN FIELDS WITH DEFAULT VALUES" for descriptions and contents of the fields corresponding to the column headers.

CHANGING DEFAULT COLUMN PARAMETERS

You can change the default column parameters using the optional expression (w.pf,split), as follows:

```
compile_log_format = " %elap_time %area %wns %tns %drc %endpoint".
```

```
string compile_log_format = "%keyword(w.pf,split)"
```

The quantities w, p, f, and split are defined as follows.

w

Specifies the column width. Specifying a width less than 6 defaults the width to 6. For string data types, specifying a width greater than 99 defaults the width to 99; for decimal or floating point data types, specifying a width greater than 25 defaults to 25.

p

For floating point numbers only. Specifies the precision in number of digits. See also the definition of f.

f

For floating point numbers only. Specifies the precision format; values are *f* or *g*. *f* specifies that the precision is expressed as the number of digits to the right of the decimal point; *g* specifies that the precision is expressed as the total number of significant digits. For example, expressing the floating point number 13.533 with a precision of 3 in format *f* reports the number as 13.533; in format *g*, 13.5.

split

By default, if the information in a given field exceeds the column width, it pushes out the next field and the next field is not printed on a new line. Specifying **split** overrides the default and causes the next field to begin on a new line, starting in the correct column.

```
%elap_time %area %wns %tns %drc %endpoint
```

1998.02 COMPILE LOG FORMAT

The fields for the 1998.02 version are TRIALS, AREA, DELTA DELAY, TOTAL NEGATIVE SLACK, and DESIGN RULE COST. The DELTA DELAY field is renamed MAX DELAY COST in the 1998.08 format.

To display the same log format as the 1998.02 version, set the variable as follows:

```
compile_log_format = ""
```

DEFINITIONS OF COLUMN FIELDS WITH DEFAULT VALUES

The fields listed under the five columns are defined in the following text, showing the default values. Except where noted, units are those defined by the library.

AREA

Shows the area of the design during the optimization.
Data type: floating point
Keyword: are
Width: 9
Precision: 1
Format: f

CPU SEC

Shows the process cpu time used, in seconds.
Data type: decimal
Keyword: cpu
Width: 7
Precision: ignored
Format: ignored

DELTA DELAY

See MAX DELAY COST.

DESIGN RULE COST

Measures the distance between the actual results and user-specified design rule constraints.
Data type: floating point
Keyword: drc
Width: 9
Precision: 1
Format: f

ELAPSED TIME

Tracks the elapsed time since the beginning of the current **compile** or **reoptimize_design**.
Data type: string
Keyword: elap_time
Width: 9
Precision: ignored
Format: ignored

MAX DELAY COST

Shows the current max delay cost of the design, which is the sum of the worst

negative slack (max_path violation) in each path group. Called "DELTA DELAY" in the 1998.02 version.
Data type: floating point
Keyword: max_delay
Width: 9
Precision: 2
Format: f

MBYTES

Shows the process memory used, in mbytes.
Data type: floating point
Keyword: mem
Width: 6
Precision: 1
Format: f

MIN DELAY COST

Shows the current min delay cost of the design, which is the sum of the worst negative slack (min_path violation) in each path group.
Data type: floating point
Keyword: min_delay
Width: 9
Precision: 2
Format: f

TIME OF DAY

Shows the current time.
Data type: string
Keyword: time
Width: 8
Precision: ignored
Format: ignored

TOTAL NEG SLACK

Shows the sum of the negative slack across all endpoints in the design.
Data type: floating point
Keyword: tns
Width: 9
Precision: 1
Format: f

TRIALS

Tracks the number of transformations that the optimizer tries before making the current selection.
Data type: decimal
Keyword: trials
Width: 6
Precision: ignored
Format: ignored

WORST NEG SLACK

Shows the worst negative slack (max_path violation) in all path groups.
Data type: floating point
Keyword: wns
Width: 9

Precision: 2
Format: f

ENDPOINT

Shows the current endpoint being worked on. When the delay violation is being fixed, the object for the ENDPOINT is a cell or a port. When the design rule violations are being fixed, the object for the ENDPOINT is a net.
Data type: string
Keyword: endpoint
Width: 25
Precision: ignored
Format: ignored

PATH GROUP

Shows the current path group of a valid endpoint.
Data type: string
Keyword: group_path
Width: 10
Precision: ignored
Format: ignored

DYNAMIC POWER

Shows the dynamic power of the design during optimization.
Data type: floating point
Keyword: dynamic_power
Width: 9
Precision: 4
Format: f

LEAKAGE POWER

Shows the leakage power of the design during optimization.
Data type: floating point
Keyword: leakage_power
Width: 9
Precision: 4
Format: f

TOTAL POWER

Shows the total power of the design during optimization. (total_power = dynamic_power + leakage_power)
Data type: floating point
Keyword: total_power
Width: 9
Precision: 4
Format: f
%elap_time %area %wns %tns %drc %endpoint

EXAMPLES

The following example increases the precision of the WORST NEG SLACK column by 1 (to 3 digits from its default of 2 digits).

```
prompt> compile_log_format = " %elap_time %area %wns(.3) %tns %drc %endpoint"
```

The following example replaces the TOTAL NEG SLACK column in the default format, with the CPU column.

```
prompt> compile_log_format = " %elap_time %area %wns %cpu %drc %endpoint"
```

In the following example, if the ENDPOINT value exceeds the column width, the next field begins on a new line, starting in the correct column.

```
prompt> compile_log_format = " %elap_time %wns %endpoint(19,split) %group_path"
```

The following example displays the MIN DELAY COST column only, changes the column width to 12 characters from the default of 9, and expresses the value with a precision of 3 significant digits.

```
prompt> compile_log_format = " %min_delay(12.3g)"
```

The following example sets the compile log to the same format as the 1998.02 version.

```
prompt> compile_log_format = ""
```

To determine the current value of this variable, type **printvar compile_log_format**. For a list of all **compile** variables and their current values, type **print_variable_group compile**.

SEE ALSO

`compile_variables(3)`

compile_power_domain_boundary_optimization

Sets the variable to false to disable boundary optimization across power domain boundaries.

TYPE

Boolean

DEFAULT

true

GROUP

mv

DESCRIPTION

This variable controls whether to allow boundary optimization across all power domain boundaries. By default, boundary optimization across power domain boundaries is enabled in **compile_ultra**, unless specifically disabled by a command such as **set_boundary_optimization**. This variable provides an automatic way to disable boundary optimization across all power domain boundaries.

SEE ALSO

compile_retime_exception_registers

Controls whether registers with common path exceptions, including `max_path`, `min_path`, `multicycle_path`, `false_path`, and `group_path`, can be moved by adaptive retiming.

TYPE

Boolean

DEFAULT

false

GROUP

compile_variables

DESCRIPTION

This variable controls whether registers with common path exceptions, including `max_path`, `min_path`, `multicycle_path`, `false_path`, and `group_path`, can be moved by adaptive retiming.

For example, if an SDC script contains the following command where **reg** is a register, there is a path exception on **reg**:

```
set_max_delay 1.0 -to reg
```

The variable only affects flows that use the **compile_ultra** command with the **-retime** option.

Allowed values are **false** (the default) and **true**.

If **false** is specified, adaptive retiming does not attempt to move registers with exceptions to improve timing or area.

If **true** is specified, adaptive retiming may try to move registers with the `max_path`, `min_path`, `multicycle_path`, `false_path`, and `group_path` path exceptions to improve timing or area.

SEE ALSO

compile_seqmap_identify_shift_registers

Controls the identification of shift registers in **compile -scan**. This feature is only supported in test-ready compile with Design Compiler Ultra with a multiplexed scan-style.

TYPE

Boolean

DEFAULT

true

GROUP

compile_variables

DESCRIPTION

When the value of this variable is set to the default value of true, Design Compiler Ultra automatically identifies shift registers in the design during test-ready compile.

When all of the shift registers are identified, only the first register is mapped to a scan cell, while the remaining registers are mapped to non-scan cells. This can save a significant amount of area for designs containing many identified shift registers.

Once these shift registers are identified by Design Compiler Ultra, DFT Compiler will also recognize the identified shift registers as shift-register scan segments. But DFT Compiler will break these scan segments, if necessary, to respect test setup requirements such as maximum chain length.

Shift registers that contain synchronous logic between the registers can also be identified if the synchronous logic can be controlled such that the data can be shifted from the output of the first register to the input of the next register. This synchronous logic can either be internal to the register (for example, synchronous reset and enable) or it can be external synchronous logic (for example, multiplexor logic between the registers). For shift registers identified with synchronous logic between the registers, DFT Compiler will add additional logic to the scan-enable signal during scan insertion in order to allow the data to be shifted between the registers when in scan mode. This capability is controlled by the **compile_seqmap_identify_shift_registers_with_synchronous_logic** variable, and is enabled by default. See the **compile_seqmap_identify_shift_registers_with_synchronous_logic** variable man page for details.

Shift-register identification is only supported in test-ready compile with Design Compiler Ultra with a multiplexed scan-style.

Set the **compile_seqmap_identify_shift_registers** variable to false if you do not want **compile_ultra -scan** to identify shift registers, or if you want to re-scan the shift registers already identified in the design back to scan cells.

The **compile_seqmap_identify_shift_registers_with_synchronous_logic** variable does not have any effect when shift-register identification is disabled with the **compile_seqmap_identify_shift_registers** variable.

SEE ALSO

`compile_variables(3)`

compile_ultra_ungroup_small_hierarchies

Determines whether to automatically ungroup small hierarchies in the compile_ultra flow.

TYPE

Boolean

DEFAULT

true

GROUP

compile_variables

DESCRIPTION

In the compile_ultra flow in XG mode, small user design hierarchies are automatically ungrouped at the beginning of the compile flow. To turn off this behavior, set the above variable to false, or run **compile_ultra** with the -**no_autoungroup** option.

Use the **printvar compile_ultra_ungroup_small_hierarchies** command to determine the current value of this variable.

SEE ALSO

compile_use_fast_delay_mode

Selects the algorithm used for delay calculations when using the CMOS2 or nonlinear delay models.

TYPE

Boolean

DEFAULT

true

GROUP

compile_variables

DESCRIPTION

When true, turns on delay calculation techniques that improve **compile** run times when the CMOS2 or nonlinear delay models are being used. The default is true. The improvements have the greatest impact when high fanout nets are encountered, as is often the case during sequential mapping.

Unlike the delay calculation techniques used in **compile_use_low_timing_effort**, the corresponding techniques used in **compile_use_fast_delay_mode** do not affect timing accuracy. Fast delay mode may be used in conjunction with low timing effort, if desired.

To determine the current value of this variable, type **printvar compile_use_fast_delay_mode**. For a list of all **compile** variables and their current values, type **print_variable_group compile**.

SEE ALSO

compile_variables(3)

compile_variables

SYNTAX

```
Boolean auto_wire_load_selection = "true"
Boolean compile_assume_fully_decoded_three_state_busses = "false"
integer compile_auto_ungroup_area_num_cells = 30
Boolean compile_auto_ungroup_count_leaf_cells = "false"
Boolean compile_auto_ungroup_override_wlm = "false"
string compile_automatic_clock_phase_inference = "strict"
Boolean compile_checkpoint_phases = "false"
float compile_cpu_limit = "0.0"
Boolean compile_create_wire_load_table = "false"
Boolean compile_delete_unloaded_sequential_cells = "true"
Boolean compile_disable_area_opt_during_inplace_opt = "false"
Boolean compile_disable_hierarchical_inverter_opt = "false"
Boolean compile_dont_touch_annotated_cell_during_inplace_opt = "false"
Boolean compile_fix_cell_degradation = "false"
Boolean compile_hold_reduce_cell_count = "false"
Boolean compile_ignore_area_during_inplace_opt = "false"
Boolean compile_ignore_footprint_during_inplace_opt = "false"
Boolean compile_implementation_selection = "true"
string compile_instance_name_prefix = "U"
string compile_instance_name_suffix = ""
string compile_log_format = "%elap_time %area %wns %tns %drc %endpoint"
Boolean compile_negative_logic_methodology = "false"
Boolean compile_no_new_cells_at_top_level = "false"
Boolean compile_ok_to_buffer_during_inplace_opt = "false"
Boolean compile_preserve_subdesign_interfaces = "false"
Boolean compile_seqmap_propagate_constants = "false"
Boolean compile_top_all_paths = "false"
Boolean compile_update_annotated_delays_during_inplace_opt = "true"
Boolean compile_use_fast_delay_mode = "true"
Boolean compile_use_low_timing_effort = "false"
string default_port_connection_class = "universal"
Boolean enable_recovery_removal_arcs = "false"
string port_complement_naming_style = "%s_BAR"
string reoptimize_design_changed_list_file_name = ""
float rtl_load_resistance_factor = 0.0
Boolean hlo_disable_datapath_optimization = "false"
Boolean compile_clock_gating_through_hierarchy = "true"
```

DESCRIPTION

These variables directly affect the **compile** command.

For a list of these variables and their current values, type **print_variable_group compile**. To view this manual page online, type **help compile_variables**. To view an individual variable description, type **help var**, where *var* is the variable name.

auto_wire_load_selection

When *true* (the default value), turns on the automatic selection of the wire load model.

`compile_assume_fully_decoded_three_state_busses`

When *true*, **compile** and **translate** assume that three-state busses are fully decoded and therefore can be replaced by multiplexed busses when mapping to a library that contains no three-state cells. The default is *false*.

`compile_auto_ungroup_area_num_cells`

Provides control over the size of the hierarchy suitable for area-based automatic ungrouping during **compile -auto_ungroup area**. Its default value is 30.

`compile_auto_ungroup_override_wlm`

Specifies if a cell instance should be considered for `auto_ungroup` during `compile` if its wire load model differs from that of its parent. Its default value is *false*.

`compile_automatic_clock_phase_inference`

When set to *strict*, **compile** will attempt to determine the desired clock phase for each unmapped register, and will not allow opposite phase devices to be used in constructing registers. When set to *relaxed*, **compile** will allow the implementation of an opposite phase device for a register only if there is no other way to implement that register. When set to *none*, **compile** will ignore clock phase during sequential mapping. The default is *strict*.

`compile_checkpoint_phases`

When *true*, checkpoints automatically between each phase of **compile**. The default is *false*.

`compile_cpu_limit`

Specifies a time, in minutes, to be used as the limit for the amount of time to be spent in the phases after structuring and mapping. Optimization aborts when the limit is reached. The default value, "0.0", indicates that there is no limit.

`compile_create_wire_load_table`

Controls the type of wire load model generated by the **create_wire_load** command. When *true*, the wire load models generated are in the `wire_load_table` format. The default setting of this variable is *false* and the wire load models generated are in the `wire_load` format. It includes resistance, capacitance, area slope coefficients, and `fanout_length` (`fanout`, `length`, `average_cap`, `std_dev`, and `points`)

`compile_delete_unloaded_sequential_cells`

A design can contain sequential cells that drive no loads. During **compile**, the logic driven by a sequential cell might be optimized away, resulting in an inferred no-load or no path to any primary output. By default, **compile** deletes such sequential cells. To retain such cells, set variable **compile_delete_unloaded_sequential_cells** to *false*

`compile_disable_area_opt_during_inplace_opt`

When *true*, disables area optimization during `inplace` optimization. When *false* (the default value), area optimization is enabled; that is, **compile -in_place** attempts to save design area by downsizing cells that are not a part of the critical path. Note that this downsizing can sometimes help speed up the critical path. Thus, setting this option to *true*, while reducing the number of changes made to the design, may hinder this command from achieving the

`compile_variables`

best timing optimization results.

Note: This variable no longer works for **reoptimize_design**.

`compile_disable_hierarchical_inverter_opt`

When *true*, disables hierarchical inverter optimization. When *false* (the default setting), boundary optimization pushes inverters across hierarchy to improve the optimization cost of the design.

`compile_dont_touch_annotated_cell_during_inplace_opt`

When *true*, **reoptimize_design -in place** and **compile -in place** disallow swapping cells that have annotated delays. When *false* (the default value), **reoptimize_design -in place** and **compile -in place** allow annotated cells to be swapped for cells without annotated delay.

`compile_fix_cell_degradation`

When *true*, the algorithms for fixing cell_degradation violations in **compile** and **reoptimize_design** are activated. Different strategies, such as sizing and buffering, try to fix violations of the cell_degradation design rule.

`compile_hold_reduce_cell_count`

When *true* Design Compiler uses the minimum number of cells to fix the hold time (min path) violations, rather than choosing cells that minimize the total new area. This means that the area may be worsened (compared to the default flow) while the hold time violations are being fixed.

`compile_ignore_area_during_inplace_opt`

When *true*, **compile -in place** is allowed to swap cells that have the same number of pins, pin names, logic functionality, and footprint, regardless of area. When *false* (the default value), cells are not swapped if they have different areas.

Note: This variable no longer works for **reoptimize_design**.

`compile_ignore_footprint_during_inplace_opt`

When *true*, **compile -in place** is allowed to swap cells that have the same number of pins, pin names, logic functionality, and cell area, regardless of footprint. When *false* (the default value), cells are not swapped if they have different footprints.

Note: This variable no longer works for **reoptimize_design**.

`compile_implementation_selection`

When *true* (the default), **compile** re-evaluates the current implementation of a synthetic library module and replaces it if appropriate for optimizing the design.

`compile_instance_name_prefix`

Specifies the prefix used in generating cell instance names when **compile** is executed.

`compile_instance_name_suffix`

Specifies the suffix used for generating cell instance names when **compile** is executed.

`compile_log_format`

Controls the format of the columns to be printed during the mapping phases of **compile** and **reoptimize_design**.

`compile_mux_optimization`

When *true* (the default), **compile** takes advantage of dont-care inputs, constant inputs and shared intermediate terms while optimizing MUX_OP implementations. When *false* these optimizations are disabled.

`compile_negative_logic_methodology`

When *true*, **compile** and **translate** connect floating inputs to logic 1. When *false* (the default value), floating inputs are connected to logic 0.

`compile_no_new_cells_at_top_level`

When *true*, no new cells are added to the top-level design of the hierarchy during **compile**. New cells are added only to lower levels. The default is *false*.

`compile_ok_to_buffer_during_inplace_opt`

When *true*, **compile -in_place** is allowed to add buffers (or two inverters in a row) to the design to help meet timing constraints and fix design rule violations, including minimum path timing violations. The default is *false*.

Note: This variable no longer works for **reoptimize_design**.

`compile_preserve_subdesign_interfaces`

When *true*, disables customization of logic external to a subdesign during **compile**, and preserves the subdesign interface. When *false* (the default), **compile** customizes the logic external to a subdesign based on the subdesign's internal logic.

`compile_update_annotated_delays_during_inplace_opt`

When *true* (the default value), **reoptimize_design -in_place** and **compile -in_place** are allowed to modify the values of annotated delays on nets connected to the swapped cells and to remove annotated delays on cells connected to the swapped cells. When *false*, **reoptimize_design -in_place** and **compile -in_place** disallow annotated delays to be modified.

`compile_use_fast_delay_mode`

When *true*, turns on delay calculation techniques that improve **compile** run times when the CMOS2 or nonlinear delay models are being used. The default is *true*. The improvements have the greatest impact when high fanout nets are encountered, as is often the case during sequential mapping.

`compile_use_low_timing_effort`

When *true*, **compile** uses a simplified delay model that may speed up optimization. The default is *false*.

`enable_recovery_removal_arcs`

Recovery or removal timing arcs impose constraints on asynchronous pins of sequential cells. When *true*, enables **compile**, **report_timing**, and **report_constraint** to accept recovery or removal arcs specified in the library.

`hlo_disable_datapath_optimization`

When *true*, disables the built-in datapath optimization feature in **compile**. When *false* (the default) the datapath optimization feature is enabled.

`port_complement_naming_style`

Defines the convention used by **compile** to rename ports complemented as a

`compile_variables`

result of **set_boundary_optimization**.

reoptimize_design_changed_list_file_name

The name of a file to which **reoptimize_design -in_place** and **reoptimize_design -post_layout_opto** commands should output a list of design modifications/additions.

rtl_load_resistance_factor

Specifies a factor to be used by the **set_rtl_load** command to calculate resistance values from capacitance values for RTL loads. The default is 0.0.

compile_top_all_paths

If this variable is set to *true*, the **compile -top** command corrects all design rule violations and all timing violations present in the design.

compile_clock_gating_through_hierarchy

Controls whether the **compile** or **compile_ultra** command with the **-gate_clock** option will perform clock gating through hierarchy

SEE ALSO

compile (2), **reoptimize_design** (2), **set_boundary_optimization** (2), **set_rtl_load** (2), **set_wire_load** (2), **translate** (2), **uniquify** (2).

complete_mixed_mode_extraction

Enables extraction of both routed and unrouted nets with a single command. This is known as mixed-mode extraction.

TYPE

Boolean

DEFAULT

true

GROUP

physopt

DESCRIPTION

By default, the `extract_rc` command skips unrouted or partially routed nets and extracts only completely routed nets. To estimate partially routed or unrouted nets, you must use `extract_rc -estimate`. Consequently, you must run both `extract_rc` and `extract_rc -estimate` to completely extract a partially routed design.

Mixed-mode extraction simplifies this process by enabling simultaneous handling of routed and unrouted nets. To enable this capability in IC Compiler, set the `complete_mixed_mode_extraction` variable to true. When this variable is true,

- The `extract_rc` command performs detailed extraction first, followed by estimation for broken or unrouted nets.
- When you run the `write_parasitics` command after doing mixed-mode extraction, it writes out mixed-mode parasitics.

To disable the mixed-mode extraction capability, set the value of this variable to false.

To see the current value of this variable, type

```
icc_shell-t> printvar complete_mixed_mode_extraction
```

context_check_status

Reports whether the context_check mode is enabled (read-only).

TYPE

Boolean

DEFAULT

false

GROUP

system_variables

DESCRIPTION

Reports whether the context_check mode is enabled (read-only). One of a pair of status variables, **syntax_check_status** and **context_check_status**, whose values are set by the syntax checker and not by the user. You examine these variables to determine the status of the syntax_check or context_check mode of the syntax checker. A value of *true* indicates that the mode is enabled. A value of *false* indicates that the mode is disabled. For example, a value of **context_check_status = true** indicates that the context_check mode is enabled. The two modes cannot be enabled simultaneously. These two status variables, **syntax_check_status** and **context_check_status**, allow you to determine whether one mode is enabled before you attempt to enable the other mode.

You enable or disable the syntax_check and context_check modes by executing the commands **syntax_check** or **context_check**. Alternatively, you can invoke **dc_shell**, **design_compiler**, and **dp_shell** in either the context_check or syntax_check mode by using the **-syntax_check** or **-context_check** options. For more information, refer to the man pages for these commands or to the *Design Compiler Reference Manual*.

To determine the value of this variable, type **printvar context_check_status** or **echo context_check_status**. For a list of **system** variables and their current values, type **print_variable_group system**.

SEE ALSO

dc_shell(1)
design_analyzer(1)
dp_shell(1)
syntax_check(2)
syntax_check_status(3)
system_variables(3)

core_area_attributes

Contains attributes related to core area.

DESCRIPTION

Contains attributes related to core area.

You can use **get_attribute** to determine value of an attribute, and use **report_attribute** to get a report of all attributes on specified object. Specified with **list_attribute -class core_area -application**, the definition of attributes can be listed.

Core Area Attributes

area

Specifies area of a core area object.
The data type of **area** is double.
This attribute is read-only.

bbox

Specifies the bounding-box of a core area. The **bbox** is represented by a **rectangle**.
The format of a *rectangle* specification is {{llx lly} {urx ury}}, which specifies the lower-left and upper-right corners of the rectangle.
The data type of **bbox** is string.
This attribute is read-only.

boundary

Specifies point list of a core area's boundary.
The data type of **boundary** is string.
This attribute is read-only.

cell_id

Specifies Milkyway design ID in which a core area object is located.
The data type of **cell_id** is integer.
This attribute is read-only.

direction

Specifies the direction to orient the rows in a core area.
The valid values can be horizontal and vertical.
The data type of **direction** is string.
This attribute is read-only.

is_double_back

Specifies whether a core area contains pairs of rows with one row flipped in each pair.
The data type of **is_double_back** is boolean.
This attribute is read-only.

is_flip_first_row

Specifies whether to flip the first row at the bottom of a horizontal core area or at the left of a vertical core area.

core_area_attributes

The data type of **is_flip_first_row** is boolean.
This attribute is read-only.

is_start_first_row

Specifies whether the pairing of rows starts at the bottom of a horizontal core area or at the left of a vertical core area.
The data type of **is_start_first_row** is boolean.
This attribute is read-only.

name

Specifies name of a core area object.
The data type of **name** is string.
This attribute is read-only.

num_rows

Specifies number of rows inside a core area.
The data type of **num_rows** is integer.
This attribute is read-only.

object_class

Specifies object class name of a core area, which is **core_area**.
The data type of **object_class** is string.
This attribute is read-only.

object_id

Specifies object ID in Milkyway design file.
The data type of **object_id** is integer.
This attribute is read-only.

row_density

Specifies the ratio of total height (if it's a horizontal core area) or width (otherwise) of rows to the height or width of a core area.
The data type of **row_density** is string.
This attribute is read-only.

tile_height

Specifies height of tile cell used in a core area.
The data type of **tile_height** is double.
This attribute is read-only.

tile_width

Specifies width of tile cell used in a core area.
The data type of **tile_width** is double.
This attribute is read-only.

SEE ALSO

`get_attribute(2),`
`list_attribute(2),`
`report_attribute(2),`
`set_attribute(2).`

cp_full_abut_cts_region_aware

Set clock planning and clock tree synthesis to be region (plan group) aware. It is necessary to be true to handle design with full-abut floorplan.

TYPE

binary

DEFAULT

false

GROUP

cts_variables

DESCRIPTION

cp_full_abut_cts_region_aware adjusts the behavior of clock planning and CTS. It enables clock buffer insertion and relocation to be aware of the plan group of clock buffer's location and adjust its logic hierarchy accordingly.

It is necessary to be set *true* for designs with full-abut floorplan.

SEE ALSO

`compile_fp_clock_plan(2)`
`cp_in_full_abut_mode(3)`

cp_in_full_abut_mode

Set clock planning to handle design with full-abut floorplan

TYPE

binary

DEFAULT

false

GROUP

cts_variables

DESCRIPTION

This variable need to be set true for designs with full-abut floorplan. It adjusts the clock planning behavior to generate top level clock trees that have to be distributed in different plan groups. It also implements procedures to limit the the extra clock ports punched by clock planning.

SEE ALSO

`compile_fp_clock_plan(2)`
`cp_full_abut_cts_region_aware(3)`

cts_blockage_aware

Setting this variable to false will turn off the blockage aware clock tree synthesis algorithm in `compile_clock_tree`.

TYPE

Boolean

DEFAULT

true

GROUP

cts_variables

DESCRIPTION

Setting this variable to false will turn off the blockage aware clock tree synthesis algorithm in `compile_clock_tree`. Thus `compile_clock_tree` will use the same algorithm in releases prior to 2008.09.

SEE ALSO

`compile_clock_tree(2)`

cts_clock_opt_batch_mode

Runs the **compile_clock_tree**, **optimize_clock_tree**, and **balance_inter_clock_delay** commands in clock tree synthesis (CTS) batch mode when this variable is set to true.

TYPE

Boolean

DEFAULT

false

GROUP

cts_variables

DESCRIPTION

This variable runs the **compile_clock_tree**, **optimize_clock_tree**, and **balance_inter_clock_delay** in CTS batch mode when this variable is set to true.

For more information on batch mode, see the man page for the **set_cts_batch_mode** command.

SEE ALSO

clock_opt(2)
reset_cts_batch_mode(2)
report_cts_batch_mode(2)
set_cts_batch_mode(2)

cts_clock_source_is_exclude_pin

This variable controls the cascaded create-clock behavior. If this variable is set to true, clock tree synthesis (CTS) marks the clock source of a downstream **create_clock** command as an implicit exclude pin.

TYPE

Boolean

DEFAULT

true

GROUP

cts_variables

DESCRIPTION

This variable controls the cascaded create-clock behavior. When set to true, it enables CTS to mark the sources of cascaded create_clocks downstream as implicit exclude pins for the purpose of upstream clocks. This behavior is consistent with the timer behavior for cascaded clocks. For example, the following command:

```
prompt> create_clock CLK1
```

has a **create_clock CLK2** defined in its fanouts at pin PIN2. CTS marks PIN2 as an implicit exclude pin for CLK1. PIN2 is still a valid driver for CLK2. This decouples the two clocks and prevents quality of results (QoR) degradation resulting from the synthesis order of CLK1 and CLK2. If CLK1 is synthesized first, PIN2 still has a huge design rule checking (DRC) violation because CLK2 has not yet been touched by CTS. This affects the results for CLK1 when CTS tries to balance an unsynthesized tree with other synthesized trees.

SEE ALSO

`compile_clock_tree(2)`
`create_clock(2)`

cts_do_characterization

Specifies for clock tree synthesis to print additional information to the log file when both the **cts_do_characterization** and **cts_use_debug_mode** variable are set to true. It prints detailed characterization data for the buffers and inverters that clock tree synthesis uses.

TYPE

Boolean

DEFAULT

false

GROUP

cts_variables

DESCRIPTION

This variable, if set to true, prints information about buffer and inverter characterization. It prints estimated skew, target delay, driving resistance, and input capacitance for each buffer and inverter in the list. The buffer list includes all the available buffers and inverters in the library. If you use the **set_clock_tree_references** command, it provides a list that overwrites the **cts_do_characterization** list.

SEE ALSO

set_clock_tree_references(2)

cts_use_debug_mode(3)

cts_enable_clock_at_hierarchical_pin

Specifies that clock tree construction be performed bottom-up for clocks at hierarchical pins. It is for designs with clock sources or clock exceptions defined at hierarchical pins.

TYPE

Boolean

DEFAULT

true

GROUP

cts_variables

DESCRIPTION

Clock tree synthesis (CTS) requires that clock sources must be at points that have physical information. In general, a hierarchical pin does not have physical information for accurately calculating clock delay. Prior to version B2008.09, `create_clock` at hierarchical pins is excluded from CTS.

You might have to modify SDC constraint files and move the clocks to leaf cell pins. The **`cts_enable_clock_at_hierarchical_pin`** variable (switch) is created to minimize your manual work. By using the switch, clock tree construction is performed bottom-up for clocks at hierarchical pins. The clock source is assumed at a pin of the top-most buffer inserted by the tool.

SEE ALSO

`compile_clock_tree(2)`

cts_enable_rc_constraints

When this variable is set to true, CTS will apply internally derived RC constraints during clustering to reduce skew caused by wire delay. This feature is to be used with config file only.

TYPE

Boolean

DEFAULT

false

GROUP

cts_variables

DESCRIPTION

For a high performance design that needs to operate under very different operating conditions (PVT, TLU+), it is important for its clock tree to maintain good skew across different corners. Skew varies from corner to corner due to both cell delay and interconnect delay variations. The config file flow in ICC CTS provides a way to build a clock tree with pre-defined structure to control cell delay variation. The variable, `cts_enable_rc_constraints`, allows more control over interconnect delay variation by enforcing RC constraints during clustering stage.

Use the following command to determine the current value of the variable:

```
prompt> printvar cts_enable_rc_constraints
```

SEE ALSO

`compile_clock_tree(2)`
`cts_rc_relax_factor(3)`

cts_fix_clock_tree_sinks

Specifies for clock tree synthesis (CTS) to put the **cts_fixed** attribute on all sinks for optimization and legalization to honor, when set to true.

TYPE

Boolean

DEFAULT

false

GROUP

cts_variables

DESCRIPTION

Specifies for clock tree synthesis (CTS) to put the **cts_fixed** attribute on all sinks, except those that have already been marked fixed before CTS. Cells that have the **cts_fixed** attribute cannot be moved or sized by legalization or placement and timing optimization

By default, CTS sets the **cts_in_place_size_only** attribute on all sinks, except those that have been marked as fixed before CTS. Cells that have the **cts_in_place_size_only** attribute can be moved by the legalizer, and can be sized during placement and timing optimization.

SEE ALSO

`compile_clock_tree(2)`
`set_clock_tree_options(2)`

cts_fix_drc_beyond_exceptions

Specifies for clock tree synthesis (CTS) to fix all design rule checking (DRC) violations before skew minimization, when set to true. From the A2007.12 release forward, this tool fixes all DRC violations, including those beyond clock exceptions by default. This variable provides you with a switch to prevent DRC fixing beyond clock exceptions.

TYPE

Boolean

DEFAULT

true

GROUP

cts_variables

DESCRIPTION

Prior to the A2007.12 release, DRC violations beyond clock exceptions was performed by physopt. That is, any net that is not processed during CTS will be processed by physopt after CTS. However, from the 2007.12 release forward, physopt does not touch any clock nets, including those beyond clock exceptions. Clock nets are identified by timer. With this change, DRC violations beyond clock exceptions must be fixed by CTS itself. If you do not want to have CTS fix those DRC violations, you can set the switch to false.

SEE ALSO

compile_clock_tree(2)

cts_force_user_constraints

Specifies for clock tree synthesis (CTS) to ignore library constraints for capacitance and transition, when set to true. This variable is useful for comparing CTS results between IC Compiler and other tools.

TYPE

Boolean

DEFAULT

false

GROUP

cts_variables

DESCRIPTION

This variable enables the **compile_clock_tree** command to ignore the transition and capacitance constraints from the library when it is set to true. User constraints or default CTS constraints prevail. This is useful while comparing results with CTS in other tools.

SEE ALSO

`compile_clock_tree(2)`

cts_instance_name_prefix

Specifies string to prepend to names of cells created during `compile_clock_tree` and `optimize_clock_tree`.

TYPE

string

DEFAULT

" "

GROUP

cts_variables

DESCRIPTION

This variable specifies a string to prepend to the names of buffers and inverters created during `compile_clock_tree` and `optimize_clock_tree`. It provides for a convenient means of collecting all new cells resulting from a given run of the `compile_clock_tree` or `optimize_clock_tree` command.

SEE ALSO

`compile_clock_tree(2)`
`optimize_clock_tree(2)`
`cts_net_name_prefix(3)`

cts_move_clock_gate

This variable controls the initial relocation of existent clock gates in `compile_clock_tree`.

TYPE

Boolean

DEFAULT

true

GROUP

cts_variables

DESCRIPTION

When this variable is set to true, `compile_clock_tree` will relocate existent clock gates to their fanout centers before synthesis in order to improve insertion delay and clock skew.

SEE ALSO

`compile_clock_tree(2)`

cts_net_name_prefix

Specifies string to prepend to names of nets created during `compile_clock_tree` and `optimize_clock_tree`.

TYPE

string

DEFAULT

" "

GROUP

cts_variables

DESCRIPTION

This variable specifies a string to prepend to the names of nets created during `compile_clock_tree` and `optimize_clock_tree`. It provides for a convenient means of collecting all new nets resulting from a given run of the `compile_clock_tree` or `optimize_clock_tree` command.

SEE ALSO

`compile_clock_tree(2)`
`optimize_clock_tree(2)`
`cts_instance_name_prefix(3)`

cts_prechts_upsize_gates

Specifies for the **compile_clock_tree** command to up-size the original clock gates to the LEQ cell with the highest driving strength, when set to true.

TYPE

Boolean

DEFAULT

true

GROUP

cts_variables

DESCRIPTION

This variable specifies for the **compile_clock_tree** command to up-size the original clock gates to the LEQ cell with the highest driving strength. Up-sizing sizes all the original gates present in a clock tree to the highest available driving LEQ cell. Gates marked as fixed or dont size are not sized. Currently, this variable also sizes integrated clock gatings (ICGs).

In some cases LEQ cells might not be available in the library. In other cases, LEQ cells might be marked as dont use. In the later case, you are advised to remove the **dont_use** attribute from library cells.

This variable controls only the up-sizing during the preprocessing step of the **compile_clock_tree** command. This is different from the gate-sizing optimization step during Embedded-CTO and Standalone-CTO.

SEE ALSO

compile_clock_tree(2)

cts_push_down_buffer

Enables the **split_clock_net** command to push down clock sinks by creating new cell instances to drive them, when set to true.

TYPE

Boolean

DEFAULT

false

GROUP

cts_variables

DESCRIPTION

This variable specifies that if one net or a list of nets is specified as the object list by the **split_clock_net** command and part or all of fanout pins of those nets are clock sinks, these clock sinks are to be pushed down one gate level with a new cell instance of a certain buffer type to drive them. The new cell instance can then be cloned to several cell instances as other integrated clock gating (ICG) gates are split.

SEE ALSO

split_clock_net(2)

cts_rc_relax_factor

This variable controls the internally derived RC constraints for clustering.

TYPE

float

DEFAULT

1

GROUP

cts_variables

DESCRIPTION

Tighter RC constraints will lead to smaller clusters and more resources. This variable allows trade-offs between resource and skew variation from wire delay. Setting the value larger than one results in more relaxed RC constraints and less resource requirement.

Use the following command to determine the current value of the variable:

```
prompt> printvar cts_rc_relax_factor
```

SEE ALSO

compile_clock_tree(2)
cts_enable_rc_constraints(3)

cts_region_aware

Setting this variable to true will turn on the region aware clock tree synthesis algorithm in `compile_clock_tree`.

TYPE

Boolean

DEFAULT

false

GROUP

cts_variables

DESCRIPTION

Setting this variable to true will turn on the region aware clock tree synthesis algorithm in `compile_clock_tree`.

SEE ALSO

`compile_clock_tree(2)`

cts_target_cap

Sets target capacitance value for clock tree synthesis (CTS) clustering instead of using the tool-calculated target based on maximum capacitance.

TYPE

float

DEFAULT

0

GROUP

cts_variables

DESCRIPTION

This variable specifies that when constraint capacitance is less than target capacitance, the tool continues to use the constraint for design rule checking (DRC) fixes; however, the tool uses the user specified target for clustering. Normally, user input target capacitance overrides internal target capacitance in the tool.

Explore all other known possibilities of quality of results (QoR) improvement before changing the CTS target. Changing the target impacts clustering and CTS QoR. Making the target too tight (< 0.2), often degrades results. No easy way exists to know the best target for a design.

Change targets only when constraints are greater than the target. Do not change the targets for regular scenarios. Changing target capacitance for regular scenarios is not a recommended usage.

SEE ALSO

`compile_clock_tree(2)`
`set_clock_tree_options(2)`

cts_target_transition

Sets target transition value for clock tree synthesis (CTS) clustering instead of using the tool-calculated target based on maximum transition.

TYPE

float

DEFAULT

0

GROUP

cts_variables

DESCRIPTION

This variable specifies that when constraint transition is less than target transition, the tool continues to use the constraint for design rule checking (DRC) fixes; however, the tool uses the user specified target for clustering. Normally, user input target transition always overrides internal target transition in the tool.

Explore all other known possibilities of quality of results (QoR) improvement before changing the CTS target. Changing target impacts clustering and CTS QoR. Making the target too tight (< 0.2), often degrades results. No easy way exists to know the best target for a design.

Change targets only when constraints are greater than the target. Do not change the targets for regular scenarios. Changing target transition for regular scenarios is not a recommended usage.

SEE ALSO

`compile_clock_tree(2)`
`set_clock_tree_options(2)`

cts_traverse_dont_touch_subtrees

Specifies for **compile_clock_tree** command to set clock net type and routing properties for nets beyond dont_touch_subtree exceptions, when set to true.

TYPE

Boolean

DEFAULT

true

GROUP

cts_variables

DESCRIPTION

When this variable set to true (the default value), the **compile_clock_tree** command updates the net attributes and routing properties (routing rule and layer constraints) for nets beyond the exceptions specified by the **dont_touch_subtree** attribute. The nets on the dont touch subtree have the routing rule and the layer constraints specified by using the **set_clock_tree_options** command. When this variable is set to false, the nets on the don touch subtree retain their original routing properties and attributes.

SEE ALSO

compile_clock_tree(2)
set_clock_tree_exceptions(2)
set_clock_tree_options(2)

cts_use_debug_mode

Specifies for clock tree synthesis (CTS) to print additional debugging information in the log file, when set to true.

TYPE

Boolean

DEFAULT

false

GROUP

cts_variables

DESCRIPTION

This variables specifies for CTS to print additional information, including data such as the user-defined design rule constraints (maximum transition time, maximum capacitance, and maximum fanout); the target design rule constraints set by the tool (maximum transition time, maximum capacitance, and maximum fanout); and the user-defined clock tree timing constraints (skew, insertion delay, and levels per net).

SEE ALSO

compile_clock_tree(2)

cts_use_lib_max_fanout

When set to true, clock tree synthesis will honor max fanout constraint set on library cell pins.

TYPE

Boolean

DEFAULT

false

GROUP

cts_variables

DESCRIPTION

Max fanout constraints set on library cell pins are usually for logic synthesis purpose. Setting cts_use_lib_max_fanout to true will allow CTS to honor library max fanout constraints.

SEE ALSO

compile_clock_tree(2)

cts_use_sdc_max_fanout

When set to true, clock tree synthesis will honor SDC max fanout constraint set on current design.

TYPE

Boolean

DEFAULT

false

GROUP

cts_variables

DESCRIPTION

SDC max fanout constraint set on current design is usually for logic synthesis purpose. Setting `cts_use_sdc_max_fanout` to true will allow CTS to honor SDC max fanout constraint set on current design. Note that CTS does not support SDC max fanout constraints set on other objects.

SEE ALSO

`compile_clock_tree(2)`

current_design

Specifies the design being worked on. This variable is used by most of the Synopsys commands.

TYPE

string

DEFAULT

" "

GROUP

system_variables

DESCRIPTION

Specifies the design being worked on. This variable is used by most of the Synopsys commands.

Until a design is read into the system as the current design, the value of **current_design** is "<<undefined>>". When one or more designs are read into the system, any of them can be made current by assigning the design name to this variable.

For example, if the design "real" is in dc_shell, to make it current type:

```
current_design = real
```

To determine the current value of this variable use **printvar current_design**. For a list of all **system** variables and their current values, use the **print_variable_group system** command.

db_load_ccs_data

The variable is obsolete and is not needed any more. The tool takes care of loading the CCS timing information automatically.

TYPE

Boolean

DEFAULT

false

GROUP

none

DESCRIPTION

SEE ALSO

link(2)

dct_placement_ignore_scan

Sets the flag for the placer to ignore scan connections in Design Compiler topographical.

TYPE

Boolean

DEFAULT

false

GROUP

compile_variables

DESCRIPTION

Setting the **dct_placement_ignore_scan** variable to true flags the placer to ignore scan connections, especially for a scan-stitched design. This is similar to **create_placement -ignore_scan** in IC Compiler.

SEE ALSO

ddc_allow_unknown_packed_commands

Causes the `read_file` command to attempt to read DDC files which contain packed commands which are unknown to the current version of **dc_shell**.

TYPE

Boolean

DEFAULT

true

DESCRIPTION

When this variable is *true* (the default), the `read_file` command will attempt to read a DDC file which contains embedded commands (constraints) which are unknown to the current version of **dc_shell**. This may allow the tool to read a DDC file which was written by a newer version of **dc_shell** which, for some reason, is not currently available.

If this feature is enabled then any unrecognized commands will be discarded, possibly resulting in the loss of important data. It is strongly recommended that DDC files be read by the same (or later) version of the tool as was used to write them out.

If the variable is set to *false* then any attempt to read a file with unknown embedded commands will result in a read failure and DDC-6 error message. You may wish to set this variable to *false* as a check against possible loss of constraint data.

It may not be possible to read certain DDC files written by newer versions of the tool, even with this variable set to *true*.

This variable is only evaluated during the `read_file` command. Unknown commands read in from DDC files while this variable is *true* will continue to be skipped even if the variable is subsequently set to *false*.

SEE ALSO

`read_file(2)`

default_input_delay

Specifies the global default input delay value to be used for environment propagation.

TYPE

float

DEFAULT

30

GROUP

acs_variables

DESCRIPTION

Specifies the global default input delay value to be used for environment propagation. This variable is used by the **derive_constraints** command.

To determine the current value of this variable, type **printvar default_input_delay**.

SEE ALSO

`derive_constraints(2)`

default_name_rules

Contains the name of a name rule to be used as a default by the **change_names** command, if the command's **-rules** option does not specify a *name_rules* value.

TYPE

string

DEFAULT

" "

GROUP

system_variables

DESCRIPTION

Contains the name of a name rule to be used as a default by the **change_names** command, if the command's **-rules** option does not specify a *name_rules* value. The **change_names** command changes the names of ports, cells, and nets to conform to the rules specified by **default_name_rules**. The name_rule you assign to **default_name_rules** must already have been defined using **define_name_rules**. For information on the format and creation of name_rules, refer to the **define_name_rules** manual page.

To determine the current value of this variable, type **printvar default_name_rules**. For a list of all **system** variables and their current values, type **print_variable_group system**.

SEE ALSO

change_names(2)
define_name_rules(2)
system_variables(3)

default_output_delay

Specifies the global default output delay value to be used for environment propagation.

TYPE

float

DEFAULT

30

GROUP

acs_variables

DESCRIPTION

Specifies the global default output delay value to be used for environment propagation. This variable is used by the **derive_constraints** command.

To determine the current value of this variable, type **printvar default_output_delay**.

SEE ALSO

`derive_constraints(2)`

default_port_connection_class

Contains the value of the connection class to be assigned to ports that do not have a connection class assigned to them.

TYPE

string

DEFAULT

universal

GROUP

compile_variables

DESCRIPTION

Contains the value of the connection class to be assigned to ports that do not have a connection class assigned to them. The default value for **default_port_connection_class** is **universal**.

To determine the current value of this variable, type **printvar default_port_connection_class**. For a list of all **compile** variables and their current values, type **print_variable_group compile**.

SEE ALSO

set_connection_class(2)

default_schematic_options

Specifies options to use when schematics are generated.

TYPE

string

DEFAULT

-size infinite

GROUP

schematic_variables

view_variables

DESCRIPTION

Specifies options to use when schematics are generated. When set to "-size infinite" (default), the schematic for a design is displayed on a single page. (Used by the Design Analyzer.)

To determine the current value of this variable use **printvar default_schematic_options**. For a list of all **schematic** or **view** variables and their current values, use **print_variable_group schematic** or **print_variable_group view**.

design_attributes

DESCRIPTION

Contains attributes that can be placed on a design.

There are a number of commands used to set attributes. Most attributes, however, can be set with the **set_attribute** command. If the attribute definition specifies a **set** command, use it to set the attribute. Otherwise, use **set_attribute**. If an attribute is "read only," it cannot be set by the user.

To determine the value of an attribute, use the **get_attribute** command. To remove attributes, use the **remove_attribute** command.

For a more detailed explanation of an attribute, refer to the manual pages of the appropriate **set** command. For information on all attributes, refer to the **attributes** manual page.

Design Attributes

async_set_reset_q

Establishes the value (0 or 1) that should be assigned to the q output of an inferred register if set and reset are both active at the same time. To be used with **async_set_reset_qn**. Use these attributes only if you have used the **one_hot** or **one_cold** attributes/directives in your HDL description *and* your technology library is written using pre-V3.0a syntax; or if your technology library does not use a consistent convention for q and qn when set and reset are both active. If a V3.0a or later syntax technology library is used, then, by default, if set and reset are both active at the same time Design Compiler will use the convention of the selected technology library (**target_library**). Set with **set_attribute**.

Note: If you are unsure whether your technology library uses V3.0a syntax, ask your ASIC vendor.

async_set_reset_qn

Establishes the value (0 or 1) that should be assigned to the qn output of an inferred register if set and reset are both active at the same time. To be used with **async_set_reset_q**. Use these attributes only if you have used the **one_hot** or **one_cold** attributes/directives in your HDL description *and* your technology library is written using pre-V3.0a syntax; or if your technology library does not use a consistent convention for q and qn when set and reset are both active. If a V3.0a or later syntax technology library is used, then, by default, if set and reset are both active at the same time Design Compiler will use the convention of the selected technology library (**target_library**). Set with **set_attribute**.

Note: If you are unsure whether your technology library uses V3.0a syntax, ask your ASIC vendor.

balance_registers

Determines whether the registers in a design are retimed during **compile**. When *true* (the default value), **compile** invokes the **balance_registers** command, which moves registers to minimize the maximum register-to-register delay. Set this attribute to *false*, or remove it, to disable this behavior.

Set with **set_balance_registers**. **Note:** You cannot verify designs using **compile -verify** while the **balance_registers** attribute is set to *true*. In addition, if your design contains generic logic, you should ensure that all components are mapped to cells from the library before setting the **balance_registers** attribute.

boundary_optimization

Enables **compile** to optimize across hierarchical boundaries. Hierarchy is ignored during optimization for designs with this attribute set to *true*. Set with **set_boundary_optimization**.

default_flip_flop_type

Specifies the default flip-flop type for the current design. During the mapping process, **compile** tries to convert all unmapped flip-flops to this type. If **compile** is unable to use this flip-flop, it maps these cells into the smallest flip-flop possible. Set with **set_register_type -flip_flop flip_flop_name**.

default_flip_flop_type_exact

Specifies the exact default flip-flop type for the current design. During the mapping process, **compile** converts unmapped flip-flops to the exact flip-flop type specified here. Set with **set_register_type -exact -flip_flop flip_flop_name**.

default_latch_type_exact

Specifies the exact default latch type for the current design. During the mapping process, **compile** converts unmapped latches to the exact latch type specified here. Set with **set_register_type -exact -latch latch_name**.

design_type

Indicates the type of the **current_design**. Allowed values are **fsm** (finite state machine); **pla** (programmable logic array); **equation** (Boolean logic); or **netlist** (gates). This attribute is *read only* and cannot be set by the user.

dont_touch

Identifies designs that are to be excluded from optimization. Values are *true* (the default) or *false*. Designs with the **dont_touch** attribute set to *true* are not modified or replaced during **compile**. Setting **dont_touch** on a design has an effect only when the design is instantiated within another design as a level of hierarchy; setting **dont_touch** on the top-level design has no effect. Set with **set_dont_touch**.

flatten

When set to *true*, determines that a design is to be flattened during **compile**. By default, a design is not flattened. Set with **set_flatten**.

flatten_effort

Defines the level of CPU effort that **compile** uses to flatten a design. Allowed values are *low* (the default), *medium*, or *high*. Set with **set_flatten**.

flatten_minimize

Defines the minimization strategy used for logic equations. Allowed values are *single_output*, *multiple_output*, or *none*. Set with **set_flatten**.

design_attributes

`flatten_phase`

When *true*, allows logic flattening to invert the phase of outputs during **compile**. By default, logic flattening does not invert the phase of outputs. Used only if the **flatten** attribute is set. Set with **set_flatten**.

`is_combinational`

true if all cells of a design and all designs in its hierarchy are combinational. A cell is combinational if it is non-sequential or non-tristate and all of its outputs compute a combinational logic function. The **report_lib** command will report such a cell as not a black-box. This attribute is *read only* and cannot be set by the user.

`is_dw_subblock`

true if the object (a cell, a reference, or a design) is a DW subblock that was automatically elaborated. This attribute is *read only* and cannot be set by the user.

NOTE: DW subblocks that are manually elaborated will not have this attribute.

`is_hierarchical`

true if the design contains leaf cells or other levels of hierarchy. This attribute is *read only* and cannot be set by the user.

`is_mapped`

true if all the non-hierarchical cells of a design are mapped to cells in a technology library. This attribute is *read only* and cannot be set by the user.

`is_sequential`

true if any cells of a design or designs in its hierarchy are sequential. A cell is sequential if it is not combinational (if any of its outputs depend on previous inputs). This attribute is *read only* and cannot be set by the user.

`is_synlib_module`

true if the object (a cell, a reference, or a design) refers to an unmapped module reference or if the object is (or refers to) a design that was automatically elaborated from a synlib module or a synlib operator. This attribute is *read only* and cannot be set by the user.

NOTE: synlib modules that are manually elaborated will not have this attribute.

`is_unmapped`

true if any of the cells are not linked to a design or mapped to a technology library. This attribute is *read only* and cannot be set by the user.

`local_link_library`

A string that contains a list of design files and libraries to be added to the beginning of the **link_library** whenever a **link** operation is performed. Set with **set_local_link_library**.

`map_only`

When set to *true*, **compile** will attempt to map the object exactly in the target library, and will exclude the object from logic-level optimization (flattening and structuring). The default is *false*. Set with **set_map_only**.

max_capacitance

A floating point number that sets the maximum capacitance value for input, output, or bidirectional ports; or for designs. The units must be consistent with those of the technology library used during optimization. Set with **set_max_capacitance**.

max_dynamic_power

A floating point number that specifies the maximum target dynamic power for the **current_design**. The units must be consistent with those of the technology library. If this attribute is specified more than once for a design, the latest value is used. Set with **set_max_dynamic_power**.

max_leakage_power

A floating point number that specifies the maximum target leakage power for the **current_design**. The units must be consistent with those of the technology library. If this attribute is specified more than once for a design, the latest value is used. Set with **set_max_leakage_power**.

max_total_power

A floating point number that specifies the maximum target total power for the **current_design**. Total power is defined as the sum of dynamic and leakage power. If this attribute is specified more than once for a design, the latest value is used. Set with **set_max_total_power**.

min_porosity

Specifies the minimum porosity of the design. **compile -routability** and **reoptimize_design** ensure that the porosity of the design is greater than the specified value. Set with **set_min_porosity**.

minimize_tree_delay

When *true* (the default value), **compile** restructures expression trees in the **current_design** or in a list of specified designs, to minimize tree delay. Set this attribute to *false* for any designs that you do not wish to be restructured. Set with **set_minimize_tree_delay**.

model_map_effort

Specifies the relative amount of CPU time to be used by **compile** during modeling, typically for synthetic library implementations. Values are *low*, *medium*, and *high*, or 1, 2, and 3. If **model_map_effort** is not set, the value of **synlib_model_map_effort** is used. Set with **set_model_map_effort**.

model_scale

A floating point number that sets the model scale factor for the **current_design**. Set with **set_model_scale**.

optimize_registers

When *true* (the default value), **compile** automatically invokes the Behavioral Compiler **optimize_registers** command to retime the design during optimization. Setting the attribute to *false* disables this behavior. You cannot execute **compile -verify** if **optimize_registers** is set to *true* on the design. Also, your design cannot contain generic logic at the instant **optimize_registers** is invoked during **compile**. Set with **set_optimize_registers**.

part

A string value that specifies the Xilinx part type for a design. For valid

design_attributes

part types, refer to the Xilinx *XC4000 Databook*. Set with **set_attribute**.

resource_allocation

Indicates the type of resource allocation to be used by **compile** for the **current_design**. Allowed values are *none*, indicating no resource sharing; *area_only*, indicating resource sharing with tree balancing without considering timing constraints; *area_no_tree_balancing*, indicating resource sharing without tree balancing and without considering timing constraints; and *constraint_driven* (the default), indicating resource sharing so that timing constraints are met or not worsened. The value of this attribute overrides the value of the variable **hlo_resource_allocation** for the **current_design**. Set with **set_resource_allocation**.

resource_implementation

Indicates the type of resource implementation to be used by **compile** for the **current_design**. Allowed values are *area_only*, indicating resource implementation without considering timing constraints; *constraint_driven*, indicating resource implementation so that timing constraints are met or not worsened; and *use_fastest*, indicating resource implementation using the fastest implementation initially and using components with smaller area later in uncritical parts of the design. The value of this attribute overrides the value of the variable **hlo_resource_implementation** for the **current_design**. Set with **set_resource_implementation**.

structure

Determines if a design is to be structured during **compile**. If *true*, adds logic structure to a design by adding intermediate variables that are factored out of the design's equations. Set with **set_structure**.

structure_boolean

Enables the use of Boolean (non-algebraic) techniques during the structuring phase of optimization. This attribute is ignored if the **structure** attribute is *false*. Set with **set_structure**.

structure_timing

Enables timing constraints to be considered during the structuring phase of optimization. This attribute is ignored if the **structure** attribute is *false*. Set with **set_structure**.

ungroup

Removes a level of hierarchy from the current design by exploding the contents of the specified cell in the current design. Set with **set_ungroup**.

wired_logic_disable

When *true*, disables the creation of wired OR logic during **compile**. The default is *false*; if this attribute is not set, wired OR logic will be created if appropriate. Set with **set_wired_logic_disable**.

wire_load_model_mode

Determines which wire load model to use to compute wire capacitance, resistance, and area for nets in a hierarchical design that has different wire load models at different hierarchical levels. Allowed values are *top*, use the wire load model at the top hierarchical level; *enclosed*, use the wire load model on the smallest design that encloses a net completely; and *segmented*, break the net into segments, one within each hierarchical level.

In the *segmented* mode, each net segment is estimated using the wire load model on the design that encloses that segment. The *segmented* mode is not supported for wire load models on clusters. If a value is not specified for this attribute, **compile** searches for a default in the first library in the link path. If none is found, *top* is the default. Set with **set_wire_load**.

SEE ALSO

get_attribute(2)
remove_attribute(2)
set_attribute(2)
attributes(3)

die_area_attributes

Contains attributes related to die area.

DESCRIPTION

Contains attributes related to die area.

You can use **get_attribute** to determine value of an attribute, and use **report_attribute** to get a report of all attributes on specified object. Specified with **list_attribute -class die_area -application**, the definition of attributes can be listed.

Die Area Attributes

bbox

Specifies the bounding-box of a die area. The **bbox** is represented by a **rectangle**.

The format of a *rectangle* specification is {{llx lly} {urx ury}}, which specifies the lower-left and upper-right corners of the rectangle.

The data type of **bbox** is string.

This attribute is read-only.

boundary

Specifies point list of a die area's boundary.

The data type of **boundary** is string.

This attribute is read-only.

cell_id

Specifies Milkyway design ID in which a die area object is located.

The data type of **cell_id** is integer.

This attribute is read-only.

name

Specifies name of a die area object.

The data type of **name** is string.

This attribute is read-only.

object_class

Specifies object class name of a die area, which is **die_area**.

The data type of **object_class** is string.

This attribute is read-only.

object_id

Specifies object ID in Milkyway design file.

The data type of **object_id** is integer.

This attribute is read-only.

SEE ALSO

get_attribute(2),
list_attribute(2),

```
report_attribute(2),  
set_attribute(2).
```

disable_auto_time_borrow

Determines whether the **report_timing** command and other commands will use automatic time borrowing.

TYPE

Boolean

DEFAULT

false

GROUP

timing_variables

DESCRIPTION

Determines whether the **report_timing** command and other commands will use automatic time borrowing. When *false* (the default), automatic time borrowing occurs. Automatic time borrowing balances the slack along back-to-back latch paths, to reduce the overall delay cost. Allocating slack throughout the latch stages can improve optimization results.

When *true*, no slack balancing occurs during time borrowing. This means the first paths borrow enough time to meet the constraint until the *max_time_borrow* is reached. Setting the variable to *true* produces time-borrow results consistent with PrimeTime.

SEE ALSO

report_timing(2)
timing_variables(3)

disable_case_analysis

When true, disables constant propagation from both logic constants and **set_case_analysis** command constants.

TYPE

Boolean

DEFAULT

false

GROUP

timing

DESCRIPTION

When true, disables constant propagation from both logic constants and **set_case_analysis** command constants. By default, the variable **disable_case_analysis** is *false*, so constant propagation is performed if there has been a **set_case_analysis** command or if the variable **case_analysis_with_logic_constants** has been specified.

To determine the current value of this variable, use **printvar disable_case_analysis**.

SEE ALSO

remove_case_analysis(2)
report_case_analysis(2)
set_case_analysis(2)
case_analysis_with_logic_constants(3)

disable_library_transition_degradation

Controls whether the transition degradation table is used to determine the net transition time.

TYPE

Boolean

DEFAULT

false

GROUP

timing_variables

DESCRIPTION

When false (the default), **report_timing** and other commands that use timing in dc_shell use the transition degradation table in the library to determine the net transition time. When true, the timing commands behave as though there were no transition degradation across the net.

SEE ALSO

report_timing(2)
timing_variables(3)

do_operand_isolation

Enables or disables operand isolation as a dynamic power optimization technique for a design.

TYPE

Boolean

DEFAULT

false

GROUP

power_variables

DESCRIPTION

This variable enables or disables operand isolation as a dynamic power optimization technique for a design. When *false* (the default value), this technique is disabled. Set the value to *true* to enable operand isolation.

Operand isolation can insert isolation cells for both operators and hierarchical combinational cells. There are two mechanisms for operand isolation: automatic selection and user-driven mode. This and other parameters can be specified with the **set_operand_isolation_style** command.

To determine the current value of this variable, type **printvar do_operand_isolation**. For a list of power variables and their current values, type **print_variable_group power**.

SEE ALSO

set_operand_isolation_scope(2)

dont_touch_nets_with_size_only_cells

Specifies whether a net is marked dont touch if it is driven by at least one cell marked size_only and drives at least one cell marked by size_only.

TYPE

Boolean

DEFAULT

false

GROUP

compile_variables

DESCRIPTION

When true, this variable indicates that all the nets that are driven by at least one cell marked size_only and drive at least one cell marked size_only, will be treated as if marked dont_touch. Cells can be marked size_only by using the **set_size_only** command. If a net is marked dont touch, it can not be changed by dc_shell commands that optimize or manipulate the design.

Default value of this variable is false.

To determine the current value of this variable use **printvar dont_touch_nets_with_size_only_cells**. For a list of **compile** variables and their current values, use the **print_variable_group compile** command.

SEE ALSO

compile_variables(3)
set_dont_touch(1)
set_size_only(1)

dpcm_variables

SYNTAX

```
string dpcm_arc_sense_mapping = "TRUE"
string dpcm_debuglevel = "0"
string dpcm_functionscope = "global"
string dpcm_level = "performance"
list dpcm_libraries = ""
list dpcm_rulepath = ""
list dpcm_rulespath = ""
string dpcm_slewlimit = "TRUE"
list dpcm_tablepath = ""
string dpcm_temperaturescope = "global"
string dpcm_version = "IEEE-P1481"
string dpcm_voltagescope = "global"
string dpcm_wireloadscope = "global"
```

DESCRIPTION

These variables affect the DPCM libraries and delay calculation in DPCM mode.

For a list of these variables and their current values, type **print_variable_group dpcm**. To view this manual page online, type **help dpcm_variables**. To view an individual variable description, type **help var**, where *var* is the variable name.

dpcm_arc_sense_mapping

When *true* (the default), Design Compiler maps half unate arcs to preset/clear arcs for sequential cells. When *false*, Design Compiler leaves the arcs from DPCM as they are.

dpcm_debuglevel

This variable can be set to 0 or higher. Depending on the value, more debugging information is printed. The default is 0.

dpcm_functionscope

Allowed values are *global* (the default) or *instance*. When set to *global*, the value is cached in DPCM, and DPCM does not request FunctionalMode for every delay/slew calculation call. When set to *instance*, for every delay or slew calculation call, DPCM makes a call to the external function CurrentFunctionalMode. The behavior usually depends on the way DPCM is implemented.

dpcm_level

Allowed values are *accurate* or *performance* (the default). When set to *performance*, DPCM uses performance equations and caches various values (for example, wire load, voltage). When set to *accurate*, DPCM uses a different set of equations and does not cache values. The behaviour usually depends on the way DPCM is implemented.

dpcm_libraries

Specifies the libraries of the **link_path** that use the DPCM delay calculation. By default, delay calculation is performed with the Synopsys library delays.

dpcm_variables

The default is "". Set this variable only if a DPCM library is available for the specified library. There should be an equivalent .db file for each DPCM library.

dpcm_rulepath

A list of paths, similar to a search path, for locating the DPCM main rule. Design Compiler sets it to the DCMRULEPATH unix variable used by the DPCM delay calculation. Set this variable only if a DPCM library is available for the libraries used by the current design, and use the path specified by the DPCM provider. The default is "".

dpcm_rulespath

A list of paths, similar to a search path, for locating the DPCM subrules. Design Compiler sets it to the DCMRULEPATH unix variable used by the DPCM delay calculation. Set this variable only if a DPCM library is available for the libraries used by the current design, and use the path specified by the DPCM provider. The default is "".

dpcm_slewlimit

When *true* (the default), Design Compiler limits the slew to the maximum slew for input pins, when the slew is beyond the maximum limit. When *false*, Design Compiler does not limit the slew, and allows the DPCM to handle the situation.

dpcm_tablepath

A list of paths, similar to a search path, for locating the DPCM tables. Design Compiler sets it to the DCMTABLEPATH unix variable used by the DPCM delay calculation. Set this variable only if a DPCM library is available for the libraries used by the current design, and use the path specified by the DPCM provider. The default is "".

dpcm_temperaturescope

Allowed values are *global* (the default) or *instance*. When set to *global*, the value is cached in DPCM, and DPCM does not request Temperature for every delay/slew calculation call. When set to *instance*, for every delay or slew calculation call, DPCM makes a call to the external function `CurrentTemperature`. The behavior usually depends on the way DPCM is implemented.

dpcm_version

Specifies the version of the API used by the DPCM delay calculation. The supported DPCM API versions are *IEEE-P1481* (the default) and *IBM*.

dpcm_voltagescope

Allowed values are *global* (the default) or *instance*. When set to *global*, the value is cached in DPCM, and DPCM does not request RailVoltage values for every delay/slew calculation call. When set to *instance*, for every delay or slew calculation call, DPCM makes a call to the external function `RailVoltage`. The behavior usually depends on the way DPCM is implemented.

dpcm_wireloadscope

Allowed values are *global* (the default) or *instance*. When set to *global*, the value is cached in DPCM, and DPCM does not request Current WireLoadModel values for every delay/slew calculation call. When set to *instance*, for every delay or slew calculation call, DPCM makes a call to the external function `CurrentWireLoadModel`. The behavior usually depends on the way DPCM is

implemented.

SEE ALSO

`dpcm_arc_sense_mapping` (3), `dpcm_debug_level` (3), `dpcm_functionscope`(3), `dpcm_level` (3), `dpcm_libraries` (3), `dpcm_rulepath` (3), `dpcm_rulespath` (3), `dpcm_slewlimit` (3), `dpcm_tablepath`(3), `dpcm_temperaturescope` (3), `dpcm_version`(3), `dpcm_voltagescope` (3), `dpcm_wireloadscope` (3).

droute_advRouteLoop

DESCRIPTION

The **droute_advRouteLoop** variable specifies the number of loops for Astro command **axgAdvRouteOpt** and **astPostRouteOpt** in advanced routing. If the value is set to N, it means that the Astro command **axgAdvRouteOpt** and **astPostRouteOpt** stop after N loops.

SYNTAX

set droute_advRouteLoop value

The valid values of this variable range between 0 and 50. The default is 10.

EXAMPLE

To ensure that Astro commands stop after 25 loops, enter

```
set droute_advRouteLoop 25
```

droute_advancedRouteLoops

DESCRIPTION

The **droute_advancedRouteLoops** variable specifies the number of loops for the IC Compiler command **route_advanced**. If the value is set to N, it means that the **route_advanced** command stops after N loops.

SYNTAX

```
set droute_advancedRouteLoops value
```

The valid values of this variable range between 0 and 50. The default is 3.

EXAMPLE

To stop **route_advanced** after 15 loops, enter

```
set droute_advancedRouteLoops 15
```

droute_areaSrLoop

DESCRIPTION

The **droute_areaSrLoop** variable specifies the number of search and repair loops during area optimization and routing in the **axgAreaRoute** command. The search and repair loop terminates if DRC count reaches 0 even if the specified number of iterations are not reached. If the DRC number is still converging (reducing) after reaching the specified number of iterations, specifying more iterations could help reducing DRC count further, at the cost of more runtime.

SYNTAX

```
set droute_areaSrLoop value
```

The valid values of this variable range between 0 and 200. The default is 20.

EXAMPLE

To specify the number of search and repair loops during area optimization and routing as 50, enter

```
set droute_areaSrLoop 50
```

```
set droute_areaSrLoop
```

droute_autoSaveInterval

DESCRIPTION

The **droute_autoSaveInterval** variable specifies how frequent checkpoints (intermediate results) are saved during detail routing. If the value is set to 0, no checkpoint is saved during detail routing. Otherwise, the variable sets the time interval in minutes for each checkpoint to be saved.

SYNTAX

```
set droute_autoSaveInterval value
```

The valid values of this variable range between 0 and 14400. The default is 120.

EXAMPLE

To specify how frequent checkpoints (intermediate results) are saved during detail routing, enter

```
set droute_autoSaveInterval 150
```

droute_autoSrLoop

DESCRIPTION

The **droute_autoSrLoop** variable sets the number of search and repair loops to be carried out after initial routing. The search and repair loop terminates if a DRC violation count reaches 0 even if the specified number of iterations is not reached. If the DRC violation number is still converging (reducing) after reaching the specified number of iterations, specifying more iterations could further help in reducing the DRC violation count at the cost of more runtime.

SYNTAX

```
set droute_autoSrLoop value
```

The valid values of this variable range between 0 and 500. The default is 0.

EXAMPLE

To set the number of search and repair loops to be carried out after initial routing as 100, enter

```
set droute_autoSrLoop 100
```

droute_connBrokenNet

DESCRIPTION

The **droute_connBrokenNet** variable specifies whether broken nets are to be left broken or are to be reconnected. A broken net is a net that is not totally connected by glinks, preroutes, wires, or vias. If the value is set to 0, broken nets are ignored during detail routing. If the value is set to 1, broken nets are to be reconnected by detail routing. This variable does not affect tie-off connections, which are controlled by **the connTieOff** variable.

SYNTAX

set droute_connBrokenNet value

Value

Description

0

Ignores broken nets

1

Reconnects broken nets (the default)

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'

f2.a+
.mk 32
f2.b+
.mk 32

'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'
```



```
'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'
```

EXAMPLE

To ignore broken nets, enter

```
set droute_connBrokenNet 0
```

When set to 1, the broken nets are reconnected.

droute_connTieRail

DESCRIPTION

The **droute_connTieRail** variable specifies where to connect tie-off pins. If the value is set to 0, the router connects tie-off pins anywhere on power and ground nets. If the value is set to 1, the router connects tie-off pins to power and ground rails and power and ground pins only.

SYNTAX

set droute_connTieRail value

Value

Description

0

Connects tie-off pins anywhere (the default).

1

Connects tie pins only to power and ground rail, and power and ground pins.

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'
f2.a+
.mk 32
f2.b+
.mk 32

'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'
```

```
'|0's
(331'|
(TWu(u1's0      &
'|
(40u'
'|
(41u'
```

EXAMPLE

To connect tie pins only to power and ground rails and power and ground pins, enter

```
set droute_connTieRail 1
```

When set to 0, the tie-off pins can be connected anywhere.

droute_doMaxCapConx

DESCRIPTION

The **droute_doMaxCapConx** variable specifies whether maximum capacitance constraints should be met or ignored during in-route optimization (**axgAdvRouteOpt**). If the value is set to 0, the maximum capacitance constraints are ignored during in-route optimization. If the value is set to 1, in-route optimization tries to meet maximum capacitance constraints.

SYNTAX

set droute_doMaxCapConx value

Value

Description

0

Ignores maximum capacitance constraints.

1

Tries to meet maximum capacitance constraints during in-route optimization (the default).

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'

f2.a+
.mk 32
f2.b+
.mk 32

'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'
```

```
'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'
```

EXAMPLE

To ignore maximum capacitance constraints, enter

```
set droute_doMaxCapConx 0
```

droute_doMaxTransConx

DESCRIPTION

The **droute_doMaxTransConx** variable specifies whether maximum transition constraints should be met or ignored during in-route optimization (**axgAdvRouteOpt**). If the value is set to 0, the maximum transition constraints are ignored during in-route optimization. If the value is set to 1, in-route optimization tries to meet maximum transition constraints.

SYNTAX

set droute_doMaxTransConx value

Value

Description

0

Ignores the maximum transition constraints.

1

Tries to meet the maximum transition constraints during in-route optimization (the default).

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'

f2.a+
.mk 32
f2.b+
.mk 32

'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'
```

```
'|0's
(331'|
(TWu(ul's0
'|
(40u'
'|
(41u'
```

&

EXAMPLE

To ignore maximum transition constraints, enter

```
set droute_doMaxTransConx 0
```

droute_doProbeConx

DESCRIPTION

The **droute_doProbeConx** variable specifies whether nets with top-layer probe constraints are to be routed to top layer for probing.

SYNTAX

set droute_doProbeConx value

Value

Description

0

Ignores top-layer probe constraints (the default).

1

Nets with top-layer probe constraints are routed to top layer for probing.

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'

f2.a+
.mk 32
f2.b+
.mk 32

'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'

'|0's
```



```

(33l' |
(TWu (ul's0
' |
(40u'
' |
(41u'

```

EXAMPLE

To route the nets with top-layer probe constraints to the top layer for probing, enter

```
set droute_doProbeConx 1
```

droute_doSelectedNetAntennaConx

DESCRIPTION

The **droute_doSelectedNetAntennaConx** variable controls whether all antenna violations should be fixed or whether only antenna violations for specified nets should be fixed.

SYNTAX

set droute_doSelectedNetAntennaConx value

Value

Description

0

Fixes all antenna violations (the default)

1

Fixes antenna violations only for the specified nets

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'

                                f2.a+
                                .mk 32
                                f2.b+
                                .mk 32

'|0's
(331'|
(TWu(ul's0                                &
'|
(40u'
'|
(41u'
```

```
'|0's
(331'|
(TWu(u1's0
'|
(40u'
'|
(41u'
```

EXAMPLE

To fix antenna violation for specified nets only, enter

```
set droute_doSelectedNetAntennaConx 1
```

droute_doXtalkConx

DESCRIPTION

The **droute_doXtalkConx** variable specifies whether crosstalk constraints (such as static noise voltage constraints and capacitance constraints) are to be honored during in-route optimization (**axgAdvRouteOpt**).

SYNTAX

set droute_doXtalkConx value

Value

Description

0

Ignores crosstalk constraints (the default).

1

Honors crosstalk constraints.

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'

f2.a+
.mk 32
f2.b+
.mk 32

'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'
```

```
'|0's
(331'|
(TWu(u1's0
'|
(40u'
'|
(41u'
&
```

EXAMPLE

To honor cross-talk constraints, enter

```
set droute_doXtalkConx 1
```

droute_ecoListToFile

DESCRIPTION

The **droute_ecoListToFile** variable specifies whether to save the routing ECO list to the **ecoRoute.list** file.

SYNTAX

set droute_ecoListToFile value

Value

Description

0

Routing ECO list is not saved to the file, but it can still be found in the log file (the default).

1

Routing ECO list is output to the **ecoRoute.list** file.

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'
                                f2.a+
                                .mk 32
                                f2.b+
                                .mk 32
```

```
'|0's
(331'|
(TWu(ul's0                                &
'|
(40u'
'|
(41u'
```

droute_ecoListToFile

```
'|0's
(331'|
(TWu(u1's0      &
'|
(40u'
'|
(41u'
```

EXAMPLE

To dump a list of modified nets to the **ecoRoute.list** file, enter

```
set droute_ecoListToFile 1
```

droute_ecoMode

DESCRIPTION

The **droute_ecoMode** variable specifies what nets are to be routed in ECO mode, and how they are rerouted. If the value is set to 0, only modified nets can be rerouted. If the value is set to 1, modified nets are rerouted first, and other nets can be rerouted later. If the value is set to 2, any nets can be rerouted in any order. Mode 0 produces minimum routing change, but offers you the least freedom to resolve DRC violations. Mode 2 offers the most freedom to resolve DRC violations, but can introduce significant changes in the routing solution.

SYNTAX

```
set droute_ecoMode value
```

Value

Description

0

Reroutes modified nets only

1

Reroutes modified nets first, then tries other nets later

2

Reroutes any nets freely; best for routability (the default)

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'

f2.a+
.mk 32
f2.b+
.mk 32
```



```
'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'
```

```
'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'
```

```
'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'
```

EXAMPLE

To reroute modified nets only, enter

```
set droute_ecoMode 0
```

```
set droute_ecoMode
```

droute_ecoScope

DESCRIPTION

The **droute_ecoScope** variable specifies whether to use global or local scope during ECO routing. If the value set to 0, the router uses global scope mode. If the value is set to 1, the router uses local scope. Set this value to 0 if design has many violations. Set it to 1 to get better runtime if the design has very few violations.

SYNTAX

set droute_ecoScope value

Value

Description

0

Uses global scope if there are many violations all over the design (the default).

1

Uses local scope if there are very few localized violations (better runtime)

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'

f2.a+
.mk 32
f2.b+
.mk 32

'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'
```

```
'|0's
(331'|
(TWu(u1's0      &
'|
(40u'
'|
(41u'
```

EXAMPLE

To use local scope if there are very few localized violations, enter

```
set droute_ecoScope 1
```

droute_ecoSrLoop

DESCRIPTION

The **droute_ecoSrLoop** variable sets the number of search and repair loops to be carried out after ECO routing in the **axgECORouteDesign** or **astPostRT** command. The search and repair loop terminates if DRC violation count reaches 0 even if the specified number of iterations are not reached. If the DRC violation number is still converging (reducing) after reaching specified number of iterations, specifying more iterations could help further reduce DRC violation count at the cost of more runtime.

SYNTAX

set droute_ecoSrLoop value

The valid values of this variable range between 0 and 500. The default is 20.

EXAMPLE

To set the number of search and repair loops to be carried out after eco routing in **axgECORouteDesign** or **astPostRT** command as 90, enter the following:

```
set droute_ecoSrLoop 90
```

droute_enable_one_pass_partitioning

Specifies which partitioning algorithm to use for distributed routing.

TYPE

integer

DEFAULT

0

DESCRIPTION

The **droute_enable_one_pass_partitioning** variable specifies which partitioning algorithm to use for distributed processing of routing. The original partitioning algorithm is used when the variable is set to 0. The newly designed partitioning algorithm is used when the variable is set to 1. The one-pass partitioning algorithm improves the runtime of distributed processing of detail routing on large designs as compared to the default two-pass partitioning algorithm.

The valid value of the variable is 0 or 1. The default value is 0.

EXAMPLE

To enable the new partitioning algorithm, enter the following command:

```
prompt> set droute_enable_one_pass_partitioning 1
```

droute_expandFillTracks

DESCRIPTION

The **droute_expandFillTracks** variable specifies whether the track region for metal fill should be expanded or not.

SYNTAX

set droute_expandFillTracks value

Value

Description

0

The router inserts metal fills in core area only (the default).

1

The router expands track region for metal fill to cover whole design area.

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'

f2.a+
.mk 32
f2.b+
.mk 32

'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'

'|0's
```

```

(33l' |
(TWu(u1's0
'|
(40u'
'|
(41u'

```

EXAMPLE

To enable the router to expand the track region to cover the entire design area for metal fill, enter

```
set droute_expandFillTracks 1
```

droute_fillDataType

DESCRIPTION

The **droute_fillDataType** variable specifies a data type of filled metals. The value N is the data type of filled metals.

SYNTAX

set droute_fillDataType value

The valid values of this variable range between 0 and 256. The default is 0.

EXAMPLE

To specify the data type of filled metals as 90, enter

```
set droute_fillDataType 90
```


droute_fillEndByMinSpcPercent

DESCRIPTION

The **droute_fillEndByMinSpcPercent** variable specifies the spacing requirement between the routing wires and the ends of fill metal. If the value is set to -1, the normal required spacing is used between the routing wires and the ends of fill metal. Otherwise, the value sets the percentage of normal required spacing to be used between the routing wires and the ends of fill metal. Normally, this value is to be left at its default value of -1. It should only be changed if the user understands the impact of it on the yield, and the final verification should be set accordingly.

SYNTAX

```
set droute_fillEndByMinSpcPercent value
```

The valid values of this variable range between -1 and 10,000. The default is -1.

EXAMPLE

To use the same spacing for all sides between fill metal and routing wires as 500, enter

```
set droute_fillEndByMinSpcPercent 500
```

droute_fillMetalCloseToMinDensityValue

DESCRIPTION

The **droute_fillMetalCloseToMinDensityValue** variable specifies the target metal density for metal fill insertion. If the value is set to 0, the router tries to maximize dummy metals as long as maximum density is not violated. If the value is set to 1, the router tries to minimize dummy metals as long as minimum density is met.

SYNTAX

```
set droute_fillMetalCloseToMinDensityValue value
```

Value

Description

0

Fills metal to have metal density a little less than the maximum density value (the default).

1

Fills metal to have metal density a little more than the minimum density value.

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'

f2.a+
.mk 32
f2.b+
.mk 32
```

```
'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'
```

droute_fillMetalCloseToMinDensityValue

```
'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'
```

EXAMPLE

For fill metal to have metal density a little more than minimum density value, enter

```
set droute_fillMetalCloseToMinDensityValue 1
```

set droute_fillMetalCloseToMinDensityValue

droute_fillMetalUniformly

DESCRIPTION

The **droute_fillMetalUniformly** variable specifies whether to fill dummy metal uniformly. If the value is set to 0, the router fills dummy metal in contiguous tracks. If the value is set to 1, the router tries to fill dummy metal uniformly in each window to meet the density rule.

SYNTAX

```
set droute_fillMetalUniformly value
```

Value

Description

0

Fills metal in contiguous tracks to meet density rule (the default).

1

Fills metal uniformly in each window to meet density rule.

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'

f2.a+
.mk 32
f2.b+
.mk 32
```

```
'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'
```

```
'|0's
(331'|
(TWu(u1's0      &
'|
(40u'
'|
(41u'
```

EXAMPLE

To specify fill metal uniformly in each window to meet the density rule, enter

```
set droute_fillMetalUniformly 1
```

droute_fillViaDataType

DESCRIPTION

The **droute_fillViaDataType** variable specifies a data type of filled vias. If the value set to N, N is the data type of filled via.

SYNTAX

set droute_fillViaDataType value

The valid values of this variable range between 0 and 256. The default is 0.

EXAMPLE

To specify the data type of filled vias, enter

```
set droute_fillViaDataType 70
```

droute_fixMinEdgeLengthByFilling

DESCRIPTION

The **droute_fixMinEdgeLengthByFilling** variable specifies whether to allow filling metals to fix **minEdgeLength** violations during search and repair.

SYNTAX

set droute_fixMinEdgeLengthByFilling value

Value

Description

0

No filling to resolve **non-pin minEdgeLength** violations during search and repair (the default).

1

Allow filling to resolve **non-pin minEdgeLength** violations during search and repair.

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'

f2.a+
.mk 32
f2.b+
.mk 32

'|0's
(331'|
(TWu(ul's0
'|
(40u'
'|
(41u'

&
```

```
'|0's
(331'|
(TWu(u1's0
'|
(40u'
'|
(41u'
&
```

EXAMPLE

To allow filling for resolving non-pin **minEdgeLength** violations during search and repair, enter

```
set droute_fixMinEdgeLengthByFilling 1
```


droute_followPolyTrkForPolyFill

DESCRIPTION

The **droute_followPolyTrkForPolyFill** variable specifies to whether tracks on poly layer are used for poly fills. If the value is set to 0, the router follows M2 tracks to fill poly layer. If the value is set to 1, the router follows poly tracks to fill poly layer.

SYNTAX

set droute_followPolyTrkForPolyFill value

Value

Description

0

Follows M2 tracks for metal fill on poly layer (the default).

1

Follows poly tracks for metal fill on poly layer.

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'
f2.a+
.mk 32
f2.b+
.mk 32
```

```
'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'
```

```
'|0's
(331'|
(TWu(u1's0
'|
(40u'
'|
(41u'
```

EXAMPLE

To specify whether the router should follow poly tracks for metal fill on the poly layer, enter

```
set droute_followPolyTrkForPolyFill 1
```

droute_groupSrLoop

DESCRIPTION

The **droute_groupSrLoop** variable specifies the number of search and repair loops in the **axgRouteGroup** command. The search and repair loop terminates if DRC violation count reaches 0 even if the specified number of iterations are not reached. If the DRC violation number is still converging (reducing) after reaching specifies number of iterations, specifying more iterations could help reducing DRC violation count further at the cost of more runtime.

SYNTAX

set droute_groupSrLoop value

The valid values of this variable range between 0 and 200. The default is 5.

EXAMPLE

To specify five search and repair loops in the **axgRouteGroup** command, enter

```
set droute_groupSrLoop 5
```

droute_lowSkewClkRoute

DESCRIPTION

The **droute_lowSkewClkRoute** variable specifies how many changes are allowed on nets from clock tree synthesis during detail routing. If the value is set to 0, nets from clock tree synthesis are treated the same as other nets. If the value is set to 1, minimal changes are to be made to nets from clock tree synthesis, if necessary.

SYNTAX

set droute_lowSkewClkRoute value

Value

Description

0

Normal routing.

1

Minimize changes on nets from clock tree synthesis (the default).

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'

f2.a+
.mk 32
f2.b+
.mk 32

'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'
```

```
'|0's
(331'|
(TWu(u1's0
'|
(40u'
'|
(41u'
&
```

EXAMPLE

For normal routing, enter

```
set droute_lowSkewClkRoute 0
```

droute_maxOffGridTrack

DESCRIPTION

The **droute_maxOffGridTrack** variable specifies how off-grid tracks are to be added for off-grid pins and off-grid feedthroughs. If the value is set to 0, off-grid tracks are added selectively in via regions, which are determined by the router. If the value is set to 1, as many off-grid tracks as possible are added for off-grid pins. If the value is set to 2, 3, or 4, more off-grid tracks are aggressively added in increasing order for off-grid feedthroughs and pins. By creating as many off-grid tracks as possible for off-grid pins, the router has the maximum flexibility in accessing these pins, at the cost of more routing time. It is recommended to leave **droute_maxOffGridTrack** variable at the default value of 0 to start with if the you do not know how bad the off-grid situation is, and gradually increase the value if the results suffer from off-grid pin access or off-grid feedthrough usage. If you know beforehand that there will be off-grid difficulty from previous experience, **droute_maxOffGridTrack** can be set to higher value to start with. You can also set the value to -1. This lets the router start from 0 and then automatically and gradually increase to 1, 2, 3, 4 during search and repair. The side effect of setting **droute_maxOffGridTrack** to a higher value is increased runtime.

SYNTAX

set droute_maxOffGridTrack value

Value

Description

-1

This is a combination from 0 to 4.

0

Selectively adds off-grid tracks (the default)

1

Adds as many off-grid tracks as possible for off-grid pins. This should resolve problems caused by hard-to-access pins.

2

Adds more off-grid tracks for off-grid feedthroughs

3,4

Adds even more off-grid tracks for off-grid feedthroughs

```
'|0's
(331'|
(TWu(u1's0  &
'|
(40u'
'|
(41u'

f2.a+
.mk 32
f2.b+
.mk 32
```

```
'|0's
(331'|
(TWu(u1's0      &
'|
(40u'
'|
(41u'
```

```
'|0's
(331'|
(TWu(u1's0      &
'|
(40u'
'|
(41u'
```

```
'|0's
(331'|
(TWu(u1's0      &
'|
(40u'
'|
(41u'
```

```
'|0's
(331'|
(TWu(u1's0      &
```

```
' |  
(40u'  
' |  
(41u'
```

```
' | 0's  
(331' |  
(TWu(u1's0  
' |  
(40u'  
' |  
(41u'
```

&

EXAMPLE

To selectively add off-grid tracks, enter

```
set droute_maxOffGridTrack 0
```


droute_maxTieOffDistance

DESCRIPTION

The **droute_maxTieOffDistance** variable specifies the search distance to connect tieoffs. If the value is set to -1, there is no search distance limit to connect tieoffs. Otherwise, the variable specifies the search distance for the search engine to use in number of gcells to connect tieoffs.

SYNTAX

```
set droute_maxTieOffDistance value
```

The valid values of this variable range between -1 and 20,000. The default is 10.

EXAMPLE

To specify no limit on the search distance, enter

```
set droute_maxTieOffDistance -1
```

droute_metalFillDensityIncrement

DESCRIPTION

The **droute_metalFillDensityIncrement** variable specifies increment value for metal fill. If the value is set to N, the router targets metal density N percent higher than minimum density during dummy metal insertion. The value N specifies the increment from **minDensity** value for metal fill. It is used when **fillMetalCloseToMinDensityValue** is enabled. For example, if **minDensity** (in the technology file) is 20 percent and **droute_metalFillDensityIncrement** is set as 10 percent, target density of metal fill will be 30 percent.

SYNTAX

set droute_metalFillDensityIncrement value

The valid values of this variable range between 0 and 100. The default is 10.

EXAMPLE

To specify increment value for metal fill as 50, enter

```
set droute_metalFillDensityIncrement 50
```

droute_minLengthCheckCutMode

DESCRIPTION

The **droute_minLengthCheckCutMode** variable specifies how to compute minimum length when a polygon completely encloses a via. If the value is set to 0, the router does not check whether a wire completely encloses via. If the value is set to 1, the router checks whether a wire completely encloses via. When a via connects more than one wire segment on the same metal layer, minimum length is checked against the longest wire that completely encloses the via. When a via connects only to single wire segment on one metal layer, the wire needs to be checked for minimum length rule.

SYNTAX

set droute_minLengthCheckCutMode value

Value

Description

0

Does not check overlapping cuts (the default).

1

Checks overlapping cuts on less than minLength segments.

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'

f2.a+
.mk 32
f2.b+
.mk 32
```

```
'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
```

```
' |  
(41u'
```

```
' | 0's  
(331' |  
(TWu (ul's0 &  
' |  
(40u'  
' |  
(41u'
```

EXAMPLE

To check overlapping cuts on less than minimum length segments, enter

```
set droute_minLengthCheckCutMode 1
```

When set to 0, the overlapping cuts are not checked.

droute_minShieldLength

DESCRIPTION

The **droute_minShieldLength** variable specifies minimum length for a wire to be shielded in the unit of pitches. For example, if the variable is left at its default value of 4, only the wires longer than 4 pitches are shielded.

SYNTAX

set droute_minShieldLength value

The valid values of this variable range between 0 and 100. The default is 4.

EXAMPLE

To specify the minimum length for a wire to be shielded as 20, enter

```
set droute_minShieldLength 20
```

droute_numCPUs

DESCRIPTION

The **droute_numCPUs** variable specifies the number of CPUs to be used for distributed routing.

SYNTAX

set droute_numCPUs value

The valid values of this variable range between 0 and 63. The default is 0.

EXAMPLE

To use a single CPU mode, enter

```
set droute_numCPUs 1
```

droute_offGridCost

DESCRIPTION

The **droute_offGridCost** variable specifies extra off-grid routing cost. The default on-grid unit wire cost is 1. Therefore, if the value is set to 0, off-grid routes have the same cost as on-grid cost, and wires are routed as in a gridless router. If the value is set to N, off grid unit wire cost becomes $1 + N$. This variable can be used to encourage or discourage off-grid routing against on-grid routing.

SYNTAX

`set droute_offGridCost value`

The valid values of this variable range between 0 and 5. The default is 1.

EXAMPLE

To route as a gridless router, enter

```
set droute_offGridCost 0
```

droute_offsetFillTrack

DESCRIPTION

The **droute_offsetFillTrack** variable specifies how to offset the metal fill track.

SYNTAX

set droute_offsetFillTrack value

Value

Description

0

The router automatically determines the initial track for metal fill (the default).

1

The router offsets initial track by half fill-pitch.

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'
f2.a+
.mk 32
f2.b+
.mk 32
```

```
'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'
```

```
'|0's
(331'|
```



```
(TWu(ul's0  
'|  
(40u'  
'|  
(41u'&
```

EXAMPLE

To enable the router to offset the initial track by half fill-pitch, enter

```
set droute_offsetFillTrack 1
```

droute_optDelaySlackTarget

DESCRIPTION

The **droute_optDelaySlackTarget** variable specifies slack target for delay optimization during in-route optimization (**axgAdvRouteOpt**).

SYNTAX

set droute_optDelaySlackTarget value

The valid values of this variable range between -100.000 and 100.000. The default is 0.100.

EXAMPLE

To specify slack target for delay optimization during in-route optimization as 90, enter

```
set droute_optDelaySlackTarget 90.000
```

droute_optDelaySrLoop

DESCRIPTION

The **droute_optDelaySrLoop** variable specifies the number of search and repair loops after delay optimization in the **axgAdvRouteOpt** or **astPostRouteOpt** command. The search and repair loop terminates if DRC violation count reaches 0 even if the specified number of iterations is not reached. If the DRC violation number is still converging (reducing) after reaching the specified number of iterations, specifying more iterations could help reduce DRC violation count further at the cost of more runtime.

SYNTAX

```
set droute_optDelaySrLoop value
```

The valid values of this variable range between 0 and 200. The default is 5.

EXAMPLE

To specify the number of search and repair loops as 5 after delay optimization in **axgAdvRouteOpt** or **astPostRouteOpt** command, enter the following:

```
set droute_optDelaySrLoop 5
```

droute_optSetup

DESCRIPTION

The **droute_optSetup** variable specifies whether setup slack is to be maintained or improved during in-route optimization. If the value is set to 0, the router tries to maintain setup slack, and does not try to improve the slack. If the value is set to 1, the router tries to improve setup slack.

SYNTAX

set droute_optSetup value

Value

Description

0

The router tries to maintain setup slack, and does not try to improve the slack.

1

The router tries to improve setup slack (the default).

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'

f2.a+
.mk 32
f2.b+
.mk 32

'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'
```

```
'|0's
(331'|
(TWu(u1's0      &
'|
(40u'
'|
(41u'
```

EXAMPLE

To maintain setup slack, enter

```
set droute_optSetup 0
```

droute_optSrLoop

DESCRIPTION

The **droute_optSrLoop** variable specifies the number of search and repair loops after route optimization in **axgRoutOpt** command. The search and repair loop terminates if DRC violation count reaches 0 even if the specified number of iterations is not reached. If the DRC violation number is still converging (reducing) after reaching specified number of iterations, specifying more iterations could help reduce DRC violation count further at the cost of more runtime.

SYNTAX

```
set droute_optSrLoop value
```

The valid values of this variable range between 0 and 200. The default is 20.

EXAMPLE

To specify the number of search and repair loops after route optimization as 20, enter

```
set droute_optSrLoop 20
```

droute_optViaHoldTimeThreshold

DESCRIPTION

The **droute_optViaHoldTimeThreshold** variable specifies the hold time threshold for contact optimization. If the value is set to N, the router tries to preserve hold time by not inserting redundant vias for the nets whose hold time is worse than N.

SYNTAX

set droute_optViaHoldTimeThreshold value

The valid values of this variable range between -1000000.000 and 1000000.000. The default is 0.000.

EXAMPLE

To specify the hold time threshold for contact optimization as 800, enter

```
set droute_optViaHoldTimeThreshold 800.000
```

```
set droute_optViaHoldTimeThreshold
```

droute_optViaSetupSlackThreshold

DESCRIPTION

The **droute_optViaSetupSlackThreshold** variable specifies the setup slack threshold for contact optimization. If the value is set to N, the router tries to preserve setup time by not inserting redundant vias for the nets whose setup slack is worse than N.

SYNTAX

`set droute_optViaSetupSlackThreshold value`

The valid values of this variable range between -1000000.000 and 1000000.000. The default is -0.100.

EXAMPLE

To specify the setup slack threshold for contact optimization as -800, enter

```
set droute_optViaSetupSlackThreshold
```

```
set droute_optViaSetupSlackThreshold
```


droute_optViaSrLoop

DESCRIPTION

The **droute_optViaSrLoop** variable specifies search and repair loops after contact optimization. If the value set to N, the router runs N loops of search and repair after contact optimization.

SYNTAX

```
set droute_optViaSrLoop value
```

The valid values of this variable range between 0 and 100. The default is 1.

EXAMPLE

To specify search and repair loops after contact optimization as 40, enter

```
set droute_optViaSrLoop 40
```

droute_optViaTimingDriven

DESCRIPTION

The **droute_optViaTimingDriven** variable specifies whether to preserve timing for critical nets with timing violations. If the value is set to 0, the router does contact optimization for all nets. If the value is set to 1, the router tries to preserve timing for critical nets by not doing contact optimization on those nets.

SYNTAX

set droute_optViaTimingDriven value

Value

Description

0

Performs contact optimization for all nets (the default).

1

The router tries to preserve timing for critical nets by not doing contact optimization on those nets.

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'
f2.a+
.mk 32
f2.b+
.mk 32
```

```
'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'
```

```
'|0's
(331'|
(TWu(u1's0      &
'|
(40u'
'|
(41u'
```

EXAMPLE

To perform contact optimization for all nets, enter the following:

```
set droute_optViaTimingDriven 0
```

droute_optimizeRouteGroup

DESCRIPTION

The **droute_optimizeRouteGroup** variable specifies whether optimization is to be run in the **axgRouteGroup** command. Skipping optimization at the end of the route net group could save some runtime.

SYNTAX

set droute_optimizeRouteGroup value

Value

Description

0

Optimization is skipped at the end of route net group command.

1

Optimization is run at the end of route net group command (the default).

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'

f2.a+
.mk 32
f2.b+
.mk 32

'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'
```

```
'|0's
(331'|
(TWu(u1's0
'|
(40u'
'|
(41u'
&
```

EXAMPLE

To skip optimization at the end of the route net group command, enter

```
set droute_optimizeRouteGroup 0
```

droute_parallelLengthMode

DESCRIPTION

The **droute_parallelLengthMode** variable specifies how to compute parallel length for the fat metal spacing rule. If the value is set to 0, the router merges fat neighboring shapes only and determines parallel length based on the merged fat wire. If the value is set to 1, the router merges all neighboring (fat and thin) shapes and the total length of the merged wire will be used to compute the parallel length.

SYNTAX

```
set droute_parallelLengthMode value
```

Value

Description

0

Merges with fat neighboring shapes only (the default).

1

Merges with all neighboring shapes.

```
'|0's
(33l'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'
f2.a+
.mk 32
f2.b+
.mk 32
```

```
'|0's
(33l'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'
```

```
'|0's
(331'|
(TWu(u1's0      &
'|
(40u'
'|
(41u'
```

EXAMPLE

To merge the router with all neighboring shapes, enter `axSetIntParam "droute" "droute_parallelLengthMode" 1`

When set to 0, the router merges with fat neighboring shapes only.

droute_pinTaperLengthLimit

DESCRIPTION

The **droute_pinTaperLengthLimit** variable specifies the limit for pin tapering length. If the value is set to -1, there is no limit for tapering length, and tapering should go all the way to the Steiner point. Otherwise, this variable specifies the tapering length limit in the units of routing pitches.

SYNTAX

```
set droute_pinTaperLengthLimit value
```

The valid values of this variable range between -1 and 1,000,000. The default is 10.

EXAMPLE

To specify the limit for pin tapering length as 20, enter

```
set droute_pinTaperLengthLimit 20
```


droute_pinTaperMode

DESCRIPTION

The **droute_pinTaperMode** variable specifies pin tapering width. If the value is set to 0, the tapering width is the default width. If the value is set to 1, the tapering width is the pin width.

SYNTAX

set droute_pinTaperMode value

Value

Description

0

Tapers to default width.

1

Tapers to pin width (the default).

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'

f2.a+
.mk 32
f2.b+
.mk 32

'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'
```

```
'|0's
(331'|
(TWu(u1's0
'|
(40u'
'|
(41u'
&
```

EXAMPLE

To specify tapering width as the default width, enter

```
set droute_pinTaperMode 0
```

droute_reportLimit

DESCRIPTION

The **droute_reportLimit** variable specifies the maximum number of DRC violations that the router reports. If the value is set to -1, no limit is set, and the router reports all DRC violations. Otherwise, the value specifies the maximum number of DRC violations to be reported.

SYNTAX

```
set droute_reportLimit value
```

The valid values of this variable range between -1 and 10,000. The default is 200.

EXAMPLE

To report 500 DRC violations, enter

```
set droute_reportLimit 500
```

droute_rerouteUserWire

DESCRIPTION

The **droute_rerouteUserWire** variable specifies whether user-created wires and vias are to be treated as fixed or reroutable.

SYNTAX

set droute_rerouteUserWire value

Value

Description

0

User-created wires and vias (such as the wires created in layout editor) are treated as fixed (the default).

1

User-created wires and vias are reroutable.

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'
f2.a+
.mk 32
f2.b+
.mk 32
```

```
'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'
```

```
'|0's
(331'|
(TWu(u1's0
'|
(40u'
'|
(41u'
&
```

EXAMPLE

To reroute user-created wires, enter

```
set droute_rerouteUserWire 1
```

droute_rerunDRC

DESCRIPTION

The **droute_rerunDRC** variable specifies whether DRC violations are regenerated before search and repair.

SYNTAX

set droute_rerunDRC value

Value

Description

0

DRC violations from previous results are used by search and repair (the default).

1

DRC violations are regenerated before search and repair.

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'

f2.a+
.mk 32
f2.b+
.mk 32

'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'

'|0's
```

```
(33l' |  
(TWu(u1's0  
' |  
(40u'  
' |  
(41u' &
```

EXAMPLE

To recheck violations before search and repair, enter

```
set droute_rerunDRC 1
```

droute_resetMinMaxLayer

DESCRIPTION

The **droute_resetMinMaxLayer** variable resets minimum-maximum rule constraints defined by **axgSetMinMaxLayer** and **axgSetNetConstraint** commands before search and repair.

SYNTAX

set droute_resetMinMaxLayer value

Value

Description

0

Does not change layer of wires before search and repair (the default).

1

Resets the layer of all wires based on the minimum and maximum rule before starting search and repair.

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'

f2.a+
.mk 32
f2.b+
.mk 32

'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'
```



```
'|0's
(331'|
(TWu(u1's0
'|
(40u'
'|
(41u'
&
```

EXAMPLE

To reset the layer of all wires based on the minimum-maximum rule before starting search and repair, enter

```
set droute_resetMinMaxLayer 1
```

droute_shieldLimitSboxExt

DESCRIPTION

The **droute_shieldLimitSboxExt** variable specifies the processing of routing area Sboxes during shielding, and is used to speed shielding up by limiting routing area Sbox extension size to technology file minSpacing layer parameters in such routing areas. The default is to maximize Sbox extension size by technology file fat layer parameters, which in some cases produces more accurate results, but contributes to increased shielding run time.

SYNTAX

set droute_shieldLimitSboxExt value

Value

Description

0

Sbox extension maximized by fat parameters in tech file (the default).

1

Sbox extension limited to tech file layer minSpacing (for speed-up)

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'

f2.a+
.mk 32
f2.b+
.mk 32

'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'
```

```
'|0's
(331'|
(TWu(ul's0
'|
(40u'
'|
(41u'
```

EXAMPLE

To speed shielding up by limiting routing area Sbox extension size, enter

```
set droute_shieldLimitSboxExt 1
```

droute_shieldRerouteSignalNets

DESCRIPTION

The **droute_shieldRerouteSignalNets** variable specifies whether to reroute signal nets during shielding. If the value is set to 0, the router does not reroute signal nets to improve shielding coverage. If the value is set to 1, the router reroutes signal nets and possibly creates minimized DRC violations as a tradeoff of improved shielding coverage. You need to run search and repair after shielding if DRC violations are created on signal nets.

SYNTAX

set droute_shieldRerouteSignalNets value

Value

Description

0

The router does not reroute signal nets to improve shielding coverage (the default).

1

The router reroutes signal nets and possibly creates minimized DRC violations as a trade-off of improved shielding coverage.

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'

f2.a+
.mk 32
f2.b+
.mk 32

'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
```

(41u'

'|0's

(331'|

(TWu(u1's0

&

'|

(40u'

'|

(41u'

EXAMPLE

To enable the router reroute signal nets and possibly create minimized DRC violations as a trade-off of improved shielding coverage, enter

```
set droute_shieldRerouteSignalNets 1
```

droute_shieldSkipNotShieldedSboxes

DESCRIPTION

The **droute_shieldSkipNotShieldedSboxes** variable specifies the processing of routing area Sboxes that have no shielding, and is used to speed shielding up by skipping checking for DRC violations in such routing areas.

SYNTAX

set droute_shieldSkipNotShieldedSboxes value

Value

Description

0

Check DRC in all Sboxes, even with no shielding (the default).

1

Skip check DRC in Sboxes with no shielding (for speed-up)

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'

f2.a+
.mk 32
f2.b+
.mk 32

'|0's
(331'|
(TWu(ul's0
'|
(40u'
'|
(41u'

&
```

```
'|0's
(331'|
(TWu(u1's0
'|
(40u'
'|
(41u'
```

EXAMPLE

To speed shielding up by skipping routing area Sboxes that have no shielding, enter

```
set droute_shieldSkipNotShieldedSboxes 1
```

droute_shieldViaMinSpacing

DESCRIPTION

The **droute_shieldViaMinSpacing** variable specifies the spacing requirement on shielded vias. If the value is set to 0, the specified spacing from the GUI form for shielding wires is used to shield vias. If the value is set to 1, minimum spacing is used to shield vias to minimize routing resource usage.

SYNTAX

```
set droute_shieldViaMinSpacing value
```

Value

Description

0

Shields via with specifies spacing same as wires (the default).

1

Shields via with min-spacing only to minimize overhead.

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'
f2.a+
.mk 32
f2.b+
.mk 32
```

```
'|0's
(331'|
(TWu(ul's0
'|
(40u'
'|
(41u'
&
```



```
'|0's
(331'|
(TWu(u1's0      &
'|
(40u'
'|
(41u'
```

EXAMPLE

To shield vias with minimum spacing only to minimize overhead, enter

```
set droute_shieldViaMinSpacing 1
```

droute_smallJogMinLength

DESCRIPTION

The **droute_smallJogMinLength** variable specifies the minimum length of a small jog. If the value is set to 0, the router does consider the small jog recommended rule. If the value is set to N, the router reports and fixes the small jog violation if the jog length is less than (N) times a quarter pitch.

SYNTAX

```
set droute_smallJogMinLength value
```

The valid values of this variable range between 0 and 2. The default is 0.

EXAMPLE

To specify the minimum length of a small jog as 1, enter

```
set droute_smallJogMinLength 1
```

droute_srLoop

DESCRIPTION

The **droute_srLoop** variable sets the number of search and repair loops in the search and repair phase in **axgSearchRepair** command. The search and repair loop terminates if DRC violation count reaches 0 even if the specified number of iterations is not reached. If the DRC violation number is still converging (reducing) after reaching specified number of iterations, specifying more iterations could help further reduce DRC violation count at the cost of more runtime.

SYNTAX

set droute_srLoop value

The valid values of this variable range between 0 and 1000. The default is 50.

EXAMPLE

To set the number of search and repair loops as 50 in the search and repair phase in **axgSearchRepair** command, enter

```
set droute_srLoop 50
```

droute_stopIfNoLicense

DESCRIPTION

The **droute_stopIfNoLicense** variable flags whether to stop the router or continue if the tool cannot obtain the option license. If the value is set to 0, the router continues by ignoring certain constraints if the router fails to get the corresponding option license. If the value is set to 1, the router will exit if it fails to get the needed option license.

SYNTAX

```
set droute_stopIfNoLicense value
```

Value

Description

0

Continues by ignoring certain constraints if the router fails to get option license (the default).

1

Exits router if the router fails to get option license.

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'
f2.a+
.mk 32
f2.b+
.mk 32
```

```
'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'
```

```
'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'
```

EXAMPLE

To ensure that the router exits if it fails to get the needed option license, enter

```
set droute_stopIfNoLicense 1
```

droute_timeLimit

DESCRIPTION

The **droute_timeLimit** variable specifies the corresponding detail routing step runtime limit. If the value is set to -1, no runtime limit is set. Otherwise, the variable sets the runtime limits in minutes. This is a very useful variable if you have a time limit and do not care about the final number of DRC violations as much. For example, you might want to get the feeling of how "routable" a design is in a given amount of time. Not all detail routing steps support time limits, such as **axgAutoRoute** and **axgGlobalRoute**. You can check the GUI form to see which routing steps support time limits.

SYNTAX

```
set droute_timeLimit value
```

The valid values of this variable range between -1 and 14400. The default is -1.

EXAMPLE

To specify the corresponding detail routing step runtime limit as 1000, enter

```
set droute_timeLimit 1000
```

droute_timingDriven

DESCRIPTION

The **droute_timingDriven** variable specifies whether timing-critical nets with setup violations are to be optimized during initial detail routing. If the value is set to 0, timing-critical nets with setup violations are not optimized. If the value is set to 1, timing-critical nets with setup violations are optimized. By setting the value to 1, initial detail routing tries to generate routes with less resistance and capacitance (shorter wires and fewer vias) for timing-critical nets.

SYNTAX

set droute_timingDriven value

Value

Description

0

Regular routing (the default).

1

Optimizes timing-critical (setup slack) nets.

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'
f2.a+
.mk 32
f2.b+
.mk 32
```

```
'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'
```

```
'|0's
(331'|
(TWu(u1's0
'|
(40u'
'|
(41u'
&
```

EXAMPLE

For regular routing, enter

```
set droute_timingDriven 1
```


droute_timingSpace

DESCRIPTION

The **droute_timingSpace** variable specifies whether the detailed router should try to allocate extra same-layer spacing to timing-critical net wires.

SYNTAX

set droute_timingSpace value

Value

Description

0

Normal routing (the default).

1

Reduce intra-layer capacitance on critical nets.

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'

f2.a+
.mk 32
f2.b+
.mk 32

'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'

'|0's
```

```

(331' |
(TWu(u1's0
'|
(40u'
'|
(41u'

```

EXAMPLE

To reduce intra-layer capacitance on critical nets, enter

```
set droute_timingSpace 1
```

droute_treatTiedFillAsFillToFillSpacing

DESCRIPTION

The **droute_treatTiedFillAsFillToFillSpacing** variable specifies whether fill-to-fill spacing is applied to tied fills. If the value is set to 0, the router follows fill-to-route spacing for tied fills during metal fill. If the value is set to 1, the router follows fill-to-fill spacing for tied fills.

SYNTAX

set droute_treatTiedFillAsFillToFillSpacing value

Value

Description

0

Uses fill2-route spacing for existing tied fill during metal fill (the default).

1

Uses fill2-fill spacing for existing tied fill during metal fill.

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'

                                f2.a+
                                .mk 32
                                f2.b+
                                .mk 32

'|0's
(331'|
(TWu(ul's0                                &
'|
(40u'
'|
(41u'
```

```
'|0's
(331'|
(TWu(ul's0
'|
(40u'
'|
(41u'
&
```

EXAMPLE

To use fill2-fill spacing for existing tied fill during metal fill, enter

```
set droute_treatTiedFillAsFillToFillSpacing 1
```

droute_trimUserAntenna

DESCRIPTION

The **droute_trimUserAntenna** variable determines how user-created dangling wires are handled. This is useful for creating a long bus, and the router can trim the unused part after connecting pins to the bus. Note that antenna here means dangling wires.

SYNTAX

set droute_trimUserAntenna value

Value

Description

0

User-created dangling wires are not deleted (the default).

1

User-created dangling wires (for example, prerouted bus) are trimmed after search and repair or route-net group.

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'

f2.a+
.mk 32
f2.b+
.mk 32

'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'
```

```
'|0's
(331'|
(TWu(u1's0      &
'|
(40u'
'|
(41u'
```

EXAMPLE

To trim user-created dangling wires after search and repair, enter

```
set droute_trimUserAntenna 1
```

droute_ultraWideWireMode

DESCRIPTION

The **droute_ultraWideWireMode** variable specifies the routing grids used for ultra wide wire routing. If the value is set to 0, regular routing grids are used. If the value is set to 1, wide routing grids are used. If the value is set to a larger value, even wider grids are used. Setting a large value for ultra wide wires can lead to fast routing time due to coarser grids for them. This is useful for the flip-chip designs.

SYNTAX

```
set droute_ultraWideWireMode value
```

Value

Description

0

Regular routing (the default).

1

Uses wide grids to route ultra-wide wires.

2-4

Use even wider grids

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'
                                f2.a+
                                .mk 32
                                f2.b+
                                .mk 32

'|0's
```

```

(331' |
(TWu(ul's0
'|
(40u'
'|
(41u'

```

```

'|0's
(331' |
(TWu(ul's0
'|
(40u'
'|
(41u'

```

```

'|0's
(331' |
(TWu(ul's0
'|
(40u'
'|
(41u'

```

EXAMPLE

To use wide grids to route ultra-wide wires, enter

```
set droute_ultraWideWireMode 1
```


droute_wireWidenForceWrongWay

DESCRIPTION

The **droute_wireWidenForceWrongWay** variable specifies whether to force widened wrong-way wires. If the value is set to 0, the router does not force widened wrong-way wires. If the value is set to 1, the router forces widened wrong-way wires to improve coverage of widened wires.

SYNTAX

set droute_wireWidenForceWrongWay value

Value

Description

0

Does not force widen wrong way wires (the default).

1

Force widen wrong way wires.

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'
f2.a+
.mk 32
f2.b+
.mk 32
```

```
'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'
```

```
'|0's
(331'|
(TWu(u1's0      &
'|
(40u'
'|
(41u'
```

EXAMPLE

To force widening wrong way wires, enter

```
set droute_wireWidenForceWrongWay 1
```

droute_wireWidenIgnoreMinEdgeLengthVio

DESCRIPTION

The **droute_wireWidenIgnoreMinEdgeLengthVio** variable specifies whether to ignore the minimum edge length rule during wire widening. If the value is set to 0, the router checks all DRC violations during wire widening. If the value is set to 1, the router does not check the minimum edge length violation during wire widening.

SYNTAX

```
set droute_wireWidenIgnoreMinEdgeLengthVio value
```

Value

Description

0

Uses try mode to detect DRC violation when widening wire. Checks all DRC violation types (the default).

1

Closes minimum edge length DRC violation checking in try mode.

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'
f2.a+
.mk 32
f2.b+
.mk 32
```

```
'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'
```

```
'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'
```

EXAMPLE

To close minimum edge length DRC violation checking in try mode, enter

```
set droute_wireWidenIgnoreMinEdgeLengthVio 1
```

```
set droute_wireWidenIgnoreMinEdgeLengthVio
```

droute_wireWidenPieceWise

DESCRIPTION

The **droute_wireWidenPieceWise** variable specifies whether to widen a wire segment uniformly or to widen it piece by piece. If the value is set to 0, the router will widen a wire segment uniformly. If the value is set to 1, the router first breaks a wire into several pieces according to its neighboring routing objects, then tries to widen each piece with different width. This nonuniform widening can improve coverage of widened wires.

SYNTAX

```
set droute_wireWidenPieceWise value
```

Value

Description

0

Uniformly widens a wire (the default).

1

Breaks a wire according to its neighboring routing objects. Then it tries to widen each segment with different width.

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'

f2.a+
.mk 32
f2.b+
.mk 32
```

```
'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
```

```
(41u'
```

```
'|0's
```

```
(331'|
```

```
(TWu(ul's0
```

```
&
```

```
'|
```

```
(40u'
```

```
'|
```

```
(41u'
```

EXAMPLE

To break a wire according to its neighboring routing objects and then widen each segment with different width, enter

```
set droute_wireWidenPieceWise 1
```

droute_wireWidenSrLoop

DESCRIPTION

The **droute_wireWidenSrLoop** variable specifies the number of search and repair loops after wire widening. If the value is set to N, the router runs N loops of search and repair after wire widening to fix DRC violations created during wire widening.

SYNTAX

```
set droute_wireWidenSrLoop value
```

The valid values of this variable range between 0 and 100. The default is 10.

EXAMPLE

To specify 20 search and repair loops after wire widening, enter

```
set droute_wireWidenSrLoop 20
```

droute_wireWidenTimingDriven

DESCRIPTION

The **droute_wireWidenTimingDriven** variable specifies whether to widen wires on timing-critical nets. If the value is set to 0, the router does wire widening on all signal wires. If the value is set to 1, the router does not widen wires on timing-critical nets.

SYNTAX

set droute_wireWidenTimingDriven value

Value

Description

0

Does wire widening on all signal wires (the default).

1

Freezes timing-critical nets when wire widening.

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'
f2.a+
.mk 32
f2.b+
.mk 32
```

```
'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'
```



```
'|0's
(331'|
(TWu(u1's0      &
'|
(40u'
'|
(41u'
```

EXAMPLE

To enable the router to freeze timing-critical nets while widening wires, enter

```
set droute_wireWidenTimingDriven 1
```

droute_wireWidenWidthScheme

DESCRIPTION

The **droute_wireWidenWidthScheme** variable specifies how many different widths are used for wire widening. If the value is set to N, the router tries N different widths during wire widening.

SYNTAX

```
set droute_wireWidenWidthScheme value
```

The valid values of this variable ranges between 1 and 5. The default is 2.

EXAMPLE

To specify four different widths during wire widening, enter

```
set droute_wireWidenWidthScheme 4
```

droute_wrongWayExtraCost

DESCRIPTION

The **droute_wrongWayExtraCost** variable specifies extra wrong-way wire cost. The default wrong-way unit distance cost is 2 (versus default right-way unit distance cost of 1). If the value is set to 0, no extra wrong-way cost is added. Otherwise, if the value is set to N, the wrong-way unit distance cost is 2 + N. Therefore, if the value is set to 2, the wrong-way cost is four times the right-way unit distance cost. This variable can be used to further discourage wrong-way direction routing. It can be especially useful if you observe excessive wrong-way direction routing during the **route net group** command, where most nets are not routed yet.

SYNTAX

set droute_wrongWayExtraCost value

The valid values of this variable range between 0 and 100. The default is 0.

EXAMPLE

To specify extra wrong-way wire cost as 40, enter

```
set droute_wrongWayExtraCost 40
```

duplicate_ports

Specifies whether ports are to be drawn on every sheet for which an input or output signal appears.

TYPE

Boolean

DEFAULT

false

GROUP

schematic_variables

DESCRIPTION

Partitioning option that specifies if ports are to be drawn on every sheet for which an input or output signal appears. When true, no off-sheet connectors are used for input and output signals, and signal ports are duplicated where indicated on each sheet.

To determine the current value of this variable use **printvar duplicate_ports**. For a list of all **schematic** variables and their current values, use the **print_variable_group schematic** command.

echo_include_commands

Controls whether the contents of a script file is printed as it executes.

TYPE

Boolean

DEFAULT

true

GROUP

system_variables

DESCRIPTION

When true, the **include** command prints the contents of files it executes. Otherwise, contents are not printed.

To determine the current value of this variable use **printvar echo_include_commands**. For a list of all **system** variables and their current values, use the **print_variable_group system** command.

edif_variables

List of global variables that affect the EDIF format **read**, **read_lib**, and **write** commands.

SYNTAX

```
string bus_dimension_separator_style = "]"["
string bus_extraction_style = "%s[%d:%d]"
Boolean bus_inference_descending_sort = "true"
string bus_inference_style = ""
string bus_naming_style = "%s[%d]"
string bus_range_separator_style = ":"
Boolean edifin_autoconnect_offpageconnectors = "false"
Boolean edifin_autoconnect_ports = "false"
string edifin_dc_script_flag = ""
Boolean edifin_delete_empty_cells = "true"
Boolean edifin_delete_ripper_cells = "true"
string edifin_ground_net_name = ""
string edifin_ground_net_property_name = ""
string edifin_ground_net_property_value = ""
string edifin_ground_port_name = ""
string edifin_instance_property_name = ""
string edifin_lib_in_osc_symbol = ""
string edifin_lib_in_port_symbol = ""
string edifin_lib_inout_osc_symbol = ""
string edifin_lib_inout_port_symbol = ""
string edifin_lib_logic_0_symbol = ""
string edifin_lib_logic_1_symbol = ""
string edifin_lib_mentor_netcon_symbol = ""
string edifin_lib_out_osc_symbol = ""
string edifin_lib_out_port_symbol = ""
string edifin_lib_ripper_bits_property =
string edifin_lib_ripper_bus_end =
string edifin_lib_ripper_cell_name = ""
string edifin_lib_ripper_view_name = ""
string edifin_lib_route_grid = 1024
list edifin_lib_templates = {}
string edifin_portinstance_disabled_property_name = ""
string edifin_portinstance_disabled_property_value = ""
string edifin_portinstance_property_name = ""
string edifin_power_net_name = ""
string edifin_power_net_property_name = ""
string edifin_power_net_property_value = ""
string edifin_power_port_name = ""
Boolean edifin_use_identifier_in_rename = "false"
string edifin_view_identifier_property_name = ""
string edifout_dc_script_flag = ""
string edifout_design_name = "Synopsys_edif"
string edifout_designs_library_name = "DESIGNS"
Boolean edifout_display_instance_names = "false"
Boolean edifout_display_net_names = "false"
Boolean edifout_external = "true"
string edifout_external_graphic_view_name = "Graphic_representation"
```

```

string edifout_external_netlist_view_name = "Netlist_representation"
string edifout_external_schematic_view_name = "Schematic_representation"
string edifout_ground_name = "logic_0"
string edifout_ground_net_name = ""
string edifout_ground_net_property_name = ""
string edifout_ground_net_property_value = ""
string edifout_ground_pin_name = "logic_0_pin"
string edifout_ground_port_name = "GND"
string edifout_instance_property_name = ""
Boolean edifout_instantiate_ports = "false"
string edifout_library_graphic_view_name = "Graphic_representation"
string edifout_library_netlist_view_name = "Netlist_representation"
string edifout_library_schematic_view_name = "Schematic_representation"
Boolean edifout_merge_libraries = "false"
Boolean edifout_multidimension_arrays = "false"
Boolean edifout_name_oscs_different_from_ports = "false"
Boolean edifout_name_rippers_same_as_wires = "false"
Boolean edifout_netlist_only = "false"
Boolean edifout_no_array = "false"
Boolean edifout_numerical_array_members = "false"
string edifout_pin_direction_in_value = ""
string edifout_pin_direction_inout_value = ""
string edifout_pin_direction_out_value = ""
string edifout_pin_direction_property_name = ""
string edifout_pin_name_property_name = ""
string edifout_portinstance_disabled_property_name = ""
string edifout_portinstance_disabled_property_value = ""
string edifout_portinstance_property_name = ""
string edifout_power_and_ground_representation = "cell"
string edifout_power_name = "logic_1"
string edifout_power_net_name = ""
string edifout_power_net_property_name = ""
string edifout_power_net_property_value = ""
string edifout_power_pin_name = "logic_1_pin"
string edifout_power_port_name = "VDD"
Boolean edifout_skip_port_implementations = false
string edifout_target_system = ""
Boolean edifout_top_level_symbol = "true"
string edifout_translate_origin = ""
string edifout_unused_property_value = ""
Boolean edifout_write_attributes = "false"
Boolean edifout_write_constraints = "false"
list edifout_write_properties_list = {}
Boolean write_name_nets_same_as_ports = "false"

```

DESCRIPTION

These variables directly affect the EDIF format **read**, **read_lib**, and **write** commands. The *EDIF Interface Application Note* contains more about these variables.

The *Mentor Interface Application Note* contains more information about Mentor interface variables.

For more about other format **read**, **read_lib**, and **write** commands variables, see

io_variables(3).

For more about Verilog and VHDL variables, see the *HDL Compiler for Verilog Reference*, *VHDL Compiler Reference*, respectively, and **hdl_variables(3)**.

For a list of **edif** variables and their current values, type **print_variable_group edif**. To view this manual page online, type **help edif_variables**. To view an individual variable description, type **help var**, where *var* is the name of the variable.

bus_dimension_separator_style

Affects the **read** command with the **edif**, **verilog**, or **vhdl** format options and the **write** command with the **edif** format option. With **read**, used with **bus_naming_style** to specify the naming style for a port, net, or cell instance member of a multidimensional EDIF array or a multidimensional Verilog or VHDL vector. With **write**, used with **bus_naming_style** and **bus_range_separator_style** to specify the naming style for a multidimensional port array or a net array in the EDIF file.

bus_extraction_style

Affects the **read** command with the **edif** format option. Used with **bus_naming_style** and **bus_dimension_separator_style** to specify the style used to name bus members created in **Design Compiler**.

bus_inference_descending_sort

Affects the **read** command with all format options except **db**, **verilog**, and **vhdl**; primarily used with the **lsi** option (LSI/NDL format). This variable specifies that the members of the port bus are to be sorted in descending order rather than in ascending order.

bus_inference_style

Affects the **read** command with all format options except **db**, **verilog**, and **vhdl**; primarily used with the **lsi** option (LSI/NDL format). This variable determines the style used to name inferred busses.

bus_naming_style

This variable affects the **read**, **write**, and **create_schematic** commands. For the **read** command with the **vhdl** or **verilog** format options, this variable controls naming of bit-blasted ports in **dc_shell** when they are created from multidimensional busses in the original source.

bus_range_separator_style

This variable affects the **write** and **create_schematic** commands. For the **write** command with the **edif** format option, this variable is used together with the **bus_naming_style** variable to generate the style for naming bus ranges. For the **create_schematic** command, this variable, together with the **bus_range_separator_style** variable, also controls naming of bussed nets, bussed ports and bussed rippers in the schematic. Works the same as for **write -f edif**.

edifin_autoconnect_offpageconnectors

When *true*, attaches an off-page connector to the port with the same name even if there is no explicit connection statement. If this variable is *false* (the default value), a file cannot be read at all if it contains an off-page connector and a port with the same name. Some EDIF writers do not include

explicit connections between off-page connectors and ports, but do give them the same names.

`edifin_autoconnect_ports`

When *true*, automatically connects a port to a net if they have the same name, even if there is no explicit connection statement. The default is *false*. Usually, this connection should not be made without an explicit connection statement. Some EDIF writers do not include explicit connections between ports and nets, but do give them the same names.

`edifin_dc_script_flag`

When set to a non-empty string, sends commands, embedded as comments in the EDIF file, to **Design Compiler**. To indicate that a comment contains commands, the first argument in the "comment" construct must be the value of this variable. When this variable is not set, EDIF comments are ignored during **read**.

`edifin_delete_empty_cells`

When *true* (the default value), deletes all designs that do not have cells or nets.

`edifin_delete_ripper_cells`

When *true* (the default value), deletes all designs specified as `cellType "RIPPER"`.

`edifin_ground_net_name`

Specifies EDIF ground nets. If you set this variable to the name of an EDIF ground net, the net is recognized by Synopsys software as a ground net.

`edifin_ground_net_property_name`

Used to specify EDIF ground nets. If you set this variable and **`edifin_ground_net_property_value`** equal to the property name and property value of an EDIF ground net, the net is recognized by Synopsys software as a ground net.

`edifin_ground_net_property_value`

Specifies EDIF ground nets. If you set **`edifin_ground_net_property_name`** and this variable equal to the property name and property value of an EDIF ground net, the net is recognized by Synopsys software as a ground net.

`edifin_ground_port_name`

Specifies EDIF ground ports. If you set this variable to the name of an EDIF ground port, the port is recognized by Synopsys software as a ground port.

`edifin_instance_property_name`

If a property on an instance construct has this name, and if the property value is a string, that value is assigned to the **`cell_property`** attribute of the cell instance.

`edifin_lib_in_osc_symbol`

Affects EDIF **`read_lib`**. If a cell with this name is found in the EDIF symbol library, it is declared as the name of the input off-sheet connector symbol in the Synopsys intermediate symbol library source file and Synopsys symbol library file.

`edifin_lib_in_port_symbol`

Affects EDIF **read_lib** . If a cell with this name is found in the EDIF symbol library, it is declared as the name of the input port symbol in the Synopsys intermediate symbol library source file and Synopsys symbol library file.

`edifin_lib_inout_osc_symbol`

Affects EDIF **read_lib**. If a cell with this name is found in the EDIF symbol library, it is declared as the name of the input/output off-sheet connector symbol in the Synopsys intermediate symbol library source file and Synopsys symbol library file.

`edifin_lib_inout_port_symbol`

Affects EDIF **read_lib**. If a cell with this name is found in the EDIF symbol library, it is declared as the name of the input/output off-sheet connector symbol in the Synopsys intermediate symbol library source file and Synopsys symbol library file.

`edifin_lib_logic_0_symbol`

Affects EDIF **read_lib** . If a cell with this name is found in the EDIF symbol library, it is declared as the name of the ground symbol in the Synopsys intermediate symbol library source file and Synopsys symbol library file.

`edifin_lib_logic_1_symbol`

Affects EDIF **read_lib** . If a cell with this name is found in the EDIF symbol library, it is declared as the name of the power symbol in the Synopsys intermediate symbol library source file and Synopsys symbol library file.

`edifin_lib_mentor_netcon_symbol`

Affects EDIF **read_lib** . If a cell with this name is found in the EDIF symbol library, it is declared as the name of the Mentor **\$netcon** symbol in the Synopsys intermediate symbol library source file and Synopsys symbol library file.

`edifin_lib_out_osc_symbol`

Affects EDIF **read_lib**. If a cell with this name is found in the EDIF symbol library, it is declared as the name of the output off-sheet connector symbol in the Synopsys intermediate symbol library source file and Synopsys symbol library file.

`edifin_lib_out_port_symbol`

Affects EDIF **read_lib** . If a cell with this name is found in the EDIF symbol library, it is declared as the name of the output port symbol in the Synopsys intermediate symbol library source file and Synopsys symbol library file.

`edifin_lib_ripper_bits_property`

Affects EDIF **read_lib**. If a cell with the name specified by the variable `edifin_lib_ripper_cell_name` of cellType "RIPPER" is found in the EDIF symbol library, the value of this variable is assigned to the **ripped_bits_property** attribute of this ripper symbol in the Synopsys intermediate symbol library source file and Synopsys symbol library file. In EDIF files written with this ripper symbol, the value of this attribute is the name of a property that is placed on each ripper instance; the number of the bit (or range of bits) is the property's value.

`edifin_lib_ripper_bus_end`

Affects EDIF **read_lib**. If a cell with the name specified by the variable **edifin_lib_ripper_cell_name** of cellType "RIPPER" is found in the EDIF symbol library, the value of this variable is assigned to the **ripped_pin** attribute of this ripper symbol in the Synopsys intermediate symbol library source file and Synopsys symbol library file. In EDIF files written with instances of this ripper symbol, this attribute specifies the "bus end" pin of the ripper. If no pin exists on the ripper symbol with the name specified by this variable, results might be erroneous. This information is used by **create_schematic** to identify the bus and wire ends of the ripper symbol.

`edifin_lib_ripper_cell_name`

Affects EDIF **read_lib**. If a cell with this name of cellType "RIPPER" is found in the EDIF symbol library, the values of the variables `edifin_lib_ripper_bits_property` and `edifin_lib_ripper_bus_end` are assigned to the **ripped_bits_property** and **ripped_pin** attributes of this ripper symbol in the Synopsys intermediate symbol library source file and Synopsys symbol library file.

`edifin_lib_ripper_view_name`

Affects EDIF **read_lib**. If a cell with the name specified by the variable `edifin_lib_ripper_cell_name` of cellType "RIPPER" is found in the EDIF symbol library, only the view with this name is added as this ripper symbol in the Synopsys intermediate symbol library source file and Synopsys symbol library file. If the value of this variable is not specified, only the first view of the cell is added as this ripper symbol.

`edifin_lib_route_grid`

Affects EDIF **read_lib**. The value of this variable is declared as the size of the route grid of the library in the Synopsys intermediate symbol library source file and Synopsys symbol library file.

`edifin_lib_templates`

Affects EDIF **read_lib**. This variable is a list of sublists. Each sublist contains three elements: first, a string that defines a sheet size name; second, a string that defines the template orientation (either "landscape" or "portrait"); third, a string that defines the symbol name corresponding to the sheet size specified by the first element.

`edifin_portinstance_disabled_property_name`

If the property of a portInstance construct has the same name as this variable string and the property's value is the same as **edifin_portInstance_disabled_property_value**, the **disabled** attribute is placed on the pin of the cell instance.

`edifin_portinstance_disabled_property_value`

If the property value of a portInstance construct is the same as this variable string, and if the property has the same name as **edifin_portInstance_disabled_property_name**, the **disabled** attribute is placed on the pin of the cell instance.

`edifin_portinstance_property_name`

If the property of a portInstance construct has the same name as this variable string, and if the property's value is a string, that value is assigned to the **pin_properties** attribute of the pin of the cell instance.

`edifin_power_net_name`

Specifies EDIF power nets. If you set this variable to the name of an EDIF power net, the net is recognized by Synopsys software as a power net.

`edifin_power_net_property_name`

If the values of this variable and **`edifin_power_net_property_value`** are the same as the property name and property value of an EDIF net, the net is recognized as a power net.

`edifin_power_net_property_value`

If the values of **`edifin_power_net_property_name`** and this variable are the same as the property name and property value of an EDIF net, the net is recognized as a power net.

`edifin_power_port_name`

Specifies EDIF power ports. If you set this variable to the name of an EDIF power port, the port is recognized by Synopsys software as a power port.

`edifin_use_identifier_in_rename`

When *true*, gives all objects created the name specified by the "identifier" in the "name" construct (which might be made up of a "rename" construct). When *false* (the default value), gives all created objects the name specified by the "name" in the "rename" construct (if the "name" construct is made up of a "rename" construct). Also affects EDIF **`read_lib`**.

`edifin_view_identifier_property_name`

Allows multiple views (representations) of a cell to be created in the Synopsys database. This variable specifies an EDIF property whose value becomes the name of the cell object created. When set to an empty string, only the first cell view is recognized and subsequent views are ignored. (Also affects EDIF **`read_lib`**.)

`edifout_dc_script_flag`

When set to a non-empty string, embeds comments containing Design Compiler commands into the EDIF file. This variable is used with **`edifout_write_attributes`** and **`edifout_write_constraints`**, which select the attributes and constraints to write out. The value of this variable is placed as the first argument of each of the "comment" constructs.

`edifout_design_name`

Controls the identifier in the "design" construct written at the end of EDIF files. If this variable is not set, the design identifier in the "design" construct is "**`Synopsys_edif`**". When you set this variable, any non-alphanumeric character in the string is changed to an underscore. This construct appears only at the end of an EDIF file written out.

`edifout_designs_library_name`

Specifies the name given to the EDIF library construct that contains the cell constructs for the designs being written. When set to an empty string, the name "**`DESIGNS`**" is used.

`edifout_display_instance_names`

When *true*, displays cell instance names in the schematic. The default is *false*.

`edif_variables`

`edifout_display_net_names`

When *true*, displays the net name at each port, pin, and off-sheet connector location in the schematic; the default is *false*. Two "display" constructs are included in the EDIF file for each port, pin, and off-sheet connector on a net.

`edifout_external`

When *true*, only the interface for each referenced symbol is written in an "external" form. (Symbol definitions are not included.) When *false* (the default value), complete definitions are written for all symbols used in an EDIF schematic.

`edifout_external_graphic_view_name`

Specifies the name given to the EDIF views used in libraries contained in an "external" construct in schematic EDIF files. This variable affects only symbols with no pins such as port or off-sheet connector symbols. Set this variable if your target EDIF reader expects specific view names for cells of type GRAPHIC.

`edifout_external_netlist_view_name`

Specifies the name given to the EDIF views used in libraries contained in an "external" construct in netlist EDIF files. Set this variable if your target EDIF reader expects specific view names for cells of type NETLIST.

`edifout_external_schematic_view_name`

Specifies the name given to the EDIF views used in libraries contained in an "external" construct in schematic EDIF files. This variable affects schematics and symbols, except for symbols with no pins such as port or off-sheet connector symbols. Set this variable if your target EDIF reader expects specific view names for cells of type SCHEMATIC.

`edifout_ground_name`

When **`edifout_power_and_ground_representation`** is set to *cell* and **`edifout_netlist_only`** is *true*, this is the name given to the ground cell. This variable is used in conjunction with **`edifout_ground_pin_name`**, which names the ground cell's pin.

`edifout_ground_net_name`

When **`edifout_power_and_ground_representation`** is set to *net* and this variable and the variable **`edifout_power_net_name`** are non-empty strings, the ground nets are written as one net. This variable specifies the name of the ground net.

`edifout_ground_net_property_name`

When **`edifout_power_and_ground_representation`** is set to *net* and this variable and the variables **`edifout_ground_net_property_value`**, **`edifout_power_net_property_name`**, and **`edifout_power_net_property_value`** are non-empty strings, this variable specifies the name of the property used to identify the ground nets (or the one ground net created by the variable **`edifout_ground_net_name`**).

`edifout_ground_net_property_value`

When **`edifout_power_and_ground_representation`** is set to *net* and this variable and the variables **`edifout_ground_net_property_name`**, **`edifout_power_net_property_name`**, and **`edifout_power_net_property_value`**, are

non-empty strings, this variable specifies the value of the property used to identify the ground nets (or the one ground net created by the variable **edifout_ground_net_name**).

edifout_ground_pin_name

When **edifout_power_and_ground_representation** is set to *cell* and **edifout_netlist_only** is *true*, this is the name given to the pin of the ground cell.

edifout_ground_port_name

When **edifout_power_and_ground_representation** is set to *port*, two extra port constructs are included in the interface of every cell: the power port and the ground port. This is the name given to the ground port.

edifout_instance_property_name

If a cell instance has the **cell_property** attribute, a property with the same name as this variable and value the same as the **cell_property attribute**, is included on the EDIF instance.

edifout_instantiate_ports

When *true*, "symbol" constructs for ports and off-sheet connectors are included in a "library" (or "external") construct in an EDIF schematic. In addition, instantiations referencing those symbols are included in the "portImplementation" constructs for ports and off-sheet connectors in the "contents" constructs of EDIF schematics. When *false* (the default value), schematic descriptions are included in the "portImplementation" constructs for ports and off-sheet connectors in the "contents" constructs of EDIF schematics. This variable does not affect the way "portImplementation" constructs are written in "symbol" constructs.

edifout_library_graphic_view_name

Specifies the name given to the EDIF views used in libraries contained in a "library" construct (not an "external" construct) in schematic EDIF files. This variable affects only symbols with no pins such as port or off-sheet connector symbols. Set this variable if your target EDIF reader expects specific view names for cells of type GRAPHIC.

edifout_library_netlist_view_name

Specifies the name given to the EDIF views used in libraries contained in a "library" construct (not an "external" construct) in netlist EDIF files. Set this variable if your target EDIF reader expects specific view names for cells of type NETLIST.

edifout_library_schematic_view_name

Specifies the name given to the EDIF views used in libraries contained in a "library" construct (not an "external" construct) in schematic EDIF files. This variable affects schematics and symbols, except for symbols with no pins such as port or off-sheet connector symbols. Set this variable if your target EDIF reader expects specific view names for cells of type SCHEMATIC.

edifout_merge_libraries

When *true*, writes all cells for an EDIF file in the same library. This causes problems if there is more than one cell with the same name, but this variable is included for EDIF readers that can handle only a single library per file.

`edifout_multidimension_arrays`

When *true*, a bus will be represented as a multidimensional array if the structure of the bus so permits. The default is *false*.

`edifout_name_oscs_different_from_ports`

When *true*, each off-sheet connector that is connected to a port is given a different name from the port in the descriptions of designs written in EDIF format. The default value is *false*.

`edifout_name_rippers_same_as_wires`

When *true*, a bus ripper cell instance (in the EDIF file) is named the same as the wires extracted ("ripped") from the bus net connected to the bus-end pin of the ripper instance. When *false* (the default value), bus ripper cell instances are named in the order they are created during schematic generation. The name for the ripper instance is "Ripper_n", where *n* is the incrementing integer value for each bus ripper cell instance created.

`edifout_netlist_only`

When *true*, writes an EDIF netlist only. When *false* (the default value), writes an EDIF schematic in addition to the netlist.

`edifout_no_array`

When this variable and **`edifout_netlist`** are *true*, no array constructs are written. In designs containing busses, individual bus members are written instead. The default value is *false*.

`edifout_numerical_array_members`

When **`edifout_netlist_only`** is *true* and this variable is *true*, in member constructs the integer value that is the index into an ascending array is also 0 for the first member of the array and also increases by 1 for each succeeding member of the array; the integer value that is the index into a descending array is 0 for the member with the lowest numerical value of the array and increases by 1 for each member of the array of successively increasing numerical value. When **`edifout_netlist_only`** is *false* or this variable is *false* (the default value), in member constructs the integer value that is the index into an array is 0 for the first member of the array and increases by 1 for each succeeding member of the array, regardless of whether the bus is ascending or descending.

`edifout_pin_direction_in_value`

Includes an EDIF property with the same name as **`edifout_pin_direction_property_name`**, and value the same as this variable string, on input pins.

`edifout_pin_direction_inout_value`

Includes an EDIF property with the same name as **`edifout_pin_direction_property_name`**, and value the same as this variable, on input/output pins.

`edifout_pin_direction_out_value`

Includes an EDIF property with the same name as **`edifout_pin_direction_property_name`**, and value the same as this variable, on output pins.

`edifout_pin_direction_property_name`

Includes an EDIF property on all pins. The name of the property is the same as this variable string. To determine the value of the property, this variable is used in conjunction with **`edifout_pin_direction_in_value`**, **`edifout_pin_direction_inout_value`**, and **`edifout_pin_direction_out_value`**.

`edifout_pin_name_property_name`

Includes on pins an EDIF property with the same name as this variable string, and value the same as the pin name.

`edifout_portinstance_disabled_property_name`

If the pin of a cell instance has the **`disabled`** attribute, a property with the same name as this variable string and a value the same as **`edifout_portInstance_disabled_property_value`** is created in the `portInstance` construct.

`edifout_portinstance_disabled_property_value`

If the pin of a cell instance has the **`disabled`** attribute, a property with the same name as **`edifout_portInstance_disabled_property_name`** and value the same as this variable string is created in the `portInstance` construct.

`edifout_portinstance_property_name`

If the **`pin_properties`** attribute is on the pin of a cell instance, a property with the same name as this variable string and value the same as the **`pin_properties`** attribute is created in the "portInstance" construct.

`edifout_power_and_ground_representation`

Determines power and ground representations in EDIF files. This variable can have the value *port*, *cell* (the default), or *net*.

`edifout_power_name`

When **`edifout_power_and_ground_representation`** is set to *cell*, and **`edifout_netlist_only`** is *true*, this is the name given to the power cell. This variable is used in conjunction with **`edifout_power_pin_name`**, which names the power cell's pin.

`edifout_power_net_name`

When **`edifout_power_and_ground_representation`** is set to *net*, and if this variable and the variable **`edifout_ground_net_name`** are non-empty strings, the power nets are written as one net. This variable specifies the name of the power net.

`edifout_power_net_property_name`

When **`edifout_power_and_ground_representation`** is set to *net*, and if this variable and the variables **`edifout_ground_net_property_name`**, **`edifout_ground_net_property_value`**, and **`edifout_power_net_property_value`** are non-empty strings, this variable specifies the name of the property used to identify the power nets (or the one power net created by the variable **`edifout_power_net_name`**).

`edifout_power_net_property_value`

When **`edifout_power_and_ground_representation`** is set to *net*, and if this variable and the variables **`edifout_ground_net_property_name`**, **`edifout_ground_net_property_value`**, and **`edifout_power_net_property_name`** are non-empty strings, this variable specifies the value of the property used to

identify the power nets (or the one power net created by the variable **edifout_power_net_name**).

edifout_power_pin_name

When **edifout_power_and_ground_representation** is set to *cell*, and **edifout_netlist_only** is *true*, this is the name given to the pin of the power cell.

edifout_power_port_name

When **edifout_power_and_ground_representation** is set to *port*, two extra port constructs are included in the interface of every cell: the power port and the ground port. This is the name given to the power port.

edifout_skip_port_implementations

When *true*, does not write "portImplementation" constructs for ports in the "contents" constructs of EDIF schematics. The default is *false*. Note that "portImplementation" constructs are still written in "symbol" constructs, regardless of the value of this variable.

edifout_target_system

Causes the values of related **edifout** variables to be overridden so that object names can be transferred to the target system, and to perform vendor-specific operations beyond the scope of **edifout** variables. Allowed values are *mentor*, *valid*, or *cadence*. For more details about *mentor* or *valid*, refer to the appropriate EDIF Interface Application Note.

edifout_top_level_symbol

When *true* (the default value), writes the top-level symbol in EDIF schematic files. To disable the top-level symbol, set this variable to *false*.

edifout_translate_origin

Transforms the values of coordinates in schematic descriptions to reflect the specified origin. Allowed values are *center*, which places the center of each sheet at the origin; or *lower-left*, which places the lower left corner of each sheet at the origin. Notice that when the lower left corner is at the origin, all x- and y-coordinates are non-negative.

edifout_unused_property_value

Used when writing out EDIF netlists to be processed by a Motorola EDIF reader. EDIF netlists are required to have the **unused** attribute attached to unconnected port instances (pins). The property value defined by this variable is attached to the property name defined by the variable **edifout_portInstance_property_name**. When this property/value pair satisfies the Motorola reader guidelines, the **unused** attribute is attached to the appropriate port instances.

edifout_write_attributes

When *true*, embeds comments containing **Design Compiler** attribute definitions into the EDIF file. The default is *false*. Definitions are written out for all attributes in the design that are active during the current **Design Compiler** session. This variable is used with **edifout_dc_script_flag**.

edifout_write_constraints

When *true*, embeds comments containing Design Compiler constraint commands into the EDIF file. The default is *false*. All active constraints on the design

during the current Design Compiler session are written out. This variable is used in conjunction with **edifout_dc_script_flag**.

edifout_write_properties_list

Specifies a list of library, cell, or port properties to write into the EDIF description. The value of this variable is a list of strings containing the property names.

write_name_nets_same_as_ports

When *true*, nets that are connected to ports are given the same names as those ports in the descriptions of designs written in the EDIF, LSI, or TDL format. The default is *false*.

SEE ALSO

**read (2), read_lib (2), write (2); io_variables (3), hdl_variables (3),
vhdl_io_variables (3).**

enable_cell_based_verilog_reader

This variable turns on the verilog2cel verilog reader.

TYPE

Boolean

DEFAULT

false

GROUP

hdl_variables

DESCRIPTION

By specifying this variable, user can enable verilog2cel verilog reader, which is a CEL based verilog reader and will save the netlist directly into the Milkyway CEL, without creating DC data structures.

To determine the current value of this variable, use **printvar enable_cell_based_verilog_reader**. For a list of all **hdl** variables and their current values, use the **print_variable_group hdl** command.

SEE ALSO

hdl_variables(3)
read_verilog(2)
mw_current_design(3)

enable_instances_in_report_net

Enables **report_net** to report on instances in the current design.

TYPE

Boolean

DEFAULT

true

GROUP

none

DESCRIPTION

To enable **report_net** to report on instances in the current design, set "enable_instances_in_report_net" to true.

Note that without this variable set to true, the **report_net** only reports nets for current design. Also, nets in the current instance are reported if current_instance is set.

SEE ALSO

report_net(2)

enable_page_mode

Controls whether long reports are displayed one page at a time (similar to the UNIX **more** command).

TYPE

Boolean

DEFAULT

false

GROUP

system_variables

DESCRIPTION

When true, long reports are displayed one page at a time (similar to the UNIX **more** command). Commands affected by this variable include **list**, **help**, and the **report** commands.

To determine the current value of this variable use **list enable_page_mode**. For a list of all **system** variables and their current values, use the **print_variable_group system** command.

enable_recovery_removal_arcs

Controls whether Design Compiler accepts recovery and removal arcs that are specified in the technology library.

TYPE

Boolean

DEFAULT

false

GROUP

compile_variables

DESCRIPTION

Recovery or removal timing arcs impose constraints on asynchronous pins of sequential cells. Typically, recovery time specifies the time the inactive edge of the asynchronous signal has to arrive before the closing edge of the clock. Removal time specifies the length of time the active phase of the asynchronous signal has to be held after the closing edge of clock.

To enable **compile**, **report_timing**, and **report_constraint** to accept recovery or removal arcs specified in the library, set **enable_recovery_removal_arcs** to true.

Note that independent of the value of this variable, commands **write_timing** and **report_delay_calculation** always accepts and reports recovery or removal timing information.

SEE ALSO

compile_variables(3)

enable_slew_degradation

Determines whether the transition degradation is taken into account for nets with physical information.

TYPE

Boolean

DEFAULT

true

GROUP

timing_variables

DESCRIPTION

When *true* (the default setting), timing calculation will take into account transition degradation across a net. For a long net, this may mean that the transition at the net driver could be very different than the various load pins. Because all load pins on the same net will not necessarily have the same transition time optimization with physical information will fix transitions on a per pin basis. This may lead to increased runtime for these commands.

Setting this variable to *false* will cause the timing calculation to not calculate transition degradation across a net. However, some libraries do have a transition degradation table which show how to degrade the transition across a net. If slew degradation is not enabled, then the library transition degradation tables are used unless the variable **disable_library_transition_degradation** is set to *true*. If neither slew degradation nor library transition degradation is enabled, the transition at the net driver will be the same transition at the load pin. Because all load pins on the same net have the same transition time, optimization with physical information will attempt to fix transitions on a per net basis.

Regardless of the setting of this variable, slew degradation will not occur for multi-driven nets. For multi-driven nets, there can be cases of too much pessimism.

Regardless of the setting of this variable, slew degradation can only occur if there are either delay back-annotation for the net or physical locations for the pins of the net. Otherwise, the transition time calculation at the driver pin is too inaccurate to be degraded.

To determine the current value of this variable, type **printvar enable_slew_degradation**. For a list of all **timing** variables and their current values, type **print_variable_group timing**.

SEE ALSO

disable_library_transition_degradation(3)

timing_variables(3)

enable_special_level_shifter_naming

Setting this variable to true would enable special naming for automatically inserted level shifters

TYPE

Boolean

DEFAULT

false

GROUP

mv

DESCRIPTION

When this variable is set to true, automatically inserted level shifters by `insert_level_shifters`, `compile` and other commands are named specially. The name follows the template `<prefix> + <PD OR Design name> + "_LS" + #`. `<prefix>` is a user specified prefix using the variable `level_shifter_naming_prefix`. `#` is a number internally generated to keep this name unique. `<PD OR Design Name>` is the name of power domain where the level shifter is being added, or the design name if the power domain is not defined

SEE ALSO

`level_shifter_naming_prefix(3)`

estimate_io_latency

Uses estimated I/O latency in timing calculations for ports when true.

TYPE

Boolean

DEFAULT

false

GROUP

timing

DESCRIPTION

When true, uses estimated I/O latency in timing calculations for ports.

For each input port the I/O latency for max case is defined as the minimum clock network latency for the clocks in the fanout set of the port. The I/O latency for min case is the maximum clock latency in the fanout set.

For each output port the I/O latency for max case is defined as the maximum clock network latency for the clocks in the fanin set of the port. The I/O latency for min case is the minimum clock latency in the fanin set.

The I/O latency will not be added to external delay in timing calculations if the `network_delay_included` switch is used. The ideal clocks are not used for I/O latency calculation.

This variable should ideally be used after clock tree synthesis.

To determine the current value of this variable, use **printvar estimate_io_latency**.

SEE ALSO

`set_clock_latency(2)`
`set_propagated_clock(2)`
`report_timing(2)`

exit_delete_command_log_file

Controls whether the file specified by the variable **command_log_file** is deleted after **design_analyzer** or dc_shell exits normally.

TYPE

string

DEFAULT

false

GROUP

system_variables

DESCRIPTION

When true, causes the file specified by the variable **command_log_file** to be deleted after **design_analyzer** or dc_shell exits normally. The default value is false. Set **exit_delete_command_log_file** to false if you want the file to be retained.

To determine the current value of this variable, type **printvar exit_delete_command_log_file**. For a list of all **system** variables and their current values, type **print_variable_group system**.

SEE ALSO

exit_delete_filename_log_file

Controls whether the file specified by the variable **filename_log_file** is deleted after **design_analyzer** or dc_shell exits normally.

TYPE

string

DEFAULT

true

GROUP

system_variables

DESCRIPTION

When true (the default value), causes the file specified by the variable **filename_log_file** to be deleted after **design_analyzer** or dc_shell exits normally. Set **exit_delete_filename_log_file** to false if you want the file to be retained.

To determine the current value of this variable, type **printvar exit_delete_filename_log_file**. For a list of all **system** variables and their current values, type **print_variable_group system**.

SEE ALSO

filename_log_file

Specifies the name of the filename log file to be used in case a fatal error occurs during execution of **design_analyzer** or **dc_shell**.

TYPE

string

DEFAULT

filenames.log

GROUP

system_variables

DESCRIPTION

Specifies the name of the filename log file to be used in case a fatal error occurs during execution of **design_analyzer** or **dc_shell**. The file specified by **filename_log_file** will contain all the filenames read in by **design_analyzer** or **dc_shell**, including db, script, verilog, vhdl or include files for one invocation of the program (however, the support to log filenames read in by **read_sdc** is not in yet). If there is a fatal error, you can easily identify the data files needed to reproduce the fatal error. If this variable is not specified, the default filename **filenames.log** will be used. This file will be deleted if the program exits normally, unless **exit_delete_filename_log_file** is set to false.

The variable is valid both in eqn mode as well as in tcl mode.

If the application has been invoked using "-no_log" switch, then the process id of the application and the timestamp is appended to filename log file, something like -filenames_<process_id>_<timestamp>.log.

To determine the current value of this variable, type **printvar filename_log_file**. For a list of all **system** variables and their current values, type **print_variable_group system**.

SEE ALSO

find_allow_only_non_hier_ports

Controls find command to search for ports in sub-designs (described as hier_ports here).

TYPE

Boolean

DEFAULT

false

GROUP

none

DESCRIPTION

When set to true, directs the find command to search for top level ports only, ignoring ports in sub-designs.

By default, **find port** will also fetch ports in the sub-designs.

For example, if cell 'c' is an instance of design SUB1, then with this variable set to false, the command "find port c/A" will fetch the port A on design SUB1. With the variable set to true, "find port c/A" will result in a warning message as below,

```
prompt> printvar find_allow_only_non_hier_ports
find_allow_only_non_hier_ports = "false"
prompt> find port c/A
{"c/A"}
prompt> find_allow_only_non_hier_ports = true
"true"
prompt> printvar find_allow_only_non_hier_ports
find_allow_only_non_hier_ports = "true"
prompt> find port c/A
Warning: Can't find port 'c/A' in design 'SUB1'. (UID-95)
```

This variable is to facilitate the netlist editing commands connect_net and disconnect_net which allow net and pin instances in addition to handling nets and pins in the current_design.

SEE ALSO

```
connect_net(2)
disconnect_net(2)
remove_port(2)
get_ports(2)
```

find_converts_name_lists

Controls whether the **find** command converts the *name_list* string to a list of strings before searching for design objects.

TYPE

Boolean

DEFAULT

false

GROUP

system_variables

DESCRIPTION

When true, directs the **find** command to convert the *name_list* string to a list of strings before searching for design objects. In addition, when this variable is true, all commands that use the implicit **find** will convert appropriate strings to lists of strings before searching for objects. For example, **current_instance** uses the implicit **find** and would convert the string *instance* to a list of strings before searching for objects.

find_converts_name_lists provides backward compatibility with the pre-modification **find** command. When the variable is false (the default value), **find** executes according to its post-modification behavior; that is, strings are not converted to lists of strings.

To determine the current value of this variable, type **printvar find_converts_name_lists**. For a list of all **system** variables and their current values, type **print_variable_group system**.

SEE ALSO

current_instance(2)
system_variables(3)

find_ignore_case

Controls whether the **find** command is case-sensitive when matching object names.

TYPE

Boolean

DEFAULT

false

DESCRIPTION

Normally, the **find** command is case-sensitive when matching names of objects. That is, for either an explicit or implicit invocation of the **find** command, **find** only matches objects whose names have the same case as the specified string.

However, sometimes it may be more desirable to use case-insensitive matching. The **find_ignore_case** variable provides that capability.

When the **find_ignore_case** variable is true, the **find** command performs case-insensitive string comparisons. This variable affects both implicit and explicit invocations of the **find** command. The default value for this variable is false.

To determine the current value of this variable, type **list find_ignore_case**. If the variable has not been defined yet, the **list** command will fail indicating that the variable is undefined.

Use this variable only when necessary, as it may slightly increase the run-time of find operations.

SEE ALSO

floorplan_data_attributes

Contains attributes related to floorplan data on different modules in separate views.

DESCRIPTION

Contains attributes related to floorplan data on different modules in separate views.

Floorplan data attributes are read-only. You can use **get_floorplan_data** to determine value of an attribute, and use **report_floorplan_data** to get a report of all the floorplan data on module objects in a specified view. If you want to know the list of valid floorplan data names, you can use **list_floorplan_data**.

Floorplan Data Attributes

area

Specifies the area of a module. This attribute does not exist on a logical module.

The tool calculates the attribute based on cell boundary.

aspect_ratio

Specifies the **height:width** ratio of a module. This attribute does not exist on a logical module.

hard_macro_area_percentage

Specifies ratio of sum of **area** of hard macros in a module to top module's **physical_area**.

height

Specifies the height of a module. This attribute only exists on soft macros or hard macros in **logical** view.

The tool calculates the attribute based on the **bbox** of a module.

macro_area_percentage

Specifies the ratio of sum of **area** of macros in a module to top module's **physical_area**.

Note that the definition of **macro_area_percentage** in this document is different from that in **cell_attributes.3**. Compared to the definition in **cell_attributes.3**, the numerator of ratio remains while the denominator is **physical_area** of top module instead of **physical_area** of the specified module.

number_of_black_box

Specifies the count of black boxes in a module. This attribute does not exist on plan_group.

Whether a cell is a black box can be determined by the attribute **is_black_box**.

number_of_hard_macro

Specifies the count of hard macros in a module.

Whether a cell is a hard macro can be determined by the attribute **is_hard_macro**.

`number_of_io_cell`

Specifies the count of io cells in a module. This attribute does not exist on **plan_group**.

The tool counts cells in when its **mask_layout_type** is **io_pad**, **corner_pad**, **pad_filler**, or **flip_chip_pad**.

`number_of_macro`

Specifies the count of macros in a module. This attribute does not exist on **plan_group**.

The tool counts cells in when its **mask_layout_type** is **macro**.

`number_of_standard_cell`

Specifies the count of standard cells in a module.

The tool counts cells in when its **mask_layout_type** matches ***std***.

`physical_area`

Specifies the physical area of a module.

The physical area of a hard macro is equal to its **area**.

In **one_level** or **logical** view, the physical area of a soft macro is equal to its **area**. However, in **physical** view, physical area is the sum of **physical_area** of macros and **area** of standard cells inside the specified soft macro.

The physical area of a plan group is sum of **area** of macros and standard cells in it.

For a top module or a logical module, rules for calculating **physical_area** are applied as:

In a **one_level** view, only children in the current level are counted and children should be either macro or standard cell. The physical area of a module in **one_level** is sum of the **area** of the counted children.

In a **logical** view, the hierarchy tree in the module is traversed and the **area** of macros and standard cells in the tree will be added.

In the **physical** view, the hierarchy tree in the module is traversed and the **area** of standard cells and **physical_area** of macros in the tree will be added.

`physical_area_percentage_in_top_design`

Specifies the ratio of **physical_area** of a module to top module's **physical_area**.

`utilization`

Specifies the utilization of a module.

The tool calculates the attribute using **physical_area:area** ratio of a module.

This attribute does not exist on a logical module or a top module.

`width`

Specifies the width of a module. This attribute only exists on soft macros or hard macros in **logical** view.

The tool calculates the attribute based on the **bbox** of a module.

SEE ALSO

`get_floorplan_data(2)`

`list_floorplan_data(2)`

`report_floorplan_data(2)`

focalopt_endpoint_margin

Read and set the endpoint slack value during focal_opt setup or hold optimization.

TYPE

Boolean

DEFAULT

true

GROUP

focalopt_variables

DESCRIPTION

It enables the endpoint margin feature for focal_opt. This features only applies to the **-setup_endpoints** and **-hold_endpoints** options of focal_opt.

When variable is set to true, the tool will read the slack value for the respective endpoint specified in the setup_endpoint file or hold_endpoint file and overwrite the tool's current slack value with the specified value.

When variable is set to false, the tool will only optimize the endpoint according to the tool's current slack value.

This feature is useful for tackling correlation issues for specific endpoints in postroute optimization stage.

Please refer to **focal_opt(2)** man page for accepted FILE formats.

SEE ALSO

focal_opt(2)

fsm_auto_inferring

Determines whether or not to automatically extract finite state machine during the **compile**.

TYPE

Boolean

DEFAULT

false

GROUP

fsm_variables

DESCRIPTION

This variable determines whether the compiler performs finite state machine (FSM) automatic extraction during **compile**. If a design has previously had state machine extraction performed on it, the compiler does not perform extraction again with the same encoding style.

EXAMPLES

In the Presto flow, the compiler detects the FSM attributes from the HDL code and extracts the FSM during **compile**, as shown here:

```
prompt> fsm_auto_inferring=true
prompt> read -f verilog example.v
prompt> set_fsm_encoding_style one_hot
prompt> compile
```

SEE ALSO

```
fsm_enable_state_minimization(3)
fsm_export_formality_state_info(3)
```

fsm_enable_state_minimization

Determines whether or not the state minimization is performed for all finite state machines (FSMs) in the design.

TYPE

Boolean

DEFAULT

false

GROUP

fsm_variables

DESCRIPTION

When this option is set to *true*, the compiler performs the state minimization after the state extraction. However, if the state number is changed, Formality and the newly developed FSM verification feature of the **compile -verify** command and the **compare_design -fsm** variable cannot verify the design. To pass the verification, set this option to *false*.

SEE ALSO

fsm_auto_inferring(3)
fsm_export_formality_state_info(3)

fsm_export_formality_state_info

Determines whether or not state machine encoding information is exported into the files that will be used by Formality.

TYPE

Boolean

DEFAULT

false

GROUP

fsm_variables

DESCRIPTION

When this variable is set to *true*, the state encoding information before and after finite state machine extraction is exported into two files, <module_name>.ref and <module_name>.imp, which will be used for Formality verification. Default value for this variable is *false*.

SEE ALSO

fsm_auto_inferring(3)
fsm_enable_state_minimization(3)

fsm_variables

Variables that affect finite state machine (FSM) optimization.

SYNTAX

```
Boolean fsm_auto_inferring = true
Boolean fsm_enable_state_minimization = false
Boolean fsm_export_formality_state_info = false
```

DESCRIPTION

These variables directly affect aspects of finite state machine (FSM) optimization in **dc_shell**. Defaults are shown under "SYNTAX."

For a list of fsm variables, type **print_variable_group fsm**. To view this manual page online, type **help fsm_variables**. To view an individual variable description, type **help var**, where *var* is the name of the variable.

fsm_auto_inferring

Determines whether the compiler performs finite state machine (FSM) automatic extraction during **compile**. If a design has previously had state machine extraction performed on it, the compiler does not perform extraction again. The introduction of this new feature coincides with the old FSM compiler becoming obsolete.

fsm_enable_state_minimization

When this option is set to *true*, the compiler performs state minimization after state extraction. However, if the state number is changed, Formality and the newly developed FSM verification feature of the **compile -verify** command and the **compare_design -fsm** variable cannot verify the design. To pass the verification, set this option to *false*.

fsm_export_formality_state_info

When this variable is set to *true*, the state encoding information before and after FSM extraction is exported into two files, <module_name>.ref and <module_name>.imp, which are used for Formality verification. The default value of this variable is *false*.

fsm_extract_moore_machine

If this variable is *ftruefp*, the Moore finite state machines will be extracted.

fsm_set_safe_mode

If this variable is *ftruefp*, the safe-mode finite state machines will be extracted.

When a finite state machine(FSM) get into a invalid state for any reason, especially when power up. FSM may not possible returnng a valid state without reset. The safe-mode FSM is for sure the FSM can return from any invalid state to one of the valid states without reset. The aonther good feature is even with the safe-mode, the synthesised netlist can still be verified with Formality.

SEE ALSO

`compare_design` (2), `compile` (2), `report_fsm` (2).

gen_bussing_exact_implicit

Controls whether schematics generated using the **create_schematic -implicit** command should contain implicit bus names instead of bus rippers.

TYPE

Boolean

DEFAULT

false

GROUP

schematic_variables

DESCRIPTION

When true, specifies that schematics generated using **create_schematic -implicit** should contain no bus rippers. Instead, all bused connections should be shown with implicit bus names. This should be used with the **-implicit** command line option. By default, schematics generated using the **-implicit** option have rippers between any bus connections where the ripper connects to a pin in a column adjacent to the originating bus pin. Bused connections between cell pins more than one column away from each other are always shown disconnected with the **-implicit** option.

To determine the current value of this variable, type **printvar gen_bussing_exact_implicit**. For a list of all **schematic** variables and their current values, type **print_variable_group schematic**.

SEE ALSO

schematic_variables(3)

gen_cell_pin_name_separator

Specifies the character used to separate cell names and pin names in the bus names generated by the **create_schematic** command.

TYPE

string

DEFAULT

/

GROUP

schematic_variables

DESCRIPTION

If this variable is set, then its value is used to separate the cell and pin names in the bus names generated by **create_schematic**. By default, "/" is used to separate the cell and pin names, thus creating bus names like "U0/OUT[0:3]"

To determine the current value of this variable, type **printvar gen_cell_pin_name_separator**. For a list of all **schematic** variables and their current values, type **print_variable_group schematic**.

SEE ALSO

gen_create_netlist_busses

Controls whether **create_schematic** creates netlist buses whenever it creates buses on the schematic.

TYPE

Boolean

DEFAULT

true

GROUP

schematic_variables

DESCRIPTION

Controls whether **create_schematic** creates netlist buses whenever it creates buses on the schematic. When true (the default), the **create_schematic** command does so. Usually this happens when **create_schematic** creates buses to connect to bused pins on the schematic. But it might also happen when there are bused ports on the schematic.

To determine the current value of this variable, type **printvar gen_create_netlist_busses**. For a list of all **schematic** variables and their current values, type **print_variable_group schematic**.

SEE ALSO

gen_dont_show_single_bit_busses

Controls whether single-bit buses are generated in the schematic.

TYPE

Boolean

DEFAULT

false

GROUP

schematic_variables

DESCRIPTION

This variable is used in conjunction with the **gen_show_created_busses** variable. When **gen_show_created_busses** is true and **gen_dont_show_single_bit_busses** is also set to true, single bit buses created by gen are not printed out. This suppresses messages about creation of single bit buses in the schematic.

To determine the current value of this variable use **printvar** **gen_dont_show_single_bit_busses**. For a list of all **schematic** variables and their current values, use the **print_variable_group schematic** command.

SEE ALSO

gen_match_ripper_wire_widths

Controls whether the **create_schematic** command generates rippers whose width always equals the width of the ripped net.

TYPE

Boolean

DEFAULT

false

GROUP

schematic_variables

DESCRIPTION

Controls whether the **create_schematic** command generates rippers whose width always equals the width of the ripped net. The default is *false*. When set to *true*, any rippers whose wire ends connect to scalar nets are of unit width.

By default (*false*), the **create_schematic** command connects scalar nets to the wire ends of multibit rippers. In such a case, all of the concerned bits of the ripper are assumed to be shorted together and connected to that scalar net.

To determine the current value of this variable, type **printvar gen_match_ripper_wire_widths**. For a list of all **schematic** variables and their current values, type **print_variable_group schematic**.

SEE ALSO

schematic_variables(3)

gen_max_compound_name_length

Controls the maximum length of compound names of bus bundles (for the **create_schematic -sge** command).

TYPE

integer

DEFAULT

256

GROUP

schematic_variables

DESCRIPTION

Controls the maximum length of compound names of bus bundles (for the **create_schematic -sge** command). The default is 256, which is the maximum length supported by SGE. Any buses with names longer than this variable are decomposed into their individual members in the schematic. If any such buses connect to cells referencing library symbols, those library symbols are ignored and, instead, new gen-created symbols are used. Any buses these gen-created symbols have whose compound names exceed this length are blown up into their individual members.

To determine the current value of this variable, use **printvar gen_max_compound_name_length**. For a list of all **schematic** variables and their current values, use the **print_variable_group schematic** command.

SEE ALSO

schematic_variables(3)

gen_max_ports_on_symbol_side

Specifies the maximum allowed size of a symbol created by **create_schematic**.

TYPE

integer

DEFAULT

0

GROUP

schematic_variables

DESCRIPTION

Specifies the maximum allowed size of a symbol created by **create_schematic**. For example, if this variable is five, symbols with no more than five ports on any one side are created. If this variable is not set or is set to zero, all input ports are placed on the left side of the symbol and all inout and output ports are on the right.

To determine the current value of this variable use **printvar gen_max_ports_on_symbol_side**. For a list of all **schematic** variables and their current values, use the **print_variable_group schematic** command.

gen_open_name_postfix

Specifies the postfix to be used by **create_schematic -sge** when creating placeholder net names for unconnected pins.

TYPE

Boolean

DEFAULT

" "

GROUP

schematic_variables

DESCRIPTION

Specifies the postfix to be used by **create_schematic -sge** when creating placeholder net names for unconnected pins. The default is " ".

The format of the net names is "%s%d%s", where the first "%s" is replaced by the value of **gen_open_name_prefix**, the second "%s" is replaced by the value of **gen_open_name_postfix**, and the "%d" is replaced by an integer whose value is generated automatically by **create_schematic -sge**.

For example, if **gen_open_name_prefix** = "Open", and **gen_open_name_postfix** = "_net", then the names created by **create_schematic** would be "Open1_net", "Open2_net", and so on.

The default values for **gen_open_name_prefix** and for **gen_open_name_postfix** are "Open" and " ", respectively, so the default names created by **create_schematic** are "Open1", "Open2", and so on.

To determine the current value of this variable, type **printvar gen_open_name_postfix**. For a list of all **schematic** variables and their current values, type **print_variable_group schematic**.

SEE ALSO

gen_open_name_prefix(3)
schematic_variables(3)

gen_open_name_prefix

Specifies the prefix to be used by **create_schematic -sge** when creating placeholder net names for unconnected pins.

TYPE

string

DEFAULT

Open

GROUP

schematic_variables

DESCRIPTION

Specifies the prefix to be used by **create_schematic -sge** when creating placeholder net names for unconnected pins. The default is "Open".

The format of the net names is "%s%d%s", where the first "%s" is replaced by the value of **gen_open_name_prefix**, the second "%s" is replaced by the value of **gen_open_name_postfix**, and the "%d" is replaced by an integer whose value is generated automatically by **create_schematic -sge**.

For example, if **gen_open_name_prefix** = "Open", and **gen_open_name_postfix** = "_net", then the names created by **create_schematic** would be "Open1_net", "Open2_net", and so on.

The default values for **gen_open_name_prefix** and for **gen_open_name_postfix** are "Open" and "", respectively, so the default names created by **create_schematic** are "Open1", "Open2", and so on.

To determine the current value of this variable, type **printvar gen_open_name_prefix**. For a list of all **schematic** variables and their current values, type **print_variable_group schematic**.

SEE ALSO

gen_open_name_postfix(3)
schematic_variables(3)

gen_show_created_busses

Controls whether a message is printed out every time a schematic bus is created from cell pins for which no equivalent net bus exists in the netlist.

TYPE

Boolean

DEFAULT

false

GROUP

schematic_variables

DESCRIPTION

When true, a message is printed out every time a schematic bus is created from cell pins for which no equivalent net bus exists in the netlist. The default is false.

To determine the current value of this variable, type **printvar gen_show_created_busses**. For a list of all **schematic** variables and their current values, type **print_variable_group schematic**.

SEE ALSO

schematic_variables(3)

gen_show_created_symbols

Controls whether **create_schematic** prints a warning message every time it generates a new symbol for a cell because an appropriate symbol could not be found in the symbol libraries.

TYPE

Boolean

DEFAULT

false

GROUP

schematic_variables

DESCRIPTION

Controls whether **create_schematic** prints a warning message every time it generates a new symbol for a cell because an appropriate symbol could not be found in the symbol libraries. The default is false.

To determine the current value of this variable, use **printvar gen_show_created_symbols**. For a list of all **schematic** variables and their current values, use the **print_variable_group schematic** command.

SEE ALSO

schematic_variables(3)

gen_single_osc_per_name

Controls whether more than one off-sheet connector with any particular name is drawn on any schematic sheet.

TYPE

Boolean

DEFAULT

false

GROUP

schematic_variables

DESCRIPTION

When this variable is set to true, only one off-sheet connector with any particular name is drawn on any schematic sheet. In cases where there could potentially be more than one off-sheet connector with the same name on any schematic page, only one connector is drawn and the others just have their net segments show up as unconnected stubs.

To determine the current value of this variable use **printvar gen_single_osc_per_name**. For a list of all **schematic** variables and their current values, use the **print_variable_group schematic** command.

SEE ALSO

schematic_variables(3)

generic_symbol_library

Specifies the generic symbol library used for schematics.

TYPE

string

DEFAULT

generic.sdb

GROUP

schematic_variables

DESCRIPTION

The **db** file that contains generic symbols, templates, and layers used for schematics.

To determine the current value of this variable use **printvar generic_symbol_library**. For a list of all **schematic** variables and their current values, use the **print_variable_group schematic** command.

groute_VABoundaryToLSWeight

DESCRIPTION

The **groute_VABoundaryToLSWeight** variable is used in multivoltage mode. It specifies the value to adjust the cost for a level-shifter connection when switching voltage area from one to another.

SYNTAX

EXAMPLE

groute_avoidCouplingUser

DESCRIPTION

The **groute_avoidCouplingUser** variable enables the global router to space nets during routing. The nets to be considered need to be set with the Set Net Constraints command. If this variable is set to 1, timing spacing will be honored.

SYNTAX

EXAMPLE

groute_avoidXtalk

DESCRIPTION

The **groute_avoidXtalk** variable turns on/disables crosstalk prevention during global routing. If this variable is set to 1, the global router tries to avoid assigning nets with coupling to the same gcell.

SYNTAX

EXAMPLE

groute_blncdToSkewCntrlRatio

DESCRIPTION

The **groute_blncdToSkewCntrlRatio** variable sets a threshold for turning on the balanced skew control mode. For nets with an aspect ratio smaller than the variable value, balanced skew control mode is enabled. The aspect ratio is calculated based on the bounding box formed by enclosing the pins.

SYNTAX

EXAMPLE

groute_blockEdgeAccess

DESCRIPTION

The **groute_blockEdgeAccess** variable allows the global router to access pins on edges of hard macros. By default, the global router reaches pins on edges of hard macros. When the variable is set to 1, it allows the global router is allowed to access or drop vias on whole macro pins without edges limitation.

SYNTAX

EXAMPLE

groute_brokenNetsThresholdPercent

DESCRIPTION

The **groute_brokenNetsThresholdPercent** variable specifies a threshold for incremental global routing to be performed. This is effective when incremental is set to 1.

SYNTAX

EXAMPLE

groute_clockBalanced

DESCRIPTION

The **groute_clockBalanced** variable turns balanced routing on clock nets on and off.

SYNTAX

EXAMPLE

groute_clockComb

DESCRIPTION

The **groute_clockComb** variable enables the global router to connect ports directly to the prerouted clock trunks to minimize clock skew. Be aware that this requires greater routing resources, if the clock pins are not close to the clock trunks. The Comb mode works on designs with pre-existing clock nets.

SYNTAX

EXAMPLE

groute_combDistance

DESCRIPTION

The **groute_combDistance** variable sets a distance threshold, in gcell units, for clock routing to connect clock pins directly to clock nets.

SYNTAX

EXAMPLE

groute_combMaxConnections

DESCRIPTION

The **groute_combMaxConnections** variable limits the number of direct connections allowed to the clock pins from the same clock trunk. The default value of -1 allows a clock net to be connected to any number of clock pins.

SYNTAX

EXAMPLE

groute_compactMode

DESCRIPTION

The **groute_compactMode** variable determines the size of gcell used for global routing. If it is set to 0, gcells of 1 cellrow height will be created. If it is set to 1, the global router automatically adjusts the global route cell size. Increasing the size of gcell will complete the global routing faster at the cost of quality as routing becomes coarser.

SYNTAX

EXAMPLE

groute_congestionWeight

DESCRIPTION

The **groute_congestionWeight** variable specifies the relative importance of routing congestion versus wire length. As the variable value increases, the router tries harder to avoid routing congestion at the cost of increased wire length.

SYNTAX

EXAMPLE

groute_densityDriven

DESCRIPTION

The **groute_densityDriven** variable turns density-driven global routing on or off. In the default mode, the router decides the weight given to density relative to wire length during global routing. If timing driven or crosstalk is turned on, global route turns on the **groute_densityDriven** automatically.

SYNTAX

EXAMPLE

groute_detourLimitMinNetLen

DESCRIPTION

The **groute_detourLimitMinNetLen** variable controls the way the global router implements **maxDetourPercent** on nets. If the value is set to 0, the router forces **maxDetourPercent** on all nets. If the value is set to n, **maxDetourPercent** is applied only to nets of length greater than n gcells.

SYNTAX

EXAMPLE

groute_extraCostsApplyPercent

DESCRIPTION

The **groute_extraCostsApplyPercent** variable applies the **wireCost** and **viaCost** settings to the top n percent of nets in the design. The **wireCost** and **viaCost** variables are route variables. The route extra cost applies to global routing, track assignment and detail routing. This variable applies the extra cost percentage only for global route.

SYNTAX

EXAMPLE

groute_extraWireLengthOpt

DESCRIPTION

The **groute_extraWireLengthOpt** variable instructs the global router to run an additional rerouting phase to reduce wire length on nets that have no congestion. It does not perform any optimization.

SYNTAX

EXAMPLE

groute_forceUpperLayersForCritNets

DESCRIPTION

The **groute_forceUpperLayersForCritNets** variable specifies the mode for upper layers usage. To improve timing, Astro will route timing-critical nets on upper layers that have lower RC.

SYNTAX

EXAMPLE

groute_horReserveTracks

DESCRIPTION

The **groute_horReserveTracks** variable determines the number of horizontal free tracks reserved in each gcell.

SYNTAX

EXAMPLE

groute_ignoreViaBlockage

DESCRIPTION

The **groute_ignoreViaBlockage** variable specifies the mode to honor a via blockage. By default, global route ignores via blockage.

SYNTAX

EXAMPLE

groute_incremental

DESCRIPTION

The **groute_incremental** variable controls whether global router runs `groute_incrementally`.

SYNTAX

EXAMPLE

groute_macroBndryDir

DESCRIPTION

The **groute_macroBndryDir** variable controls the use of **macroBndryTrkUtil** for layers in different directions. If the value is set to 1, **macroBndryTrkUtil** will be applied to layers in both directions.

SYNTAX

EXAMPLE

groute_macroBndryTrkUtil

DESCRIPTION

The **groute_macroBndryTrkUtil** variable limits the utilization of tracks available in the gcells near a macro boundary to a specified percentage. This variable is used to control the accessibility of pins and congestion at the macro boundaries. By default, the router uses 100 percent of available tracks in the macro boundary width.

SYNTAX

EXAMPLE

groute_macroBndryWidth

DESCRIPTION

The **groute_macroBndryWidth** variable specifies a distance from the corners of macros. Within this distance, the global router obeys the limits on track utilization specified by **macroCornerTrkUtil** and **macroBndryTrkUtil**. By default, one row or column of gcells is considered from the corners of the macro.

SYNTAX

EXAMPLE

groute_macroCornerTrkUtil

DESCRIPTION

The **groute_macroCornerTrkUtil** variable limits the utilization of tracks available in the gcells near a macro corner to a specified percentage. This variable is used to control the accessibility of pins and congestion at the macro corners. By default, the router uses 100 percent of available tracks in the macro boundary width.

SYNTAX

EXAMPLE

groute_mapOnly

DESCRIPTION

The **groute_mapOnly** variable specifies whether the router generates the congestion map based on global routing without creating the global wires.

SYNTAX

EXAMPLE

groute_maxDetourPercent

DESCRIPTION

The **groute_maxDetourPercent** variable directs the global router to have no more than the specified percentage of detours on any net. If the value is set to -1, the router is free to make any number of detours (or none).

SYNTAX

EXAMPLE

groute_netCriticality

DESCRIPTION

The **groute_netCriticality** variable determines the order in which the global router routes the nets during initial route. Net criticality can be set on nets in the design by using the Scheme function **dbSetNetCriticality**. If this variable is set to 1, the global router first routes the nets with higher criticality value. If the value is set to 0, net criticality has no effect on routing order. However, net criticality always has an effect on the congestion cost.

SYNTAX

EXAMPLE

groute_noTopLevelBusFeedThroughs

DESCRIPTION

The **groute_noTopLevelBusFeedThroughs** variable determines whether feedthroughs are allowed on bus signals.

SYNTAX

EXAMPLE

groute_paEqPinNetMaxPort

DESCRIPTION

Setting the **groute_paEqPinNetMaxPort** variable to 1 creates equivalent pins for nets with no more than n ports.

SYNTAX

EXAMPLE

groute_powerDriven

DESCRIPTION

The **groute_powerDriven** variable turns power-driven global routing on or off.

SYNTAX

EXAMPLE

groute_rcOptByLength

DESCRIPTION

The **groute_rcOptByLength** variable controls the choice of layers for global router to reduce RC. The global router chooses layers with lower RC values based on the value of this variable. This variable is only active when the timing driven global route option is enabled.

SYNTAX

EXAMPLE

groute_reportDemandOnly

DESCRIPTION

The **groute_reportDemandOnly** variable specifies the mode to report demand only. In this mode, Astro performs virtual route only, with no reroute phases. In the log file, it reports average gcell capacity per layer.

SYNTAX

EXAMPLE

groute_reportEffectiveOverflow

DESCRIPTION

The **groute_reportEffectiveOverflow** variable specifies the mode for generating an effective overflow report.

SYNTAX

EXAMPLE

groute_reportGCellDensity

DESCRIPTION

The **groute_reportGCellDensity** variable controls reporting of gcell density for each layer. In density-driven mode, the router generates a report of gcell density. However, this variable is independent of the density-driven switch.

SYNTAX

EXAMPLE

groute_reportNetOrdering

DESCRIPTION

The **groute_reportNetOrdering** variable specifies the number of nets to be reported according to the routing order. By default, the global router does not report on net ordering. If this variable is set to n, global route will report the first n nets in the order of routing.

SYNTAX

EXAMPLE

groute_reserveTracksForPowerFile

DESCRIPTION

The file indicated by the **groute_reserveTracksForPowerFile** variable is used to define the percentage of routing tracks on each layer that are reserved for power routing. For example, Suppose the **reservedTracks.rc** file defines METAL1 layer as 20. Then, the router reserves 20 percent of available routing tracks in METAL1 for power routing later. Therefore, global route uses only 80 percent of the routing tracks.

SYNTAX

EXAMPLE

groute_skewControl

DESCRIPTION

The **groute_skewControl** variable turns skew control on or off during global routing. If the value is set to 1, the global router tries to minimize the gross delay in net skew. Skew control applies to all signal nets (except for small nets) but skew control for clock nets occurs only when **clockBalanced** is set to 1.

SYNTAX

EXAMPLE

groute_skewControlWeight

DESCRIPTION

The **groute_skewControlWeight** variable determines the importance given to skew control on the net during global routing. You can set the skew control weight from 1 to 10 based on net criticality.

SYNTAX

EXAMPLE

groute_speed

DESCRIPTION

The **groute_speed** variable specifies the effort at which the global router should run. The global router runs a different number of phases, depending on the specified value. It is recommended you run the router in default mode.

SYNTAX

EXAMPLE

groute_timingDriven

DESCRIPTION

The **groute_timingDriven** variable turns timing-driven global routing on or off. The **timingWeight** variable controls the trade-off between timing and wire length during global routing. By default, timing-driven mode is turned off.

SYNTAX

EXAMPLE

groute_timingWeight

DESCRIPTION

The **groute_timingWeight** variable sets the weight given to the timing relative to wire length during global routing. This variable is effective only in timing-driven mode.

SYNTAX

EXAMPLE

groute_turboMode

DESCRIPTION

The **groute_turboMode** variable is used to improve runtime.

SYNTAX

EXAMPLE

groute_verReserveTracks

DESCRIPTION

The **groute_verReserveTracks** variable determines the number of vertical free tracks reserved in each gcell.

SYNTAX

EXAMPLE

groute_xtalkWeight

DESCRIPTION

The **groute_xtalkWeight** variable defines the weight given to crosstalk prevention during global routing.

SYNTAX

EXAMPLE

hdl_variables

SYNTAX

```
string bus_dimension_separator_style =    "]"["
string bus_minus_style =                  "-%d"
string bus_naming_style =                  "%s[%d]"
long design_filename_length = "0"
Boolean hdl_keep_licenses =                "true"
string hdl_preferred_license =              ""
Boolean hdlin_auto_save_templates = "false"
Boolean hdlin_check_input_netlist = "false"
Boolean hdlin_check_no_latch = "false"
Boolean hdlin_elab_errors_deep = "false"
Boolean hdlin_enable_assertions = "false"
Boolean hdlin_enable_configurations = "false"
Boolean hdlin_enable_rtlsrc_info = "false"
Boolean hdlin_ff_always_async_set_reset = "true"
Boolean hdlin_ff_always_sync_set_reset = "false"
string hdlin_field_naming_style = ""
string hdlin_generate_naming_style = "%s_%d"
string hdlin_generate_separator_style = "_"
Boolean hdlin_ignore_textio_constructs = "true"
Boolean hdlin_infer_function_local_latches = "false"
string hdlin_infer_multibit = "default_none"
string hdlin_infer_mux = "default"
string hdlin_keep_signal_name = "all_driving"
Boolean hdlin_latch_always_async_set_reset = "false"
Boolean hdlin_module_arch_name_splitting = "false"
int hdlin_module_name_limit = 256
int hdlin_mux_oversize_ratio = 100
int hdlin_mux_size_limit = 32
int hdlin_mux_size_min = 2
int hdlin_mux_size_only = 1
int hdlin_optimize_pla_effort = 2
string hdlin_preserve_sequential = "none"
string hdlin_presto_cell_name_prefix = "C"
string hdlin_presto_net_name_prefix = "N"
Boolean hdlin_prohibit_nontri_multiple_drivers = "true"
string hdlin_reporting_level = "basic"
Boolean hdlin_shorten_long_module_name = "false"
Boolean hdlin_subprogram_default_values = "false"
int hdlin_sv_ieee_assignment_patterns = 1
string hdlin_sv_packages = "enable"
Boolean hdlin_sv_tokens = "false"
Boolean hdlin_upcase_names = "false"
Boolean hdlin_vhdl93_concat = "true"
Boolean hdlin_vhdl_87 = "false"
int hdlin_vrlg_std = 2001
int hdlin_while_loop_iterations = 1024
string hlo_resource_allocation = "constraint_driven"
string hlo_resource_implementation = "use_fastest"
string systemcout_levelize = "true"
string template_naming_style = "%s_%p"
```

```

string template_parameter_style = "%s%d"
string template_separator_style = "_"
Boolean verilogout_equation = "false"
Boolean verilogout_higher_designs_first = "FALSE"
Boolean verilogout_ignore_case = "false"
list verilogout_include_files = {}
Boolean verilogout_no_tri = "false"
Boolean verilogout_single_bit = "false"
string verilogout_unconnected_prefix = "SYNOPSYS_UNCONNECTED_"
string xterm_executable = "xterm"

```

DESCRIPTION

These variables affect the **read** and **write** commands for Verilog and VHDL.

For more information on Verilog and VHDL variables, refer to the *HDL Compiler for Verilog Reference* and *VHDL Compiler Reference* manuals.

For a list of these variables and their current values, type **print_variable_group hdl**. To view this manual page online, type **help hdl_variables**. To view an individual variable description, type **help var**, where *var* is the variable name.

bus_dimension_separator_style

This variable affects the **read** command with the **verilog**, **vhdl** or **edif** format options. In conjunction with the **bus_naming_style** variable, **bus_dimension_separator_style** controls the naming of individual bit-blasted ports derived from multidimensional arrays. This variable also affects the naming of bit-blasted multidimensional instance arrays and bit-blasted multidimensional net arrays in exactly the same way for ports.

bus_minus_style

This variable affects the **read** command with **vhdl** format option. For this option, this variable controls the naming of individual members of bit-blasted port, instance, or net busses with negative indices.

bus_naming_style

This variable affects the **read**, **write**, and **create_schematic** commands. For the **read** command with the **vhdl** or **verilog** format options, this variable controls the naming of bit-blasted ports in **dc_shell** when they are created from multidimensional busses in the original source.

For the **write** command with the **edif** format option, this variable controls the naming of individual members of each bus in the **edif** output. Also, together with the **bus_range_separator_style** and **bus_multiple_separator_style** variables, this variable controls how ranged names of busses are written to the **edif** output.

For the **create_schematic** command, this variable controls the naming of bus rippers that rip off bits from bussed nets. Together with the **bus_range_separator_style** variable, it also controls the naming of bussed nets, bussed ports, and bussed rippers in the schematic. Works the same as **write -f edif**.

hdl_keep_licenses

When *true* (the default value), **hdl** licenses that are checked out remain checked out throughout the **dc_shell** session. When this variable is *false*, **hdl**

licenses are released during execution of **compile**, after **compile** has completed the subtasks that require the license.

hdl_preferred_license

Selects an hdl license to check out, if none is currently checked out. Allowed values are *vhdl*, which selects the VHDL-Compiler license, or *verilog*, which selects the HDL-Compiler license.

hdlin_auto_save_templates

Controls whether HDL designs containing parameters are read in as templates. The default is *false*.

hdlin_check_input_netlist

Instructs the Verilog netlist reader in *dc_shell*/*psyn_shell* to check for the names conflict. The default is *false*.

hdlin_check_no_latch

When *true*, a warning message is issued if a latch is inferred from a design. This is useful for verifying that a combinational design does not contain memory components. The default is *false*.

hdlin_elab_errors_deep

Allows the user to be in debug mode to clean RTL with elaboration errors, link errors and internal errors or not. The default is *false*.

hdlin_enable_assertions

Control Presto HDL compiler's use of SystemVerilog Assertions. The default is *false*.

hdlin_enable_configurations

Control the configuration support by Presto VHDL. The default is *false*.

hdlin_enable_rtl_drc_info

When *true*, RTL TestDRC filename and linenummer information is created for designs processed by subsequent *dc_shell* commands. When *false*, no RTL TestDRC information is created.

hdlin_ff_always_async_set_reset

When *true* (the default value), the HDL Compiler checks and reports asynchronous set and reset conditions of flip-flops. Setting this variable to *false* disables this behavior. Set this variable to *false* if you: do not use asynchronous set or reset conditions; do not want asynchronous set or reset devices inferred; and/or want your design to be input faster.

hdlin_ff_always_sync_set_reset

When *true*, for a design subsequently analyzed, every constant 0 loaded on a flip-flop under the clock event is used for synchronous reset, and every constant 1 loaded on a flip-flop under the clock event is used for synchronous set. The default is *false*.

hdlin_field_naming_style

Defines the parts of the net names that Presto HDL Compiler generates corresponding to the fields in VHDL records or in SystemVerilog structs. By default, the **hdlin_field_naming_style** is derived from the **bus_naming_style** and **bus_dimension_separator_style**. The default is empty string "".

hdl_variables

hdlin_generate_naming_style
 Specifies the naming style for *generated* design instances in VHDL designs. The default is `%s_%d`.

hdlin_generate_separator_style
 Specifies the separator string for instances generated in multiple-nested loops. The default is `_`.

hdlin_ignore_textio_constrcuts
 Controls whether the two commands **read** and **analyze** should warn or error when encountering STD.TEXTIO constructs in VHDL code. The default is *true*.

hdlin_infer_function_local_latches
 Controls whether the Presto HDL Compiler infers latches inside functions and tasks. The default is *false*.

hdlin_infer_multibit
 Specifies inference of multibit components for an entire design. The allowed values for **hdlin_infer_multibit** are *default_all*, *default_none*, and *never*. The default is *default_none*.

hdlin_infer_mux
 When *all*, HDL Compiler attempts to infer a MUX_OP for a signal/variable assigned in a *case* statement. When *none*, HDL Compiler does not attempt to infer any MUX_OPs for a Verilog/VHDL design. When *default* (the default value), HDL Compiler attempts to infer a MUX_OP for a signal/variable assigned in a *case* statement if the statement is in a process associated with the **infer_mux** attribute/directive.

hdlin_keep_signal_name
 Determines whether HDL Compiler attempts to keep a signal name. The allowed values are **all**, **none**, **user**, **user_driving**, and **all_driving**. The default is *all_driving*.

hdlin_latch_always_async_set_reset
 Uses, for asynchronous reset, every constant 0 loaded on a latch, and uses, for asynchronous set, every constant 1 loaded on a latch, for a design subsequently analyzed. The default is *false*.

hdlin_module_arch_name_splitting
 Controls whether Presto HDL Compiler recognizes a special format of Verilog module names, which allows users to specify both a module and an implementation architecture. The default is *false*.

hdlin_module_name_limit
 The length threshold for compressing elaborated module names when **hdlin_shorten_long_module_name** is true. The default is 256.

hdlin_mux_oversize_ratio
 An integer that prevents inference of a sparse multiplexor. When the ratio of MUX_OP data inputs to unique data inputs is above the **hdlin_mux_oversize_ratio**, a MUX_OP will not be inferred. The default ratio is 100.

hdlin_mux_size_limit

An integer that limits the number of inputs of an inferred multiplexer. The default is 32. HDL Compiler does not generate MUX_OPs for multiplexers specified with more than this maximum number of inputs. The size of a multiplexer can be impounded by nested **if** or **case** statements.

hdlin_mux_size_min

Sets the lower bound for the number of inputs required to infer a multiplexer. The default value is 2.

hdlin_mux_size_only

Controls which MUX_OP cells receive the **size_only** attribute in Presto HDL Compiler. When 0, no cells receive the **size_only** attribute. When 1, MUX_OP cells that are generated with the RTL **infer_mux** pragma and that are on set/reset signals receive the **size_only** attribute. When 2, all MUX_OP cells that are generated with the RTL **infer_mux** pragma receive the **size_only** attribute. When 3, all MUX_OP cells on set/reset signals receive the **size_only** attribute. When 4, all MUX_OP cells receive the **size_only** attribute. The default value is 1.

hdlin_optimize_pla_effort

Controls the effort the Presto HDL Compiler puts into optimization of PLA like constant CASE statements. The allowed values are 1, 2 and 3. The default value is 2.

hdlin_preserve_sequential

Controls whether the **elaborate** and **read** commands retain unloaded sequential cells in the design. The allowed values are *none* (or *false*), *all* (or *true*), *all+loop_variables* (or *true+loop_variables*), *ff*, *ff+loop_variables*, *latch*, and *latch+loop_variables*. The default value is *none*.

hdlin_presto_cell_name_prefix

Sets the internal cell name prefix for HDL Compiler. The default value is *C*.

hdlin_presto_net_name_prefix

Sets internal net name prefix for HDL Compiler. The default value is *N*.

hdlin_prohibit_nontri_multiple_drivers

Controls whether the HDL Compiler issues an error, or only a warning, when it finds multiple drivers of a net. The default is *true*.

hdlin_reporting_level

Determines whether HDL Compiler prints which information in the report. The allowed values are *none*, *basic*, *comprehensive*, and *verbose*. The default is *basic*.

hdlin_shorten_long_module_name

Controls whether HDL Compiler compresses long names of elaborated modules. The default is *false*.

hdlin_subprogram_default_values

Determines which value HDL Compiler will use as the default value for variables, 'LEFT of its type or 0s. When this variable is set to *true*, 'LEFT of the type of variable is used as its default value. If you set this variable to *false*, 0s are used. The default is *false*.

hdlin_sv_ieee_assignment_patterns

Controls the level of support for IEEE-1800 SystemVerilog assignment patterns. The allowed values are *0*, *1* and *2*. When *0*, the IEEE-1800 SystemVerilog assignment patterns are not supported. When *1*, the IEEE-1800 SystemVerilog assignment patterns are supported in the right side of all legal, synthesizable assignment-like contexts, except module and interface instantiations. When *2*, the IEEE-1800 SystemVerilog assignment patterns are supported in the right side of all legal, synthesizable assignment-like contexts, including module instantiations. The default value is *1*.

hdlin_sv_packages

Specifies whether and how System Verilog packages should be analyzed. The allowed values are *none*, *chain*, *dont_chain*, and *enable*. The default value is *enable*.

hdlin_sv_tokens

Specifies whether a tokens file should be written out during the analysis of SystemVerilog designs. The default is *false*.

hdlin_upcase_names

Controls whether identifiers in the Verilog source code are converted to uppercase letters or left in their original case. The default is *false*.

hdlin_vhdl93_concat

Controls the concatenation behavior the tool uses to conform to the VHDL '93 Standard or the VHDL '87 Standard. The default is *true*.

hdlin_vhdl_87

Controls whether VHDL Compiler (Presto) follows VHDL '93 Standard or VHDL '87 Standard. The default is *false*.

hdlin_vrlg_std

Controls whether Presto Verilog/SystemVerilog enforces Verilog 1995 or Verilog 2001 or Verilog/SystemVerilog 2005 or SystemVerilog 2009. The allowed values are *1995*, *2001*, *2005*, and *2009*. The default is *2001*.

hdlin_while_loop_iterations

Places an upper bound on the number of times a loop is unrolled (to prevent potential infinite loops). The default is *1024*.

hlo_resource_allocation

Sets the default resource sharing type if the **resource_allocation** attribute is not set. Allowed values are *constraint_driven*, *area_only*, *area_no_tree_balancing* and *none*.

hlo_resource_implementation

Sets the default implementation selection type if the **resource_implementation** attribute is not set. Allowed values are *constraint_driven*, *area_only*, and *use_fastest*.

systemcout_levelize

Levelizes and flattens the netlist (when true) and replaces standard DesignWare operations with simulatable SystemC, before writing out the netlist, during **write -f systemc** command activity.

template_naming_style

One of three string variables that determine the naming conventions for parameterized modules (templates). Determines what character(s) will appear between the design name and the parameter name. The default is an underscore(_).

template_parameter_style

One of three string variables that determine the naming conventions for parameterized modules (templates). Determines what character(s) will appear between the parameter name and its value. The default is null (no separation).

template_separator_style

One of three string variables that determine the naming conventions for parameterized modules (templates). Determines what character(s) will appear between parameter names for templates that have more than one parameter. The default is an underscore (_).

verilogout_equation

When *true*, writes Verilog "assign" statements (Boolean equations) for combinational gates, rather than gate instantiations.

verilogout_higher_designs_first

When *true*, writes Verilog "modules" ordered so that higher level designs come before lower level designs as defined by the design hierarchy. Default is to write lower level designs first.

verilogout_ignore_case

When *true*, case is not considered when identifiers are compared against Verilog reserved words.

verilogout_include_files

write -f verilog writes an include statement with the value that you set in this variable.

verilogout_no_tri

When *true*, three-state nets are declared as Verilog "wire" instead of "tri." This variable is useful in eliminating "assign" primitives and "tran" gates in the Verilog output.

verilogout_single_bit

When *true*, does not output vectored ports in Verilog output. Instead, all vectors are written as single bits.

verilogout_unconnected_prefix

When this variable is set, the verilog writer in dc_shell uses this name to create unconnected wire names. The general form of the is "SYNOSPYS_UNCONNECTED_%d".

xterm_executable

Specifies the path to an xterm program that is spawned to run Synopsys analysis tools such as RTL Analyzer or BCView. If an xterm is not found in your path, you can set this variable to point to an xterm executable.

SEE ALSO

`elaborate (2)`, `read (2)`, `write (2)`.

hdlin_auto_save_templates

Controls whether HDL designs containing parameters are read in as templates.

TYPE

Boolean

DEFAULT

false

GROUP

hdl_variables

DESCRIPTION

This variable, when set to true, reads in HDL designs containing parameters as templates. HDL parameter files include Verilog modules with parameter declarations and VHDL entities with generic declarations.

When an HDL file is read in as a template, it can be manipulated with the **printvar - templates**, **remove_template**, and **elaborate** commands. The template can also be built automatically when instantiated from another HDL design.

When false (the default value), HDL designs are read in and built instantly. This can be overridden for a design with a template pseudo comment.

For Verilog, place the following comment anywhere in the module:

```
// synopsys template
```

For VHDL, place the following comment in the entity after the **port** declaration:

```
-- synopsys template
```

To determine the current value of this variable, use the **printvar hdlin_auto_save_templates** command. For a list of HDL variables and their current values, use the **print_variable_group hdl** command.

SEE ALSO

template_parameter_style(3)
template_separator_style(3)

hdlin_enable_assertions

Control Presto HDL compiler's use of SystemVerilog Assertions.

TYPE

Boolean

DEFAULT

false

GROUP

hdl_variables

DESCRIPTION

Setting **hdlin_enable_assertions** to *true* allows the **elaborate** and **read_sverilog** commands to process a synthesis-friendly subset of SystemVerilog RTL Assertions. Facts added via assertions can contribute to optimization by ruling out machine states that cannot arise during normal operation of the design. This switch controls actions taken only during **elaborate**-phase, including elaborations that occur during linkage or compilation.

To be activated, an assertion statement must belong to a narrow category of synthesizable deferred immediate assertions. It must have a dedicated statement label that gives it a unique, lexically scoped, name. And it must be **analyze**'d in **sverilog** format (or by **read_sverilog**).

- The asserted expression should compare only one variable or signal to a compile-time constant, or else
- It should make a \$onehot or \$onehot0 claim about a collection of signal wires.

Consult the SystemVerilog User Guide for the exact definition of the subset currently supported by this release. All labelled assertions within this subset survive analysis regardless of the `enable_assertions` switch setting.

To **confirm** that an assertion should be considered during optimization:

- Set **hdlin_enable_assertions true** when it is being elaborated, *and*
- Set the lexically scoped name of its statement label as an element of the **confirmed_SVA()** array variable in the `dc_shell` environment in which the assertion is elaborated; give it the value *true*.

When all the above conditions are met, the labeled and confirmed assertions encoded in the intermediate (or template) design files can begin to influence logic minimization done by Presto HDL compiler. Note that either linking or elaborating designs with unresolved template references can cause subdesign elaborations whose confirmed assertions may also be exploited by Presto's optimizations. Here is an

example that confirms three assertions named "assertion_label1:",
"global_assertion1", and "assumption_about_port":

```
analyze -f sverilog my_file.sv
# The following lines can be brought in via a source command
set confirmed_SVA(module1.scope1.assertion_label1) true
set confirmed_SVA(module1.global_assertion1) true
set confirmed_SVA(module2.generated_scope[0].assumption_about_port) true

set hdlin_enable_assertions true
elaborate module2
```

SEE ALSO

hdlin_mux_size_only

Controls which MUX_OP cells receive the **size_only** attribute in Presto HDL Compiler.

TYPE

integer

DEFAULT

1

GROUP

hdl_variables

DESCRIPTION

To ensure that MUX_OP GTECH cells are mapped to MUX technology cells, you must apply a **size_only** attribute to the cells to prevent logic decomposition in later optimization steps. Beginning with the B-2008.09-SP3 release, you can control which MUX_OP cells receive the **size_only** attribute by using the **hdlin_mux_size_only** variable. The following options are valid for **hdlin_mux_size_only**:

0 Specifies that no cells receive the **size_only** attribute

1 Specifies that MUX_OP cells that are generated with the RTL **infer_mux** pragma and that are on set/reset signals receive the **size_only** attribute

2 Specifies that all MUX_OP cells that are generated with the RTL **infer_mux** pragma receive the **size_only** attribute

3 Specifies that all MUX_OP cells on set/reset signals receive the **size_only** attribute: for example, MUX_OP cells that are generated by the **hdlin_infer_mux** variable set to **all**

4 Specifies that all MUX_OP cells receive the **size_only** attribute: for example, MUX_OP cells that are generated by the **hdlin_infer_mux** variable set to **all**.

SEE ALSO

set_size_only(2)

hdlin_optimize_pla_effort

Controls the effort the Presto HDL Compiler puts into optimization of PLA like constant CASE statements

TYPE

integer

DEFAULT

2

GROUP

hdl_variables

DESCRIPTION

This variable controls the effort that the Presto HDL Compiler puts into optimization of constant CASE statements that are FULL and PARALLEL.

The default value of this variable is 2. Default value can be overridden With 1 or 3. When the default value is overridden with 1, optimization of the constant CASE statement may be less likely. If the default value is overridden with 3, Presto will put higher effort in optimization of the constant CASE statements.

hdlin_reporting_level

Determines which information Presto HDL Compiler prints in the report.

TYPE

string

DEFAULT

basic

GROUP

hdl_variables

DESCRIPTION

This variable controls the amount of output information to be included in the Presto (elaboration) report.

The following information is under control:

floating_net_to_ground prints the report for floating net connects to ground. This variable is better used in conjunction with the **set hdlin_keep_signal_name user** command and is not guaranteed to report all nets. The **check_design** command is recommended for detecting unconnected pins and ports.

fsm prints the report for inferred state variables.

inferred_modules prints the report for inferred sequential elements.

mux_op prints the report for MUX_OPs.

syn_cell prints the report for synthetic cells.

tri_state prints the report for inferred tri-state elements.

The **hdlin_reporting_level** variable can be set to 4 base settings: **none**, **basic**, **comprehensive**, and **verbose**, as shown in the following table:

Table 1 Base Settings

Information included in report	none	basic	comprehensive	verbose
floating_net_to_ground	false	false	true	true
fsm	false	false	true	true
inferred_modules	false	true	true	verbose
mux_op	false	true	true	true
syn_cell	false	false	true	true
tri_state	false	true	true	true

In addition to the base settings above, you can also modify the base settings to have fine grain control of individual reports through either adding (+) or

subtracting (-) specific report(s) from the base setting with the following keywords:

```
floating_net_to_ground
fsm
syn_cell
mux_op
inferred_modules
tri_state
```

EXAMPLES

The following example uses **comprehensive-fsm**:

```
set hdlin_reporting_level comprehensive-fsm
```

The generated report shows the following settings:

```
floating_net_to_ground  true
fsm                     false
inferred_modules        true
mux_op                  true
syn_cells               true
tri_states              true
```

The following example uses **verbose-mux_op-tri_state**:

```
set hdlin_reporting_level verbose-mux_op-tri_state
```

The generated report shows the following settings:

```
floating_net_to_groundi true
fsm                     true
inferred_modules        verbose
mux_op                  false
syn_cell                true
tri_statei              false
```

The following example shows two commands that generate equivalent reports:

```
set hdlin_reporting_level basic+floating_net_to_ground+syn_cell+syn_cell+fsm
```

```
set hdlin_reporting_level comprehensive
```

SEE ALSO

hdl_variables(3)

hdlin_sv_ieee_assignment_patterns

Controls the level of support for IEEE-1800 SystemVerilog assignment patterns.

TYPE

integer

DEFAULT

1

GROUP

hdl_variables

DESCRIPTION

This variable controls the level of support for IEEE-1800 SystemVerilog assignment patterns.

The value of this variable can be overridden to 0 or to 2. When the value of this variable is 0, the IEEE-1800 SystemVerilog assignment patterns are not supported. When the value of this variable is set to 1, the IEEE-1800 SystemVerilog assignment patterns are supported in the right side of all legal, synthesizable assignment-like contexts, except module and interface instantiations. When the value of this variable is set to 2, the IEEE-1800 SystemVerilog assignment patterns are supported in the right side of all legal, synthesizable assignment-like contexts, including module instantiations.

Values less than 0 are treated as 0. Values greater than 2 are treated as 2.

SEE ALSO

hdl_variables(3)

hdlin_sv_packages

Specifies whether and how System Verilog packages should be analyzed.

TYPE

string

DEFAULT

enable

GROUP

hdl_variables

DESCRIPTION

Specifies which, if any, semantics the `analyze` or `read` command should apply when a `-format sverilog` source file declares a package. The setting affects the `analyze` step of SystemVerilog package declarations or references; it has no effect during `elaborate`: all synthesizable package semantics (including VHDL packages) are supported by `elaborate`, `link` and `compile`. The allowed values for **hdlin_sv_packages** are *none*, *chain*, *dont_chain* and the recommended setting: *enable*.

The setting *none* prevents parsing of package declarations or references.

All other settings accept "packages" (declarations, references and imports) as specified in section 19.2 of the IEEE-1800-2005 System Verilog standard. The default (and recommended) setting for SV package users is *enable*, it provides a synthesizable subset of packages that is compatible with the current release of Synopsys' VCS and Formality products.

Although the SV package standard was approved after the first commercial implementations had been released, there is only one known dialect incompatibility. If you receive a VER-934 Informational message, you may need to choose a specific package definition to be compatible with your local simulation tool. The only difference is in how an *import* statement treats names imported into the topmost (global) scope of a `package_declaration`:

- The *dont_chain* setting prevents imported names from being re-exported to clients of the package being declared.
- The *chain* setting always re-exports names that are imported into the global scope of a package; they may all be imported by the intermediate package's clients. An imported name and its definition which are re-exported ("chained" in VCS parlance) will not collide or interfere with copies of themselves in those cases where several intermediate packages redistribute content they acquired from a common source package (provided they all acquire it from a compatible analyzed version of the same source file).

In both variants, an imported name can be used freely within a package declaration to implement the package's exported content. The analyzed result, a file named `<package_identifier>.pvk`, always contains a full copy of all imported content. A package's `.pvk` file can stand alone; it does not require its clients to access the `.pvk` files that supplied its imported ingredients (unlike source-level file inclusion).

The chaining issue only concerns whether imported names become explicitly visible to an intermediate package's clients as do objects explicitly declared at the outermost level of the intermediate package. Because a wildcard `"import intermediate_pkg::*;"` encumbers all of the exportable names found in `"intermediate_pkg"`, the `chain/dont_chain` choice can alter the outcome of name resolutions when several packages are combined in a downstream client.

The setting of `hdlin_sv_packages` at the time a package is analyzed is compiled into a "visibility" property on the imported, global names in the resulting `.pvk` file. This is an independent property that can be different at each level of a supply chain; it is not an inherited property of the name itself. A VER-934 informational message always indicates how this property is being set for those names where it may eventually matter.

Synopsys feels that intermediate (redistribution) packages are a valuable means to manage the "greatest hits" likely to be found in large design shops. In future releases, the `enable` setting will continue to track developments as the definition of SV packages converges on a comprehensive standard. The settings `chain` and `dont_chain` will continue to implement the `import_statement` semantics specified above, one of which will eventually be ruled non-standard.

For details, refer to the *IEEE-1800-2005 System Verilog Reference Manual* or the *VCS Simulation Compiler Reference Manual*.

To determine the current value of this variable, type **`printvar hdlin_sv_packages`**. For a list of hdl variables and their current values, type **`print_variable_group hdl`**.

SEE ALSO

`hdl_variables(3)`

hercules_home_dir

Specifies the path to the Hercules installation to be used for VUE to ICC integration.

TYPE

string

DEFAULT

" "

DESCRIPTION

This variable specifies the version of Hercules which should be used to load the Hercules extensions to the ICC GUI. This extension provides additional functions for launching Hercules VUE and connecting it to the ICC GUI. If this variable is set (and if it points to a valid Hercules installation) then the Hercules extensions to the ICC GUI will be automatically loaded when the ICC GUI is first brought up. If you have the HERCULES_HOME_DIR environment variable set, but you do not wish to have the Hercules GUI extensions loaded into ICC, then set this variable in your .synopsys_dc.setup file to "".

hier_dont_trace_ungroup

Disables ungroup tracing set on the design with the **ungroup** command.

TYPE

Boolean

DEFAULT

0

DESCRIPTION

Disables ungroup tracing set on the design with the **ungroup** command. When **hier_dont_trace_ungroup** is set to 0 (the default), the **ungroup** command places on the design being ungrouped a string attribute that describes the ungroup operation. Other tools (for example, RTL Analyzer) can later use the attribute to recreate the ungroup operation and thus trace between the mapped and GTECH (generic) circuits.

Setting **hier_dont_trace_ungroup** to 1 disables ungroup tracing and can increase the efficiency of the **ungroup** and other commands.

SEE ALSO

`ungroup(2)`

high_fanout_net_pin_capacitance

Specifies the pin capacitance used to compute the loading of high-fanout nets.

TYPE

float

DEFAULT

1.000000

GROUP

timing_variables

DESCRIPTION

Specifies the pin capacitance used to compute the loading of high-fanout nets.

The pin capacitance for high-fanout nets is computed by multiplying the capacitance specified by the **high_fanout_net_pin_capacitance** variable times the high-fanout threshold.

For best results the pin capacitance chosen should be large enough to cause violations on all constrained high-fanout nets. This should force the nets to be replaced with buffer trees during compilation.

To determine the current value of this variable, type **printvar high_fanout_net_pin_capacitance**. For a list of all timing variables and their current values, type **print_variable_group timing**.

SEE ALSO

high_fanout_net_threshold(3)

high_fanout_net_threshold

Specifies the minimum number of loads for a net to be classified as a high-fanout net.

TYPE

integer

DEFAULT

1000

GROUP

timing_variables

DESCRIPTION

Specifies the minimum number of loads for a net to be classified as a high-fanout net.

Delays and loads of high-fanout are computed using a simplified model assuming a fixed fanout number. The rationale behind this is that delays of high-fanout nets are expensive to compute but such nets are often unconstrained (as in the case of global reset nets, scan enable nets, and so on). Those high-fanout nets that actually are constrained should eventually be replaced by buffer trees. So detailed delay calculations on such nets are expensive and usually unnecessary.

Setting the threshold to 0 (or to a very large number) ensures that no nets will be treated as high-fanout nets. However you should be aware that forcing fully accurate delay calculations on high-fanout can significantly increase compilation runtime in some cases.

The pin capacitance for high-fanout nets is computed by multiplying the capacitance specified by the **high_fanout_net_pin_capacitance** variable times the high-fanout threshold plus the number of net drivers.

The simplified net delay model is only used when computing data delays. Propagated clock latencies are always computed using the full accuracy net delay model.

To determine the current value of this variable, type **printvar high_fanout_net_threshold**. For a list of all timing variables and their current values, type **print_variable_group timing**.

SEE ALSO

`high_fanout_net_pin_capacitance(3)`

icc_magnetpl_stop_after_seq_cell

Controls if sequential cells need to be pulled towards a specified magnet during **magnet_placement** the with **-stop_by_sequential_cells** option.

TYPE

Boolean

DEFAULT

false

DESCRIPTION

The **icc_magnetpl_stop_after_seq_cell** variable controls whether sequential cells need to be pulled towards a specified magnet when using the **magnet_placement** command with the **-stop_by_sequential_cells** option. By default, the magnet placement operation is terminated before the sequential cell element when specified with the **-stop_by_sequential_cells** option.

SEE ALSO

get_magnet_cells(2)
magnet_placement(2)

icc_snapshot_storage_location

Specifies the location for the `create_qor_snapshot`, `remove_qor_snapshot`, and `report_qor_snapshot` utilities.

TYPE

string

DEFAULT

snapshot

DESCRIPTION

This variable specifies the location in which to store snapshot data for the **`create_qor_snapshot`** command. The **`report_qor_snapshot`** command generates and reports snapshot data from this location. The **`remove_qor_snapshot`** command deletes snapshot(s) from this location.

SEE ALSO

`create_qor_snapshot(2)`
`remove_qor_snapshot(2)`
`report_qor_snapshot(2)`

ignore_guardband

Specifies that power switches inserted will not honor other voltage areas' guardband while executing command `create_power_switch_array`. The default is *false*.

TYPE

Boolean

DEFAULT

false

DESCRIPTION

When this variable is set *true*, power switches inserted by command `create_power_switch_array` will not honor other voltage areas' guardband.

SEE ALSO

`create_power_switch_array(2)`

ilm_enable_power_calculation

Perform power calculation on design which is to be used as ILM block.

TYPE

Boolean

DEFAULT

true

GROUP

power_variables

DESCRIPTION

create_ilm command processes the hierarchical block and remove the core logic, leaving only the interface logic behind. Subsequent power reporting commands cannot report power consumption correctly as some logic is missing in the netlist.

The **ilm_enable_power_calculation** variable is to instruct the **create_ilm** command to invoke power calculation API. Power consumption of the ILM design is calculated before core logic removal during **create_ilm**. The power data are stored as attributes on the ILM design, they will be used by **report_power** command during the final assembly step of the entire chip. Thus **report_power** command will be able to report more accurate power consumption for the designs with ILM blocks.

ilm_enable_power_calculation is on by default. If power license is not available, power calculation step will not be invoked.

ilm_preserve_core_constraints

Enables the ILM mode (`ilm_mode`), which preserves constraints set on an interface logic model (ILM) core, if set to `true`.

TYPE

Boolean

DEFAULT

false

DESCRIPTION

ILM mode supports budgeting of designs containing interface logic models (ILMs). When you set the value of the **ilm_preserve_core_constraints** variable as `true`, you enable the tool to characterize such designs *before* the creation of constraint scripts using the **write_script** command. For more information, see the man page for the **create_ilm** command.

Operating in ILM mode, the tool captures commands that set constraints, if the commands try to access design objects that are cut out of the design, that is, objects that are not part of the interface logic. The tool captures all commands that attempt to retrieve objects from within an ILM and that try to set constraints on the objects.

When you then invoke the **characterize** command on a cell (a design instance), the ILM mode attaches to the design all captured commands that could affect this instance or any module in the hierarchical subtree of this instance. This occurs *only* if the characterized cell is an ILM cell or if it contains an ILM in its subtree.

When you follow the characterization of a cell with the **write_script** command or the **write_environment** command on the design (still in ILM mode), the "attached" commands appear at the end of the **write_script** or **write_environment** output. The tool modifies the commands before they print out, as follows:

- Hierarchical paths in the arguments are modified.
- Variable references are substituted with the variable value.

In the generated script

- The current design is set to the module the script is generated for. This might be different from the current design at the time the captured command executed. This change of scope needs to be reflected in the command's arguments
- Any variable reference (`$<varname>`) in the command line is replaced by the value

of the corresponding variable at the time the captured command was executed.

Certain limitations to this approach exist, as follows:

- Use only very simple constraint commands. Do not use for loops, if statements, or any other Tcl construct.

- Use only the following commands while ILM mode is enabled:

```
concat
create_clock
find
list
remove_attribute
set_attribute
set_critical_range
set_disable_timing
set_dont_touch
set_dont_touch_network
set_false_path
set_input_delay
set_max_delay
set_min_delay
set_multicycle_path
set_operating_conditions
set_output_delay
set_wire_load_model
```

- You can also use commands starting with "get_", such as

```
get_cells
get_ports
and so on
```

and commands starting with "set_default_", such as

```
set_default_input_delay
set_default_load
and so on
```

- Change the value of the **ilm_preserve_core_constraints** variable only in the global scope. For example, do not enable ILM mode inside a for loop or inside a Tcl process.

- Do not change the value of Tcl variables while ILM mode is enabled.

- Do not use multiple commands in one line, separated by a semicolon.

- Do not source byte-code compiled Tcl scripts.

A command that the tool does not support will execute at the time you enter it at the command line (or source it). But the tool does not capture it, and therefore it is not added by **characterize**, nor is it printed out as a result of running **write_script**.

ILM mode is helpful in the following activities:

- When you set constraints on a design containing ILMs.
- When you perform budgeting and modifications on the design.
- When you create constraint files for subpartitions.

If you then load these subpartitions separately and replace the ILMs with the full design representation, the scripts ILM mode generates transfer all constraints from the original constraint file to that subpartition. This occurs even though you use an ILM representation to divide the constraints.

To see the current value of this variable, type

```
psyn_shell-xg-t> printvar ilm_preserve_core_constraints
```

EXAMPLES

In the following example, the tool reads in and processes a design that has one ILM called I_ALU, which is instantiated from the top level of the design.

```
psyn_shell-xg-t> read_db RISC_CORE_ILM.db
psyn_shell-xg-t> set ilm [get_cell I_ALU]
psyn_shell-xg-t> set dt "mult"
psyn_shell-xg-t> set ilm_preserve_core_constraints true
psyn_shell-xg-t> set_dont_touch [get_cells $ilm/*/ $dt]
psyn_shell-xg-t> set_dont_touch [get_cells I_DATA_PATH/*]
psyn_shell-xg-t> characterize I_ALU
psyn_shell-xg-t> write_environment -cell I_ALU
                    -constraints -out I_ALU.con
```

The above example reads in a design that contains an ILM named I_ALU; enables ILM mode; and sets some constraints on the design.

The example then creates a constraint script for the subinstance I_ALU (by characterizing it and invoking the **write_environment** command). The ILM mode adds to the generated output file the line **set_dont_touch [get_cells */mult]**.

The first **set_dont_touch** command tries to retrieve cells from within the ILM. Because the command uses wildcards, it might set the don't touch attribute on fewer cells than exist in the ILM, in comparison with the execution on the full design. Thus the command is added to the script. If you then apply the script to the full design, it will rerun the command and set the constraint on all cells.

Before the tool added the command to the script, a variable reference was replaced by the variable value. In addition, the hierarchical path to the characterized module I_ALU was removed from any argument. For example,

The tool first transforms the argument \$ilm/*/ \$dt
to
I_ALU/*/mult.

When it removes the path, the argument becomes
*/mult

SEE ALSO

characterize(2)
create_ilm(2)
write_environment(2)
write_script(2)

initial_target_library

Specifies the list of technology libraries of components to be used for the first part of leakage power optimization in **place_opt**.

TYPE

list

DEFAULT

" "

GROUP

system_variables

DESCRIPTION

Leakage power can be optimized for multi-vth designs in two different flows in **place_opt**. One is to use all the target libraries throughout optimization. The other is to use a subset of target libraries in the first part of the optimization steps and all the libraries in the second part. **initial_target_library** specifies the list of technology libraries of components to be used for the first part of leakage power optimization **place_opt**.

To determine the current value of this variable, use **echo \$initial_target_library**.

SEE ALSO

place_opt(2)
system_variables(3)

insert_dft_clean_up

Causes the **insert_dft** command to use area recovery techniques to reduce the amount of test point logic.

TYPE

string

DEFAULT

true

GROUP

insert_dft variables

DESCRIPTION

Causes the **insert_dft** command to use area recovery techniques to reduce the amount of test point logic. The default is true. When the value of this variable is set to false, the **insert_dft** command does not optimize the test point logic.

To determine the current value of this variable, type **printvar insert_dft_clean_up**. For a list of all **insert_dft** variables and their current values, type **print_variable_group insert_dft**.

SEE ALSO

insert_dft_variables

Variables that affect the **insert_dft** and **preview_dft** commands.

SYNTAX

```
string insert_dft_clean_up = "true"
string test_point_keep_hierarchy = false
int compile_dont_use_dedicated_scanout = 1
string insert_test_design_naming_style = "%s_test_%d"
boolean insert_test_map_effort_enabled = "TRUE"
string test_clock_port_naming_style = "test_c%s"
boolean test_dedicated_subdesign_scan_outs = "FALSE"
int test_default_min_fault_coverage = 95
boolean test_disable_find_best_scan_out = "FALSE"
boolean test_dont_fix_constraint_violations = "FALSE"
int test_isolate_hier_scan_out = 0
string test_mode_port_inverted_naming_style = "test_mode_i%s"
string test_mode_port_naming_style = "test_mode%s"
string test_non_scan_clock_port_naming_style = "test_nsc_%s"
string test_scan_clock_a_port_naming_style = "test_sca%s"
string test_scan_clock_b_port_naming_style = "test_scb%s"
string test_scan_clock_port_naming_style = "test_sc%s"
string test_scan_enable_inverted_port_naming_style = "test_sei%s"
string test_scan_enable_port_naming_style = "test_se%s"
string test_scan_in_port_naming_style = "test_si%s%s"
string test_scan_out_port_naming_style = "test_so%s%s"
string test_mux_constant_so = "FALSE"
string test_mux_constant_si = "FALSE"
```

DESCRIPTION

These variables directly affect the **insert_dft** and **preview_dft** commands. Defaults are shown above, under Syntax.

For a list of **insert_dft** variables and their current values, type **print_variable_group insert_dft**. To view this manual page online, type **help insert_dft_variables**. To view an individual variable description, type **help var**, where *var* is the name of the variable.

insert_dft_clean_up

When *true* (the default), **insert_dft** uses area recovery techniques to reduce the amount of test point logic. When *false*, **insert_dft** does not optimize the test point logic.

test_point_keep_hierarchy

When *false* (the default), **insert_dft** synthesizes test points and ungroups the test point design. When *true*, **insert_dft** keeps each test point design in a separate level of hierarchy.

compile_dont_use_dedicated_scanout

When *1* (the default), test-ready **compile** (**compile -scan**), and subsequent compiles, do not use a scan cell's dedicated scan-out pin for functional

connections. When *0*, **compile** can use dedicated scan-out pins for functional connections.

insert_test_map_effort_enabled

When *false*, disables the **-map_effort** option of **insert_scan** and **insert_dft**, thus disabling any potential use of sequential mapping-based scan selection. When *true* (the default), the **-map_effort** option is enabled. Set this variable to *false* if you want the pre-3.3a behavior of **insert_dft** with respect to selection of scan equivalents.

insert_test_design_naming_style

Specifies how **insert_scan** and **insert_dft** names new designs created during the addition of test circuitry. When **insert_scan** or **insert_dft** modifies a design by adding test circuitry, it creates the design with a new, unique name. The new name is derived from the original design name and the format specified by this variable.

test_clock_port_naming_style

Specifies the naming style used by **insert_scan** and **insert_dft** for global test signal ports created in designs during the addition of test circuitry. New ports are not added if suitable ports are identified with the **set_scan_signal** or **set_signal_type** command.

test_dedicated_subdesign_scan_outs

Constrains how **insert_scan** and **insert_dft** route scan chains. When *true*, makes DFT Compiler create dedicated scan-out ports on subdesigns. When *false* (the default), DFT Compiler uses existing subdesign ports where possible.

test_default_min_fault_coverage

Specifies the default desired minimum fault coverage percent for the current design for the partial scan test methodology when the **set_min_fault_coverage** command has not be used for the current design.

test_disable_find_best_scan_out

When *false* (the default), **insert_scan** and **insert_dft** select scan cell scan-out pins that have the greatest timing slack. You can disable this behavior by setting the variable *true*.

test_dont_fix_constraint_violations

When *false* (the default), **insert_scan** and **insert_dft** attempt to minimize performance constraint violations. You can disable this behavior by setting the variable *true*.

test_isolate_hier_scan_out

When *1*, **insert_dft** inserts logic that isolates scan connections at hierarchical boundaries during functional operation; this can reduce dynamic switching currents and output loading. When *0* (the default), no logic is inserted. The variable does not affect **insert_scan** commands.

test_mode_port_inverted_naming_style

Specifies the style used to name new type test_hold_logic_zero test mode signal ports. New ports are not added if suitable ports are identified using **set_dft_signal**.

`test_mode_port_naming_style`

Used the same as **`test_mode_port_inverted_naming_style`** .

`test_non_scan_clock_port_naming_style`

Specifies how to name ports created by clock gating for nonscan clocks. The %s is filled with a string identifying the original clock, its inversion (either "i" for inverted or "n" for not-inverted), and inactive level (either 0 or 1).

`test_scan_clock_a_port_naming_style`

Used the same as **`test_clock_port_naming_style`**.

`test_scan_clock_b_port_naming_style`

Used the same as **`test_clock_port_naming_style`** .

`test_scan_clock_port_naming_style`

Used the same as **`test_clock_port_naming_style`** .

`test_scan_enable_inverted_port_naming_style`

Used the same as **`test_clock_port_naming_style`** .

`test_scan_enable_port_naming_style`

Used the same as **`test_clock_port_naming_style`** .

`test_scan_in_port_naming_style`

Specifies the naming style used by **`insert_dft`** for serial test-signal ports created in designs during the addition of test circuitry. New ports are not added if suitable ports are identified with the **`set_scan_signal`** or **`set_signal_type`** command.

`test_scan_out_port_naming_style`

Used the same as **`test_scan_in_port_naming_style`** .

`test_mux_constant_so`

Specifies how scan insertion uses a port you declare as scan output when this one is tied high or to the ground in functional mode. When you set this variable to *false* (the default value), scan insertion ignores the tie-off logic and directly uses the port as a scan output. This might change the output of the design during functional mode. When you set this variable to *true*, scan insertion multiplexes the scan output signal with the constant logic, using the scan enable signal to control the multiplexer.

`test_mux_constant_si`

Specifies how scan insertion uses a port you declare as scan input when this one is tied high or to the ground in functional mode. When you set this variable to *false* (the default value), scan insertion ignores the tie-off logic and directly uses the port as a scan input. This might change the output of the design during functional mode. When you set this variable to *true*, scan insertion multiplexes the scan input signal with the constant logic, using the scan enable signal to control the multiplexer.

SEE ALSO

`insert_dft` (2), **`preview_dft`** (2); **`compile_dont_use_dedicated_scan_port`** (3),

`insert_dft_variables`

```
insert_test_design_naming_style (3), test_clock_port_naming_style (3),  
test_default_min_fault_coverage (3), test_mode_port_inverted_naming_style (3),  
test_mode_port_naming_style (3), test_isolate_hier_scan_out (3),  
test_non_scan_clock_port_naming_style (3), test_scan_clock_a_port_naming_style (3),  
test_scan_clock_b_port_naming_style (3), test_scan_clock_port_naming_style (3),  
test_scan_enable_inverted_port_naming_style (3), test_scan_in_port_naming_style (3),  
test_scan_out_port_naming_style (3), insert_test_map_effort_enabled (3).
```

insert_test_design_naming_style

Specifies how the **insert_dft** command names new designs created during the addition of test circuitry.

TYPE

string

DEFAULT

GROUP

insert_dft_variables

DESCRIPTION

Specifies how the **insert_dft** command names new designs created during the addition of test circuitry. When **insert_dft** modifies a design by adding test circuitry, it creates the design with a new, unique name. The new name is derived from the original design name and the format specified by this variable.

This variable must contain only one %s (percent s) and %d (percent d) character sequence. The percent sign has special meaning in the formatting process. To use a percent sign in the design name, two are needed in the variable setting (%%).

When **insert_dft** generates a new design name, it replaces %s with the original design name and %d with an integer. The integer is one that ensures the new name is unique. A single percent sign is substituted for %%.

For example, if this variable is set to %s_test_%d, and the original design name is my_design, the new design name is:

```
my_design_test_1
```

If the **insert_dft** command is repeated (for example, with a different test methodology), the new design name is:

```
my_design_test_2
```

To determine the current value of this variable, type **printvar insert_test_design_naming_style**. For a list of **insert_dft** variables and their current values, type **print_variable_group insert_dft** command.

SEE ALSO

insert_dft_variables(3)

insert_test_variables

This command has become obsolete with 2000.04 release, and has been replaced by **insert_dft_variables**.

io_variables

Variables that affect the **read_file**, **read_lib**, **write**, and **write_lib** commands.

SYNTAX

```
Boolean bus_inference_descending_sort = "true"
string bus_inference_style = ""
string equationout_and_sign = "*"
string equationout_or_sign = "+"
Boolean equationout_postfix_negation = "true"
Boolean hdlout_internal_busses = "false"
integer libgen_max_difference = "1"
Boolean pla_read_create_flip_flop = "false"
Boolean read_db_lib_warnings = false
list read_name_mapping_nowarn_libraries = {"lsi_10k"}
Boolean read_translate_msff = false
string sdfin_fall_cell_delay_type = "maximum"
string sdfin_fall_net_delay_type = "maximum"
float sdfin_min_fall_cell_delay = 0.000000
float sdfin_min_fall_net_delay = 0.000000
float sdfin_min_rise_cell_delay = 0.000000
float sdfin_min_rise_net_delay = 0.000000
string sdfin_rise_cell_delay_type = "maximum"
string sdfin_rise_net_delay_type = "maximum"
string sdfin_top_instance_name = ""
float sdfout_min_fall_cell_delay = 0.000000
float sdfout_min_fall_net_delay = 0.000000
float sdfout_min_rise_cell_delay = 0.000000
float sdfout_min_rise_net_delay = 0.000000
float sdfout_time_scale = 1.000000
string sdfout_top_instance_name = ""
Boolean sdfout_write_to_output = "false"
list write_name_mapping_nowarn_libraries = {"lsi_10k"}
Boolean write_name_nets_same_as_ports = "false"
```

DESCRIPTION

These variables directly affect the **read_file**, **read_lib**, **write**, and **write_lib** commands.

For more about Verilog and VHDL variables, see the *HDL Compiler for Verilog Reference*, *VHDL Compiler Reference*, respectively, and the `hdl_variables` man page.

For a list of **io** variables and their current values, type **print_variable_group io**. To view this manual page online, type **help io_variables**. To view an individual variable description, type **help var**, where *var* is the name of the variable.

bus_inference_descending_sort

Affects the **read_file** command with all format options except **db**, **verilog**, and **vhdl**; primarily used with the **lsi** option (LSI/NDL format). When *true* (the

default variable), members of the port bus will be sorted in descending order rather than in ascending order.

`bus_inference_style`

Affects the **read_file** command with all format options except **db**, **verilog**, and **vhdl**; primarily used with the **lsi** option (LSI/NDL format). This variable determines the style used to name inferred busses.

`equationout_and_sign`

Specifies the "and" sign to use when writing a design in equation format. It must be either "*" or "&". If you specify an invalid value, the default is used.

`equationout_or_sign`

Specifies the "or" sign to use when writing a design in equation format. It must be either "+" or "|". If you specify an invalid value, the default is used.

`equationout_postfix_negation`

When *true* (the default value), the ' (apostrophe) is used as the negation operator when writing a design in equation format. When *false*, the prefix negation operator ! (exclamation point) is used.

`hdlout_internal_busses`

Controls how the **write -format verilog** and **write -format vhdl** commands write out bused nets by parsing their names when set to *true*.

`libgen_max_difference`

Specifies to **read_lib** the maximum number of differences to list between the v3.1 format description of a library cell and its statetable description. The default value, -1, allows all differences to be listed.

`pla_read_create_flip_flop`

Affects **read_file -f pla**. When *true*, enables output register information in PLA files to be read in and stored. When *false* (the default value), only **D** flip-flop information is read in and output register declarations are ignored.

`read_db_lib_warnings`

When *true*, indicates that warnings are to be printed while a technology db library is being read in with **read_file**. When *false* (the default), no warnings are given.

`read_name_mapping_nowarn_libraries`

Specifies a list of libraries for which no warning messages are to be issued by **read_file -f edif -names_file** if the libraries are not found. The default is to issue warning messages for all libraries not found.

`read_translate_msff`

When *true*, indicates that master-slave flip-flops are to be automatically translated to master-slave latches while a technology db library or a technology library is being read in. When *false* (the default), both master and slave remain flip-flops. Note that DFT Compiler requires this variable to be set to *true*.

This variable is used while a technology db library is being read in when

read_file is executed; and while a technology library is being read in by Library Compiler when **read_lib** is executed. The technology db library is affected ONLY if the program reports that the db library is being updated and asks you to save the results. Library Compiler always follows this variable during processing.

Note that DFT Compiler requires this variable to be set to *true*.

sdfin_fall_cell_delay_type

Specifies the delay type for fall cell delays read from a timing file in S.D.F. format. Delays from timing files are annotated in Design Compiler with **read_timing** .

sdfin_fall_net_delay_type

Specifies the delay type for fall net delays read from a timing file in S.D.F. format. Delays from timing files are annotated in Design Compiler with **read_timing** .

sdfin_min_fall_cell_delay

Specifies the minimum fall cell delay read from a timing file in S.D.F. format. Delays from timing files are annotated in Design Compiler with **read_timing** .

sdfin_min_fall_net_delay

Specifies the minimum fall net delay read from a timing file in S.D.F. format. Delays from timing files are annotated in Design Compiler with **read_timing** .

sdfin_min_rise_cell_delay

Specifies the minimum rise cell delay read from a timing file in S.D.F. format. Delays from timing files are annotated in Design Compiler with **read_timing** .

sdfin_min_rise_net_delay

Specifies the minimum rise net delay read from a timing file in S.D.F. format. Delays from timing files are annotated in Design Compiler with **read_timing** .

sdfin_rise_cell_delay_type

Specifies the delay type for rise cell delays read from a timing file in S.D.F. format. Delays from timing files are annotated in Design Compiler with **read_timing** .

sdfin_rise_net_delay_type

Specifies the delay type for rise net delays read from a timing file in S.D.F. format. Delays from timing files are annotated in Design Compiler with **read_timing** .

sdfin_top_instance_name

Specifies the name prepended to all instance names in timing files in S.D.F. format. Delays from timing files are annotated in Design Compiler with **read_timing** .

sdfout_min_fall_cell_delay

Specifies the minimum fall cell delay written to a timing file in S.D.F. format. Delays from Design Compiler are written to timing files with **write_timing**.

`sdfout_min_fall_net_delay`

Specifies the minimum fall net delay written to a timing file in S.D.F. format. Delays from Design Compiler are written to timing files with **write_timing**.

`sdfout_min_rise_cell_delay`

Specifies the minimum rise cell delay written to a timing file in S.D.F. format. Delays from Design Compiler are written to timing files with **write_timing**.

`sdfout_min_rise_net_delay`

Specifies the minimum rise net delay written to a timing file in S.D.F. format. Delays from Design Compiler are written to timing files with **write_timing**.

`sdfout_time_scale`

Specifies the time scale of the delays written to timing files in S.D.F. format. Delays from Design Compiler are written to timing files with **write_timing**.

`sdfout_top_instance_name`

Specifies the name prepended to all instance names when writing timing files in S.D.F. format. Timing files are written with the command **write_timing**. By default, **write_timing** prepends no name to all cell instance names.

`sdfout_write_to_output`

When *true*, **write_timing -f sdf** will write interconnect delays between cells and top level output ports, and will also write output-to-output pin IOPATH statements for cells that contain output-to-output timing arcs. The default is *false*. This variable must be set before using **write_timing**.

`write_name_mapping_nowarn_libraries`

Specifies a list of libraries for which no warning messages are to be issued by **write -f edif -names_file** if the libraries are not found. The default is to issue warning messages for all libraries not found.

`write_name_nets_same_as_ports`

When *true*, nets connected to ports have the same names as the ports in the descriptions of designs written in EDIF, LSI, or TDL format. The default is *false*. Other nets can be renamed to avoid creating shorts. Net names in the design are unchanged.

SEE ALSO

`read_file(2)` `read_lib(2)` `write(2)` `write_lib(2)` `edif_variables(3)` `hdl_variables(3)`
`vhdlio_variables(3)`

layer_attributes

Contains attributes related to layer.

DESCRIPTION

Contains attributes related to layer.

You can use **get_attribute** to determine value of an attribute, and use **report_attribute** to get a report of all attributes on specified object. Specified with **list_attribute -class layer -application**, the definition of attributes can be listed.

Layer Attributes

data_type_details

Specifies detail information of data types on a layer.
The data type of **data_type_details** is string.
This attribute is read-only.

data_types

Specifies data types on a layer.
The data type of **data_types** is string.
This attribute is read-only.

defaultWidth

Specifies the default width of any dimension of an object on a layer.
The data type of **defaultWidth** is float.
This attribute is read-only.

fatContactThreshold

Specifies the threshold for using a fat wire contact on a lyer instead of the default contact.
The data type of **fatContactThreshold** is float.
This attribute is read-only.

fatFatMinSpacing

Specifies the minimum distance required between wires on a layer when the widths of both wires are greater than or equal to **fatWireThreshold**.
The data type of **fatFatMinSpacing** is float.
This attribute is read-only.

fatThinMinSpacing

Specifies the minimum distance required between wires on a layer when the width of one of the wires is greater than or equal to **fatWireThreshold**.
The data type of **fatThinMinSpacing** is float.
This attribute is read-only.

fatWireThreshold

Specifies the threshold for using the fat wire spacing rule instead of the default spacing rule on a layer.
The data type of **fatWireThreshold** is float.
This attribute is read-only.

isDefaultLayer

Specifies the layer used for routing when there are multiple layers with the same **mask_name** value.
The data type of **isDefaultLayer** is integer.
This attribute is read-only.

is_routing_layer

Specifies whether layer is a routing layer.
The data type of **is_routing_layer** is boolean.
This attribute is read-only.

layerNumber

Defines the number that identifies a layer.
The data type of **layerNumber** is integer.
This attribute is read-only.

layer_number

Defines the number that identifies a layer.
The data type of **layer_number** is integer.
This attribute is read-only.

layer_type

Specifies type of a layer.
The data type of **layer_type** is string.
This attribute is read-only.

mask_name

Specifies the physical layer associated with the specified layer object.
The data type of **mask_name** is string.
This attribute is read-only.

maxCurrDensity

Specifies the floating-point number representing in amperes per centimeter the maximum current density a layer can carry.
The data type of **maxCurrDensity** is double.
This attribute is read-only.

maxStackLevel

Defines the maximum number of vias that can stack at the same point.
The data type of **maxStackLevel** is integer.
This attribute is read-only.

minArea

Specifies the minimum area rule of any dimension of an object on a layer.
The data type of **minArea** is float.
This attribute is read-only.

minSpacing

Specifies the minimum separation distance between the edges of objects on a layer, if the objects are on different nets.
The data type of **minSpacing** is float.
This attribute is read-only.

minWidth

Specifies the minimum width of any dimension of an object on a layer.

The data type of **minWidth** is float.
This attribute is read-only.

name

Specifies name of a layer object.
The data type of **name** is string.
This attribute is read-only.

object_class

Specifies object class name of a layer, which is **layer**.
The data type of **object_class** is string.
This attribute is read-only.

pitch

Specifies the predominant separation distance between the centers of objects on a layer.
The data type of **pitch** is float.
This attribute is read-only.

preferred_direction

Specifies the preferred routing direction for a layer.
The data type of **preferred_direction** is string.
This attribute is read-only.

unitMaxCapacitance

Specifies the maximum capacitance of a layer.
The data type of **unitMaxCapacitance** is double.
This attribute is read-only.

unitMaxHeightFromSub

Specifies the maximum distance of a layer.
The data type of **unitMaxHeightFromSub** is double.
This attribute is read-only.

unitMaxResistance

Specifies the maximum resistance of a layer.
The data type of **unitMaxResistance** is double.
This attribute is read-only.

unitMaxSideWallCap

Specifies the maximum sidewall capacitance of a layer.
The data type of **unitMaxSideWallCap** is double.
This attribute is read-only.

unitMaxThickness

Specifies the maximum thickness of a layer.
The data type of **unitMaxThickness** is double.
This attribute is read-only.

unitMinCapacitance

Specifies the minimum capacitance of a layer.
The data type of **unitMinCapacitance** is double.
This attribute is read-only.

layer_attributes

unitMinHeightFromSub
Specifies the minimum distance of a layer.
The data type of **unitMinHeightFromSub** is double.
This attribute is read-only.

unitMinResistance
Specifies the minimum resistance of a layer.
The data type of **unitMinResistance** is double.
This attribute is read-only.

unitMinSideWallCap
Specifies the minimum sidewall capacitance of a layer.
The data type of **unitMinSideWallCap** is double.
This attribute is read-only.

unitMinThickness
Specifies the minimum thickness of a layer.
The data type of **unitMinThickness** is double.
This attribute is read-only.

unitNomCapacitance
Specifies the nominal capacitance of a layer.
The data type of **unitNomCapacitance** is double.
This attribute is read-only.

unitNomHeightFromSub
Specifies the nominal distance of a layer.
The data type of **unitNomHeightFromSub** is double.
This attribute is read-only.

unitNomResistance
Specifies the nominal resistance of layer.
The data type of **unitNomResistance** is double.
This attribute is read-only.

unitNomSideWallCap
Specifies the nominal sidewall capacitance of a layer.
The data type of **unitNomSideWallCap** is double.
This attribute is read-only.

unitNomThickness
Specifies the nominal thickness of a layer.
The data type of **unitNomThickness** is double.
This attribute is read-only.

visible
Specifies a layer's visibility.
The data type of **visible** is integer.
This attribute is read-only.

SEE ALSO

`get_attribute(2),`
`list_attribute(2),`
`report_attribute(2),`

```
set_attribute(2).
```


lbo_cells_in_regions

Puts new cells at specific locations within a cluster.

TYPE

Boolean

DEFAULT

false

GROUP

links_to_layout_variables

DESCRIPTION

Puts new cells at specific locations within a cluster. Location based optimization (LBO) does this when the variable is set to *false* (the default). When set to *true*, LBO converts the specific location into a preferred region for the cell, by putting X_BOUNDS and Y_BOUNDS attributes on the cell when it is written to the PDEF file.

The proper setting for this variable depends on the engineering change order (ECO) capabilities of the back-end tools being used. Ideally the back-end tool will be able to support putting the new cells exactly where the **reoptimize_design** command wants them to go. If tools do not support that level of ECO, set this variable to *true* so that the PDEF file will at least contain regions into which the cells can be placed.

To determine the current value of this variable, type **printvar lbo_cells_in_regions**. For a list of all **links_to_layout** variables and their current values, type **print_variable_group links_to_layout**.

SEE ALSO

links_to_layout_variables(3)

level_shifter_naming_prefix

Using this variable, users can specify a prefix for the level shifters names

TYPE

string

DEFAULT

" "

GROUP

mv

DESCRIPTION

When `enable_special_level_shifter_naming` variable is set to true, automatically inserted level shifters by `insert_level_shifters`, `compile` and other commands are named specially. The name follows the template `<prefix> + <PD OR Design name> + "_LS" + #`. `<prefix>` is a user specified prefix using the variable `level_shifter_naming_prefix`. `<PD OR Design Name>` is the name of power domain where the level shifter is being added, or the design name if the power domain is not defined

SEE ALSO

`enable_special_level_shifter_naming(3)`

lib_thresholds_per_lib

Causes trip-point values in the Synopsys library to override user-specified values.

TYPE

Boolean

DEFAULT

true

GROUP

timing_variables

DESCRIPTION

Setting this variable as *false* causes user-specified trip-point values to override values defined in the Synopsys library. The default value is *true*.

Do not override the library trip-point values unless you are completely sure that these values are incorrect. Overriding trip-point values specified by the library creator is a questionable practice, which can result in inaccurate delay computations.

The following variables are affected:

```
rc_slew_lower_threshold_pct_fall rc_slew_lower_threshold_pct_rise
rc_slew_upper_threshold_pct_fall rc_slew_upper_threshold_pct_rise
rc_slew_derate_from_library rc_input_threshold_pct_rise rc_input_threshold_pct_fall
rc_output_threshold_pct_rise rc_output_threshold_pct_fall
```

To determine the current value of this variable, type **printvar lib_thresholds_per_lib**.

For a list of all timing variables and their current values, type **print_variable_group timing**.

SEE ALSO

```
rc_input_threshold_pct_rise(3)
rc_input_threshold_pct_fall(3)
rc_output_threshold_pct_fall(3)
rc_output_threshold_pct_rise(3)
rc_slew_lower_threshold_pct_fall(3)
rc_slew_lower_threshold_pct_rise(3)
rc_slew_upper_threshold_pct_fall(3)
rc_slew_upper_threshold_pct_rise(3)
rc_slew_derate_from_library(3)
```

lib_use_thresholds_per_pin

Causes pin specific trip-point values in the Synopsys library to override Library default trip-point values.

TYPE

Boolean

DEFAULT

true

GROUP

timing_variables

DESCRIPTION

Setting this variable as *false* causes Synopsys Library default trip-point values to override values defined for each library pin in the Synopsys library. The default value is *true*.

This variable is provided for backward compatibility. In case the user wants to use library defaults for all library pins instead of pin specific trip_point values, then this variable should be used.

The following variables are affected:

```
rc_slew_lower_threshold_pct_fall rc_slew_lower_threshold_pct_rise
rc_slew_upper_threshold_pct_fall rc_slew_upper_threshold_pct_rise
rc_slew_derate_from_library rc_input_threshold_pct_rise rc_input_threshold_pct_fall
rc_output_threshold_pct_rise rc_output_threshold_pct_fall lib_thresholds_per_lib
```

To determine the current value of this variable, type **printvar lib_use_thresholds_per_pin**.

For a list of all timing variables and their current values, type **print_variable_group timing**.

SEE ALSO

```
rc_input_threshold_pct_rise(3)
rc_input_threshold_pct_fall(3)
rc_output_threshold_pct_fall(3)
rc_output_threshold_pct_rise(3)
rc_slew_lower_threshold_pct_fall(3)
rc_slew_lower_threshold_pct_rise(3)
rc_slew_upper_threshold_pct_fall(3)
rc_slew_upper_threshold_pct_rise(3)
rc_slew_derate_from_library(3)
```

lib_use_thresholds_per_pin

lib_thresholds_per_lib(3)

library_attributes

Contains attributes placed on libraries.

DESCRIPTION

Contains attributes that can be placed on a library.

To set library attributes, use the **set_attribute** command. To determine the value of an attribute, use the **get_attribute** command. To remove attributes, use the **remove_attribute** command.

For more details on library attributes, see the *Library Compiler Reference Manual*. For information on all attributes, refer to the **attributes** manual page.

Library Attributes

default_fanout_load
Fanout load of input pins in a library.

default_inout_pin_cap
Capacitance of inout pins.

default_inout_pin_fall_res
Fall resistance of inout pins.

default_inout_pin_rise_res
Rise resistance of inout pins.

default_input_pin_cap
Capacitance of input pins.

default_intrinsic_fall
Intrinsic fall delay of timing arcs.

default_intrinsic_rise
Intrinsic rise delay of a timing arc.

default_max_fanout
Maximum fanout of pins.

default_max_transition
Maximum transition of pins.

default_min_porosity
Minimum porosity of designs.

default_output_pin_cap
Capacitance of output pins.

default_output_pin_fall_res
Fall resistance of output pins.

default_output_pin_rise_res
Rise resistance of output pins.

default_slope_fall
Fall sensitivity factor of a timing arc.

default_slope_rise
Rise sensitivity factor of a timing arc.

k_process_drive_fall
Process scale factor applied to the fall resistance of timing arcs.

k_process_drive_rise
Process scale factor applied to the rise resistance of timing arcs.

k_process_intrinsic_fall
Process scale factor applied to the intrinsic fall delay of timing arcs.

k_process_intrinsic_rise
Process scale factor applied to the intrinsic rise delay of timing arcs.

k_process_pin_cap
Process scale factor applied to pin capacitance of timing arcs.

k_process_slope_fall
Process scale factor applied to the fall slope sensitivity of timing arcs.

k_process_slope_rise
Process scale factor applied to the rise slope sensitivity of timing arcs.

k_process_wire_cap
Process scale factor applied to the wire capacitance of timing arcs.

k_process_wire_res
Process scale factor applied to the wire resistance of timing arcs.

k_temp_drive_fall
Scale factor applied to timing arc fall resistance due to temperature variation.

k_temp_drive_rise
Scale factor applied to timing arc rise resistance due to temperature variation.

k_temp_intrinsic_fall
Scale factor applied to the intrinsic fall delay of a timing arc due to temperature variation.

k_temp_intrinsic_rise
Scale factor applied to the intrinsic rise delay of a timing arc due to temperature variation.

k_temp_pin_cap
Scale factor applied to pin capacitance due to temperature variation.

k_temp_slope_fall
Scale factor applied to timing arc fall slope sensitivity due to temperature variation.

k_temp_slope_rise
Scale factor applied to timing arc rise slope sensitivity due to temperature variation.

k_temp_wire_cap
Scale factor applied to wire capacitance due to temperature variation.

k_temp_wire_res
Scale factor applied to wire resistance due to temperature variation.

k_volt_drive_fall
Scale factor applied to timing arc fall resistance due to voltage variation.

k_volt_drive_rise
Scale factor applied to timing arc rise resistance due to voltage variation.

k_volt_intrinsic_fall
Scale factor applied to the intrinsic fall delay of a timing arc due to voltage variation.

k_volt_intrinsic_rise
Scale factor applied to the intrinsic rise delay of a timing arc due to voltage variation.

k_volt_pin_cap
Scale factor applied to pin capacitance due to voltage variation.

k_volt_slope_fall
Scale factor applied to timing arc fall slope sensitivity due to voltage variation.

k_volt_slope_rise
Scale factor applied to timing arc rise slope sensitivity due to voltage variation.

k_volt_wire_cap
Scale factor applied to wire capacitance due to voltage variation.

k_volt_wire_res
Scale factor applied to wire resistance due to voltage variation.

nom_process
Nominal process value used for library characterization. Fixed at 1.0 for most technology libraries.

nom_temperature
Nominal ambient temperature used for library characterization. Usually 25 degrees Celsius. Multipliers use the nominal value to determine the change in temperature between nominal and operating conditions.

nom_voltage

Nominal source voltage value used in library element characterization. Typically 5 volts for a CMOS library. Multipliers use the nominal value to determine the change in voltage between nominal and operating conditions.

no_sequential_degenerates

When *true*, disables mapping to degenerated flip-flops or latches (that is, devices that have some input pins connected to 0 or to 1). The default for the attribute is *false* or *nonexistence*, implying that degenerate devices will be allowed by default in the library. This attribute may be overridden on a component-by-component basis by using the attribute on library cells.

sequential_bridging

When *true*, enables **Design Compiler** to take a multiplexed flip-flop and bridge (that is, connect) the output to the input to get a desired functionality. The default for the attribute is *false* or *nonexistent*, implying that bridging will be disabled by default in the library. Bridging is required for mapping in cases where there is no flip-flop with internal feedback in the target library but one is desired in the HDL. This attribute may be overridden on a component-by-component basis by using the attribute on library cells.

NOTE: Setting this attribute to *true* can result in an increase in run times and memory consumption for Design Compiler. The increased run times depend on the number of flip-flops in the target library or libraries which have the attribute set.

SEE ALSO

get_attribute(2)
remove_attribute(2)
set_attribute(2)
attributes(3)

library_cell_attributes

Contains attributes that can be placed on a library cell.

DESCRIPTION

Contains attributes that can be placed on a library cell.

To set an attribute, use the command identified in the individual description of that attribute. To determine the value of an attribute, use the **get_attribute** command. To remove attributes, use the **remove_attribute** command. If an attribute is "read-only," you cannot set it.

To determine the value of an attribute, use the **get_attribute** command. To remove attributes, use the **remove_attribute** command.

For a more detailed explanation of an attribute, refer to the manual pages of the appropriate **set** command. For information on all attributes, refer to the **attributes** manual page.

Library Cell Attributes

dont_touch

Identifies library cells to be excluded from optimization. Values are *true* (the default) or *false*. Library cells with the **dont_touch** attribute set to *true* are not modified or replaced during **compile**. Setting **dont_touch** on a hierarchical cell sets the attribute on all cells below it. Set with **set_dont_touch**.

dont_use

Disables the specified library cells so that they are not added to a design during **compile**. Set with **set_dont_use**.

no_sequential_degenerates

When *true*, disables mapping to versions of this latch or flip flop that have some input pins connected to 0 or to 1. Set with **set_attribute**. This attribute may also be set on the library itself, and that value will apply as the default for all registers in the library which do not have the attribute set individually.

preferred

Specifies the preferred library gate to use during technology translation when there are other gates with the same function in the target library. Set with **set_prefer**.

scan

When *true*, specifies that the instances of the library cell are always replaced by equivalent scan cells during **insert_dft**. When *false*, instances are not replaced. Set with **set_scan**.

scan_group

A user-defined string variable that allows you to specify to DFT Compiler a preferred scan equivalent for a non-scan storage element, when a library

contains multiple scan equivalents. Typical values are *low*, *medium*, and *high*, for low, medium and high drive strengths. However, you can define any string variable, and it need not describe drive strength. The default behavior is for DFT Compiler to attempt to choose a scan element that best matches the electrical characteristics of the non-scan element. For a more detailed explanation, refer to the *DFT Compiler Reference Manual*. The matching of electrical characteristics works well with the standard CMOS delay model, but is not accurate with other delay models. Normally, **scan_group** would be set by the ASIC vendor or library developer, but you can also set **scan_group**. Consult your ASIC vendor before attempting to set **scan_group** with **set_attribute**. For more information about **scan_group**, refer to the *DFT Compiler Reference Manual*.

`sequential_bridging`

When *true*, enables Design Compiler to take a multiplexed flip-flop and bridge (that is, connect) the output to the input to get a desired functionality. The default is *false*, so this attribute must be set in order to enable the functionality. Bridging is required for mapping in cases where there is no flip-flop with internal feedback in the target library but one is desired in the HDL. Set with **set_attribute**. This attribute may also be set on the library itself, and that value will apply as the default for all registers in the library which do not have the attribute set individually.

NOTE: Setting this attribute to *true* can result in an increase in run times and memory consumption for Design Compiler. The increased run times depend on the number of flip-flops in the target library or libraries for which this attribute has been set.

SEE ALSO

`get_attribute(2)`
`remove_attribute(2)`
`set_attribute(2)`
`attributes(3)`

link_force_case

Controls the case-sensitive or case-insensitive behavior of the **link** command.

TYPE

string

DEFAULT

check_reference

GROUP

system_variables

DESCRIPTION

Controls the case-sensitive or case-insensitive behavior of the **link** command. The value of this variable can be *case_sensitive*, *case_insensitive*, or *check_reference*. The default value is *check_reference*; and the reference being linked is checked to ascertain the case-sensitivity of the input format that created that reference. That case-sensitivity is then enforced. For example, a VHDL reference is linked case-insensitively, and a Verilog reference is linked case-sensitively. To override this behavior, you can set the value of the **link_force_case** variable to either *case_sensitive* or *case_insensitive*.

Setting this variable to *case_insensitive* is not recommended if you are reading in any source files from formats that are case-sensitive, such as Verilog. To do so can lead to inconsistent and undesirable results.

To determine the value of this variable, use **printvar link_force_case**. For a list of all **system** variables and their values, use the **print_variable_group system** command.

SEE ALSO

link(2)

link_library

Specifies the list of design files and libraries used during linking.

TYPE

list

DEFAULT

* your_library.db

GROUP

system_variables

DESCRIPTION

Specifies the list of design files and libraries used during linking. The **link** command looks at those files and tries to resolve references in the order of specified files. A "*" entry in the value of this variable indicates that the **link** command is to search all the designs loaded in dc_shell while trying to resolve references. If file names do not include directory names, files are searched for in the directories in **search_path**. The default is {"*" your_library.db}. Change *your_library.db* to reflect your library name.

To determine the current value of this variable, use **\$list link_library**. For a list of all **system** variables and their current values, use the **print_variable_group system** command.

SEE ALSO

link(2)

links_to_layout_variables

Variables that affect the **links_to_layout** capability.

SYNTAX

```
Boolean auto_wire_load_selection = "true"
Boolean compile_disable_area_opt_during_inplace_opt = "false"
Boolean compile_dont_touch_annotated_cell_during_inplace_opt = "false"
Boolean compile_ignore_area_during_inplace_opt = "false"
Boolean compile_ignore_footprint_during_inplace_opt = "false"
Boolean compile_ok_to_buffer_during_inplace_opt = "false"
Boolean compile_update_annotated_delays_during_inplace_opt = "true"
Boolean lbo_buffer_insertion_enabled = "false"
Boolean lbo_buffer_removal_enabled = "false"
Boolean lbo_cells_in_regions = "false"
Boolean ltl_enable_mean_physical_port_location = "false"
Boolean ltl_obstruction_type = "placement_only"
string reoptimize_design_changed_list_file_name = ""
Boolean reoptimize_design_disable_area_opt_during_postlayout_opt = "false"
Boolean sdfout_allow_non_positive_constraints = "false"
```

DESCRIPTION

These variables directly affect the **links_to_layout** capability. Defaults are shown above, under Syntax.

For a list of these variables and their current values, type **print_variable_group links_to_layout**. To view this manual page online, type **help links_to_layout_variables**. To view an individual variable description, type **help var**, where *var* is the variable name.

auto_wire_load_selection

When *true* (the default value), turns on the automatic selection of the wire load model.

compile_disable_area_opt_during_inplace_opt

When *true*, disables area optimization during inplace optimization. When *false* (the default value), area optimization is enabled; that is, **compile -in_place** attempts to save design area by downsizing cells that are not a part of the critical path. Note that this downsizing can sometimes help speed up the critical path. Thus, setting this option to *true*, while reducing the number of changes made to the design, may hinder this command from achieving the best timing optimization results.

Note: This variable no longer works for **reoptimize_design**.

compile_dont_touch_annotated_cell_during_inplace_opt

When *true*, **reoptimize_design -in_place** and **compile -in_place** disallow swapping cells that have annotated delays. When *false* (the default value), **reoptimize_design -in_place** and **compile -in_place** allow annotated cells to be swapped for cells without annotated delay.

`compile_ignore_area_during_inplace_opt`

When *true*, **compile -in place** is allowed to swap cells that have the same number of pins, pin names, logic functionality, and footprint, regardless of area. When *false* (the default value), cells are not swapped if they have different areas.

Note: This variable no longer works for **reoptimize_design**.

`compile_ignore_footprint_during_inplace_opt`

When *true*, **compile -in place** is allowed to swap cells that have the same number of pins, pin names, logic functionality, and cell area, regardless of footprint. When *false* (the default value), cells are not swapped if they have different footprints.

Note: This variable no longer works for **reoptimize_design**.

`compile_ok_to_buffer_during_inplace_opt`

When *true*, **compile -in place** is allowed to add buffers (or two inverters in a row) to the design to help meet timing constraints and fix design rule violations, including minimum path timing violations. The default is *false*.

Note: This variable no longer works for **reoptimize_design**.

`compile_update_annotated_delays_during_inplace_opt`

When *true* (the default value), **reoptimize_design -in place** and **compile -in place** are allowed to modify the values of annotated delays on nets connected to the swapped cells and to remove annotated delays on cells connected to the swapped cells. When *false*, **reoptimize_design -in place** and **compile -in place** disallow annotated delays to be modified.

`lbo_buffer_insertion_enabled`

When *false* (the default value), location based optimization is not used when doing buffer insertion.

`lbo_buffer_removal_enabled`

When *false* (the default value), location based optimization is not used when doing buffer removal, and in fact, buffer removal itself is not done during IPO or PLO.

`lbo_cells_in_regions`

When *false* (the default value), location based optimization will insert new cells at specific locations within clusters. When *true*, new cells are instead inserted into 'preferred' regions via X_BOUNDS and Y_BOUNDS attributes on the cells in the PDEF file. The best setting of this variable is best on the ECO capabilities of the back-end P&R or floorplanning too.

`ltl_enable_mean_physical_port_location`

When *true*, **reoptimize_design** uses the arithmetic mean of all physical locations for ports that have multiple physical equivalents. When *false* (the default), **reoptimize_design** ignores nets of ports that have multiple physical equivalents.

`ltl_obstruction_type`

Controls the routing blockage type for the named obstructions, without route type being specified.

`reoptimize_design_changed_list_file_name`

The name of a file to which **reoptimize_design -in place** and **reoptimize_design**

-post_layout_opto commands should output a list of design modifications/additions.

reoptimize_design_disable_area_opt_during_postlayout_opt

When *false* (the default setting), **reoptimize_design -post_layout_opto** attempts to downsize cells that are not a part of the critical path, in order to save design area. This occurs after cell groups along the critical path have been restructured to meet timing constraints. Setting this variable to *true* will cause **reoptimize_design -post_layout_opto** to skip the area downsizing step. By skipping this step, the changes made by **reoptimize_design** will be restricted to just those that improve the timing of the critical path or the legality of the design (**max_transition** or **min_path**) violations).

sdfout_allow_non_positive_constraints

When *true*, **write_constraints -format sdf** can write out PATHCONSTRAINT constructs with nonpositive (≤ 0) constraint values. When *false* (the default), paths with nonpositive constraints are written with a constraint value of 0.01.

SEE ALSO

compile (2), **help** (2) **list** (2) **reoptimize_design** (2), **set_wire_load** (2), **write_constraints** (2); **compile_variables** (3), **io_variables** (3).

ltl_obstruction_type

Controls the routing blockage type for the named obstructions, without route type being specified.

TYPE

Boolean

DEFAULT

placement_only

GROUP

links_to_layout_variables

DESCRIPTION

Controls the routing blockage type for the named obstructions, without route type being specified. When the setting is `placement_only` (the default), the obstructions are treated as placement obstruction only and routing wires can still go through. When the setting is `routing_none`, the obstructions are treated as routing blockages and no routing wires are allowed.

To determine the current value of this variable, type **printvar ltl_obstruction_type**. For a list of all `links_to_layout` variables and their current values, type **print_variable_group links_to_layout**.

SEE ALSO

`lbo_cells_in_regions(3)`
`links_to_layout_variables(3)`

mcmn_enable_high_capacity_flow

Enables Multi-corner/Multi_mode (MCMM) high capacity flow in IC Compiler

TYPE

Boolean

DEFAULT

false

GROUP

MCMM

DESCRIPTION

When set to true, this variable enables ICC's high capacity flow for optimizing MCMM designs during the place_opt and route_opt mega commands. Setting this variable to true can reduce the memory high-water mark of these commands. It can, however, affect the quality of results and the run-time of these commands. It has also been extended to support the optimization phase of clock_opt and signoff_opt.

SEE ALSO

set_active_scenarios(2)
get_dominant_scenarios(2)
all_scenarios(2)
all_active_scenarios(2)
place_opt(2)
route_opt(2)
clock_opt(2)
signoff_opt(2)

mcmm_high_capacity_effort_level

Controls the behavior of Multi-corner/Multi_mode (MCMM) scenario reduction.

TYPE

Float. Valid range is between 0 and 10.

DEFAULT

0

GROUP

MCMM

DESCRIPTION

This variable controls how aggressively the MCMM scenario reduction feature (see **get_dominant_scenarios(2)** and **mcmm_enable_high_capacity_flow(3)**) reduces the number of dominant scenarios. In its default setting (0), any scenario with a violation that is worst across all scenarios is included in the dominant set of scenarios. As you increase the value of this variable, scenario reduction adjusts its criteria for comparing the slack of a violating object across different scenarios. This allows for further reduction of the dominant scenario set, but can implies that few violations will not be fixed during optimization.

If you set this variable to a value smaller than 0, scenario reduction will be performed using an effort level of 0. If you set this variable to a value larger than 10, scenario reduction will be performed using an effort level of 10.

SEE ALSO

get_dominant_scenarios(2)
mcmm_enable_high_capacity_flow(3)
set_active_scenarios(2)
all_scenarios(2)
all_active_scenarios(2)
place_opt(2)
route_opt(2)

monitor_cpu_memory

Displays the CPU time, elapsed time, and peak memory usage before and after each core command.

TYPE

Boolean

DEFAULT

false

DESCRIPTION

When **monitor_cpu_memory** is true, the CPU time, elapsed time, and peak memory usage are printed out before and after each major command, such as **place_opt** and **clock_opt**.

CPU time and elapsed time are the total time spent on the main process and all its child processes or multiple threads. For example, when you use the **-num_cpus** option, the reported CPU time includes the sum of the CPU usage of the main process and all child processes or threads, similar to the output of the **cputime -self -child** or **cputime -all** command.

Peak memory is defined as the memory high-water mark of the main process and its child processes.

To determine the current value of this variable, use **printvar monitor_cpu_memory**.

When you use the **-num_cpus** option, the tool runs multiple threads. Currently the operating system measures the CPU time by adding the usage for all threads. It does not take into account parallelization of the threads. This means that the report might show a larger CPU time than elapsed time when you specify the **-num_cpus** option.

The elapsed time (wall-clock time) depends on many external factors and can vary for every session. It depends on factors such as the I/O traffic, the network traffic, RAM and swap usage, and the other processes running on the same machine. When the elapsed time is much longer than the CPU time, it might point out an inefficiency of the computing environment, such as insufficient memory, too many processes running on the same machine, or a slow network. The only way to make the elapsed time close to the CPU time is to run only one session on a machine with enough RAM and using the local disk.

EXAMPLE

If set the **monitor_cpu_memory** variable to true, the tool outputs a PSYN-508 message in the log file after each major command. A sample PSYN-508 message is shown below:

```
Information:CPU: ### s (## hr) ELAPSE: ### s (## hr) MEM-PEAK: ### mb Mon Oct 28
```

12:20:01 2008 (PSYN-508)

SEE ALSO

`mem(2)`

`cputime(2)`

mpc_disable_macro_fitting

Controls whether to disable the function that calculates core area to include all the macro blocks automatically.

TYPE

integer

DEFAULT

false

GROUP

physopt

DESCRIPTION

In the execution of the minimal physical constraints flow, the tool calculates the initial core area to include automatically all of the macro blocks. If you set the value of this variable as true, the tool disables this feature. If you set the value as false (the default), the tool enables this feature.

To determine the current value of this variable, type

```
psyn_shell-xg-t> printvar mpc_disable_macro_fitting
```

The **mpc_disable_macro_fitting** variable is part of Physical Compiler only.

SEE ALSO

`mpc_disable_pad_legalization(3)`

mpc_disable_pad_legalization

Controls whether to disable the function that legalizes I/O pad cells.

TYPE

integer

DEFAULT

false

GROUP

physopt

DESCRIPTION

In the execution of the minimal physical constraints flow, the default behavior of the tool is to place I/O pad cells on valid locations.

If you set the value of this variable as true, the tool disables this feature. If you set the value as false (the default), the tool enables this feature.

To determine the current value of this variable, type

```
psyn_shell-xg-t> printvar mpc_disable_pad_legalization
```

The **mpc_disable_pad_legalization** variable is part of Physical Compiler only.

SEE ALSO

`mpc_disable_macro_fitting(3)`

mpc_dont_cut_pnet_over_macros

Controls whether power nets created in minimal physical constraints flow are to be cut over macros.

TYPE

integer

DEFAULT

false

GROUP

physopt

DESCRIPTION

In the execution of the minimal physical constraints flow, the default behavior of the tool is to cut the power structures created over macros by the **set_mpc_pnet_options** command. If you set the value of this variable as true, the tool disables this feature and the power structures are not cut. If you set the value as false (the default), the tool enables this feature and the power structures are cut.

To determine the current value of this variable, type

```
psyn_shell-xg-t> printvar mpc_dont_cut_pnet_over_macros
```

This **mpc_dont_cut_pnet_over_macros** variable is part of Physical Compiler only.

SEE ALSO

report_mpc_ring_options(2)

set_mpc_pnet_options(2)

multibit_variables

SYNTAX

```
string bus_multiple_separator_style = ","
```

DESCRIPTION

These variables directly affect the multibit mapping and optimization capability in **compile** command.

For a list of these variables and their current values, type **print_variable_group multibit**. To view this manual page online, type **help multibit_variables**. To view an individual variable description, type **help var**, where *var* is the variable name.

SEE ALSO

```
compile(2), hdlin_infer_multibit(3)
```

`mux_auto_inferring_effort`

Specifies the MUX inferring effort level.

TYPE

integer

DEFAULT

2

GROUP

fpga_variables

DESCRIPTION

The **`mux_auto_inferring_effort`** variable controls the MUX inferring effort of Design Compiler FPGA. Valid values are **0** through **6**. The default value is **2**. The larger the integer value, the more MUX is inferred.

mv_allow_ls_on_leaf_pin_boundary

Sets the variable to **true** to allow level-shifter insertion on leaf pin (such as macro cell pin) boundaries.

TYPE

Boolean

DEFAULT

false

GROUP

mv

DESCRIPTION

This variable controls whether or not to allow level-shifter insertion on leaf pin boundaries that are not power domain boundaries. When a macro cell is operating at a voltage different from its surrounding logic, and you want level shifters to be inserted at the interface, the recommended flow is to define a power domain around the macro cell by specifying the macro cell as the root cell of a power domain.

If you do not define the macro cell as the root cell, level shifters are not inserted at the interface, because the interface is not a power domain boundary. By default, level shifters are only inserted at power domain boundaries.

If you are unable to define a power domain around the macro cell, but still require level shifters to be inserted, you can use the variable to enable the non-default behavior.

SEE ALSO

mw_allow_rect_and_polygon_in_def

Controls whether the **read_def** command imports rectangles and polygons in the special net section.

TYPE

Boolean

DEFAULT

false

GROUP

read_def

DESCRIPTION

Controls whether the **read_def** command imports rectangles and polygons in the special net section. The polygon edges must be parallel to the x-axis and the y-axis or they must be at a 45-degree angle to the axes. To avoid the potential issues related to polygons in other application commands, you can use the **convert_polygon_to_path** command to convert the rectangles and polygons to point-to-point style routes after using the **read_def** command.

To determine the current value of this variable, use the **printvar mw_allow_rect_and_polygon_in_def** command.

SEE ALSO

read_def(2)

mw_attr_value_extra_braces

Controls whether extra braces are added to the value returned by the **get_attribute** command.

TYPE

Boolean

DEFAULT

false

DESCRIPTION

This variable controls whether extra braces are added to the value returned by the **get_attribute** command.

By default (false), no extra braces are added and the return value can be passed directly to another command.

When true, extra braces '{' and '}' are added to the number list returned by **get_attribute**, which prevents you from passing the value directly to another command. You should set this variable to true only for backward-compatibility, such as when you are executing an old script. When you set this variable to true, the tools issues an MWUI-041 warning message.

EXAMPLES

The following example shows how different **get_attribute** returns different values, depending on the value of this variable.

```
prompt> set mw_attr_value_extra_braces false
false
prompt> get_attribute [get_cells U1] bbox
{30.000 30.000} {40.000 40.000}
```

```
prompt> set mw_attr_value_extra_braces true
Warning: Extra braces will be added for number list returned from
get_attribute. (MWUI-041)
true
prompt> get_attribute [get_cells U1] bbox
{{30.000 30.000} {40.000 40.000}}
```

SEE ALSO

get_attribute(2)

mw_attr_value_no_space

Controls whether the `route_type` and `net_type` attribute values returned by the **get_attribute** and **report_attribute** commands contain spaces or underscores.

TYPE

Boolean

DEFAULT

false

DESCRIPTION

This variable controls whether the `route_type` and `net_type` attribute values returned by the **get_attribute** and **report_attribute** commands contain spaces or underscores.

By default (false), the commands return the backward-compatible attribute values, which contain spaces.

When true, the **get_attribute** and **report_attribute** commands return attribute values with underscores, instead of spaces. These `route_type` attribute values are accepted by the **create_net_shape** and **create_via** commands.

Note that the **set_attribute** command accepts the attribute values returned by the **get_attribute** and **report_attribute** commands, regardless of the setting of this variable.

EXAMPLES

The following example shows how different attribute values are returned, depending on the value of this variable.

```
prompt> set mw_attr_value_no_space false
false
prompt> get_attribute [get_vias VIA#40704] route_type
P/G Ring
prompt> get_attribute [get_nets n300] net_type
Split Clock

prompt> set mw_attr_value_no_space true
prompt> get_attribute [get_vias VIA#40704] route_type
pg_ring
prompt> get_attribute [get_nets n300] net_type
split_clock
prompt> set rt [get_attribute [get_net_shapes HWIRE#42240] route_type]
prompt> create_net_shape -route_type $rt -type wire -origin {0 0} \
    -length 10 -net VSS -width 5 -layer METAL4
```

SEE ALSO

`create_net_shape(2)`
`create_via(2)`
`get_attribute(2)`
`report_attribute(2)`

mw_cell_name

Contains the Milkyway design cell name.

TYPE

string

DEFAULT

" "

DESCRIPTION

Contains the Milkyway design cell name. The default is the empty string. If given, **read_mdb** reads in the cell specified by this variable, or **read_mdb** modifies this variable to indicate the cell, view, and version of the MDB cell read in. The **write_mdb** command searches for this variable when writing data to an MDB cell. If this variable is set, it writes to the cell specified by this variable, or it writes to a cell using the current design name.

SEE ALSO

mw_design_library

Contains the Milkyway design library.

TYPE

string

DEFAULT

" "

DESCRIPTION

Contains the Milkyway design libraries. The default is the empty string. By setting this variable, the Milkyway design will be stored in the directory specified by this variable. If this variable is set, it will be used by the **read_milkyway**, **write_milkyway** and **create_mw_design** commands.

This variable needs to be set for a smooth data transfer to Milkyway.

SEE ALSO

mw_disable_escape_char

Specifies to disable the escape characters for hierarchy delimiter.

TYPE

Boolean

DEFAULT

true

DESCRIPTION

This variable controls the behavior of escape characters for hierarchies. This variable is used only by the **read_mdb** and **write_mdb** commands.

The default value is always to escape the hierarchy delimiters, if they are part of names.

If set to "true", the behavior is similar to setting "No Backslash Insertion to avoid Hier Name Collisions" in Astro.

Make sure that the design does not have name collisions.

SEE ALSO

mw_hdl_bus_dir_for_undef_cell

Specify how to determine the bus direction for undefined cell.

TYPE

Integer

DEFAULT

0

GROUP

hdl_variables

DESCRIPTION

If any port of any undefined cell is a bus, verilog2cel verilog reader creates a bus port for the undefined cell and instantiates it. The direction of the bus is specified via this variable.

For example, if an undefined cell is instantiated like the following:

```
sub si (.port(net[x:y]),...);
```

the number of bus bits = $r = |x-y|+1$

defines the bus origin according to the value given:

0 (From Connection)

x > y type [r:0] port

x < y type [0:r] port

1 (Descending) type [r:0] port

2 (Ascending) type [0:r] port

To determine the current value of this variable, use **printvar variable_name_filler**. For a list of all **hdl** variables and their current values, use the **print_variable_group hdl** command.

SEE ALSO

enable_cell_based_verilog_reader(3)

hdl_variables(3)

mw_hdl_expand_cell_with_no_instance

This variable determines whether to expand netlist cells without instances or not.

TYPE

Boolean

DEFAULT

false

GROUP

hdl_variables

DESCRIPTION

This variable determines whether verilog2cel verilog reader to expands netlist cells that do not contain physical descriptions or not. Turn on this option if you have netlist instances containing only nets. If you do not turn on this option, and you have netlist instances with no physical description, expansion fails. The default is off.

To determine the current value of this variable, use **printvar mw_hdl_expand_cell_with_no_instance**. For a list of all **hdl** variables and their current values, use the **print_variable_group hdl** command.

SEE ALSO

hdl_variables(3)
enable_cell_based_verilog_reader(3)

mw_hdl_verilogel_variables

TCL Variables for the Milkyway cell based verilog reader (verilog2cel). Specify certain variables so that to make verilog2cel behaves as desired.

SYNTAX

```
mw_hdl_allow_dirty_netlist
mw_hdl_create_multi_pg_net
mw_hdl_bus_dir_for_undef_cell
mw_hdl_expand_cell_with_no_instance
mw_hdl_stop_at_FRAM_cells
```

```
Boolean enable_cell_based_verilog_reader = "false" (default)
Boolean mw_hdl_allow_dirty_netlist = "false" (default)
Boolean mw_hdl_create_multi_pg_net = "true" (default)
Boolean mw_hdl_bus_dir_for_undef_cell = 0 (default)
Boolean mw_hdl_expand_cell_with_no_instance = "false" (default)
Boolean mw_hdl_stop_at_FRAM_cells = "false" (default)
```

DESCRIPTION

These variables affect the **read_verilog** command when invoking Milkyway cell based verilog reader (verilog2cel) to import designs. Besides these variables, **mw_logic1_net** and **mw_logic0_net** and **mw_current_design** will also be used to indicate the net names for power(1'b1) and ground(1'b0).

```
enable_cell_based_verilog_reader
    Enable Milkyway cell based verilog reader. See
    enable_cell_based_verilog_writer(3) for details.
```

```
mw_hdl_allow_dirty_netlist
    Enable verilog2cel to handle dirty netlist. See
    mw_hdl_allow_dirty_netlist(3) for details.
```

```
mw_hdl_create_multi_pg_net
    Generate multiple power and ground nets. See mw_hdl_create_multi_pg_net(3)
    for details.
```

```
mw_hdl_bus_dir_for_undef_cell
    Specify the bus direction for undefined cell. See
    mw_hdl_bus_dir_for_undef_cell(3) for details.
```

```
mw_hdl_expand_cell_with_no_instance
    This will enable verilog2cel to expand cell hierarchy which has no cell
    instance. See mw_hdl_expand_cell_with_no_instance(3) for details.
```

```
mw_hdl_stop_at_FRAM_cells
    Tell verilog2cel to honor FRAM view cell. See mw_hdl_stop_at_FRAM_cells(3)
    for details.
```

SEE ALSO

`mw_logic0_net` (3), `mw_logic1_net` (3), `read_verilog` (2).

mw_hvo_variables

TCL Variables for the Milkyway cell based verilog (HVO) writer.

SYNTAX

```
Boolean enable_cell_based_verilog_writer = "false" (default)
Boolean mw_hvo_pg_ports = "false" (default)
Boolean mw_hvo_pg_nets = "true" (default)
Boolean mw_hvo_split_bus = "false" (default)
Boolean mw_hvo_empty_cell_definition = "false" (default)
Boolean mw_hvo_corner_pad_cells = "true" (default)
Boolean mw_hvo_pad_filler_cells = "true" (default)
Boolean mw_hvo_core_filler_cells = "true" (default)
Boolean mw_hvo_unconnected_cells = "true" (default)
Boolean mw_hvo_unconnected_ports = "false" (default)
Boolean mw_hvo_strip_backslash_before_hiersep = "true" (default)
Boolean mw_hvo_diode_ports = "false" (default)
Boolean mw_hvo_output_wire_declaration = "false" (default)
Boolean mw_hvo_output_onezero_for_pg = "true" (default)
Boolean mw_hvo_generate_macro_definition = "false" (default)
string mw_hvo_dump_master_names = "" (default)
```

DESCRIPTION

These variables affect the **write** command when invoking Milkyway cell based verilog writer (HVO) to export design. Besides these variables, **mw_logic1_net** and **mw_logic0_net** will also be used by HVO to indicate the net names for power(1'b1) and ground(1'b0).

enable_cell_based_verilog_writer
Enable Milkyway cell based verilog writer. See **enable_cell_based_verilog_writer(3)** for details.

mw_hvo_pg_ports
Generate power and ground ports. See **mw_hvo_pg_ports(3)** for details.

mw_hvo_pg_nets
Generate power and ground nets. See **mw_hvo_pg_nets(3)** for details.

mw_hvo_split_bus
Generate individual bus bits. See **mw_hvo_split_bus(3)** for details.

mw_hvo_empty_cell_definition
Generate definition of empty cells. See **mw_hvo_empty_cell_definition(3)** for details.

mw_hvo_corner_pad_cells
Generate corner pad cell instances. See **mw_hvo_corner_pad_cells(3)** for details.

`mw_hvo_pad_filler_cells`
 Generate pad filler cell instances. See **`mw_hvo_pad_filler_cells(3)`** for details.

`mw_hvo_core_filler_cells`
 Generate core filler cell instances. See **`mw_hvo_core_filler_cells(3)`** for details.

`mw_hvo_unconnected_cells`
 Generate unconnected cell instances. See **`mw_hvo_unconnected_cells(3)`** for details.

`mw_hvo_unconnected_ports`
 Generate unconnected cell ports. See **`mw_hvo_unconnected_ports(3)`** for details.

`mw_hvo_strip_backslash_before_hiersep`
 Do not generate backslashes before hierarchy separators. See **`mw_hvo_strip_backslash_before_hiersep(3)`** for details.

`mw_hvo_diode_ports`
 Generate diode ports. See **`mw_hvo_diode_ports(3)`** for details.

`mw_hvo_output_wire_declaration`
 Generate wire declarations of nets. See **`mw_hvo_output_wire_declaration(3)`** for details.

`mw_hvo_output_onezero_for_pg`
 Generate 1'b1 for power and 1'b0 for ground nets. See **`mw_hvo_output_onezero_for_pg(3)`** for details.

`mw_hvo_generate_macro_definition`
 Generate macro declarations. See **`mw_hvo_generate_macro_definition(3)`** for details.

`mw_hvo_dump_master_names`
 Specify the cell instance masters that must be dumped out. See **`mw_hvo_dump_master_names(3)`** for details.

SEE ALSO

`mw_logic0_net (3)`, **`mw_logic1_net (3)`**, **`write (2)`**.

mw_logic0_net

Contains the equivalent logic0 net for the design.

TYPE

string

DEFAULT

VSS

DESCRIPTION

Contains the milkyway logic0(1'b0) net for the design. The default is "VSS".

mw_logic1_net

Contains the equivalent logic1 net for the design.

TYPE

string

DEFAULT

VDD

DESCRIPTION

Contains the milkyway logic1(1'b1) net for the design. The default is "VDD".

mw_reference_library

Contains the Milkyway reference libraries.

TYPE

list

DEFAULT

" "

DESCRIPTION

Contains the Milkyway reference libraries. The default is the empty string. By setting this variable, the `search_path` and the `physical_library` will be enhanced to use the Milkyway libraries.

SEE ALSO

mw_site_name_mapping

Specifies pairs of site names that is used to synchronize floorplan's site name with physcal library's site name.

TYPE

string

DEFAULT

" "

GROUP

physopt

DESCRIPTION

Specifies pairs of site names that is used to synchronize floorplan's site name with physcal library's site name, the usage is `<set mw_site_name_mapping "old_site_name1 new_site_name1 old_site_name2 new_site_name2 ... " >`. The `old_site_name` must pairs off with `new_site_name`. User uses this variable to change `old_site_name` to `new_site_name` during db loading, Note, the variable must be set before db loading.

To determine the current value of this variable, use **`printvar mw_site_name_mapping`**.

By the way, the old command `change_site_name` cannot be used in XG mode because the site name mapping needs to be happened before the design loading. The command `change_site_name` only works after the design is loaded so it doesn't work in XG mode. The `change_site_name` command only works in normal mode, not in XG mode.

EXAMPLES

The following example change the site name for the design floorplan from 'core' to 'unit'.

```
psyn_shell-t> set mw_site_name_mapping "core unit"
```

SEE ALSO

mwdc_allow_higher_mem_usage

Specifies the frequency that the tool flushes in-memory data to disk during optimization (including the mega commands `place_opt/clock_opt/route_opt`, and the command `create_placement/legalize_placement, compile_clock_tree...`). It should be set as one of the values 0, 1, and 2. The default value is 0. It can be used to tune runtime and memory.

TYPE

integer

DEFAULT

0

DESCRIPTION

Value 0 (default), means the tool will flush data to disk as frequent as possible to have the least memory usage, and as a side effect it might take a much longer runtime; Value 1, means the tool will never flush data to disk during optimization, until user explicitly issues a command `"save_mw_cel"`, and this way it will have the worst memory usage, but it usually will have the best runtime if the working-machine has enough physical memories (The runtime probably gets worse when the physical memory is not enough and the tool starts to use swap disk as virtual memory.); Value 2, means the tool will flushes data to disk adaptively - flushing happens as less as possible, e.g., when the memory usage hits 90% of system available physical memory, or when the accumulated changed data hits a certain threshold, and freeing the unchanged in-memory data when possible, as a result, it will have a very close runtime, but a much better memory compared to Value 1.

This variable is allowed only in this tool.

SEE ALSO

`psynopt(2)`
`place_opt(2)`
`clock_opt(2)`
`route_opt(2)`

net_attributes

Contains attributes that can be placed on a net.

DESCRIPTION

Contains attributes that can be placed on a net.

To set an attribute, use the command identified in the individual description of that attribute. If an attribute is "read-only," the user cannot set it.

To determine the value of an attribute, use the **get_attribute** command. To remove attributes, use the **remove_attribute** command.

For a more detailed explanation of an attribute, refer to the manual pages of the appropriate **set** command. For information on all attributes, refer to the **attributes** manual page.

Net Attributes

ba_net_resistance

A floating point number that specifies the back-annotated net resistance on a net. Set with **set_resistance**.

dont_touch

Identifies nets to be excluded from optimization. Values are *true* (the default) or *false*. Nets with the **dont_touch** attribute set to *true* are not modified or replaced during **compile**. Set with **set_dont_touch**.

is_test_circuitry

Set by **insert_dft** on the scan cells and nets added to a design during the addition of test circuitry. This attribute is read-only and cannot be set by the user.

load *

A floating point number that specifies the wire load value on a net. The total load on a net is the sum of all the loads on pins, ports, and wires associated with that net. This attribute represents only the wire load; pin and port loads are not included in the attribute value unless the attribute *subtract_pin_load* is set to **true** for the same net. Set with **set_load**.

static_probability

A floating point number that specifies the percentage of time that the signal is in the logic 1 state; this information is used by **report_power**. If this attribute is not set, **report_power** will use the default value of 0.5, indicating that the signal is in the logic 1 state half the time. Set with **set_switching_activity**.

subtract_pin_load

Causes **compile** to reduce the wire load value of a net by an amount equal to its pin load. Specifies that the **load** attribute includes the capacitances of all pins on the net. If the resulting wire load is negative, it is set to zero. Set with **set_load -subtract_pin_load**.

net_attributes

`toggle_rate`

A positive floating point number that specifies the toggle rate; that is, the number of zero-to-one and one-to-zero transitions within a library time unit period. This information is used by **report_power**; if this attribute is not set, **report_power** will use the default value of $2 * (\text{static_probability}) (1 - \text{static_probability})$. The default will be scaled by any associated clock signal (if one is available). Set with **set_switching_activity**.

`wired_and`

One of a set of two wired logic attributes that includes **wired_or**. When present and set to *true*, **wired_and** determines that the associated net has more than one driver and implements a wired AND function. Wired logic attributes cannot be manually set by the user. To cause wired logic attributes to be added to a netlist design that contains multiply-driven nets, you have two alternatives: 1. execute **compile** or **translate** on the design; or 2. specify the wired logic types using a resolution function in the HDL file.

`wired_or`

One of a set of two wired logic attributes that includes **wired_and**. When present and set to *true*, **wired_or** determines that the associated net has more than one driver and implements a wired OR function. Wired logic attributes cannot be manually set by the user. To cause wired logic attributes to be added to a netlist design that contains multiply-driven nets, you have two alternatives: 1. execute **compile** or **translate** on the design; or 2. specify the wired logic types using a resolution function in the HDL file.

SEE ALSO

`get_attribute(2)`
`remove_attribute(2)`
`attributes(3)`

optimize_reg_always_insert_sequential

Controls whether the **optimize_registers** command will remove and reinsert the sequential elements in the circuits even if no register was moved.

TYPE

Boolean

DEFAULT

false

GROUP

retiming_variables

DESCRIPTION

When set to 'true', **optimize_registers** will remove all existing movable elements from the design and reinsert and remap them, even if no registers were moved to improve delay or area cost. By default (value 'false') **optimize_registers** leaves sequential elements unchanged, if none of them are moved to improve delay or area cost. If your design contains register trees which are not build optimally setting this variable to 'true' before **optimize_registers** is executed might reduce the register count.

SEE ALSO

optimize_reg_max_time_borrow

Specifies the maximum amount of time borrowing at all latches when retiming latches using the **optimize_registers** command. A negative value means there is no limit on borrowing other than the one resulting from the clock period.

TYPE

float

DEFAULT

-1048576.0

GROUP

retiming_variables

DESCRIPTION

This variable limits the amount of borrowing that can occur at latches while performing retiming optimization. By default, during retiming, you can borrow latches up to one half of the clock period at a latch in order to avoid having negative slack. A negative value means there is no limit on the amount (other than one half of the clock period) of borrowing allowed.

SEE ALSO

optimize_reg_retime_clock_gating_latches

Specifies whether to move clock gating latches during retiming of latches.

TYPE

Boolean

DEFAULT

false

GROUP

retiming_variables

DESCRIPTION

The **optimize_registers** command allows to retime latches when using the `-latch` option, but will by default not move clock-gating latches. Clock-gating latches are latches that drive clock gating cells and are used to prevent glitches on gated clocks. If for some reason you want to move clock-gating latches during retiming you can set this variable to true. If you want to control individual clock gating latches you can set the variable to true and use the `set_dont_touch` or `set_transform_for_retiming` with value `'dont_retime'`.

SEE ALSO

physical_bus_attributes

Contains attributes related to physical bus.

DESCRIPTION

Contains attributes related to physical bus.

You can use **get_attribute** to determine value of an attribute, and use **report_attribute** to get a report of all attributes on specified physical bus. Specified with **list_attribute -class physical_bus -application**, the definition of attributes can be listed.

Physical Bus Attributes

cell_id

Specifies Milkyway design ID in which a physical bus object is located.
This attribute is read-only.

name

Specifies name of a physical bus object.
This attribute is read-only.

num_nets

Specifies count of nets in a physical bus object.
The nets can be collected by **get_nets -of_object <physical_bus_object>**.
This attribute is read-only.

object_class

Specifies object class name of a physical bus object, which is **physical_bus**.
This attribute is read-only.

object_id

Specifies object ID in Milkyway design file.
This attribute is read-only.

SEE ALSO

get_attribute(2),
list_attribute(2),
report_attribute(2).

physopt_area_critical_range

Specifies a margin of slack for cells during area optimization. If a cell has a slack less than the area critical range, area optimization is not done for the cell.

TYPE

float

DEFAULT

-1.04858e+06

GROUP

physopt

DESCRIPTION

The area critical range specifies a margin of slack for cells during area optimization. If a cell has a slack less than the area critical range, area optimization is not done for the cell. The default value is minus infinity; that is, all cells are optimized for area during area recovery.

Use the following command to determine the current value of the variable:

```
prompt> printvar physopt_area_critical_range
```

SEE ALSO

physopt_ultra_high_area_effort(3)

physopt_change_list

Controls tracking of eco changes when `physopt -incremental` is running. By default the tracking is always on. Use this variable to turn off the tracking.

TYPE

Boolean

DEFAULT

true

GROUP

physopt

DESCRIPTION

This variable is used when `physopt -incremental` is running. By default it is true, so after `physopt -incremental` is finished, type `report_change_list` to get a list of changes. If this variable is set to false before running `physopt`, then there will be no changes to report.

This variable is allowed only in the Physical Compiler.

SEE ALSO

physopt_check_site_array_overlap

Checks for multi-type site array overlapping in floorplan, within a certain threshold.

TYPE

Boolean

DEFAULT

true

GROUP

physopt

DESCRIPTION

If multiple types of site arrays are defined in the floorplan, the detail placer requires that the overlapping occur within a certain threshold, to ensure best quality of results. You set the threshold with the **physopt_row_overlap_threshold** variable.

The default value of **physopt_check_site_array_overlap** is *true*. Setting the value of this variable to *false* disables checking.

SEE ALSO

physopt_row_overlap_threshold(3)

physopt_checkpoint_stage

Writes an intermediate database at intervals during the physical optimization run.

TYPE

integer

DEFAULT

0

GROUP

physopt

DESCRIPTION

During a physical optimization run, after coarse placement is done, a number of optimization and placement stages occur. When this variable is set to an integer value, Physical Compiler writes out a database (.db file or CEL view) at these placement intervals, according to the value you specify in this variable. These intermediate databases are useful for debugging purposes.

For DB (Tcl) mode, Physical Compiler overwrites the output .db file each time. For XG mode, Physical Compiler will have version control for the checkpoint CEL view created.

The **physopt_checkpoint_stage** variable is valid only in Physical Compiler.

To determine the current value of this variable, enter the following command:

```
psyn_shell-t> printvar physopt_checkpoint_stage
```

SEE ALSO

physopt_cpu_limit

This variable is obsolete and cannot be enabled. Please use `set_physopt_cpulimit_options` command instead.

TYPE

float

DEFAULT

0

GROUP

physopt

DESCRIPTION

Please remove the obsolete variable, and replace it with the new command, **set_physopt_cpulimit_options**. For details, please check the **set_physopt_cpulimit_options** man page.

SEE ALSO

`set_physopt_cpulimit_options(2)`

physopt_create_missing_physical_libcells

Directs Physical Compiler to create dummy physical descriptions of missing physical library cells.

TYPE

Boolean

DEFAULT

false

GROUP

physopt

DESCRIPTION

This variable is used to enable Physical Compiler to create a dummy physical cell if a cell missing from the user-supplied physical libraries.

Physical Compiler uses a simple physical description for these dummy physical cells. This is mainly required in the exploration flow so that Physical Compiler will not stop when you do not have the final physical libraries. This is not intended as a replacement for specifying the correct physical libraries. For a final and accurate solution, you must specify the correct physical libraries.

The dummy physical cells created by Physical Compiler are not persistent. They exist in the current session only and are not stored in the .db database. These cells will be re-created in a new Physical Compiler session, if they are still required.

The **physopt_create_missing_physical_libcells** variable is valid only in Physical Compiler.

To determine the current value of this variable, enter the following command:

```
psyn_shell-t> printvar physopt_create_missing_physical_libcells
```

SEE ALSO

physopt_delete_unloaded_cells

Controls whether the **physopt** command deletes unloaded cells, including both sequential and combinational cells.

TYPE

Boolean

DEFAULT

true

GROUP

Physopt

DESCRIPTION

Controls whether the **physopt** command deletes unloaded cells. A design can contain cells that drive no loads. During **physopt**, the logic driven by a cell might be optimized away, resulting in an inferred no-load, or no path to any primary output. By default, **physopt** deletes such cells. To retain these cells, set this variable, **physopt_delete_unloaded_cells**, to *false*.

SEE ALSO

physopt_enable_extractor_rc

Enables and disables the support of extractor-based RC computation.

TYPE

Boolean

DEFAULT

true

GROUP

physopt

DESCRIPTION

The **physopt_enable_extractor_rc** variable enables the support of extractor-based RC computation. The default value is **true**.

If you want to disable the support of extractor-based RC computation in your design, set the value of this variable as **false**.

To see the current value of this variable, type

```
psyn_shell-xg-t> printvar physopt_enable_extractor_rc
```

SEE ALSO

physopt_enable_power_optimization

Enables power optimization in Physical Compiler.

TYPE

Boolean

DEFAULT

true

GROUP

physopt

DESCRIPTION

The **physopt_enable_power_optimization** variable enables and disables power optimization in Physical Compiler.

To disable power optimization during the execution of the **physopt** command and **compile_physical** command, set the value to false.

To enable power power optimization during the execution of these two commands, set the value to true (the default).

To see the current value of this variable, type the following:

```
psyn_shell-t> printvar physopt_enable_power_optimization
```

SEE ALSO

physopt_enable_router_process

Enables and disables the use of a separate process to perform routing.

TYPE

Boolean

DEFAULT

true

GROUP

physopt

GROUP

physopt

DESCRIPTION

This variable enables the use of a separate process to perform routing when set to true and disables it when set to false.

SEE ALSO

physopt_enable_rp_in_xg_mode

Determines whether the tool is to honor relative placement in xg mode.

TYPE

Boolean

DEFAULT

false

GROUP

physopt

DESCRIPTION

The value you specify for the **physopt_enable_rp_in_xg_mode** variable determines whether the tool carries out its default behavior and honors relative placement constraints. The default value of this variable is **false**. This variable has effect only in xg mode.

If you want the tool to perform structured placement on your design in xg mode, set the value of this variable to **true** before your design is read into memory.

To see the current value of this variable, type

```
psyn_shell-xg-t> printvar physopt_enable_rp_in_xg_mode
```

This variable is supported only in Physical Compiler (psyn_shell-xg-t).

SEE ALSO

`create_rp_group(2)`
`physopt_ignore_structure(3)`

physopt_enable_tlu_plus

Enables and disables the support of TLU+ based RC computation.

TYPE

Boolean

DEFAULT

true

GROUP

physopt

DESCRIPTION

The **physopt_enable_tlu_plus** variable enables the support of TLU+ based RC computation in your design. The default value is **true**.

If you want to disable the support of TLU+ based RC computation in your design, set the value of this variable as **false**.

To see the current value of this variable, type

```
psyn_shell-xg-t> printvar physopt_enable_tlu_plus
```

SEE ALSO

physopt_enable_tlu_plus_process

Enables and disables using a separate process to perform TLU+ based RC extraction.

TYPE

Boolean

DEFAULT

true

GROUP

physopt

DESCRIPTION

When you set the value of the variable to *true*, TLU+ based RC extraction is done in a separate process. This variable is only valid with post-route extraction with TLU+.

From 2007.03, the default setting is to run TLU+ based rc extraction in separate process automatically, it isn't necessary to set this variable.

SEE ALSO

physopt_enable_via_res_support

Enables and disables the support of via resistance for virtual route RC estimation.

TYPE

Boolean

DEFAULT

false

GROUP

physopt

DESCRIPTION

Setting the value of this variable as **true** enables the support of via resistance for virtual route RC estimation. The default value is **false**.

If you want to disable the support of via resistance for virtual route RC estimation, set the value of this variable as **false** (the default value).

Use the following command to see the current value of this variable:

```
prompt> printvar physopt_enable_via_res_support
```

physopt_hard_keepout_distance

Specifies the keepout distance used by the **physopt**, **create_placement**, and **legalize_placement** commands.

TYPE

float

DEFAULT

0

GROUP

physopt

DESCRIPTION

Use this variable to specify the keep-out distance used by the **physopt**, **create_placement**, and **legalize_placement** commands. Specify the distance in micron units.

To prevent congestion, it is useful to mark as a "hard keep-out area" an area in the design that surrounds a fixed macro, a capability this variable provides. If you specify an area as a hard keep-out area, Physical Compiler does not place any cells there. Define the area to be marked by setting a value for this variable, which the tool then uses to inflate the fixed cell's rectangle the same distance in all four directions.

Setting this variable is optional. The default value is 0.0.

To determine the variable's current value, type the following:

```
psyn_shell-t> printvar physopt_hard_keepout_distance
```

SEE ALSO

`create_placement(2)`
`legalize_placement(2)`

physopt_heterogeneous_site_array

Enables the detailed placer to handle floorplan with multi-height site arrays in multi-voltage mode.

TYPE

Boolean

DEFAULT

false

GROUP

physopt

DESCRIPTION

If the arrays of multiple types of sites with different site-heights are defined in the floorplan, to enable the detailed placer to place cells properly on those sites this variable needs to be set to true. It is supported only in multi-voltage design synthesis.

If it is set to false, detailed placer ignores the multi-height site types even if they are present in the floorplan.

physopt_ignore_lpin_fanout

The tool ignore max fanout constraints which are specfied in the library.

TYPE

Boolean

DEFAULT

false

GROUP

physopt

DESCRIPTION

When this variable is turned on, tools will ignore max_fanout violatios from the constraints in the library. Only optimization ignores those constraints and report_constraint will still report the violation.

physopt_ignore_structure

Determines whether the tool ignores the relative placement groups.

TYPE

Boolean

DEFAULT

false

GROUP

physopt

DESCRIPTION

The value you specify for the **physopt_ignore_structure** variable determines whether the tool carries out its default behavior and utilizes the relative placement. The default is false.

If you do not want the tool to perform relative placement on your design, set this variable to true.

To see the current value of this variable, enter

```
prompt> printvar physopt_ignore_structure
```

SEE ALSO

place_opt(2)
physopt_rp_enable_orient_opt(3)

physopt_macro_cell_height_threshold

Specifies the threshold value for the tool's detail placer to decide whether an extremely tall standard cell is to be treated as a "hard macro." The tool's detail placer is designed to place standard cells. If the design has some extremely tall standard cells, then the detail placer might not work as well as it does when placing "normal" standard cells. Thus, by default, if an extremely tall standard cell has a height that is greater than this threshold value, the detail placer treats the standard cell as a "hard macro."

TYPE

integer

DEFAULT

6

GROUP

physopt

DESCRIPTION

This variable specifies the threshold value for the tool's detail placer. This threshold determines whether a standard cell becomes a "hard macro." For example, if a standard cell has a 10x site height, then it is treated as a hard macro. The default threshold value is 6 times the site height. You can set this variable to adjust the "threshold value." The tool's detail placer treats some very tall standard cells as "hard macros" by default.

This variable is allowed only in the this tool.

SEE ALSO

check_legality(2)
legalize_placement(2)
psynopt(2)
place_opt(2)

physopt_mw_checkpoint_filename

Specifies the name of the file to which the MW database containing all hierarchy of the checkpointed design is to be written.

TYPE

string

DEFAULT

" "

GROUP

physopt

DESCRIPTION

Specifies the name of the file to which the MW database containing all hierarchy of the checkpointed design is to be written. The filename must be purely relative. The directory path must be specified in the variable `mw_design_library`. This variable will be honored only during checkpointing to CEL in XG mode.

To determine the current value of this variable, use **printvar** **physopt_mw_checkpoint_filename**.

SEE ALSO

`mw_design_library(3)`

physopt_new_fix_constants

Determines whether the tool is to observe the maximum capacitance constraint during tie-off optimization.

TYPE

Boolean

DEFAULT

true

DESCRIPTION

Determines whether the tool is to observe the maximum capacitance constraint (set with the **max_capacitance** attribute of the **set_max_capacitance** command) during tie-off optimization.

During postprocessing after optimization, the tool maps all generic constant logic cells to tie-off cells. If you set this variable as **true** (the default) during this phase, the tool optimizes the number of tie-off cells required to drive the loads to constant logic value. To derive the number of tie-off cells required, and their locations, the tool considers the max_fanout design rule constraint and the max_cap design rule constraint on the design.

If you set this variable as **false**, the tool considers only the max_fanout design rule constraint (but not the max_cap design rule constraint) in performing the tie-off optimization.

To see the current value of this variable, type

```
psyn_shell-xg-t> printvar physopt_new_fix_constants
```

SEE ALSO

set_max_capacitance(2)

physopt_pin_based_pad

Specifies whether is_pad attribute is set to pin.

TYPE

Boolean

DEFAULT

false

GROUP

physopt

DESCRIPTION

By default, physopt places implicit dont_touch on nets connected to cells which have "is_pad" attribute. If this variable is set to true, then physopt places implicit dont_touch on nets connected to pin which has "is_pad" attribute.

SEE ALSO

physopt_power_critical_range

Specifies a margin of slack for cells during leakage power optimization. If a cell has a slack less than the power critical range, power optimization will not be done for the cell.

TYPE

float

DEFAULT

-1.04858e+06

GROUP

physopt

DESCRIPTION

The power critical range specifies a margin of slack for cells during leakage power optimization. If a cell has a slack less than the power critical range, leakage power optimization will not be done for the cell. The default value is minus infinity; that is, all cells will be optimized for leakage power during the leakage power optimization phase of the **physopt** command.

SEE ALSO

set_max_leakage_power(2)

physopt_ref_pdef_loaded

Stores the name of the reference loaded during `report_cell_displacement -load_pdef`. Otherwise, stores the null string.

TYPE

String

DEFAULT

" "

GROUP

physopt

DESCRIPTION

This variable stores the name of the reference that PDEF loaded during `report_cell_displacement -load_pdef xx.pdef`. This is used to obtain the value of the PDEF file inside `psyn_shell`, and is used to assign values to other temporary variables. The variable gets updated after running `report_cell_displacement`. However to clear its value, you must run `report_cell_displacement -remove_pdef`.

SEE ALSO

`report_cell_displacement(2)`

physopt_row_overlap_threshold

Specifies a threshold for checking multi-type site array overlapping floorplan.

TYPE

float

DEFAULT

0.1

GROUP

physopt

DESCRIPTION

A specified threshold is used to check multi-type site array overlapping in a floorplan. A threshold set at 0.1 means that a 10 percent difference of normal core area is allowed.

It is not recommended that you set the threshold to larger number than 0.5, which means 50 percent difference. A larger setting will adversely affect quality of result.

SEE ALSO

`physopt_check_site_array_overlap(3)`

physopt_rp_enable_orient_opt

Determines whether the tool is to allow orientation optimization of cells in relative placement groups.

TYPE

Boolean

DEFAULT

true

GROUP

physopt

DESCRIPTION

The value you specify for the **physopt_rp_enable_orient_opt** variable determines whether the tool performs orientation optimization of cells within relative placement groups, which is the default behavior of the tool. (The default value of this variable is **true**.)

For the remainder of the cells in your design, if you prefer to utilize both user-specified orientation and automatic orientation, leave the value of this variable as **true** (the default). This ensures that the tool will respect those instances that have a user-specified orientation, and will perform orientation optimization on the remaining cells.

If you want to completely disable orientation optimization on all cells inside relative placement groups, set the value of the **physopt_rp_enable_orient_opt** variable as **false**. If you set the value as **false**,

- The tool respects a user-specified orientation, if the orientation is valid.
- The tool chooses a default valid orientation if no user-specified orientation exists.

To see the current value of this variable, type

```
prompt> printvar physopt_rp_enable_orient_opt
```

SEE ALSO

place_opt(2)
physopt_ignore_structure(3)

physopt_tie_const_cells

Connects all unconnected pins in the same hierarchy to one logic cell.

TYPE

Boolean

DEFAULT

false

GROUP

physopt

DESCRIPTION

By default, when the design has some unconnected pins, Physical Compiler connects each unconnected pin to unique logic cell. When **fBphysopt_tie_const_cells** is true, Physical Compiler will connect all unconnected pins in the same hierarchy to one logic cell.

SEE ALSO

physopt_tie_spare_cells

Instructs the physical optimization to connect the inputs of a spare cells to tie-off cells.

TYPE

Boolean

DEFAULT

true

GROUP

physopt

DESCRIPTION

This variable when set to true (default) , instructs the physopt not to dis-associate the constants *logic*1/*logic*0 from the inputs of a spare cells. Subsequently allowing the optimization to map them to tie-high/tie-low cells appropriately.

When set to false , it would dis-associate any constants *logic*1/*logic*0 from the inputs of spare cells, thus making the inputs as floating.

If the inputs to the spare cells are connected to the tie cells, subsequent optimization might result in multiple spare cells being connected to a single tie cells. Since spare cells are sprinkled in a area, the common tie cells between them might result in long wires connections. To turn off any such optimization, user must turn off the following switch **physopt_new_fix_constants**.

This variable is allowed only in the Physical Compiler.

SEE ALSO

physopt_new_fix_constants(3)

physopt_ultra_high_area_effort

Enables very high effort area optimization for potentially better area recovery but with more runtime.

TYPE

Boolean

DEFAULT

false

GROUP

physopt

DESCRIPTION

This variable enables very high effort area optimization during high effort area recovery for potentially better QOR, but with more runtime.

This variable can be used only with `-area_effort high`. This variable is valid only in Physical Compiler.

SEE ALSO

`physopt_area_critical_range(3)`

pin_attributes

Contains attributes placed on pins.

DESCRIPTION

Contains attributes that can be placed on a pin.

There are a number of commands used to set attributes; however, most attributes can be set with the **set_attribute** command. If the attribute definition specifies a **set** command, use it to set the attribute. Otherwise, use **set_attribute**. If an attribute is *read only*, it cannot be set by the user.

To determine the value of an attribute, use the **get_attribute** command. To remove attributes, use the **remove_attribute** command.

For a more detailed explanation of an attribute, refer to the manual pages of the appropriate **set** command. For information on all attributes, refer to the **attributes** manual page.

Pin Attributes

`disable_timing`

Disables timing arcs. This has the same affect on timing as not having the arc in the library. Set with **set_disable_timing**.

`fall_delay`

Specifies an offset from the falling edge of the ideal clock waveform. Set with **set_clock_skew -fall_delay**.

`max_fall_delay`

A floating point value that specifies the maximum falling delay on ports, clocks, pins, cells, or on paths between such objects. Set with **set_max_delay**.

`max_rise_delay`

A floating point value that specifies the maximum rising delay on ports, clocks, pins, cells, or on paths between such objects. Set with **set_max_delay**.

`min_fall_delay`

A floating point value that specifies the minimum falling delay on ports, clocks, pins, cells, or on paths between such objects. Set with **set_min_delay**.

`min_rise_delay`

A floating point value that specifies the minimum rising delay on ports, clocks, pins, cells, or on paths between such objects. Set with **set_min_delay**.

`minus_uncertainty`

Specifies a negative uncertainty from the edges of the ideal clock waveform. Set with **set_clock_skew -minus_uncertainty**.

observe_pin

Specifies the (internal) observe pin name of an LSI Logic scan macrocell (LSI CTV only). This attribute is used by the **write_test** command. Set with **set_attribute**.

pin_direction

Specifies the direction of a pin. Allowed values are *in*, *out*, *inout*, or *unknown*. This attribute is **read only** and cannot be set by the user.

pin_properties

Lists valid EDIF property values to be attached to different versions of the output pin. The EDIF property values correspond to different output emitter-follower resistance values on the output pin. For details about the use of this attribute, refer to the *Library Compiler Reference Manual*. Set with **set_attribute**.

plus_uncertainty

Specifies a positive uncertainty from the edges of the ideal clock waveform. Affects all sequential cells in the transitive fanout of this port. Set with **set_clock_skew -plus_uncertainty**.

propagated_clock

Specifies that the clock edge times be delayed by propagating the values through the clock network. If this attribute is not present, ideal clocking is assumed. Set with **set_clock_skew -propagated**.

rise_delay

Specifies an offset from the rising edge of the ideal clock waveform. Set with **set_clock_skew -rise_delay**.

set_pin

Specifies the (internal) set pin name of an LSI Logic scan macrocell (LSI CTV only). This attribute is used by the **write_test** command. Set with **set_attribute**.

signal_type

Used to indicate that a pin or port is of a special type, such as a **clocked_on_also** port in a master/slave clocking scheme, or a **test_scan_in** pin for scan-test circuitry. Set with **set_signal_type**.

static_probability

A floating point number that specifies the percentage of time that the signal is in the logic 1 state; this information is used by **report_power**. If this attribute is not set, **report_power** will use the default value of 0.5, indicating that the signal is in the logic 1 state half the time. Set with **set_switching_activity**.

test_assume

A string that represents a constant logic value to be assumed for specified pins throughout test design rule checking, test pattern generation, and fault simulation by **check_test**, **create_test_patterns**, and **fault_simulate**. "1", "one", or "ONE" specifies a constant value of logic one; "0", "zero", or "ZERO" specifies a constant value of logic zero. Use **report_test -assertions** for a report on objects that have the **test_assume** attribute set. Set with **set_test_assume**.

pin_attributes

test_dont_fault

Specifies pins not faulted during test pattern generation. If no command options are specified, this attribute is set for both stuck-at-0 and stuck-at-1 faults. Set with **set_test_dont_fault**.

test_initial

A string that represents an initial logic value to be assumed for specified pins at the start of test design rule checking and fault simulation by **check_test** and **fault_simulate**. "1", "one", or "ONE" specifies an initial value of logic one; "0", "zero", or "ZERO" specifies an initial value of logic zero. Use **report_test -assertions** for a report on objects that have the **test_initial** attribute set. Set with **set_test_initial**.

test_isolate

Indicates that the specified sequential cells, pins, or ports are to be logically isolated and considered untestable during test design rule checking by **check_test**. When this attribute is set on a cell, it is also placed on all pins of that cell. Do not set this attribute on a hierarchical cell. Use **report_test -assertions** for a report on isolated objects. Set with **set_test_isolate**.

Note: Setting this attribute suppresses the warning messages associated with the isolated objects.

test_require

Specifies a constant, fixed logic value that a pin is required to have during scan test vector generation. The pin maintains the same value for each test vector generated. Use **report_test -assertions** for a report on objects that have the **test_require** attribute set. Set with **set_test_require**.

test_routing_position

Specifies the preferred routing order of the scan-test signals of the identified cells. Set with **set_test_routing_order**.

toggle_rate

A positive floating point number that specifies the toggle rate; that is, the number of zero-to-one and one-to-zero transitions within a library time unit period. This information is used by **report_power**; if this attribute is not set, **report_power** will use the default value of $2 * (\text{static_probability}) (1 - \text{static_probability})$. The default will be scaled by any associated clock signal (if one is available). Set with **set_switching_activity**.

true_delay_case_analysis

Specifies a value to set all or part of an input vector for **report_timing -true** and **report_timing -justify**. Allowed values are *0*, *1*, *r* (rise, X to 1), and *f* (fall, X to 0). Set with **set_true_delay_case_analysis**.

SEE ALSO

get_attribute(2)
remove_attribute(2)
set_attribute(2)
attributes(3)

pin_shape_attributes

Contains attributes related to pin shape.

DESCRIPTION

Contains attributes related to pin shape.

You can use **get_attribute** to determine value of an attribute, and use **report_attribute** to get a report of all attributes on specified physical bus. Specified with **list_attribute -class pin_shape -application**, the definition of attributes can be listed.

Pin Shape Attributes

access_direction

Specifies the accessible direction(s) of a pin shape.
This attribute is read-only.
The valid values can be:

- **Left** indicates the object can be accessed from left.
- **Right** indicates the object can be accessed from right.
- **Up** indicates the object can be accessed from above.
- **Down** indicates the object can be accessed from below.
- **Left Right** indicates the object can be accessed from left and right.
- **Left Up** indicates the object can be accessed from left and above.
- **Left Down** indicates the object can be accessed from left and below.
- **Right Up** indicates the object can be accessed from right and above.
- **Right Down** indicates the object can be accessed from right and below.
- **Up Down** indicates the object can be accessed from above and below.
- **Left Right Up** indicates the object can not be access from below.

- **Left Right Down** indicates the object can not be access from above.
- **Left Up Down** indicates the object can not be access from right.
- **Right Up Down** indicates the object can not be access from left.
- **Left Right Up Down** indicates the object can be accessed from all directions.

base_name

Specifies the base name of a pin shape. The **base_name** of a pin shape is similar with the **name** of the corresponding terminal in the child MW design. This attribute is read-only.

bbox

Specifies the bounding-box of a pin shape. The **bbox** is represented by a **rectangle**.

The format of a *rectangle* specification is {{llx lly} {urx ury}}, which specifies the lower-left and upper-right corners of the rectangle.

The *bbox* of a pin shape is calculated by the **origin** and **orientation** of its cell and the actual **bbox** of its corresponding terminal from the child MW design.

This attribute is read-only.

bbox_ll

Specifies the lower-left corner of the bounding-box of a pin shape.

The **bbox_ll** is represented by a **point**. The format of a *point* specification is {x y}.

You can get the **bbox_ll** of a pin shape by accessing the first element of its **bbox**.

This attribute is read-only.

bbox_llx

Specifies x coordinate of the lower-left corner of the bounding-box of a pin shape.

The data type of **bbox_llx** is double.

This attribute is read-only.

bbox_lly

Specifies y coordinate of the lower-left corner of the bounding-box of a pin shape.

The data type of **bbox_lly** is double.

This attribute is read-only.

bbox_ur

Specifies the upper-right corner of the bounding-box of a pin shape.

The **bbox_ur** is represented by a **point**. The format of a *point* specification is {x y}.

You can get the **bbox_ur** of a pin shape by accessing the second element of its

bbox.

This attribute is read-only.

bbox_urx

Specifies x coordinate of the upper-right corner of the bounding-box of a pin shape.

The data type of **bbox_urx** is double.

This attribute is read-only.

bbox_ury

Specifies y coordinate of the upper-right corner of the bounding-box of a pin shape.

The data type of **bbox_ury** is double.

This attribute is read-only.

cell_id

Specifies Milkyway design ID in which a pin shape object is located.

This attribute is read-only.

direction

Specifies the direction of a pin shape.

The valid values can be: in, out, inout and tristate.

This attribute is read-only.

full_name

Specifies the full name of a pin shape.

The full name of a pin shape consists of the full name of its owned cell and the name of the corresponding terminal from child MW design.

This attribute is read-only.

is_fixed

Indicates whether a pin shape is fixed or not.

This attribute is read-only.

layer

Specifies the layer name of a pin shape.

This attribute is read-only.

name

Specifies name of a pinshape. It's identical as the attribute **full_name**.

This attribute is read-only.

number_of_points

Specifies the number of points to illustrate the boundary of a pin shape.

You can refer to the attribute **points**. The list length of **points** is the value of **number_of_points**.

This attribute is read-only.

object_class

Specifies object class name of a pin shape, which is **pin_shape**.

This attribute is read-only.

points

Specifies points of the boundary of a pin shape. A pin shape can be a rectangle, a rectilinear polygon, or multiple rectangles.

pin_shape_attributes

When a pin shape is either a rectangle or a rectilinear polygon, its **points** is represented by a list of points. The last element of the list is the same as the first element.

When a pin shape consists of multiple rectangles, its **points** is represented by a list of points of rectangles. Every five points represent one rectangle. The *points* of a pin shape is calculated by the **origin** and **orientation** of its cell and the actual **points** of its corresponding terminal from the child MW design.

This attribute is read-only.

status

Specifies the PR status of a pin shape.

The valid values are: fixed, placed, cover, and unplaced.

This attribute is read-only.

SEE ALSO

get_attribute(2),
list_attribute(2),
report_attribute(2).

placement_blockage_attributes

Contains attributes related to placement blockage.

DESCRIPTION

Contains attributes related to placement blockage.

You can use **get_attribute** to determine value of an attribute, and use **report_attribute** to get a report of all attributes on specified object. Specified with **list_attribute -class placement_blockage -application**, the definition of attributes can be listed.

Placement Blockage Attributes

affects

Specifies the affects of a placement blockage, which is placement.
The data type of **affects** is string.
This attribute is read-only.

area

Specifies area of a placement blockage.
The data type of **area** is float.
This attribute is read-only.

bbox

Specifies the bounding-box of a placement blockage. The **bbox** is represented by a **rectangle**.
The format of a *rectangle* specification is {{llx lly} {urx ury}}, which specifies the lower-left and upper-right corners of the rectangle.
The data type of **bbox** is string.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

blocked_percentage

Specifies the percentage blockage for a partial blockage.
The data type of **blocked_percentage** is integer.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

cell_id

Specifies Milkyway design ID in which a placement blockage object is located.
The data type of **cell_id** is integer.
This attribute is read-only.

layer

Specifies layer name of a placement blockage.
The data type of **layer** is string.
Its valid values are:

- **PlaceBlockage**

- **SoftPlaceBlk**

- **pinBlockage**

- **MacroBlockage**

- **PartialPlaceBlk**

This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

name

Specifies name of a placement blockage object.

The data type of **name** is string.

This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

object_class

Specifies object class name of a placement blockage, which is

placement_blockage.

The data type of **object_class** is string.

This attribute is read-only.

object_id

Specifies object ID in Milkyway design file.

The data type of **object_id** is integer.

This attribute is read-only.

pin_blockage_layers

Specifies the layers for which routing to pins are blocked. This attribute only applies on pin blockage type.

The data type of **pin_blockage_layers** is string.

This attribute is read-only.

type

Specifies type of a placement blockage.

The data type of **type** is string.

Its valid values are:

- **hard**

- **soft**

- **pin**

- **hard_macro**

- **partial**

This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

SEE ALSO

```
get_attribute(2),  
list_attribute(2),  
report_attribute(2),  
set_attribute(2).
```

placer_disable_auto_bound_for_gated_clock

Determines whether automatic group bounding is disabled for gated clocks created by Power Compiler.

TYPE

Boolean

DEFAULT

true

DESCRIPTION

The gated-clock method reduces a design's power consumption by controlling the switching activity from the clock signal to flip-flop registers. The automatic bound function that this variable enables (when set to *false*, the default is true) works only for the gated-clock elements Power Compiler creates. The **placer_disable_auto_bound_for_gated_clock** variable does not affect your design unless you use the clock-gating functionality of Power Compiler.

To reduce clock skew, place the clock-gating element and the flip-flops it controls close together in your design. The tool automatically creates a group bound for each clock-gating element and the flip-flops the element drives. This group bound helps place the flip-flops closer to the clock-gating element.

If this variable remains true, the tool does not create a group bound for the clock-gating elements created with Power Compiler.

SEE ALSO

remove_bounds(2)
report_bounds(2)
create_bounds(2)

placer_disable_macro_placement_timeout

Prevents the coarse placer from timing out during macro placement.

TYPE

Boolean

DEFAULT

false

DESCRIPTION

Use this variable to prevent the coarse placer from timing out during macro placement when running **create_placement** with floating macros.

By default, macro placement exits early if runtime is too long when compared to the rest of coarse placement. This is to prevent excessively long runtimes that can occur when there are too many floating macros, too many constraints on macros, or bad constraints. The result is that some macros may be placed illegally.

When this variable is set to true, the placer will let macro placement run to completion regardless of runtime.

The default value of this variable is false.

SEE ALSO

set_mpc_macro_array(2)
create_placement(2)

placer_dont_error_out_on_conflicting_bounds

Prevents the coarse placer from erroring out when it detects conflicting bounds.

TYPE

Boolean

DEFAULT

true

DESCRIPTION

Use this variable to prevent the tool from erroring out when it detects conflicting bounds when running **place_opt** or **create_placement**.

By default, the placer will automatically adjust the conflicting groupbounds and continue instead of erroring out.

When this variable is set to false, the placer checks for conflicting movebounds and groupbounds and errors out if a conflict is detected. These bounds can be user-specified bounds or bounds generated by the tool.

The default value of this variable is true.

SEE ALSO

`create_bounds(2)`
`create_placement(2)`
`place_opt(2)`

placer_enable_enhanced_router

Enables a mode of coarse placement in which congestion removal is done with the global router.

TYPE

Boolean

DEFAULT

false

DESCRIPTION

Enables a mode of coarse placement in which congestion removal is driven by the global router.

When this variable is set to false, the congestion removal in coarse placement is driven by an internal global route estimator.

For most designs, QoR does not change much when turning on this feature. But for some designs, you may see a significant congestion reduction when this feature is turned on.

An important change when using the variable is that the **set_congestion_options -layer** command is not supported when **placer_enable_enhanced_router** is enabled. Instead, use the standard command for passing layer availability constraints to the global router, **create_route_guide**.

You can use this feature in conjunction with any command that invokes congestion-driven placement, such as **place_opt -congestion**, **psynopt -congestion**, and others.

For example, to enable this feature, enter

```
prompt> set placer_enable_enhanced_router true
```

SEE ALSO

place_opt(2)
psynopt(2)

placer_gated_register_area_multiplier

Specifies the value of the multiplier used to generate automatic group bounds for gated clocks.

TYPE

float

DEFAULT

20

DESCRIPTION

The gated-clock method reduces a design's power consumption by controlling the switching activity from the clock signal to flip-flop registers. The automatic bound function works only for the gated-clock elements Power Compiler creates. The **placer_gated_register_area_multiplier** variable does not affect your design unless you use the clock-gating functionality of Power Compiler.

To reduce clock skew, place the clock-gating element and the flip-flops it controls close together in your design. Physical Compiler automatically creates a floating group bound for each clock-gating element and the flip-flops the element drives. This group bound helps place the flip-flops closer to the clock-gating element.

The size of the group bound is equal to the square root of the product of the total area of flip-flop elements the gate controls within the group bound and the value of the **placer_gated_register_area_multiplier** variable.

For example, if a clock-gate element drives five flip-flops, and the total area of these six cells is 45, the size of the group bound is $\text{sqrt}(20 \times 45) = 30$.

SEE ALSO

physopt_check_site_array_overlap(3)

placer_max_cell_density_threshold

Enables a mode of coarse placement in which cells can clump together.

TYPE

float

DEFAULT

-1

DESCRIPTION

Enables a mode of coarse placement in which cells are not distributed evenly across the surface of the chip, but are allowed to clump together. The value you specify sets the threshold of how tightly the cells are allowed to clump. The value of 1.0 allows no gaps between cells.

A reasonable value is one that is above the background utilization of your design but below 1.0. For example, if your background utilization is 40%, or 0.4, a reasonable value for this variable is a value between 0.4 and 1.0. The higher the value, the more tightly the cells clump together.

You can use this feature in conjunction with any command that invokes coarse placement, such as **create_placement** and **place_opt**.

For example, to set the threshold to 0.7, enter

```
prompt> set placer_max_cell_density_threshold 0.7
```

SEE ALSO

`create_placement(2)`

`place_opt(2)`

placer_run_in_separate_process

Enables and disables the use of a separate process to perform placement.

TYPE

Boolean

DEFAULT

true

DESCRIPTION

This variable enables the use of a separate process to perform placement when set to true and disables it when set to false.

SEE ALSO

placer_soft_keepout_channel_width

Specifies a soft keepout distance that is used by the **place_opt** and **create_placement** commands.

TYPE

float

DEFAULT

0

DESCRIPTION

This variable is used to specify a soft keepout distance that is used by the **place_opt** and **create_placement** commands. The distance must be specified in micron units. If set, this variable causes the tool to automatically identify thin channels (regions) around fixed cells and blockages as soft keepout areas.

Note that putting too many cells in such a thin keepout area might potentially lead to poor results. If an area is identified as a soft keepout area, the tool tries not to put too many cells in that area.

If set, this variable causes the tool to mark various areas near fixed RAMs and blockages as soft keepout areas. The soft keepout areas are not generated for every fixed RAM or blockage. Such areas are generated for an object (fixed RAM or blockage) only if the distance between the object and the core area boundary is less than the soft keepout distance or if the distance between two such objects is less than the soft keepout distance (forming a thin channel between the objects).

Setting this variable is optional. If unspecified, the default is 0.0.

To determine the current value of this variable use the following command:

```
prompt> printvar placer_soft_keepout_channel_width
```

SEE ALSO

```
create_placement(2)  
legalize_placement(2)  
place_opt(2)
```

plan_group_attributes

Contains attributes related to plan group.

DESCRIPTION

Contains attributes related to plan group.

You can use **get_attribute** to determine value of an attribute, and use **report_attribute** to get a report of all attributes on specified object. Specified with **list_attribute -class plan_group -application**, the definition of attributes can be listed.

Plan Group Attributes

aspect_ratio

Specifies the **height:width** ratio of a plan group.
The data type of **aspect_ratio** is double.
This attribute is read-only.

bbox

Specifies the bounding-box of a plan group. The **bbox** is represented by a **rectangle**.
The format of a *rectangle* specification is {{llx lly} {urx ury}}, which specifies the lower-left and upper-right corners of the rectangle.
The data type of **bbox** is string.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

bbox_ll

Specifies the lower-left corner of the bounding-box of a plan group.
The **bbox_ll** is represented by a **point**. The format of a *point* specification is {x y}.
You can get the **bbox_ll** of a plan group, by accessing the first element of its **bbox**.
The data type of **bbox_ll** is string.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

bbox_llx

Specifies x coordinate of the lower-left corner of the bounding-box of a plan group.
The data type of **bbox_llx** is double.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

bbox_lly

Specifies y coordinate of the lower-left corner of the bounding-box of a plan group.
The data type of **bbox_lly** is double.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

bbox_ur

Specifies the upper-right corner of the bounding-box of a plan group.
The **bbox_ur** is represented by a **point**. The format of a *point* specification is {x y}.
You can get the **bbox_ur** of a plan group, by accessing the second element of its **bbox**.
The data type of **bbox_ur** is string.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

bbox_urx

Specifies x coordinate of the upper-right corner of the bounding-box of a plan group.
The data type of **bbox_urx** is double.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

bbox_ury

Specifies y coordinate of the upper-right corner of the bounding-box of a plan group.
The data type of **bbox_ury** is double.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

bottom_padding

Specifies bottom-side width of interior paddings.
The data type of **bottom_padding** is double.
This attribute is read-only. You can use **create_fp_plan_group_padding** to set its value.

bottom_padding_external

Specifies bottom-side width of exterior paddings.
The data type of **bottom_padding_external** is double.
This attribute is read-only. You can use **create_fp_plan_group_padding** to set its value.

bottom_shielding

Specifies bottom-side widths of signal shielding inside a plan group.
The data type of **bottom_shielding** is string.
This attribute is read-only. You can use **create_fp_block_shielding** to set its value.

bottom_shielding_external

Specifies bottom-side widths of signal shielding outside a plan group.
The data type of **bottom_shielding_external** is string.
This attribute is read-only. You can use **create_fp_block_shielding** to set its value.

color

Specifies color to draw a plan group and its associated instances.
The data type of **color** is string.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

plan_group_attributes

`is_fixed`

Specifies that a plan group is in a fixed location, and the shaping will ignore it.

The data type of **`is_fixed`** is boolean.

This attribute is writable. You can use **`set_attribute`** to modify its value on a specified object.

`left_padding`

Specifies left-side width of interior paddings.

The data type of **`left_padding`** is double.

This attribute is read-only. You can use **`create_fp_plan_group_padding`** to set its value.

`left_padding_external`

Specifies left-side width of exterior paddings.

The data type of **`left_padding_external`** is double.

This attribute is read-only. You can use **`create_fp_plan_group_padding`** to set its value.

`left_shielding`

Specifies left-side widths of signal shielding inside a plan group.

The data type of **`left_shielding`** is string.

This attribute is read-only. You can use **`create_fp_block_shielding`** to set its value.

`left_shielding_external`

Specifies left-side widths of signal shielding outside a plan group.

The data type of **`left_shielding_external`** is string.

This attribute is read-only. You can use **`create_fp_block_shielding`** to set its value.

`logic_cell`

Specifies name of the hierarchical cell associated with a plan group.

The data type of **`logic_cell`** is string.

This attribute is read-only.

`name`

Specifies name of a plan group object.

The data type of **`name`** is string.

This attribute is read-only.

`number_of_hard_macro`

Specifies number of hard macro cells inside a plan group.

The data type of **`number_of_hard_macro`** is integer.

This attribute is read-only.

`number_of_pin`

Specifies number of pins on the hierarchical cell associated with a plan group.

The data type of **`number_of_pin`** is integer.

This attribute is read-only.

`number_of_standard_cell`

Specifies number of standard cells inside a plan group.

The data type of **`number_of_standard_cell`** is integer.

This attribute is read-only.

`object_class`

Specifies object class name of a plan group, which is **plan_group**.
The data type of **object_class** is string.
This attribute is read-only.

`points`

Specifies point list of a plan group's boundary.
The data type of **points** is string.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

`right_padding`

Specifies right-side width of interior paddings.
The data type of **right_padding** is double.
This attribute is read-only. You can use **create_fp_plan_group_padding** to set its value.

`right_padding_external`

Specifies right-side width of exterior paddings.
The data type of **right_padding_external** is double.
This attribute is read-only. You can use **create_fp_plan_group_padding** to set its value.

`right_shielding`

Specifies right-side widths of signal shielding inside a plan group.
The data type of **right_shielding** is string.
This attribute is read-only. You can use **create_fp_block_shielding** to set its value.

`right_shielding_external`

Specifies right-side widths of signal shielding outside a plan group.
The data type of **right_shielding_external** is string.
This attribute is read-only. You can use **create_fp_block_shielding** to set its value.

`target_utilization`

Specified target utilization set on a plan group.
The data type of **target_utilization** is double.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

`top_padding`

Specifies top-side width of interior paddings.
The data type of **top_padding** is double.
This attribute is read-only. You can use **create_fp_plan_group_padding** to set its value.

`top_padding_external`

Specifies top-side width of exterior paddings.
The data type of **top_padding_external** is double.
This attribute is read-only. You can use **create_fp_plan_group_padding** to set its value.

`plan_group_attributes`

`top_shielding`

Specifies top-side widths of signal shielding inside a plan group.

The data type of **top_shielding** is string.

This attribute is read-only. You can use **create_fp_block_shielding** to set its value.

`top_shielding_external`

Specifies top-side widths of signal shielding outside a plan group.

The data type of **top_shielding_external** is string.

This attribute is read-only. You can use **create_fp_block_shielding** to set its value.

`utilization`

Specifies the ratio of total area size of associated instances to the area of a plan group.

The data type of **utilization** is double.

This attribute is read-only.

SEE ALSO

```
create_fp_block_shielding(2),  
create_fp_plan_group_padding(2),  
get_attribute(2),  
list_attribute(2),  
report_attribute(2),  
set_attribute(2).
```

plot_variables

Variables that affect the **plot** command.

SYNTAX

```
Boolean plot_box = "false"
string plot_command = "lpr -Plw"
string plot_orientation = "best_fit"
integer plot_scale_factor = "100"
integer plotter_maxx = 584
integer plotter_maxy = 764
integer plotter_minx = 28
integer plotter_miny = 28
```

DESCRIPTION

These variables directly affect the **plot** command, which produces a PostScript plot of the current design. Defaults are listed above, under Syntax.

For a list of these variables and their current values, type **print_variable_group plot**. To view this manual page online, type **help plot_variables**. To view an individual variable description, type **help var**, where *var* is the variable name.

plot_box

When *true*, a box is drawn around the plot. The default is *false*.

plot_command

Specifies the operating system command that produces a hard copy of the plot. The PostScript output of the **plot** command is piped as standard input (stdin) to the given command. If this variable is not a valid system command, an operating system error occurs during **plot**. The default is "lpr -Plw". Usually, this variable is set only once for a site in the system **.synopsys_dc.setup** initialization file.

plot_orientation

Specifies whether the schematic is vertical or horizontal. If *landscape*, the plot is output horizontally. If *portrait*, the plot is output vertically. If *best_fit* (the default value), the plot is output in a manner that best fits the aspect ratio of the current design schematic.

plot_scale_factor

Specifies a scaling factor for the schematic. Line widths are multiplied by the specified percentage value when the schematic is plotted.

plotter_maxx

Specifies the x coordinate of the upper right corner of the plot output device. Usually, this variable is set only once for a site in the **.synopsys_dc.setup** initialization file.

plotter_maxy

Specifies the y coordinate of the upper right corner of the plot output device. Usually, this variable is set only once for a site in the

.synopsys_dc.setup initialization file.

plotter_minx

Specifies the x coordinate of the lower left corner of the plot output device. Usually, this variable is set only once for a site in the **.synopsys_setup.dc** initialization file.

plotter_miny

Specifies the y coordinate of the lower left corner of the plot output device. Usually, this variable is set only once for a site in the **.synopsys_setup.dc** initialization file.

SEE ALSO

highlight_path (2), **plot** (2), **set_layer** (2); **schematic_variables** (3).

port_attributes

Contains attributes that can be placed on a port.

DESCRIPTION

Contains attributes that can be placed on a port.

There are a number of commands used to set attributes. Most attributes, however, can be set with the **set_attribute** command. If the attribute definition specifies a **set** command, use it to set the attribute. Otherwise, use **set_attribute**. If an attribute is "read-only," the user cannot set it.

To determine the value of an attribute, use the **get_attribute** command. To remove attributes, use the **remove_attribute** command.

For a more detailed explanation of an attribute, refer to the manual pages of the appropriate **set** command. For information on all attributes, refer to the **attributes** manual page.

Port Attributes

connection_class

A string that specifies the connection class label to be attached to a port or to a list of ports. **compile**, **insert_pads**, and **insert_dft** will connect only those loads and drivers that have the same connection class label. The labels must match those in the library of components for the design, and must be separated by a space. The labels *universal* and *default* are reserved. *universal* indicates that the port can connect with any other load or driver. *default* is assigned to any ports that do not have a connection class already assigned. Set with **set_connection_class**.

dont_touch_network

When a design is optimized, **compile** assigns **dont_touch** attributes to all cells and nets in the transitive fanout of **dont_touch_network** clock objects. The **dont_touch** assignment stops at the boundary of storage elements. An element is recognized as storage only if it has setup or hold constraints. Set with **set_dont_touch_network**.

driven_by_logic_one

Specifies that input ports are driven by logic one. **compile** uses this information to create smaller designs. After optimization, a port connected to logic one usually does not drive anything inside the optimized design. Set with **set_logic_one**.

driven_by_logic_zero

Specifies that input ports are driven by logic zero. **compile** uses this information to create smaller designs. After optimization, a port connected to logic zero usually does not drive anything inside the optimized design. Set with **set_logic_zero**.

driving_cell_dont_scale

When *true*, the transition time on the port using the driving cell is not

scaled. Otherwise the transition time will be scaled by operating condition factors. Set with **set_driving_cell**.

driving_cell_fall

A string that names a library cell from which to copy fall drive capability to be used in fall transition calculation for the port. Set with **set_driving_cell**.

driving_cell_from_pin_fall

A string that names the **driving_cell_fall** input pin to be used to find timing arc fall drive capability. Set with **set_driving_cell**.

driving_cell_from_pin_rise

A string that names the **driving_cell_rise** input pin to be used to find timing arc rise drive capability. Set with **set_driving_cell**.

driving_cell_library_fall

A string that names the library in which to find the **driving_cell_fall**. Set with **set_driving_cell**.

driving_cell_library_rise

A string that names the library in which to find the **driving_cell_rise**. Set with **set_driving_cell**.

driving_cell_multiply_by

A floating point value by which to multiply the transition time of the port marked with this attribute. Set with **set_driving_cell**.

driving_cell_pin_fall

A string that names the **driving_cell_fall** output pin to be used to find timing arc fall drive capability. Set with **set_driving_cell**.

driving_cell_pin_rise

A string that names the **driving_cell_rise** output pin to be used to find timing arc rise drive capability. Set with **set_driving_cell**.

driving_cell_rise

A string that names a library cell from which to copy rise drive capability to be used in rise transition calculation for the port. Set with **set_driving_cell**.

fall_delay

Specifies an offset from the falling edge of the ideal clock waveform. Set with **set_clock_skew -fall_delay**.

fall_drive

Specifies the drive value of high to low transition on input or inout ports. Set with **set_drive**.

fanout_load

Specifies the fanout load on output ports. Set with **set_fanout_load**.

load

Specifies the load value on ports. The total load on a net is the sum of all the loads on pins, ports, and wires associated with that net. Set with

set_load.

max_capacitance

A floating point number that sets the maximum capacitance value for input, output, or bidirectional ports; or for designs. The units must be consistent with those of the technology library used during optimization. Set with **set_max_capacitance.**

max_fall_delay

A floating point value that specifies the maximum falling delay on ports, clocks, pins, cells, or on paths between such objects. Set with **set_max_delay.**

max_fanout

Specifies the maximum fanout load for the net connected to this port. **compile** ensures that the fanout load on this net is less than the specified value. Set with **set_max_fanout.**

max_rise_delay

A floating point value that specifies the maximum rising delay on ports, clocks, pins, cells, or on paths between such objects. Set with **set_max_delay.**

max_time_borrow

A floating point number that establishes an upper limit for time borrowing; that is, it prevents the use of the entire pulse width for level-sensitive latches. Units are those used in the technology library. Set with **set_max_time_borrow.**

max_transition

Specifies the maximum transition time for the net connected to this port. **compile** ensures that the transition time on this net is less than the specified value. Set with **set_max_transition.**

min_capacitance

A floating point number that sets the minimum capacitance value for input or bidirectional ports. The units must be consistent with those of the technology library used during optimization. Set with **set_min_capacitance.**

min_fall_delay

A floating point value that specifies the minimum falling delay on ports, clocks, pins, cells, or on paths between such objects. Set with **set_min_delay.**

min_rise_delay

A floating point value that specifies the minimum rising delay on ports, clocks, pins, cells, or on paths between such objects. Set with **set_min_delay.**

minus_uncertainty

Specifies a negative uncertainty from the edges of the ideal clock waveform. Affects all sequential cells in the transitive fanout of this port. Set with **set_clock_skew -minus_uncertainty.**

port_attributes

model_drive

A non-negative floating point number that specifies the estimated drive value on ports in terms of standard drives of the current technology library. Set with **set_model_drive**.

model_load

A non-negative floating point number that specifies the estimated load value on ports in terms of standard loads of the current technology library. Set with **set_model_load**.

op_used_in_normal_op

Specifies that a scan-out port is also used in normal operation (system mode). This attribute is used by the **insert_dft** command.

output_not_used

Determines that an output port is unconnected. Used by **compile** to create smaller designs because the logic that drives an unconnected output port might not need to be maintained. After a design with an unconnected output port is compiled, the port is usually not driven by anything inside the design. Set with **set_unconnected**.

pad_location

A string value that specifies the Xilinx pad location (pin number) to be assigned to a port. Setting a **pad_location** attribute on a port causes the Synopsys XNF writer to indicate in the XNF netlist that this port has the pad location given by the value of the **pad_location** attribute. No checks are performed to verify that the specified location is valid; for valid pad locations, refer to the Xilinx *XC4000 Databook*. Set with **set_attribute**.

plus_uncertainty

Specifies a positive uncertainty from the edges of the ideal clock waveform. Affects all sequential cells in the transitive fanout of this port. Set with **set_clock_skew -plus_uncertainty**.

port_direction

Direction of a port. Value can be *in*, *out*, *inout*, or *unknown*. This attribute is read-only and cannot be set by the user.

propagated_clock

Specifies the delay of the clock edge times by propagating the values through the clock network. Affects all sequential cells in the transitive fanout of this port. If this attribute is not present, ideal clocking is assumed. Set with **set_clock_skew -propagated**.

rise_delay

Specifies an offset from the rising edge of the ideal clock waveform. Set with **set_clock_skew -rise_delay**.

rise_drive

Specifies the drive value of low to high transition on input or inout ports. Set with **set_drive**.

signal_index

Used to enumerate different ports with the same signal type (for example, scan-in ports for a design with multiple scan chains). Set with

set_signal_type.

signal_type

Used to indicate that a port is of a "special" type, such as a "clocked_on_also" port in a master/slave clocking scheme, or a "test_scan_in" pin for scan-test circuitry. Set with **set_signal_type**.

static_probability

A floating point number that specifies the percentage of time that the signal is in the logic 1 state. This information is used by **report_power**. If this attribute is not set, **report_power** will use the default value of 0.5, indicating that the signal is in the logic 1 state half the time. Set with **set_switching_activity**.

test_dont_fault

If set, ports are not faulted during test pattern generation. If no command options are specified, this attribute is set for both "stuck-at-0" and "stuck-at-1" faults. Set with **set_test_dont_fault**.

test_hold

Specifies a fixed, constant logic value at a port during test generation. Set with **set_test_hold**.

test_isolate

Indicates that the specified sequential cells, pins, or ports are to be logically isolated and considered untestable during test design rule checking by **check_test**. When this attribute is set on a cell, it is also placed on all pins of that cell. Do not set this attribute on a hierarchical cell. Use **report_test -assertions** for a report on isolated objects. Set with **set_test_isolate**.

Note: Setting this attribute suppresses the warning messages associated with the isolated objects.

toggle_rate

A positive floating point number that specifies the toggle rate; that is, the number of zero-to-one and one-to-zero transitions within a library time unit period. This information is used by **report_power**. If this attribute is not set, **report_power** will use the default value of $2 * (\text{static_probability}) (1 - \text{static_probability})$. The default will be scaled by any associated clock signal (if one is available). Set with **set_switching_activity**.

true_delay_case_analysis

Specifies a value to set all or part of an input vector for **report_timing -true** and **report_timing -justify**. Allowed values are *0*, *1*, *r* (rise, X to 1), and *f* (fall, X to 0). Set with **set_true_delay_case_analysis**.

SEE ALSO

get_attribute(2)
remove_attribute(2)
set_attribute(2)
attributes(3)

port_complement_naming_style

Defines the convention the **compile** command uses to rename ports complemented as a result of using the **set_boundary_optimization** command.

TYPE

string

DEFAULT

%s_BAR

GROUP

compile_variables

DESCRIPTION

Defines the convention the **compile** command uses to rename ports complemented as a result of using the **set_boundary_optimization** command.

The variable string must contain one occurrence of %s (percent s). When **compile** generates a new port name, If this does not create a unique port name within the cell, the smallest possible integer that makes the name unique is appended to the end of the name (for example, X_BAR_0, X_BAR_1, and so on).

To determine the current value of this variable, use **printvar port_complement_naming_style**. For a list of all **compile** variables and their current values, use the **print_variable_group compile** command.

SEE ALSO

compile_variables(3)

power_attributes

Lists the predefined Power Compiler attributes.

DESCRIPTION

Attributes are properties assigned to objects such as nets, cells, pins and designs, and describe design features to be considered during optimization. A subset of attributes are specific to Power Compiler; they are only available when a Power Compiler license exists.

The Power Compiler attributes are "read-only": they cannot be set by the user. To determine the value of an attribute, use the **get_attribute** command. For information on all attributes, refer to the **attributes** manual page.

The Power Compiler attributes are grouped into the following categories:

- cell
- pin
- design

Definitions for these attributes are provided in the subsections that follow.

Cell Attributes

is_clock_gate

true if the cell is a clock gate. If the clock gating logic is encapsulated in a hierarchical clock gate wrapper, this attribute will only return *true* when applied to the hierarchical instance.

is_icg

true if the cell is an integrated clock gate (ICG). This attribute can only return *true* when applied to leaf cells. If the ICG cell is encapsulated in a hierarchical clock gate wrapper, this attribute will return *false* when applied to the hierarchical instance.

is_gicg

true if the cell is a generic integrated clock gate (GICG). Since GICGs cannot be encapsulated in a hierarchical clock gate wrapper, this attribute can only return *true* when applied to leaf cells.

is_latch_based_clock_gate

true if the cell is a latch-based clock gate.

is_latch_free_clock_gate

true if the cell is a latch-free clock gate.

is_positive_edge_clock_gate

true if the cell is a positive edge clock gate.

is_negative_edge_clock_gate

true if the cell is a negative edge clock gate.

power_attributes

`clock_gate_has_precontrol`
 true if the cell is a clock gate with (pre-latch) control point.

`clock_gate_has_postcontrol`
 true if the cell is a clock gate with (post-latch) control point.

`clock_gate_has_observation`
 true if the cell is a clock gate with observation point.

`is_clock_gated`
 true if the cell is a clock gated register or clock gate.

`clock_gating_depth`
 The number of clock gates on the clock path to this cell; -1 if the cell is not a clock gate or register.

`clock_gate_level`
 The number of clock gates on the longest clock branch in the fanout of this cell; -1 if not a clock gate.

`clock_gate_fanout`
 The number of registers and clock gates in the direct fanout of the clock gate; -1 if not a clock gate.

`clock_gate_register_fanout`
 The number of registers in the direct fanout of the clock gate; -1 if not a clock gate.

`clock_gate_multi_stage_fanout`
 The number of clock gates in the direct fanout of the clock gate; -1 if not a clock gate.

`clock_gate_transitive_register_fanout`
 The number of register in the transitive fanout of the clock gate; -1 if not a clock gate.

`clock_gate_module_fanout`
 The number of modules in the local fanout of the clock gate; -1 if not a clock gate.

`is_operand_isolator`
 true if the cell is an operand isolation cell.

`is_isolated_operator`
 true if the cell is an operator that was isolated with operand isolation.

`operand_isolation_style`
 Stores the operand isolation style of the isolation cell or isolated operator.

Pin Attributes

`is_clock_gate_enable_pin`
 true if the pin is a clock gate enable input.

`is_clock_gate_clock_pin`
 true if the pin is a clock gate clock input.

`is_clock_gate_output_pin`
 true if the pin is a gated-clock output of a clock gate.

`is_clock_gate_test_pin`
 true if the pin is a clock gate scan-enable or test-mode input.

`is_clock_gate_observation_pin`
 true if the pin is a clock gate observation point.

`is_operand_isolation_control_pin`
 true if the pin is the control pin of an operand isolation cell.

`is_operand_isolation_data_pin`
 true if the pin is the data input of an operand isolation cell.

`is_operand_isolation_output_pin`
 true if the pin is the data output of an operand isolation cell.

"Design Attributes"

`is_clock_gating_design`
 true if the design is a clock gating design.

`is_clock_gating_observability_design`
 true if the design is a clock gating observability design.

SEE ALSO

`get_attribute(2)`
`attributes(3)`

power_cg_all_registers

Specifies to the **insert_clock_gating** command whether to clock gate all registers, including those that do not meet the necessary requirements.

TYPE

Boolean

DEFAULT

false

GROUP

power_variables

DESCRIPTION

Specifies whether to clock gate all registers, including those that do not meet the necessary requirements. If this variable is set to *false* (the default value), registers that do not meet the setup, width or enable condition are not considered for clock gating, unless they are explicitly included with the **set_clock_gating_registers** command. When set to *true*, a redundant clock gate will be inserted for these registers. This can be useful for clock tree balancing. If necessary, the redundant clock gates will be duplicated to meet the *max_fanout* constraint. Note that the *minimum_bitwidth* constraint is not honored for the redundant clock gated registers.

This variable is valid only with Design Compiler (*dc_shell*, *dc_shell-t*) and Physical Compiler (*psyn_shell*).

To determine the current value of this variable, type **printvar power_cg_all_registers**. For a list of power variables and their current values, type **print_variable_group power**.

SEE ALSO

power_variables(3)

power_cg_balance_stages

Controls clock gate stage balancing is on or off during **compile** [**-incremental_mapping**] **-gate_clock** or **compile_ultra** [**-incremental_mapping**] **-gate_clock**.

TYPE

Boolean

DEFAULT

false

GROUP

power_variables

DESCRIPTION

This variable can be used to reduce the un-evenness in the number of stages of clock gates feeding different register banks. If this variable is set to true, **compile -gate_clock** or **compile_ultra -gate_clock** would reconfigure the different stage of clock gates so that there is exactly the same number of clock gates in each path from the clock root to the clock pin of all *gatable* register banks. It is necessary to define clocks using **create_clock** command for each clock network where clock gates need to be reconfigured.

Only the tool inserted clock gates and integrated clock gating (ICG) cells are considered during stage balancing.

To determine the current value of this variable, type **printvar power_cg_balance_stages**.

SEE ALSO

[power_cg_reconfig_stages\(3\)](#)
[power_variables\(3\)](#)

power_cg_cell_naming_style

Specifies the naming style for clock gating cells created during **insert_clock_gating**.

TYPE

String

DEFAULT

" "

GROUP

power

DESCRIPTION

Determines the way clock gating cells are named.

This variable must be set before issuing **insert_clock_gating** command.

This variable can contain any string in addition to the different tokens listed below. The tokens are replaced by appropriate value during clock gating and other strings are retained the way they are.

```
set power_cg_cell_naming_style \  
  "prefix_%c_%e_midfix_%r_%R_%d_suffix"
```

where,

- clockgates and not applicable for factored clock gates)
- for module or factored clock gates)

For all object names only simple (non-hierarchical) names are used.

If there is no occurrence of "%d" in the power_cg_cell_naming_style, Power Compiler will assume a %d at the end.

Example :

```
dc_shell-t> set power_cg_cell_naming_style "clk_gate_%r_%d  
dc_shell-t> set power_cg_cell_naming_style "clock_gate_cell_%c_%r_%d_name"
```

SEE ALSO

power_cg_module_naming_style(3)
power_cg_gated_clock_net_naming_style(3)

power_cg_derive_related_clock

When *true*, clock domain relationship between registers will be derived from the hierarchical context.

TYPE

Boolean

DEFAULT

false

GROUP

power_variables

DESCRIPTION

For latch-free clock gate insertion with the **insert_clock_gating** command the setup condition must be met before a bank can be clock gated. This implies that the enable condition of the bank must be combinationaly dependent on nets that are known to be synchronous (i.e., belong to the same clock domain) with the registers of the bank that are being clock gated.

The clock domain of nets is determined by the registers withing the module (subdesign) that drive the nets and the clock relationship specified for ports with the **set_input_delay** command. By default the clock domain relationship is analyzed locally, i.e., within the module. This is to ensure that clock gating on subdesigns is context independent: if a module is instantiated from a design different than the current design, the clock gating result will still be correct.

If the non-combinational driver (register or top level port) of an input to a module exists outside of that module, the clock domain of that input is considered unknown and no latch-free clock gating can be performed with enable conditions that depend on that particular input.

The setup condition can be relaxed to perform context specific analysis of the clock domain relationship. This is achieved by setting the variable **power_cg_derive_related_clock** to *true*. In that case the clock domain of any net will be derived from the non-combinational drivers in the (hierarchical) fanin of the net.

To determine the current value of this variable, type **printvar power_cg_derive_related_clock**. For a list of power variables and their current values, type **print_variable_group power**.

SEE ALSO

power_variables(3)

power_cg_designware

Performs clock gating on DesignWare sequential components in the design.

The use of **power_cg_designware** variable will be obsolete in a future release. Clock gating insertion with **compile_ultra -gate_clock** automatically inserts clock gates in DesignWare modules.

TYPE

Boolean

DEFAULT

false

GROUP

power_variables

DESCRIPTION

The use of the **power_cg_designware** variable will be obsolete in a future release. Clock gating insertion using the **compile_ultra** command with the **-gate_clock** option automatically inserts clock gates in DesignWare modules.

The **power_cg_designware** variable instructs the **compile** command to invoke DesignWare clock gating. During the compile stage, all DesignWare sequential components are clock gated if there is a clock gating opportunity.

A **Clock Gate Insertion Report** is generated after **Implementation Selection**. You can use the **insert_dft** command to connect test ports inside DesignWare components. The **report_clock_gating** command can be used to get more details about the clock gating result.

The following example shows a TCL script invoking DesignWare clock gating:

```
prompt> set power_cg_designware true
prompt> analyze -f verilog DW_cntr_gray_inst.v
prompt> elaborate DW_cntr_gray_inst
prompt> create_clock -period 5 [get_ports inst_clk]
prompt> compile
prompt> report_clock_gating
```

SEE ALSO

power_cg_enable_alternative_algorithm

Specifies to the **insert_clock_gating**, **compile-gate_clock** and **compile_ultra - gate_clock** commands whether to use an alternative algorithm to find gatable registers.

TYPE

Boolean

DEFAULT

false

GROUP

power_variables

DESCRIPTION

Depending on the design clock gating can have a long runtime. When set to *true* **power_cg_enable_alternative_algorithm** changes the clock gating algorithm in Design Compiler. The alternative algorithm that is enabled often reduces the runtime for clock gating especially for larger designs, but might increase the number of clock gates that are created compared to the default algorithm. The number of gated registers may vary.

To determine the current value of this variable, type **printvar power_cg_enable_alternative_algorithm**.

SEE ALSO

power_variables(3)

power_cg_flatten

Specifies to different **ungroup** commands whether to flatten Synopsys clock-gating cells.

TYPE

Boolean

DEFAULT

false

GROUP

power_variables

DESCRIPTION

Specifies to different **ungroup** commands whether to flatten Synopsys clock-gating cells. The list of commands include **ungroup**, **compile -ungroup**, **optimiz_regsiters -ungroup**, **balance_registers** and **ungroup**.

If this variable is set to *false* (the default value), the clock-gating cells are not flattened during any ungroup step. To flatten the clock gating cells, set the value to *true* before using the **ungroup** command or any other ungrouping steps listed above.

In normal usage, ungrouping the clock gates is not recommended. Ungrouping the clock gates before compile could have serious side effects. For example, ungrouped clock gates can not be mapped to integrated clock gating cells. Power Compiler commands like **report_clock_gating**, **remove_clock_gating** and **rewire_clock_gating** assumes that the clock gates have a hierarchy of its own. Also Physical Compiler placement of clock gates and registers may not be optimal when clock gating cells are flattened. Flattened clock gates are supported when using integrated clock gating cells, provided the flattening is done only after **compile**.

This variable is valid only with Design Compiler (dc_shell, dc_shell-t) and Physical Compiler (psyn_shell).

To determine the current value of this variable, type **printvar power_cg_flatten**. For a list of power variables and their current values, type **print_variable_group power**.

SEE ALSO

ungroup(2)
power_variables(3)

power_cg_gated_clock_net_naming_style

Specifies the naming style for gated clock nets created during **insert_clock_gating**.

TYPE

String

DEFAULT

" "

GROUP

power

DESCRIPTION

Determines the way gated clock nets are named.

This variable must be set before issuing **insert_clock_gating** command.

This variable can contain any string in addition to the different tokens listed below. The tokens are replaced by appropriate value during clock gating.

```
set power_cg_gated_clock_net_naming_style \  
    "prefix_%c_%n_%g_%d_suffix'
```

For all object names only simple (non-hierarchical) names are used.

If there is no occurrence of "%d" in the power_cg_gated_clock_net_naming_style, Power Compiler will assume a %d at the end.

Example :

```
dc_shell-t> set power_cg_gated_clock_net_naming_style "gated_%c_%d"
```

SEE ALSO

power_cg_module_naming_style(3)
power_cg_cell_naming_style(3)
power_cg_gated_clock_net_naming_style(3)

power_cg_ignore_setup_condition

When *true*, the setup condition will be ignored for latch-free clock gating.

TYPE

Boolean

DEFAULT

false

GROUP

power_variables

DESCRIPTION

For latch-free clock gate insertion with the **insert_clock_gating** command the setup condition must be met before a bank can be clock gated. This implies that the enable condition of the bank must be combinationaly dependent on nets that are known to be synchronous (i.e., belong to the same clock domain) with the registers of the bank that are being clock gated.

The setup condition can be ignored during latch-free clock gating. This is achieved by setting the variable **power_cg_ignore_setup_condition** to *true*. Note that this is generally not safe, since latch-free clock gating of a bank with an enable that is not synchronous to the registers of that bank can lead to undesired glitches on the clock net. In this case it is the responsibility of the designer to ensure that the result after clock gating is functionally correct.

To determine the current value of this variable, type **printvar power_cg_ignore_setup_condition**. For a list of power variables and their current values, type **print_variable_group power**.

SEE ALSO

power_variables(3)

power_cg_inherit_timing_exceptions

Specifies that during **compile -gate_clock** or **compile_ultra [-incr] -gate_clock**, timing exceptions defined on registers have to be automatically inferred on to the enable pin of the clock gate that is gating these registers.

TYPE

Boolean

DEFAULT

false

GROUP

power

DESCRIPTION

If this variable is set before **compile -gate_clock** or **compile_ultra -gate_clock**, then clock gate insertion tries to inherit the timing exceptions of the gated registers to clock gate enable pin. The following conditions apply.

Only cell level exceptions are inherited. This means all synchronous pins of a register should have the same set of timing exceptions before this can be inferred onto a clock gate.

If a set of registers with same enable condition has different timing exceptions among them, then this is split into smaller set of registers with homogeneous exceptions before clock gate insertion. This may create small banks that fall below the minimum bit width specified for clock gating and hence may remain ungated.

SEE ALSO

power_cg_module_naming_style

Specifies the naming style for clock gating modules created during **insert_clock_gating**.

TYPE

String

DEFAULT

" "

GROUP

power

DESCRIPTION

Determines the way clock gate modules (hierarchical designs created for clock gates during **insert_clock_gating**) are named.

This variable must be set before issuing **insert_clock_gating** command.

This variable can contain any string in addition to the different tokens listed below. The tokens are replaced by appropriate value during clock gating.

```
set power_cg_module_naming_style \  
    "prefix_%e_%l_midfix_%p_%t_%d_suffix"
```

where,

prefix/midfix/suffix are just examples of any constant strings that can be specified.

concatenated target_library names

If there is no occurrence of "%d" in the power_cg_module_naming_style, Power Compiler will assume a %d at the end.

Example :

```
dc_shell-t> set power_cg_module_naming_style "SNPS_CLOCK_GATE %e %p  
dc_shell-t> set power_cg_module_naming_style "clock_gate_module %e %t %d"
```

SEE ALSO

power_cg_cell_naming_style(3)

power_cg_gated_clock_net_naming_style(3)

power_cg_print_enable_conditions

When *true*, the enable conditions of registers and clock gates will be reported during clock gate insertion.

TYPE

Boolean

DEFAULT

false

GROUP

power_variables

DESCRIPTION

For debugging purposes and to achieve a general better understanding of the design structure and functionality it can be useful to print the enable conditions of clock gates and registers when performing automatic RTL clock gate insertion with the **insert_clock_gating** command.

The enable condition of a register or clock gate is a combinational function of nets in the design. As such, enable conditions can be represented by Boolean expressions of nets. The enable condition of a register represents the states for which a clock signal must be passed to the register. The enable condition of a clock gate corresponds to the states for which a clock will be passed to the registers in the fanout of the clock gate. Power Compiler utilizes the enable condition of the registers for clock gate insertion.

Reporting of the enable conditions during clock gating can be enabled by setting the variable **power_cg_print_enable_conditions** to *true* before issuing the **insert_clock_gating** command.

To determine the current value of this variable, type **printvar power_cg_print_enable_conditions**. For a list of power variables and their current values, type **print_variable_group power**.

SEE ALSO

power_cg_print_enable_conditions_max_terms(3)
power_variables(3)

power_cg_print_enable_conditions_max_terms

Specifies the maximum number of product terms to be reported in the sum of product expansion of the enable condition.

TYPE

Integer

DEFAULT

10

GROUP

power_variables

DESCRIPTION

For debugging purposes and to achieve a general better understanding of the design structure and functionality it can be useful to print the enable conditions of clock gates and registers when performing automatic RTL clock gate insertion with the **insert_clock_gating** command.

The enable conditions are reported as a sum of product expression. Since for complex expressions such a representation is known to grow very large, the maximum number of product terms is limited by the variable **power_cg_print_enable_conditions_max_terms**. By default at most 10 product terms are printed. If the actual number of product terms exceeds this limit, the enable condition is reported as "?? (too many product terms)". If necessary, the number of product terms to be shown can be increased by setting the variable **power_cg_print_enable_conditions_max_terms** to a larger value.

To determine the current value of this variable, type **printvar power_cg_print_enable_conditions_max_terms**. For a list of power variables and their current values, type **print_variable_group power**.

SEE ALSO

power_cg_print_enable_conditions(3)
power_variables(3)

power_cg_reconfig_stages

Controls the reconfiguration of multistage clock gates during **compile** [**-incremental_mapping**] **-gate_clock** or **compile_ultra** [**-incremental_mapping**] **-gate_clock**.

TYPE

Boolean

DEFAULT

false

GROUP

power_variables

DESCRIPTION

Multistage reconfiguration involves addition or reduction of stages of clock gates. You specify the maximum permissible number of stages of clock gates in the design using the **set_clock_gating_style -num_stages** command. A clock gate stage is added when a common enable condition can be factored out of many clock gates without violating the maximum stages specified. A clock gate stage is reduced if the design has more stages than what is specified.

These reconfigurations are performed during **compile_ultra -gate_clock** or **compile -gate_clock**, **only** if the variable **power_cg_reconfig_stages** is set to true. Also it is necessary to define clocks using **create_clock** command for each clock network where clock gates need to be reconfigured.

Only the tool inserted clock gates and integrated clock gating (ICG) cells can be reconfigured.

To determine the current value of this variable, type **printvar power_cg_reconfig_stages**.

SEE ALSO

power_cg_balance_stages(3)
power_variables(3)

power_default_static_probability

Specifies the default static probability value.

TYPE

Float

DEFAULT

0.5

GROUP

power_variables

DESCRIPTION

The variables:

`power_default_static_probability` `power_default_toggle_rate`
`power_default_toggle_rate_type`

are used to determine the switching activity of non-user annotated nets that are driven by primary inputs or black-box cells. For other unannotated nets, Power Compiler will propagate the switching activities of the driving cell inputs based on the cell functionality to derive the switching activity required for power calculations. This mechanism cannot be used for primary inputs and black-box outputs. Instead the following values are used for these type of nets:

- User annotated values are used, even when the net is partially annotated (for example, the static probability is annotated, but the toggle rate is not).
- In some cases, unannotated switching activity values may still be accurately derived, for example, if the net drives a buffer cell and the output of this cell is user annotated, then the user annotated values are used as the default values. Also, if the input is a clock then the clock period and waveform are used to derive the switching activity values.
- If the static probability is not annotated then the value of the **power_default_static_probability** variable is used for the static probability value.
- If the toggle rate is not annotated, then the default toggle rate value is derived from the **power_default_toggle_rate_type** and **power_default_toggle_rate** values. If the value of the **power_default_toggle_rate_type** variable is *fastest_clock* then the following is used for the toggle rate value:

`dtr * fclk`

where `fclk` is the frequency of the related clock if specified by the **set_switching_activity** command, or the frequency of the fastest clock in the design.

If the design has no clocks, then a value of 1.0 is used for `fclk`; and `dtr` is the value of the `power_default_toggle_rate` variable.

If the value of `power_default_toggle_rate_type` is *absolute*, then the value of the `power_default_toggle_rate` variable is used as the toggle rate.

The value of `power_default_static_probability` should be between 0.0 and 1.0, both inclusive. The value of `power_default_toggle_rate` should be greater or equal to 0.0. Also, if the value of `power_default_static_probability` is 0.0 or 1.0, then the value of `power_default_toggle_rate` should be 0.0. If the value of `power_default_toggle_rate` is 0.0, then the value of `power_default_static_probability` should be either 0.0 or 1.0.

The default value of `power_default_toggle_rate` variable is 0.1. The default value of `power_default_static_probability` variable is 0.5.

The value of `power_default_toggle_rate_type` can be either *fastest_clock* or *absolute*. The default value is *fastest_clock*.

SEE ALSO

```
set_switching_activity(2)
power_default_toggle_rate(3)
power_default_toggle_rate_type(3)
```

power_default_toggle_rate

Specifies the default toggle rate value.

TYPE

Float

DEFAULT

0.1

GROUP

power_variables

DESCRIPTION

The variables:

`power_default_static_probability` `power_default_toggle_rate`
`power_default_toggle_rate_type`

are used to determine the switching activity of non-user annotated nets that are driven by primary inputs or black-box cells. For other unannotated nets, Power Compiler will propagate the switching activities of the driving cell inputs based on the cell functionality to derive the switching activity required for power calculations. This mechanism cannot be used for primary inputs and black-box outputs. Instead the following values are used for these type of nets:

- User annotated values are used, even when the net is partially annotated (for example, the static probability is annotated, but the toggle rate is not).
- In some cases, unannotated switching activity values may still be accurately derived, for example, if the net drives a buffer cell and the output of this cell is user annotated, then the user annotated values are used as the default values. Also, if the input is a clock then the clock period and waveform are used to derive the switching activity values.
- If the static probability is not annotated then the value of the **power_default_static_probability** variable is used for the static probability value.
- If the toggle rate is not annotated, then the default toggle rate value is derived from the **power_default_toggle_rate_type** and **power_default_toggle_rate** values. If the value of the **power_default_toggle_rate_type** variable is *fastest_clock* then the following is used for the toggle rate value:

`dtr * fclk`

where `fclk` is the frequency of the related clock if specified by the **set_switching_activity** command, or the frequency of the fastest clock in the design.

If the design has no clocks, then a value of 1.0 is used for `fclk`; and `dtr` is the value of the `power_default_toggle_rate` variable.

If the value of `power_default_toggle_rate_type` is *absolute*, then the value of the `power_default_toggle_rate` variable is used as the toggle rate.

The value of `power_default_static_probability` should be between 0.0 and 1.0, both inclusive. The value of `power_default_toggle_rate` should be greater or equal to 0.0. Also, if the value of `power_default_static_probability` is 0.0 or 1.0, then the value of `power_default_toggle_rate` should be 0.0. If the value of `power_default_toggle_rate` is 0.0, then the value of `power_default_static_probability` should be either 0.0 or 1.0.

The default value of `power_default_toggle_rate` variable is 0.1. The default value of `power_default_static_probability` variable is 0.5.

The value of `power_default_toggle_rate_type` can be either *fastest_clock* or *absolute*. The default value is *fastest_clock*.

SEE ALSO

```
set_switching_activity(2)
power_default_static_probability(3)
power_default_toggle_rate_type(3)
```

power_default_toggle_rate_type

Specifies the default toggle rate type.

TYPE

String

DEFAULT

fastest_clock

GROUP

power_variables

DESCRIPTION

The variables:

`power_default_static_probability` `power_default_toggle_rate`
`power_default_toggle_rate_type`

are used to determine the switching activity of non-user annotated nets that are driven by primary inputs or black-box cells. For other unannotated nets, Power Compiler will propagate the switching activities of the driving cell inputs based on the cell functionality to derive the switching activity required for power calculations. This mechanism cannot be used for primary inputs and black-box outputs. Instead the following values are used for these type of nets:

- User annotated values are used, even when the net is partially annotated (for example, the static probability is annotated, but the toggle rate is not).
- In some cases, unannotated switching activity values may still be accurately derived, for example, if the net drives a buffer cell and the output of this cell is user annotated, then the user annotated values are used as the default values. Also, if the input is a clock then the clock period and waveform are used to derive the switching activity values.
- If the static probability is not annotated then the value of the **power_default_static_probability** variable is used for the static probability value.
- If the toggle rate is not annotated, then the default toggle rate value is derived from the **power_default_toggle_rate_type** and **power_default_toggle_rate** values. If the value of the **power_default_toggle_rate_type** variable is *fastest_clock* then the following is used for the toggle rate value:

`dtr * fclk`

where `fclk` is the frequency of the related clock if specified by the **set_switching_activity** command, or the frequency of the fastest clock in the design.

If the design has no clocks, then a value of 1.0 is used for `fclk`; and `dtr` is the value of the `power_default_toggle_rate` variable.

If the value of `power_default_toggle_rate_type` is *absolute*, then the value of the `power_default_toggle_rate` variable is used as the toggle rate.

The value of `power_default_static_probability` should be between 0.0 and 1.0, both inclusive. The value of `power_default_toggle_rate` should be greater or equal to 0.0. Also, if the value of `power_default_static_probability` is 0.0 or 1.0, then the value of `power_default_toggle_rate` should be 0.0. If the value of `power_default_toggle_rate` is 0.0, then the value of `power_default_static_probability` should be either 0.0 or 1.0.

The default value of `power_default_toggle_rate` variable is 0.1. The default value of `power_default_static_probability` variable is 0.5.

The value of `power_default_toggle_rate_type` can be either *fastest_clock* or *absolute*. The default value is *fastest_clock*.

SEE ALSO

```
set_switching_activity(2)
power_default_static_probability(3)
power_default_toggle_rate(3)
```

power_do_not_size_icg_cells

Controls whether compile does not size the integrated clock-gating cells in a design to correct DRC violations because doing so may result in lower area and power.

TYPE

Boolean

DEFAULT

false

GROUP

power_variables

DESCRIPTION

When this variable is set to **true**, **compile** does not size the integrated clock-gating cells in the design to correct DRC violations, because doing so may result in lower area and power when the integrated clock-gating cell is the last element in the clock tree and drives all gated registers.

The default is **true**.

If the clock tree synthesis (CTS) tool inserts buffers after the clock gating, the fanout of the integrated clock-gating cell is limited to the clock-tree buffers. While running **compile** before performing clock tree synthesis, this information is not available in the design. If you set **power_do_not_size_icg_cells** to **true**, **compile** ignores DRC violations for the integrated clock-gating cells, because the CTS tool would insert buffers at the output of the cell. Once your design netlist has CTS buffers, you can set this variable to **false** to enable **compile** to fix any DRC violation still existing for the integrated clock-gating cell.

This variable is valid only under `dc_shell` (Design Compiler).

To determine the current value of this variable, type **printvar power_do_not_size_icg_cells**. For a list of power variables and their current values, type **print_variable_group power**.

SEE ALSO

power_driven_clock_gating

Controls whether switching activity and dynamic power of the register banks should be considered when optimizing the clock gating of the design.

TYPE

Boolean

DEFAULT

false

GROUP

power_variables

DESCRIPTION

When the **-gate_clock** option is specified with **compile** or **compile_ultra**, clock gates are automatically inserted or removed during the optimization phase. By default this optimization is not based on the switching activity and dynamic power of the register banks.

In general, power-driven clock gating will yield better results at the expense of increased runtime. However, in some cases it may be best to not use the power-driven aspect of the optimization algorithm because the power calculation is expected not to be sufficiently accurate. This could be because either no realistic switching activity can be provided or because the target library does not have power characterization for all cells.

In the default case, when power-driven clock gating is switched off, clock gates will be inserted if the register bank size meets the minimum bit-width condition set by the **set_clock_gating_style** command. This is similar to the behavior of the **insert_clock_gating** command, except that clock gate insertion can be performed on a mapped netlist (i.e., gate-level clock gating).

To enable power-driven gate-level clock gating, set the variable **power_driven_clock_gating** to *true*.

To determine the current value of this variable, type **printvar power_driven_clock_gating**. For a list of power variables and their current values, type **print_variable_group power**.

SEE ALSO

power_variables(3)

power_enable_one_pass_power_gating

When *true*, one-pass flow power gating will be enabled.

TYPE

Boolean

DEFAULT

false

GROUP

power_variables

DESCRIPTION

When *true*, one-pass flow power gating will be enabled. One pass flow eliminates the need of compile incremental, and simplifies the user interface.

The default is *false*.

The following are examples of the original power gating flow and the one-pass flow.

- Original power gating flow:

```
set_power_gating_style -type CLK_FREE [get_cells lev1b_inst/*reg*]
set_power_gating_signal -power_pin_index 1 [get_pin lev1b_inst/retain]
set_power_gating_signal -power_pin_index 2 [get_pin lev1b_inst/shutdown]
set power_enable_power_gating true
compile
hookup_power_gating_ports
compile -incr
write -format verilog -hierarchy -output post_compile.v
```

- One-pass power gating flow:

```
set_power_gating_style -type CLK_FREE [get_cells lev1b_inst/*reg*]
set_power_gating_signal -power_pin_index 1 [get_pin lev1b_inst/retain]
set_power_gating_signal -power_pin_index 2 [get_pin lev1b_inst/shutdown]
set power_enable_one_pass_power_gating true
hookup_power_gating_ports -port_naming_style \
    {lev1a_inst/retain lev1a_inst/shutdown} \
    -default_port_naming_style power_pin_%d
compile
write -format verilog -hierarchy -output post_compile.v
```

SEE ALSO

`hookup_power_gating_ports(2)`
`set_power_gating_signal(2)`
`set_power_gating_style(2)`

power_enable_power_gating

When set to true **compile** will enable the power gating flow which allows the selected retention registers from target library to be used to map sequential elements.

TYPE

Boolean

DEFAULT

false

GROUP

power

DESCRIPTION

The **power_enable_power_gating** variable enables and disables power gating flow during the **compile** and **physopt** commands.

Retention registers are the registers which can save the values of the registers and restore it back later. Retention registers might have different styles. The cell level attribute *power_gating_cell* in target libraries are used to specify the styles. In order to only allow the retention registers with certain types used for the specified sequential elements during **compile**, the **power_enable_power_gating** variable needs to be set to *true*. The command requires a Power Compiler license during **compile**, otherwise Design Compiler will not be able to handle retention register correctly. If the variable is *true*, it will also prevent **compile** and **physopt** commands to swap the retention registers back to regular sequential elements.

SEE ALSO

power_fix_sdpd_annotation

Specifies whether user-annotated SDPD switching activity annotation is corrected before it is used.

TYPE

Boolean

DEFAULT

true

GROUP

power_variables

DESCRIPTION

This variable specifies whether Power Compiler will modify the user-annotated state-dependent and/or path-dependent (SDPD) switching activity to fix any inconsistencies before they are used. The accuracy of switching activity annotation, including the SDPD annotation, affects the accuracy of power calculation, and when this variable is set Power Compiler will check the SDPD annotation for inconsistencies. The SDPD annotation will be modified automatically to fix any inconsistencies found. In most cases, some inconsistencies are created during normal switching activity flows, and the SDPD fixing step modifies the SDPD annotation slightly to improve the power estimation accuracy. For example, during SAIF generation using a simulator, the total of rise and fall toggle on a pin may be different, if say, an odd number of toggles are captured. In this case, the SDPD fixing step scales the SDPD toggle rate annotations so that the rise and fall totals are the same. Setting this variable to false will disable the SDPD fixing step. Setting the variable **power_fix_sdpd_annotation_verbose** to true makes the SDPD fixing step issue verbose messages when user annotated switching activity is modified.

The following checks and modifications are performed during the SDPD fixing step:

- false states (states that always evaluate to 0, including the default state on cells whose other states cover all possible states) with non-zero state-dependent (SD) static probabilities have their static probability set to 0.0.
- Unannotated false states on cells with partially annotated SD static probabilities are automatically annotated with the 0.0.
- Cells with fully annotated SD static probabilities have their static probabilities scaled so that they add up to 1.0.
- Cells with partially annotated SD static probabilities that add up to more than 1.0 have their static probabilities scaled down so that they add up to 1.0. On such

cells, an SD static probability of 0.0 is set on the unannotated states.

- false states/arcs with non-zero state-dependent and/or path-dependent (SDPD) toggle rates have their toggle rate set to 0.0.
- Unannotated false states/arcs on pins with partially annotated SDPD toggle rates are automatically annotated with the 0.0.
- Pins with fully annotated SDPD toggle rates have their toggle rates scaled so that they add up to the non-SDPD toggle rate of the pin (that is, the non-SDPD toggle rate on the net connected to the pin).
- Pins with partially annotated SDPD toggle rates that add up to more than the pin toggle rate have their SDPD toggle rates scaled down so that they add up to the non-SDPD toggle rate. On such pin, an SDPD toggle rate of 0.0 is set on the unannotated states/arcs.
- Pins with partially annotated SDPD toggle rates have their toggle rates scaled so that the totals of rise and fall SDPD toggle rates are equal.
- The sum of the SDPD toggle rates on pins with fully annotated SDPD toggle rate information is annotated as the non-SDPD pin toggle rate (that is, the total toggle rate of the net connected to the pin) if this was not previously annotated.

SEE ALSO

`power_fix_sdpd_annotation_verbose(3)`
`power_sdpd_message_tolerance(3)`

power_fix_sdpd_annotation_verbose

Specifies whether verbose messages are reported during fixing of user-annotated SDPD switching activity.

TYPE

Boolean

DEFAULT

false

GROUP

power_variables

DESCRIPTION

If this variable is set to true, then an information or warning message is reported for every modification (exceeding a tolerance criteria) to the user-annotated SDPD switching activity performed by the SDPD fixing step. The SDPD fixing step is enabled by the **power_fix_sdpd_annotation** variable; please check the man page of **power_fix_sdpd_annotation** for more information on this step. When the **power_fix_sdpd_annotation_verbose** variable is set to false, such verbose message are not reported and a single message indicating that SDPD annotation is being modified is reported instead. Whether this variable is set to true or not, SDPD fixing messages are only reported if they exceed the tolerance criteria specified by the **power_sdpd_message_tolerance** variable.

SEE ALSO

power_fix_sdpd_annotation(3)
power_sdpd_message_tolerance(3)

power_hdlc_do_not_split_cg_cells

When *true*, **insert_clock_gating** does not split clock-gating cells to limit their fanout.

TYPE

Boolean

DEFAULT

false

GROUP

power_variables

DESCRIPTION

When *true*, **insert_clock_gating** does not split clock-gating cells to limit their fanout. When false (the default), **insert_clock_gating** splits clock-gating cells to limit their fanout. This activity is based on the value specified by the **set_clock_gating_style -max_fanout** command, whose default is unlimited. When *true*, **insert_clock_gating** does not split clock-gating cells, resulting in a netlist where all registers are gated by a single clock-gating cell if they share the same enable signal. And, if *true*, **insert_clock_gating** does not honor the value specified by **set_clock_gating_style -max_fanout**.

Set the variable to *true* if your clock-tree synthesis (CTS) tool inserts buffers after the clock-gating cell. In this case, the fanout of the clock-gating cell is limited to the buffers inserted by the CTS tool. This information is not available in the design while the **insert_clock_gating** command is performing RTL clock gating. If you set this variable to *true*, **insert_clock_gating** does not split the load of the clock-gating cells (by duplicating the cells) to save area and power.

This variable is valid under `dc_shell` (Design Compiler) and HDL Compiler.

To determine the current value of this variable, type **printvar power_hdlc_do_not_split_cg_cells**. For a list of power variables and their current values, type **print_variable_group power**.

SEE ALSO

power_keep_license_after_power_commands

Affects the amount of time a Power Compiler license is checked out during a `dc_shell` (Design Compiler) session.

TYPE

Boolean

DEFAULT

false

GROUP

power_variables

DESCRIPTION

This variable affects the amount of time a Power Compiler license is checked out during a `dc_shell` (Design Compiler) session.

When **true**, a Power Compiler license that is checked out under `dc_shell` remains checked out throughout the `dc_shell` session. When this variable is set to **false** (the default value), the Power Compiler license remains checked out only as long as a command is using it, and at the completion of the command, the license is released.

To determine the current value of this variable, type **printvar power_keep_license_after_power_commands**. For a list of power variables and their current values, type **print_variable_group power**.

SEE ALSO

`report_power(2)`

power_lib2saif_rise_fall_pd

Specifies whether lib2saif generates forward SAIF files with directives to generate rise/fall dependent path-dependent toggle counts.

TYPE

Boolean

DEFAULT

false

GROUP

power_variables

DESCRIPTION

When this variable is set to true the **lib2saif** command generates forward SAIF files with directives to generate separate rise and fall values for non-state-dependent path-dependent (PD) toggle counts. When this variable is set to false, directives to generate just the total (of the rise and fall) values for non-state-dependent PD toggle counts are generated. For more accurate power calculations, it is suggested to use separate rise and fall toggle counts, however older simulators and simulation interfaces may not recognize such directives and will fail to read the library forward SAIF file. The Synopsys SAIF generation PLI utility provided with Power Compiler X-2005.09 supports directives for separate rise and fall values for PD toggle rates, but older versions of the utility do not. The default value of this variable is currently false for backward compatibility, but will be changed to true in future releases.

Note that this variable affects only directives for path-dependent toggle counts that are not state-dependent. Whether this variable is set to true or false, directives for separate rise and fall values are generated for state-dependent and both state and path-dependent toggle counts.

SEE ALSO

lib2saif(2)

power_min_internal_power_threshold

Specifies the minimum cell internal power value that can be used in power calculations.

TYPE

string

DEFAULT

" "

GROUP

power_variables

DESCRIPTION

The value of this variable specifies the minimum threshold used for the cell internal power value. Internal power values are computed using the cell's switching activity and internal power characterization. If this variable has a numeric value and a cell's computed internal power is less than the variable's value, then the variable's value is used instead. Note that this variable has an effect only if it has a numeric value. The default value of this variable is " " which is non-numeric and therefore specifies that no minimum threshold is used on the cell internal power. In general, this variable should not be used since the internal power characterization specifies the correct internal power values.

power_model_preference

Specifies the preference between the CCS power and the NLPM models in library cells that have power specified in both models.

TYPE

string

DEFAULT

ccs

GROUP

power_variables

DESCRIPTION

A library can contain CCS power, NLPM or both types of data within a cell definition. Use this variable to specify the power model preference if the library contains both NLPM and CCS power data.

Allowed values are as follows:

ccs instructs Power Compiler to use CCS power data in the library (if present) to calculate both static and dynamic power. If CCS power data is not found, Power Compiler uses NLPM data.

nlpm (the default) instructs Power Compiler to use NLPM data. If NLPM data is not found, Power Compiler uses CCS power data.

If neither CCS power nor NLPM data is found for a cell in the library, this cell is not characterized for power analysis.

power_opto_extra_high_dynamic_power_effort

This variable makes the **compile** command invoke more dyanmic power optimization algorithms.

TYPE

Boolean

DEFAULT

false

GROUP

power

DESCRIPTION

Dynamic power optimization during **compile** can be invoked by **set_max_dynamic_power** or **set_max_total_power** command. This variable causes **compile** command to invoke extra dyanmic power optimization algorithms to further reduce the dynamic power. Since those algorithms are runtime intensive, they are not turned on by default. Be aware of the runtime overhead when using this variable.

The following example will cause the **compile -incr** to run extra algorithms for better dynamic power.

```
prompt> set power_opto_extra_high_dynamic_power_effort true
prompt> set_max_dynamic_power 0.0
prompt> compile -incr
```

SEE ALSO

set_max_dynamic_power(2)
set_max_total_power(2)

power_preserve_rtl_hier_names

Preserves the hierarchy information of the RTL objects in the RTL design.

TYPE

Boolean

DEFAULT

false

GROUP

power_variables

DESCRIPTION

When *true*, HDL Compiler preserves the hierarchy information of the RTL objects in the RTL design. The **rtl2saif** command, which generates RTL forward-annotation SAIF files, needs this information. When this variable is *false* (the default value), **rtl2saif** cannot extract the correct synthesis invariant objects because the hierarchy information is not preserved.

To determine the current value of this variable, type **printvar power_preserve_rtl_hier_names**. For a list of power variables and their current values, type **print_variable_group power**.

SEE ALSO

power_rclock_inputs_use_clocks_fanout

Specifies whether clock network objects in an input port fanout are used to infer the input port's related clock.

TYPE

Boolean

DEFAULT

true

GROUP

power_variables

DESCRIPTION

This variable is used during related clock inference to decide whether the inferred related clock on design port is chosen to be the fastest clock whose clock network objects are in the port's transitive fanout. For example, if this variable is set to **true**, then if the transitive fanout of an input port contains a number of cells, then the fastest clock on these flip-flop cells is chosen as the inferred related clock on the input port. If the variable is set to **false**, then the input port will not have an inferred related clock.

For more information on the mechanism used to infer related clock information, please refer to the man page of the **propagate_switching_activity** command.

SEE ALSO

propagate_switching_activity(2)
power_rclock_use_async_inputs(3)
power_rclock_unrelated_use_fastest(3)

power_rclock_unrelated_use_fastest

Specifies whether the fastest clock is set as the related clock of a design object when a related clock is not inferred by the related clock inference mechanism.

TYPE

Boolean

DEFAULT

true

GROUP

power_variables

DESCRIPTION

This variable is used during the last stage of related clock inference to decide whether the design objects that do not have an inferred related clock will be set a related clock or not. The user can use the **set_switching_activity** command with the argument **-clock ""** to specify that Power Compiler will automatically infer the related clocks for any specified objects. If the related clock inference mechanism did not infer a related clock for a number of such objects, then, when the value of the **power_rclock_unrelated_use_fastest** is true, Power Compiler will set the fastest design clock as the objects' related clock. When the variable is set to **false**, such objects will not have a related clock.

For more information on the mechanism used to infer related clock information, please refer to the man page of the **propagate_switching_activity** command.

SEE ALSO

propagate_switching_activity(2)
power_rclock_inputs_use_clocks_fanout(3)
power_rclock_use_async_inputs(3)

power_rclock_use_asynch_inputs

Specifies whether the inferred related clock on an asynchronous pin of a flip-flop is used to determine the inferred related clock on the cell's outputs.

TYPE

Boolean

DEFAULT

false

GROUP

power_variables

DESCRIPTION

This variable is used during related clock inference to decide whether the inferred related clock a flip-flop cell output considers the inferred related clocks on the cell's asynchronous inputs. When this variable is set to **false**, then the inferred related clock on a flip-flop cell output is the inferred related clock on the cell's clock pin. When this variable is set to **true**, then the inferred related clock on a flip-flop cell output is the fastest inferred clock on the cell's clock pin and asynchronous input pins.

For more information on the mechanism used to infer related clock information, please refer to the man page of the **propagate_switching_activity** command.

SEE ALSO

propagate_switching_activity(2)
power_rclock_inputs_use_clocks_fanout(3)
power_rclock_use_asynch_inputs(3)

power_remove_redundant_clock_gates

Specifies to the **compile -incremental** and **physopt -incremental** commands whether to **remove redundant Synopsys clock gating cells**.

TYPE

Boolean

DEFAULT

true

GROUP

power_variables

DESCRIPTION

Specifies whether to remove redundant Synopsys clock gating cells during incremental compile. A clock gate is considered redundant when it is always enabled. This is the case when the enable net is tied to logic one. If this variable is set to *true* (the default value), the redundant clock-gating cells are removed during incremental compile. To disable automatic removal of redundant clock gating cells, set the value to *false* before issuing the **compile** or **physopt** commands.

This variable is valid only with Design Compiler (dc_shell, dc_shell-t) and Physical Compiler (psyn_shell).

To determine the current value of this variable, type **printvar power_remove_redundant_clock_gates**. For a list of power variables and their current values, type **print_variable_group power**.

SEE ALSO

power_variables(3)

power_rtl_saif_file

Defines for the **rtl2saif** command where to store the forward-annotation SAIF file, if you do not specify the **-output** option.

TYPE

Boolean

DEFAULT

`power_rtl.saif`

GROUP

`power_variables`

DESCRIPTION

Defines for the **rtl2saif** command where to store the forward-annotation SAIF file, if you do not specify the **-output** option. The default for this variable is `power_rtl.saif`.

This variable is valid only under `dc_shell` (Design Compiler).

To determine the current value of this variable, type **printvar power_rtl_saif_file**. For a list of power variables and their current values, type **print_variable_group power**.

SEE ALSO

power_sa_propagation_effort

Specifies the default effort level used when propagating switching activity.

TYPE

string

DEFAULT

low

GROUP

power_variables

DESCRIPTION

Power calculations need switching activity information on all design nets, and Power Compiler uses a switching activity propagation mechanism to estimate the activity on the nets that are not annotated by the user. This variable specifies the default effort level used by the switching activity propagation mechanism.

The following Power Compiler commands may use the propagation mechanism:

report_power, synthesis commands like **compile** when used with power constraints, and **write_saif** when specified with the **-propagated** option. The **propagate_switching_activity** command can be used to force a re-propagation of the switching activity.

The **-analysis_effort** argument of the **report_power** command, and the **-effort** argument of the **propagate_switching_activity** command, specify the effort level used by the switching activity propagation mechanism. When these options are not specified, the value of the **power_sa_propagation_effort** variable is used.

The **power_sa_propagation_effort** variable can have the following values: **low**, **medium**, **high**.

SEE ALSO

`propagate_switching_activity(2)`
`power_sa_propagation_verbose(3)`

power_sa_propagation_verbose

Specifies the default verbose mode used when propagating switching activity.

TYPE

Boolean

DEFAULT

false

GROUP

power_variables

DESCRIPTION

Power calculations need switching activity information on all design nets, and Power Compiler uses a switching activity propagation mechanism to estimate the activity on the nets that are not annotated by the user. This variable specifies the default verbose level used when propagating switching activity. During verbose mode, the propagation mechanism displays more warning and information messages.

The following Power Compiler commands may use the propagation mechanism: **report_power**, synthesis commands like **compile** when used with power constraints, and **write_saif** when specified with the **-propagated** option. The **propagate_switching_activity** command can be used to force a re-propagation of the switching activity.

The **-verbose** flag of the **propagate_switching_activity** command can be used to propagate the switching activity in verbose mode.

SEE ALSO

`propagate_switching_activity(2)`
`power_sa_propagation_effort(3)`

power_same_switching_activity_on_connected_objects

Forces the tool to use the last user-annotated switching activity data on all connected tool objects.

TYPE

Boolean

DEFAULT

false

GROUP

power_variables

DESCRIPTION

The **power_same_switching_activity_on_connected_objects** variable forces all switching activity data of all connected tool objects to use the latest user-annotated switching activity data. The user-annotated switching activity information can come from the **read_saif** command or the **set_switching_activity** command. Power reporting commands may produce different power results, since the switching activity data may be changed.

The **power_same_switching_activity_on_connected_objects** variable is off (false) by default.

SEE ALSO

read_saif(2)
set_switching_activity(2)

power_sdpg_message_tolerance

Specifies the tolerance value for issuing warnings and information messages during fixing of user-annotated SDPD switching activity.

TYPE

Float

DEFAULT

0.00001

GROUP

power_variables

DESCRIPTION

This variable specifies a tolerance value that is used when messages are reported during the SDPD fixing step. The SDPD fixing step is enabled by the **power_fix_sdpg_annotation** variable; please check the man page of **power_fix_sdpg_annotation** for more information on this step. Messages reported by the SDPD fixing step need to specify the tolerance criteria specified by this variable. For example, SDPD fixing scales state-dependent static probabilities so that they add up to 1.0. A message is reported by the SDPD fixing step if the difference between the sum of the state-dependent static probabilities and 1.0 is not within the tolerance value. A tolerance value of 0.0 makes the SDPD fixing step report a message for every check/modification to the SDPD annotation, however this will most likely report non-issues due to floating point errors. A high value of the **power_sdpg_message_tolerance** value will filter out all but the most significant messages. Also note, that the verbosity of the SDPD fixing step is determined by the **power_fix_sdpg_annotation_verbose** variable. When **power_fix_sdpg_annotation_verbose** is set to false most of the messages reported by the SDPD fixing step are replaced by a single message indicating that user-annotated SDPD switching activity is being corrected.

SEE ALSO

power_fix_sdpg_annotation(3)
power_fix_sdpg_annotation_verbose(3)

power_sdpd_saif_file

Defines for the **lib2saif** command where to store the forward-annotation SAIF file, if you do not specify the **-output** option.

TYPE

Boolean

DEFAULT

power_sdpd.saif

GROUP

power_variables

DESCRIPTION

Defines for the **lib2saif** command where to store the forward-annotation SAIF file, if you do not specify the **-output** option. The default for this variable is *power_sdpd.saif*.

This variable is valid only under **dc_shell** (Design Compiler).

To determine the current value of this variable, type **printvar power_sdpd_saif_file**. For a list of power variables and their current values, type **print_variable_group power**.

SEE ALSO

lib2saif(2)

power_variables

Variables that affect Power Compiler commands.

SYNTAX

```
float    power_default_static_probability = "0.5"
float    power_default_toggle_rate = "0.1"
Boolean  power_do_not_size_icg_cells = "false"
Boolean  power_hdlc_do_not_split_cg_cells = "false"
Boolean  power_keep_license_after_power_commands = "true"
Boolean  power_preserve_rtl_hier_names = "false"
string   power_rtl_saif_file = "power_rtl.saif"
string   power_sa_propagation_effort = "low"
Boolean  power_sa_propagation_verbose = "false"
string   power_sdpd_saif_file = "power_sdpd.saif"
Boolean  power_remove_redundant_clock_gates = "true"
Boolean  power_driven_clock_gating = "false"
Boolean  power_cg_all_registers = "false"

Boolean  power_cg_derive_related_clock = "false"
Boolean  power_cg_ignore_setup_condition = "false"
Boolean  power_cg_print_enable_conditions = "false"
int      power_cg_print_enable_conditions_max_terms = "10"
Boolean  do_operand_isolation = "true"
Boolean  power_cg_enable_alternative_algorithm = "false"
```

DESCRIPTION

These variables directly affect the Power Compiler commands. Default values are shown above in the Syntax section.

For a list of **power** variables and their current values, type **print_variable_group power**. To view this manual page online, type **man power_variables**. To view an individual variable description, type **man var**, where *var* is the name of the variable.

power_default_static_probability

The static probability value on unannotated primary input nets and black box outputs used during power calculations. The value of this variable must be between 0.0 and 1.0, otherwise it will be ignored and the default value of 0.5 is used.

power_default_toggle_rate

This variable specifies the toggle rate value used for unannotated nets driven by primary inputs and black box outputs. For such nets, power calculations assume a toggle rate value derived by multiplying the value of **power_default_toggle_rate** with the frequency of the fastest clock in the design. The value of this variable must be a non-negative number, otherwise the default value of 0.1 is used.

power_do_not_size_icg_cells

When *false* (the default), the **compile** command sizes integrated clock-gating

cells in the design to correct DRC violations. When *true*, **compile** does not size the cells. Set this variable to *true* if your clock tree synthesis (CTS) tool inserts buffers after the integrated cell, and you do not want to fix DRC violations before the CTS buffers are inserted.

`power_hdlc_do_not_split_cg_cells`

When *false* (the default), **elaborate** splits clock-gating cells to limit their fanout, controlled by the value specified by the **set_clock_gating_style -max_fanout** command, whose default is 128. If *true*, **elaborate** does not split clock-gating cells, resulting in a netlist where all registers are gated by a single clock-gating cell if they share the same enable signal. **elaborate** does not honor the **set_clock_gating_style -max_fanout** value specified. Set this variable to *true* if your clock tree synthesis (CTS) tool inserts buffers after the clock-gating cell, and you do not want **elaborate** to limit the fanout of the clock-gating cell.

`power_keep_license_after_power_commands`

When *true*, a Power Compiler license that is checked out under **dc_shell** (DesignCompiler) will remain checked out throughout the **dc_shell** session. When this variable is *false* (the default value), the Power Compiler license will remain checked out only as long as a command is using it. At the completion of the command, the license will be released.

`power_preserve_rtl_hier_names`

When *true*, HDL compiler will preserve the hierarchy information of the RTL objects in the RTL design. The information is needed by *rtl2saif* which generates RTL forward annotation SAIF files. When this variable is *false* (the default value), *rtl2saif* will not be able to extract the correct synthesis invariant objects since the hierarchy information is not preserved.

`power_rtl_saif_file`

This is the name of the file where *rtl2saif* will store the forward annotation saif if the **-output** option is not specified for this command.

`power_sa_propagation_effort`

The default effort level used during switching activity propagation. Valid values are: *low* (the default), *medium* and *high*.

`power_sa_propagation_verbose`

The default verbose level used during switching activity propagation. During verbose mode the switching activity propagation mechanism displays more warning messages, for example, when the design contains primary input nets and black-box outputs without switching activity annotation.

`power_sdpd_saif_file`

This is the name of the file where *lib2saif* will store the forward annotation saif if the **-output** option is not specified for this command.

`power_remove_redundant_clock_gates`

When *true*, redundant Synopsys clock gating cells will be automatically removed during incremental compile.

`power_driven_clock_gating`

Controls whether switching activity and dynamic power of the register banks should be considered when optimizing the clock gating of the design.

`power_cg_all_registers`

When *true*, a (potentially redundant) clock gate will be inserted for all registers.

`power_cg_derive_related_clock`

When *true*, clock domain relationship between registers will be derived from the hierarchical context.

`power_cg_ignore_setup_condition`

When *true*, the setup condition will be ignored for latch-free clock gating.

`power_cg_print_enable_conditions`

When *true*, the enable conditions of registers and clock gates will be reported during clock gate insertion.

`power_cg_print_enable_conditions_max_terms`

Specifies the maximum number of product terms to be reported in the sum of product expansion of the enable condition.

`power_cg_enable_alternative_algorithm`

When *true*, an algorithm different from the default algorithm will be used to find gatable registers. For larger designs it may shorten the runtime for clock gating.

`do_operand_isolation`

When *true*, enables operand isolation as a dynamic power optimization technique for a design.

SEE ALSO

`report_power` (2), `lib2saif` (2), `rtl2saif` (2), `set_clock_gating_style` (2),
`insert_clock_gating` (2), `elaborate` (2), `compile` (2);
`power_default_static_probability` (3), `power_default_toggle_rate` (3),
`power_do_not_size_icg_cells` (3), `power_hdlc_do_not_split_cg_cells` (3),
`power_keep_license_after_power_commands` (3), `power_rtl_saif_file` (3),
`power_sa_propagation_effort` (3), `power_sa_propagation_verbos` (3),
`power_sdpd_saif_file` (3), `power_remove_redundant_clock_gates` (3),
`power_cg_enable_alternative_algorithm` (3), `do_operand_isolation` (3).

preview_scan_variables

SYNTAX

```
Boolean test_jump_over_bufs_invs = "1"  
string test_preview_scan_shows_cell_types = "FALSE"  
string test_scan_link_so_lockup_key = "1"  
string test_scan_link_wire_key = "w"  
string test_scan_segment_key = "s"  
string test_scan_true_key = "t"
```

DESCRIPTION

These variables directly affect the **preview_scan** command. Defaults are shown above, under Syntax.

For a list of **preview_scan** variables, type **print_variable_group preview_scan**. To view this manual page on-line, type **help preview_scan_variables**. To view an individual variable description, type **help variable-name**, where *variable-name* is the name of the variable.

test_jump_over_bufs_invs

Determines whether the internal clock detection mechanism considers the output pins of buffers and inverters as internal clocks. The default is *true*.

test_preview_scan_shows_cell_types

Specifies whether **preview_scan** shows cell types.

test_scan_link_so_lockup_key

Specifies the key **preview_scan** uses to report cells whose scan-outs drive lockup latches.

test_scan_link_wire_key

Specifies the key **preview_scan** uses to report cells whose scan-outs drive wire scan links.

test_scan_segment_key

Specifies the key **preview_scan** uses to report scan segments.

test_scan_true_key

Specifies the key **preview_scan** uses to report cells with true scan attributes.

SEE ALSO

preview_scan (2), **test_jump_over_bufs_invs** (3), **test_preview_scan_shows_cell_types** (3), **test_scan_link_so_lockup_key** (3), **test_scan_link_wire_key** (3), **test_scan_segment_key** (3), **test_scan_true_key** (3).

psyn_onroute_disable_cap_drc

This variable turns on and off the max_cap fixing optimization during route_opt DRC fixing

TYPE

Boolean

DEFAULT

" "

GROUP

routeopt_variables

DESCRIPTION

If set to true, this variable disables fixing max capacitance violation during route_opt DRC fixing

SEE ALSO

route_opt(2)

psyn_onroute_disable_fanout_drc

This variable turns on and off the max_fanout optimization during route_opt DRC fixing

TYPE

Boolean

DEFAULT

" "

GROUP

routeopt_variables

DESCRIPTION

If set to true, this variable disables max_fanout optimization during route_opt DRC fixing

SEE ALSO

route_opt(2)

psyn_onroute_disable_hold_fix

This variable turns on and off the hold fixing optimization during route_opt.

TYPE

Boolean

DEFAULT

" "

GROUP

routeopt_variables

DESCRIPTION

If set to true, this variable disables hold_fixing optimization during route_opt and hold fixing will not be performed during post-route optimization.

SEE ALSO

route_opt(2)

psyn_onroute_disable_netlength_drc

This variable turns on and off the max_net_length_fixing optimization during route_opt DRC fixing

TYPE

Boolean

DEFAULT

" "

GROUP

routeopt_variables

DESCRIPTION

If set to true, this variable disables fixing max_net_length violation during route_opt DRC fixing. Then, the tool will not add buffers to reduce net length even if the physical net length is more than constraints.

SEE ALSO

route_opt(2)

psyn_onroute_disable_trans_drc

This variable turns on and off the max transition fixing during route_opt DRC fixing

TYPE

Boolean

DEFAULT

" "

GROUP

routeopt_variables

DESCRIPTION

If set to true, this variable disables fixing max transition violation during route_opt DRC fixing

SEE ALSO

route_opt(2)

psyn_stress_map

Enables generation of stress map. Set this variable to true to generate stress maps from Physical Compiler.

TYPE

Boolean

DEFAULT

false

GROUP

physopt

DESCRIPTION

Enables generation of stress map. The stress map shows how intensively the optimization (timing, DRC, power and others) methods were applied on the current design. Set this variable to true to generate stress maps from Physical Compiler. The default value is false. It must be set to true before the physopt command to generate stress maps.

To determine the current value of this variable, enter the following command:

```
psyn_shell-t> printvar psyn_stress_map
```

psynopt_high_fanout_legality_limit

The maximum high fanout threshold for performing optimization tricks before `route_opt`. This limit value also turns the feature off by setting it to 0.

TYPE

Integer

DEFAULT

0

GROUP

`psynopt_variables`

DESCRIPTION

It sets the high fanout limit for optimization tricks to be performed. If the fanout number resulted from performing the current optimization trick is greater than this limit, the trick will not be performed. This feature aids in improvement of `route_opt` performance by reducing high fanout nets. The benefit could be seen in runtime and general QoR. Setting this limit to 0 turns off this feature and optimization tricks will be performed regardless of the resulting fanout number. Please note that this variable does not impact the high fanout synthesis but controls the final fanout of nets. Also, it does not eliminate high fanout nets that existed before optimization stage.

SEE ALSO

`place_opt(2)`

rc_degrade_min_slew_when_rd_less_than_rnet

Enables or disables the use of slew degradation in min analysis mode during the RCCALC-009 condition.

TYPE

Boolean

DEFAULT

false

DESCRIPTION

When *false*, (the default), slew degradation through RC networks is not used in min analysis mode during the RCCALC-009 condition. When *true*, slew degradation is used during the RCCALC-009 condition.

The "RCCALC-009 condition" means a condition in which timing analysis checks the library-derived drive resistance, and if it is less than the dynamic RC network impedance to ground by an amount equal to or greater than the value of a particular drive-strength threshold, timing analysis adjusts the drive resistance using an empirical formula to improve accuracy, and issues the RCCALC-009 message. In case this improved accuracy is not sufficient, timing analysis provides extra pessimism by not using slew degradation in min analysis mode; however, superfluous min delay violations could occur as a side effect. You can keep slew degradation on in min analysis mode after you have qualified the RCCALC-009 methodology for your accuracy requirements, by setting this variable to *true*.

To determine the current value of this variable, type **printvar rc_degrade_min_slew_when_rd_less_than_rnet** or **echo \$rc_degrade_min_slew_when_rd_less_than_rnet**.

SEE ALSO

rc_driver_model_mode

Specifies which driver model type to use for RC delay calculation.

TYPE

String

DEFAULT

basic

GROUP

timing_variables

DESCRIPTION

DesignTime supports two types of driver models for RC delay calculation, basic and advanced. The basic model is derived from the conventional delay and slew library schema, while the advanced model is derived from a new schema. The advanced driver model is part of the Synopsys Composite Current-Source (CCS) model.

When the shell variable `rc_driver_model_mode` is set to basic, RC delay calculation will always use driver models derived from the conventional delay and slew schema present in design libraries. When set to advanced, RC delay calculation will use the advanced driver model if data for it is present. The `report_delay_calculation` command used on a cell arc will show the message "Advanced driver-modeling used" as appropriate.

When the shell variable `rc_driver_model_mode` is set to basic, and the variable `rc_receiver_model_mode` is set to advanced, DesignTime will use the advanced voltage-dependent capacitance models to derive an equivalent single capacitance dependent only on the rise, fall, min or max arc condition and these equivalent capacitances will be used in analysis instead of the pin capacitances from the library. Please check the manpage for variable `rc_receiver_model_mode` for additional details.

To determine the current value of this variable, enter the following command:

```
prompt> printvar rc_driver_model_mode
```

SEE ALSO

`rc_receiver_model_mode(3)`
`report_delay_calculation(2)`

rc_input_threshold_pct_fall

Specifies the threshold voltage that defines the startpoint of the falling cell or net delay calculation.

TYPE

float

DEFAULT

50.000000

GROUP

timing_variables

DESCRIPTION

Specifies the threshold voltage that defines the startpoint of the falling cell or net delay calculation. The value is a percent of the voltage source. Allowed values are 0.0 - 100.0 inclusive; the default is 50.0.

This variable is one of 8 variables, listed in Table 1, that affect delay and transition time computations for detailed RC networks. These variables interpret the cell delays and transition times from the Synopsys library. The values specified by these variables are overridden by trippoint values specified in the library so normally it should not be necessary to set the variables. The values specified are only applied to libraries that do not contain trippoint specifications.

Table 1

Variable Name	Default
rc_slew_lower_threshold_pct_rise	20.0
rc_slew_lower_threshold_pct_fall	20.0
rc_slew_upper_threshold_pct_rise	80.0
rc_slew_upper_threshold_pct_fall	80.0
rc_input_threshold_pct_rise	50.0
rc_input_threshold_pct_fall	50.0
rc_output_threshold_pct_rise	50.0
rc_output_threshold_pct_fall	50.0

The default values specify that a cell delay is defined from 50% of the voltage value for the input transition to 50% of the voltage value for the output transition. The default values also specify that a transition time, or slew, is defined from 20% to 80% of the voltage.

To determine the current value of this variable, type **printvar rc_input_threshold_pct_fall**.

For a list of all timing variables and their current values, type **print_variable_group timing**.

EXAMPLES

The following example specifies that cell delays from the Synopsys library are computed from 50% of the input transition to 55% of the output transition. In addition, the example specifies that transition times in the Synopsys library represent the delay from 10% to 90% of the voltage source.

```
psyn_shell-t> set rc_slew_lower_threshold_pct_fall 10 psyn_shell-t> set
rc_slew_lower_threshold_pct_rise 10 psyn_shell-t> set
rc_slew_upper_threshold_pct_fall 90 psyn_shell-t> set
rc_slew_upper_threshold_pct_rise 90 psyn_shell-t> set rc_input_threshold_pct_rise 50
psyn_shell-t> set rc_input_threshold_pct_fall 50 psyn_shell-t> set
rc_output_threshold_pct_rise 55 psyn_shell-t> set rc_output_threshold_pct_fall 55
```

SEE ALSO

```
rc_input_threshold_pct_rise(3)
rc_input_threshold_pct_fall(3)
rc_output_threshold_pct_fall(3)
rc_output_threshold_pct_rise(3)
rc_slew_lower_threshold_pct_fall(3)
rc_slew_lower_threshold_pct_rise(3)
rc_slew_upper_threshold_pct_fall(3)
rc_slew_upper_threshold_pct_rise(3)
lib_thresholds_per_lib(3)
```

rc_input_threshold_pct_rise

Specifies the threshold voltage that defines the startpoint of the rising cell or net delay calculation.

TYPE

float

DEFAULT

50.000000

GROUP

timing_variables

DESCRIPTION

Specifies the threshold voltage that defines the startpoint of the rising cell or net delay calculation. The value is a percent of the voltage source. Allowed values are 0.0 - 100.0 inclusive; the default is 50.0.

This variable is one of 8 variables, listed in Table 1, that affect delay and transition time computations for detailed RC networks. These variables interpret the cell delays and transition times from the Synopsys library. The values specified by these variables are overridden by trippoint values specified in the library so normally it should not be necessary to set the variables. The values specified are only applied to libraries that do not contain trippoint specifications.

Table 1

Variable Name	Default
rc_slew_lower_threshold_pct_rise	20.0
rc_slew_lower_threshold_pct_fall	20.0
rc_slew_upper_threshold_pct_rise	80.0
rc_slew_upper_threshold_pct_fall	80.0
rc_input_threshold_pct_rise	50.0
rc_input_threshold_pct_fall	50.0
rc_output_threshold_pct_rise	50.0
rc_output_threshold_pct_fall	50.0

The default values specify that a cell delay is defined from 50% of the voltage value for the input transition to 50% of the voltage value for the output transition. The default values also specify that a transition time, or slew, is defined from 20% to 80% of the voltage.

To determine the current value of this variable, type **printvar rc_input_threshold_pct_rise**.

For a list of all timing variables and their current values, type **print_variable_group timing**.

EXAMPLES

The following example specifies that cell delays from the Synopsys library are computed from 50% of the input transition to 55% of the output transition. In addition, the example specifies that transition times in the Synopsys library represent the delay from 10% to 90% of the voltage source.

```
psyn_shell-t> set rc_slew_lower_threshold_pct_fall 10 psyn_shell-t> set
rc_slew_lower_threshold_pct_rise 10 psyn_shell-t> set
rc_slew_upper_threshold_pct_fall 90 psyn_shell-t> set
rc_slew_upper_threshold_pct_rise 90 psyn_shell-t> set rc_input_threshold_pct_rise 50
psyn_shell-t> set rc_input_threshold_pct_fall 50 psyn_shell-t> set
rc_output_threshold_pct_rise 55 psyn_shell-t> set rc_output_threshold_pct_fall 55
```

SEE ALSO

```
rc_input_threshold_pct_rise(3)
rc_input_threshold_pct_fall(3)
rc_output_threshold_pct_fall(3)
rc_output_threshold_pct_rise(3)
rc_slew_lower_threshold_pct_fall(3)
rc_slew_lower_threshold_pct_rise(3)
rc_slew_upper_threshold_pct_fall(3)
rc_slew_upper_threshold_pct_rise(3)
lib_thresholds_per_lib(3)
```


rc_noise_model_mode

When set to **advanced**, enables the use of CCS noise, if available in the design library.

TYPE

string

DEFAULT

basic

GROUP

signal integrity

DESCRIPTION

When set to **advanced**, enables CCS noise in static noise analysis and optimization.

When basic (the default), CCS noise information is not used even if it exists in the library. However, if the library has NLDM noise information, it is still used.

To determine the current value of this variable, use **printvar rc_noise_model_mode**.

SEE ALSO

rc_output_threshold_pct_fall

Specifies the threshold voltage that defines the startpoint of the falling cell or net delay calculation.

TYPE

float

DEFAULT

50.000000

GROUP

timing_variables

DESCRIPTION

Specifies the threshold voltage that defines the startpoint of the falling cell or net delay calculation. The value is a percent of the voltage source. Allowed values are 0.0 - 100.0 inclusive; the default is 50.0.

This variable is one of 8 variables, listed in Table 1, that affect delay and transition time computations for detailed RC networks. These variables interpret the cell delays and transition times from the Synopsys library. The values specified by these variables are overridden by trippoint values specified in the library so normally it should not be necessary to set the variables. The values specified are only applied to libraries that do not contain trippoint specifications.

Table 1

Variable Name	Default
rc_slew_lower_threshold_pct_rise	20.0
rc_slew_lower_threshold_pct_fall	20.0
rc_slew_upper_threshold_pct_rise	80.0
rc_slew_upper_threshold_pct_fall	80.0
rc_input_threshold_pct_rise	50.0
rc_input_threshold_pct_fall	50.0
rc_output_threshold_pct_rise	50.0
rc_output_threshold_pct_fall	50.0

The default values specify that a cell delay is defined from 50% of the voltage value for the input transition to 50% of the voltage value for the output transition. The default values also specify that a transition time, or slew, is defined from 20% to 80% of the voltage.

To determine the current value of this variable, type **printvar rc_output_threshold_pct_fall**.

For a list of all timing variables and their current values, type **print_variable_group timing**.

EXAMPLES

The following example specifies that cell delays from the Synopsys library are computed from 50% of the input transition to 55% of the output transition. In addition, the example specifies that transition times in the Synopsys library represent the delay from 10% to 90% of the voltage source.

```
psyn_shell-t> set rc_slew_lower_threshold_pct_fall 10 psyn_shell-t> set
rc_slew_lower_threshold_pct_rise 10 psyn_shell-t> set
rc_slew_upper_threshold_pct_fall 90 psyn_shell-t> set
rc_slew_upper_threshold_pct_rise 90 psyn_shell-t> set rc_input_threshold_pct_rise 50
psyn_shell-t> set rc_input_threshold_pct_fall 50 psyn_shell-t> set
rc_output_threshold_pct_rise 55 psyn_shell-t> set rc_output_threshold_pct_fall 55
```

SEE ALSO

```
rc_input_threshold_pct_rise(3)
rc_input_threshold_pct_fall(3)
rc_output_threshold_pct_fall(3)
rc_output_threshold_pct_rise(3)
rc_slew_lower_threshold_pct_fall(3)
rc_slew_lower_threshold_pct_rise(3)
rc_slew_upper_threshold_pct_fall(3)
rc_slew_upper_threshold_pct_rise(3)
lib_thresholds_per_lib(3)
```

rc_output_threshold_pct_rise

Specifies the threshold voltage that defines the startpoint of the rising cell or net delay calculation.

TYPE

float

DEFAULT

50.000000

GROUP

timing_variables

DESCRIPTION

Specifies the threshold voltage that defines the startpoint of the rising cell or net delay calculation. The value is a percent of the voltage source. Allowed values are 0.0 - 100.0 inclusive; the default is 50.0.

This variable is one of 8 variables, listed in Table 1, that affect delay and transition time computations for detailed RC networks. These variables interpret the cell delays and transition times from the Synopsys library. The values specified by these variables are overridden by trippoint values specified in the library so normally it should not be necessary to set the variables. The values specified are only applied to libraries that do not contain trippoint specifications.

Table 1

Variable Name	Default
rc_slew_lower_threshold_pct_rise	20.0
rc_slew_lower_threshold_pct_fall	20.0
rc_slew_upper_threshold_pct_rise	80.0
rc_slew_upper_threshold_pct_fall	80.0
rc_input_threshold_pct_rise	50.0
rc_input_threshold_pct_fall	50.0
rc_output_threshold_pct_rise	50.0
rc_output_threshold_pct_fall	50.0

The default values specify that a cell delay is defined from 50% of the voltage value for the input transition to 50% of the voltage value for the output transition. The default values also specify that a transition time, or slew, is defined from 20% to 80% of the voltage.

rc_output_threshold_pct_rise

To determine the current value of this variable, type **printvar rc_output_threshold_pct_rise**.

For a list of all timing variables and their current values, type **print_variable_group timing**.

EXAMPLES

The following example specifies that cell delays from the Synopsys library are computed from 50% of the input transition to 55% of the output transition. In addition, the example specifies that transition times in the Synopsys library represent the delay from 10% to 90% of the voltage source.

```
psyn_shell-t> set rc_slew_lower_threshold_pct_fall 10 psyn_shell-t> set
rc_slew_lower_threshold_pct_rise 10 psyn_shell-t> set
rc_slew_upper_threshold_pct_fall 90 psyn_shell-t> set
rc_slew_upper_threshold_pct_rise 90 psyn_shell-t> set rc_input_threshold_pct_rise 50
psyn_shell-t> set rc_input_threshold_pct_fall 50 psyn_shell-t> set
rc_output_threshold_pct_rise 55 psyn_shell-t> set rc_output_threshold_pct_fall 55
```

SEE ALSO

```
rc_input_threshold_pct_rise(3)
rc_input_threshold_pct_fall(3)
rc_output_threshold_pct_fall(3)
rc_output_threshold_pct_rise(3)
rc_slew_lower_threshold_pct_fall(3)
rc_slew_lower_threshold_pct_rise(3)
rc_slew_upper_threshold_pct_fall(3)
rc_slew_upper_threshold_pct_rise(3)
lib_thresholds_per_lib(3)
```

rc_receiver_model_mode

Specifies which receiver model type to use for RC delay calculation.

TYPE

String

DEFAULT

basic

GROUP

timing_variables

DESCRIPTION

DesignTime supports two types of receiver models for RC delay calculation, basic and advanced. The basic model is a single capacitance dependent only on the rise, fall, min, or max arc condition. The advanced model is a voltage-dependent capacitance additionally dependent on input-slew and output capacitance. The advanced model has many advantages, one of which is that the accuracy of both delays and slews is improved. Another advantage is that nonlinearities such as the Miller effect are addressed. The advanced receiver model is part of the Synopsys Composite Current-Source (CCS) model.

When set to advanced, RC delay calculation will use the advanced receiver model if data for it is present and if the network is driven by the advanced driver model. The `report_delay_calculation` command used on a network arc will show the message "Advanced receiver-modeling used" as appropriate.

When the shell variable `rc_receiver_model_mode` is set to advanced, and the network is not driven by the advanced driver model, (i.e. the variable `rc_driver_model_mode` is set to basic or lumped load is used), DesignTime will use the advanced voltage-dependent capacitance models to derive an equivalent single capacitance dependent only on the rise, fall, min or max arc condition. These equivalent capacitances will be used in analysis instead of the pin capacitances from the library. The `report_delay_calculation` command used on a network arc will not show the message "Advanced receiver-modeling used" for these calculations, since only an equivalent single capacitance is used.

When the shell variable `rc_receiver_model_mode` is set to basic, RC delay calculation will always use the pin capacitances specified in the design libraries.

To determine the current value of this variable, enter the following command:

```
prompt> printvar rc_receiver_model_mode
```

SEE ALSO

`rc_driver_model_mode(3)`
`report_delay_calculation(2)`

rc_slew_derate_from_library

Specifies the derating needed for the transition times in the Synopsys library to match the transition times between the characterization trip points.

TYPE

float

DEFAULT

1.000000

GROUP

timing_variables

DESCRIPTION

A floating point number between 0.0 and 1.0 that specifies the derating needed for the transition times in the Synopsys library to match the transition times between the characterization trip points. The default is 1.0, which means that the transition times in the Synopsys library are used without change.

The value this variable specifies is overridden by any library-specified slew-derating values, so normally it should not be necessary to set the variable. The value specified applies only to libraries that do not contain slew-derating specifications.

A slew-derating value of 1.0 should be used if the transition times specified in the library represent the exact transition times between the characterization trip points, which is usually the case. Use a slew-derating value of less than 1.0 for libraries where the transition times have been extrapolated to the rail voltages. For example, if the transition times are characterized as between 30% and 70% and then extrapolated to the rails, the slew-derating value is $0.4 = (70 - 30) / 100$.

To determine the current value of this variable, type **printvar rc_slew_derate_from_library**.

For a list of all timing variables and their current values, type **print_variable_group timing**.

EXAMPLES

The following example specifies that cell delays from the Synopsys library have been computed from 50 percent of the input transition to 50 percent of the output transition. The example also specifies that transition times in the Synopsys library were computed by measuring the delay from 30 percent to 70 percent of the voltage source and then multiplying the measured transition times by $2.5 = (100-0)/(70-30)$ to extrapolate to 0-100 percent of the rail voltages.


```
psyn_shell-t> set rc_slew_derate_from_library 0.4
psyn_shell-t> set rc_slew_lower_threshold_pct_fall 30
psyn_shell-t> set rc_slew_lower_threshold_pct_rise 30
psyn_shell-t> set rc_slew_upper_threshold_pct_fall 70
psyn_shell-t> set rc_slew_upper_threshold_pct_rise 70
psyn_shell-t> set rc_input_threshold_pct_rise 50
psyn_shell-t> set rc_input_threshold_pct_fall 50
psyn_shell-t> set rc_output_threshold_pct_rise 55
psyn_shell-t> set rc_output_threshold_pct_fall 55
```

SEE ALSO

```
lib_thresholds_per_lib(3)
rc_input_threshold_pct_rise(3)
rc_input_threshold_pct_fall(3)
rc_output_threshold_pct_fall(3)
rc_output_threshold_pct_rise(3)
rc_slew_lower_threshold_pct_fall(3)
rc_slew_lower_threshold_pct_rise(3)
rc_slew_upper_threshold_pct_fall(3)
rc_slew_upper_threshold_pct_rise(3)
```

rc_slew_lower_threshold_pct_fall

Specifies the threshold voltage that defines the endpoint of the falling slew calculation.

TYPE

float

DEFAULT

20.000000

GROUP

timing_variables

DESCRIPTION

Specifies the threshold voltage that defines the endpoint of the falling slew calculation. The value is a percent of the voltage source. Allowed values are 0.0 - 100.0 inclusive; the default is 20.0.

This variable is one of 8 variables, listed in Table 1, that affect delay and transition time computations for detailed RC networks. These variables interpret the cell delays and transition times from the Synopsys library. The values specified by these variables are overridden by trippoint values specified in the library so normally it should not be necessary to set the variables. The values specified are only applied to libraries that do not contain trippoint specifications.

Table 1

Variable Name	Default
rc_slew_lower_threshold_pct_rise	20.0
rc_slew_lower_threshold_pct_fall	20.0
rc_slew_upper_threshold_pct_rise	80.0
rc_slew_upper_threshold_pct_fall	80.0
rc_input_threshold_pct_rise	50.0
rc_input_threshold_pct_fall	50.0
rc_output_threshold_pct_rise	50.0
rc_output_threshold_pct_fall	50.0

The default values specify that a cell delay is defined from 50% of the voltage value for the input transition to 50% of the voltage value for the output transition. The default values also specify that a transition time, or slew, is defined from 20% to 80% of the voltage.

To determine the current value of this variable, type **printvar rc_slew_lower_threshold_pct_fall**.

For a list of all timing variables and their current values, type **print_variable_group timing**.

EXAMPLES

The following example specifies that cell delays from the Synopsys library are computed from 50% of the input transition to 55% of the output transition. In addition, the example specifies that transition times in the Synopsys library represent the delay from 10% to 90% of the voltage source.

```
psyn_shell-t> set rc_slew_lower_threshold_pct_fall 10 psyn_shell-t> set
rc_slew_lower_threshold_pct_rise 10 psyn_shell-t> set
rc_slew_upper_threshold_pct_fall 90 psyn_shell-t> set
rc_slew_upper_threshold_pct_rise 90 psyn_shell-t> set rc_input_threshold_pct_rise 50
psyn_shell-t> set rc_input_threshold_pct_fall 50 psyn_shell-t> set
rc_output_threshold_pct_rise 55 psyn_shell-t> set rc_output_threshold_pct_fall 55
```

SEE ALSO

```
rc_input_threshold_pct_rise(3)
rc_input_threshold_pct_fall(3)
rc_output_threshold_pct_fall(3)
rc_output_threshold_pct_rise(3)
rc_slew_lower_threshold_pct_fall(3)
rc_slew_lower_threshold_pct_rise(3)
rc_slew_upper_threshold_pct_fall(3)
rc_slew_upper_threshold_pct_rise(3)
lib_thresholds_per_lib(3)
```

rc_slew_lower_threshold_pct_rise

Specifies the threshold voltage that defines the startpoint of the rising slew calculation.

TYPE

float

DEFAULT

20.000000

GROUP

timing_variables

DESCRIPTION

Specifies the threshold voltage that defines the startpoint of the rising slew calculation. The value is a percent of the voltage source. Allowed values are 0.0 - 100.0 inclusive; the default is 20.0.

This variable is one of 8 variables, listed in Table 1, that affect delay and transition time computations for detailed RC networks. These variables interpret the cell delays and transition times from the Synopsys library. The values specified by these variables are overridden by trippoint values specified in the library so normally it should not be necessary to set the variables. The values specified are only applied to libraries that do not contain trippoint specifications.

Table 1

Variable Name	Default
rc_slew_lower_threshold_pct_rise	20.0
rc_slew_lower_threshold_pct_fall	20.0
rc_slew_upper_threshold_pct_rise	80.0
rc_slew_upper_threshold_pct_fall	80.0
rc_input_threshold_pct_rise	50.0
rc_input_threshold_pct_fall	50.0
rc_output_threshold_pct_rise	50.0
rc_output_threshold_pct_fall	50.0

The default values specify that a cell delay is defined from 50% of the voltage value for the input transition to 50% of the voltage value for the output transition. The default values also specify that a transition time, or slew, is defined from 20% to 80% of the voltage.

rc_slew_lower_threshold_pct_rise

To determine the current value of this variable, type **printvar rc_slew_lower_threshold_pct_rise**.

For a list of all timing variables and their current values, type **print_variable_group timing**.

EXAMPLES

The following example specifies that cell delays from the Synopsys library are computed from 50% of the input transition to 55% of the output transition. In addition, the example specifies that transition times in the Synopsys library represent the delay from 10% to 90% of the voltage source.

```
psyn_shell-t> set rc_slew_lower_threshold_pct_fall 10 psyn_shell-t> set
rc_slew_lower_threshold_pct_rise 10 psyn_shell-t> set
rc_slew_upper_threshold_pct_fall 90 psyn_shell-t> set
rc_slew_upper_threshold_pct_rise 90 psyn_shell-t> set rc_input_threshold_pct_rise 50
psyn_shell-t> set rc_input_threshold_pct_fall 50 psyn_shell-t> set
rc_output_threshold_pct_rise 55 psyn_shell-t> set rc_output_threshold_pct_fall 55
```

SEE ALSO

```
rc_input_threshold_pct_rise(3)
rc_input_threshold_pct_fall(3)
rc_output_threshold_pct_fall(3)
rc_output_threshold_pct_rise(3)
rc_slew_lower_threshold_pct_fall(3)
rc_slew_lower_threshold_pct_rise(3)
rc_slew_upper_threshold_pct_fall(3)
rc_slew_upper_threshold_pct_rise(3)
lib_thresholds_per_lib(3)
```

rc_slew_upper_threshold_pct_fall

Specifies the threshold voltage that defines the startpoint of the falling slew calculation.

TYPE

float

DEFAULT

80.000000

GROUP

timing_variables

DESCRIPTION

Specifies the threshold voltage that defines the startpoint of the falling slew calculation. The value is a percent of the voltage source. Allowed values are 0.0 - 100.0 inclusive; the default is 80.0.

This variable is one of 8 variables, listed in Table 1, that affect delay and transition time computations for detailed RC networks. These variables interpret the cell delays and transition times from the Synopsys library. The values specified by these variables are overridden by trippoint values specified in the library so normally it should not be necessary to set the variables. The values specified are only applied to libraries that do not contain trippoint specifications.

Table 1

Variable Name	Default
rc_slew_lower_threshold_pct_rise	20.0
rc_slew_lower_threshold_pct_fall	20.0
rc_slew_upper_threshold_pct_rise	80.0
rc_slew_upper_threshold_pct_fall	80.0
rc_input_threshold_pct_rise	50.0
rc_input_threshold_pct_fall	50.0
rc_output_threshold_pct_rise	50.0
rc_output_threshold_pct_fall	50.0

The default values specify that a cell delay is defined from 50% of the voltage value for the input transition to 50% of the voltage value for the output transition. The default values also specify that a transition time, or slew, is defined from 20% to 80% of the voltage.

To determine the current value of this variable, type **printvar rc_slew_upper_threshold_pct_fall**.

For a list of all timing variables and their current values, type **print_variable_group timing**.

EXAMPLES

The following example specifies that cell delays from the Synopsys library are computed from 50% of the input transition to 55% of the output transition. In addition, the example specifies that transition times in the Synopsys library represent the delay from 10% to 90% of the voltage source.

```
psyn_shell-t> set rc_slew_lower_threshold_pct_fall 10 psyn_shell-t> set
rc_slew_lower_threshold_pct_rise 10 psyn_shell-t> set
rc_slew_upper_threshold_pct_fall 90 psyn_shell-t> set
rc_slew_upper_threshold_pct_rise 90 psyn_shell-t> set rc_input_threshold_pct_rise 50
psyn_shell-t> set rc_input_threshold_pct_fall 50 psyn_shell-t> set
rc_output_threshold_pct_rise 55 psyn_shell-t> set rc_output_threshold_pct_fall 55
```

SEE ALSO

```
rc_input_threshold_pct_rise(3)
rc_input_threshold_pct_fall(3)
rc_output_threshold_pct_fall(3)
rc_output_threshold_pct_rise(3)
rc_slew_lower_threshold_pct_fall(3)
rc_slew_lower_threshold_pct_rise(3)
rc_slew_upper_threshold_pct_fall(3)
rc_slew_upper_threshold_pct_rise(3)
lib_thresholds_per_lib(3)
```

rc_slew_upper_threshold_pct_rise

Specifies the threshold voltage that defines the endpoint of the rising slew calculation.

TYPE

float

DEFAULT

80.000000

GROUP

timing_variables

DESCRIPTION

Specifies the threshold voltage that defines the endpoint of the rising slew calculation. The value is a percent of the voltage source. Allowed values are 0.0 - 100.0 inclusive; the default is 80.0.

This variable is one of 8 variables, listed in Table 1, that affect delay and transition time computations for detailed RC networks. These variables interpret the cell delays and transition times from the Synopsys library. The values specified by these variables are overridden by trippoint values specified in the library so normally it should not be necessary to set the variables. The values specified are only applied to libraries that do not contain trippoint specifications.

Table 1

Variable Name	Default
rc_slew_lower_threshold_pct_rise	20.0
rc_slew_lower_threshold_pct_fall	20.0
rc_slew_upper_threshold_pct_rise	80.0
rc_slew_upper_threshold_pct_fall	80.0
rc_input_threshold_pct_rise	50.0
rc_input_threshold_pct_fall	50.0
rc_output_threshold_pct_rise	50.0
rc_output_threshold_pct_fall	50.0

The default values specify that a cell delay is defined from 50% of the voltage value for the input transition to 50% of the voltage value for the output transition. The default values also specify that a transition time, or slew, is defined from 20% to 80% of the voltage.

rc_slew_upper_threshold_pct_rise

To determine the current value of this variable, type **printvar rc_slew_upper_threshold_pct_rise**.

For a list of all timing variables and their current values, type **print_variable_group timing**.

EXAMPLES

The following example specifies that cell delays from the Synopsys library are computed from 50% of the input transition to 55% of the output transition. In addition, the example specifies that transition times in the Synopsys library represent the delay from 10% to 90% of the voltage source.

```
psyn_shell-t> set rc_slew_lower_threshold_pct_fall 10 psyn_shell-t> set
rc_slew_lower_threshold_pct_rise 10 psyn_shell-t> set
rc_slew_upper_threshold_pct_fall 90 psyn_shell-t> set
rc_slew_upper_threshold_pct_rise 90 psyn_shell-t> set rc_input_threshold_pct_rise 50
psyn_shell-t> set rc_input_threshold_pct_fall 50 psyn_shell-t> set
rc_output_threshold_pct_rise 55 psyn_shell-t> set rc_output_threshold_pct_fall 55
```

SEE ALSO

```
rc_input_threshold_pct_rise(3)
rc_input_threshold_pct_fall(3)
rc_output_threshold_pct_fall(3)
rc_output_threshold_pct_rise(3)
rc_slew_lower_threshold_pct_fall(3)
rc_slew_lower_threshold_pct_rise(3)
rc_slew_upper_threshold_pct_fall(3)
rc_slew_upper_threshold_pct_rise(3)
lib_thresholds_per_lib(3)
```

read_only_attributes

Contains informational attributes, which the user cannot set.

DESCRIPTION

Contains informational attributes. A "read-only" attribute cannot be set by the user.

To determine the value of an attribute, use the **get_attribute** command.

For information on all attributes, refer to the **attributes** manual page.

Read-only Attributes

`design_type`

Indicates the current state of the design and has the value *fsm* (finite state machine), *pla* (programmable logic array), *equation* (Boolean logic), or *netlist* (gates). This attribute cannot be set by the user.

`is_black_box`

true if the reference is not yet linked to a design. This attribute cannot be set by the user.

`is_combinational`

true if all cells of a design and all designs in its hierarchy are combinational. A cell is combinational if it is non-sequential or non-tristate and all of its outputs compute a combinational logic function. The **report_lib** command will report such a cell as not a black-box. This attribute cannot be set by the user.

`is_dw_subblock`

true if the object (a cell, a reference, or a design) is a DW subblock that was automatically elaborated. This attribute cannot be set by the user.

Note: DW subblocks that are manually elaborated will not have this attribute.

`is_hierarchical`

true if the design contains leaf cells or other levels of hierarchy. This attribute is read-only and cannot be set by the user.

`is_mapped`

true if all the non-hierarchical cells of a design are mapped to cells in a technology library. This attribute cannot be set by the user.

`is_sequential`

true if any cells of a design or designs in its hierarchy are sequential. A cell is sequential if it is not combinational. This attribute cannot be set by the user.

`is_test_circuitry`

Set by **insert_dft** on the scan cells and nets added to a design during the addition of test circuitry. This attribute cannot be set by the user.

`read_only_attributes`

`is_synlib_module`

true if the object (a cell, a reference, or a design) refers to an unmapped module reference or if the object is (or refers to) a design that was automatically elaborated from a synlib module or a synlib operator. This attribute cannot be set by the user.

Note: synlib modules that are manually elaborated will not have this attribute.

`is_synlib_operator`

true if the object (a cell or a reference) is a synthetic library operator reference. This attribute cannot be set by the user.

`is_unmapped`

true if any of the cells are not linked to a design or mapped to a technology library. This attribute cannot be set by the user.

`pin_direction`

Direction of a pin. Value can be *in*, *out*, *inout*, or *unknown*. This attribute cannot be set by the user.

`port_direction`

Direction of a port. Value can be *in*, *out*, *inout*, or *unknown*. This attribute cannot be set by the user.

`ref_name`

The reference name of a cell. This attribute cannot be set by the user.

SEE ALSO

`get_attribute(2)`

`attributes(3)`

read_translate_msff

Indicates (when *true*, the default) that master-slave flip-flops (specified with the `clocked_on_also` syntax) are to be automatically translated to master-slave latches. When *false*, both master and slave remain flip-flops.

TYPE

Boolean

DEFAULT

true

GROUP

io_variables

DESCRIPTION

Indicates (when *true*, the default) that master-slave flip-flops (specified with the `clocked_on_also` syntax) are to be automatically translated to master-slave latches. When *false*, both master and slave remain flip-flops.

This variable is used during execution of the **read** command, while a technology .db library is being read in by `dc_shell` and during execution of the **read_lib** command while a technology library is being read in by Library Compiler. The technology .db library is affected only if the program reports that the .db library is being updated and asks you to save the results. Library Compiler always follows this variable during processing.

To determine the current value of this variable, type **printvar read_translate_msff**. For a list of all **io** variables and their current values, type **print_variable_group io**.

SEE ALSO

`read_lib(2)`
`io_variables(3)`

reference_attributes

Contains attributes that can be placed on a reference.

DESCRIPTION

Contains attributes that can be placed on a reference.

Several commands exist that can be used to set attributes; however, most attributes can be set by using the **set_attribute** command. If the attribute definition specifies a **set** command, use it to set the attribute; otherwise, use **set_attribute**. If an attribute is read-only, then you cannot set it.

To determine the value of an attribute, use the **get_attribute** command. To remove attributes, use the **remove_attribute** command.

For a more detailed explanation of an attribute, see the manual page of the appropriate **set** command. For information on all attributes, refer to the **attributes** manual page.

Reference Attributes

dont_touch

Specifies that designs linked to a reference with this attribute are excluded from optimization. Valid values are true (the default) or false. Designs linked to a reference by using the **dont_touch** attribute set to true are not modified or replaced during compile. Set this by using the **set_dont_touch** attribute.

is_black_box

This is set to true if the reference is not yet linked to a design. This attribute is read-only and you cannot set it.

is_combinational

This is set to true if all the cells of the referenced design are combinational. A cell is combinational if it is nonsequential or non-tristate and all of its outputs compute a combinational logic function. The **report_lib** command reports such a cell as not a black-box. This attribute is read-only and you cannot set it.

is_dw_subblock

This is set to true if the object (a cell, a reference, or a design) is a DesignWare subblock that was automatically elaborated. This attribute is read-only and you cannot set it.

Note: DesignWare subblocks that are manually elaborated do not have this attribute.

is_hierarchical

This is set to true if the design contains leaf cells or other levels of hierarchy. This attribute is read-only and you cannot set it.

is_mapped

This is set to true if the reference is linked to a design, and all the non-

hierarchical cells of the referenced design are mapped to cells in a technology library. This attribute is read-only and you cannot set it.

`is_sequential`

This is set to true if all the cells of the referenced design are sequential. A cell is sequential if it is not combinational (if any of its outputs depend on previous inputs). This attribute is read-only and you cannot set it.

`is_synlib_module`

This is set to true if the object (a cell, a reference, or a design) refers to an unmapped module reference, or the object is (or refers to) a design that was automatically elaborated from a synlib module or a synlib operator. This attribute is read-only and you cannot set it.

Note: synlib modules that are manually elaborated do not have this attribute.

`is_synlib_operator`

This is set to true if the object (a cell or a reference) is a synthetic library operator reference. This attribute is read-only and you cannot set it.

`is_unmapped`

This is set to true if any of the non-hierarchical cells of the referenced design are not mapped to cells in a technology library, or the reference is not yet linked to a design. This attribute is read-only and you cannot set it.

`scan`

When *true*, specifies that cells of the referenced design are always replaced by equivalent scan cells. When *true*, specifies that cells of the referenced design are always replaced by equivalent scan cells during `insert_dft`. When *false*, cells are not replaced. Set by using the **`set_scan_replacement`**.

`scan_chain`

Includes the specified cells of the referenced design in the scan-chain whose index is the value of this attribute.

`ungroup`

Specifies that all designs linked to a reference with this attribute are ungrouped (levels of hierarchy represented by these design cells are removed) during compile. Set by using the **`set_ungroup`** command.

SEE ALSO

`get_attribute(2)`
`insert_dft(2)`
`remove_attribute(2)`
`set_attribute(2)`
`set_scan_replacement(2)`
`attributes(3)`

register_duplicate

Controls whether **compile** should invoke **Register duplication** or not.

TYPE

Boolean

DEFAULT

false

GROUP

compile_variables

DESCRIPTION

The **register_duplicate** variable (when set to true), duplicates the high fanout registers to reduce the number of fanouts for each register.

Fanouts for registers that exceed a certain limit can cause an adverse affect on the circuit performance. Currently, in *Design Compiler*, the fanout is controlled only by buffer insertion. Some FPGA architectures can lack buffers in the routing architecture that can cause the fixed fanout limit to exceed, which can cause an error in the back-end tool. To address this problem, the **register_duplicate** variable provides a method to duplicate registers in an optimized way.

EXAMPLES

```
prompt> set_register_max_fanout 25 top
prompt> register_duplicate = true
prompt>set_attribute xfpga_virtex2-5 -type float default_fanout_load 100
Compile will indicate register duplication status as :-
```

ELAPSED		WORST NEG	TOTAL NEG	DESIGN		
TIME	AREA	SLACK	SLACK	RULE	COST	ENDPOINT

Information: Duplicating register r1_reg with fanout load of 50.00 (REGDUP-3)

Optimization Complete

SEE ALSO

report_default_significant_digits

Sets the default number of significant digits for many reports.

TYPE

integer

DEFAULT

-1

GROUP

none

DESCRIPTION

The **report_default_significant_digits** variable sets the default number of significant digits for many reports. Allowed values are 0-13; the default is -1. A default of -1 indicates that command specific default precision value will be used for reporting. Some report commands (for example, **report_timing**, **report_cell**) have a **-significant_digits** option, which overrides the value of this variable.

Not all reports respond to this variable. Check the man pages for individual reports to determine whether they support this feature.

To determine the current value of this variable, type **printvar report_default_significant_digits** or **printvar report_default_significant_digits**.

Once set, the value of the variable will be used by the subsequent reporting commands, if command specific **-significant_digits** option is not used. The value of the variable can be reset. To do so, set the value of the variable to -1. Doing so, command specific default will be used as precision for reporting if **-significant_digits** on the command is not used.

For example, command specific default precision of **report_cell** is 6. If **report_default_significant_digits** is set to 5 and **report_cell** issued thereafter, a precision of 5 will be used during **report_cell** report. If **report_cell -significant_digits 3** is issued after the above variable setting, a precision of 3 will be followed for **report_cell** report. To view the **report_cell** report with the command default precision of 6, reset the value of the variable **report_default_significant_digits**, by setting it to -1.

If an invalid value is set(not in the range 0-13 and not -1), an error will be issued and the previous valid value will be restored. Example below illustrates the usage of the variable.

```
prompt> list report_default_significant_digits
report_default_significant_digits = -1
prompt> report_default_significant_digits = 4
```

```
4
prompt> list report_default_significant_digits
report_default_significant_digits = 4
prompt> report_default_significant_digits = -44
Error: can't set report_default_significant_digits: must be in range 0 to 13
      Use error_info for more info. (CMD-013)
```

```
4
prompt> list report_default_significant_digits
report_default_significant_digits = 4
```

SEE ALSO

```
report_timing(2)
report_clock_gating_check(2)
report_constraint(2)
write_sdf(2)
report_cell(2)
report_net(2)
report_qor(2)
```

rom_auto_inferring

Inferring ROM from RTL description.

SYNTAX

Boolean **rom_auto_inferring** *true/false*

TYPE

Boolean

DEFAULT

true

GROUP

DESCRIPTION

When this variable is *true*, the tool will try to inferring ROM from RTL description.

SEE ALSO

route_guide_attributes

Contains attributes related to route guide.

DESCRIPTION

Contains attributes related to route guide.

You can use **get_attribute** to determine value of an attribute, and use **report_attribute** to get a report of all attributes on specified object. Specified with **list_attribute -class route_guide -application**, the definition of attributes can be listed.

Route Guide Attributes

affects

Specifies the affects of a route guide, which is route.
The data type of **affects** is string.
This attribute is read-only.

area

Specifies area of a route guide.
The data type of **area** is float.
This attribute is read-only.

bbox

Specifies the bounding-box of a route guide. The **bbox** is represented by a **rectangle**.
The format of a *rectangle* specification is {{llx lly} {urx ury}}, which specifies the lower-left and upper-right corners of the rectangle.
The data type of **bbox** is string.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

cell_id

Specifies Milkyway design ID in which a route guide object is located.
The data type of **cell_id** is integer.
This attribute is read-only.

horizontal_track_utilization

Specifies the horizontal track utilization for the route guide.
The data type of **horizontal_track_utilization** is integer.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

layer

Specifies layer name on which a route guide is.
The data type of **layer** is string.
This attribute is read-only.

layer_number

Specifies layer number on which a route guide is.
The data type of **layer_number** is integer.

route_guide_attributes

This attribute is read-only.

name

Specifies name of a route guide object.

The data type of **name** is string.

This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

no_preroute_layers

Specifies the layers that cannot contain preroutes.

The data type of **no_preroute_layers** is string.

This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

no_signal_layers

Specifies the layers that cannot contain signals.

The data type of **no_signal_layers** is string.

This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

object_class

Specifies object class name of a route guide, which is **route_guide**.

The data type of **object_class** is string.

This attribute is read-only.

object_id

Specifies object ID in Milkyway design file.

The data type of **object_id** is integer.

This attribute is read-only.

object_type

Specifies geometry type of a route guide, which can be RECTANGLE or POLYGON.

The data type of **object_type** is string.

This attribute is read-only.

points

Specifies point list of a route guide's boundary.

The data type of **points** is string.

This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

preferred_direction_only_layers

Specifies the layers that cannot make nonPreferredDirection wires.

The data type of **preferred_direction_only_layers** is string.

This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

repair_as_single_sbox

Specifies whether this route guide should be repaired as a single sbox when there is a difficult violation on a prerouted wire or inside a large macro.

The data type of **repair_as_single_sbox** is boolean.

This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

`switch_preferred_direction`

Specifies whether to switch the preferred direction for the route guide.
The data type of **`switch_preferred_direction`** is boolean.
This attribute is writable. You can use **`set_attribute`** to modify its value on a specified object.

`type`

Specifies the affects of a route guide, which is route.
The data type of **`type`** is string.
This attribute is read-only.

`vertical_track_utilization`

Specifies the vertical track utilization for the route guide.
The data type of **`vertical_track_utilization`** is integer.
This attribute is writable. You can use **`set_attribute`** to modify its value on a specified object.

`zero_min_spacing`

Specifies whether zero minimum spacing is allowed for the route guide.
The data type of **`zero_min_spacing`** is boolean.
This attribute is writable. You can use **`set_attribute`** to modify its value on a specified object.

SEE ALSO

`get_attribute(2)`,
`list_attribute(2)`,
`report_attribute(2)`,
`set_attribute(2)`.

route_layerExtraCostByRC

DESCRIPTION

The **route_layerExtraCostByRC** variable specifies extra layer cost. It will control the choice of layers for detailed router to reduce RC. If the value is set to 0, user specified extra cost for all layers will be used. If the value is set to 1, extra cost of all poly and metal layers previously defined as 0 will be re-computed based on RC. If the value is set to 2, extra cost of all poly, metal layers, and vias previously defined as 0 will be re-computed based on RC.

SYNTAX

set route_layerExtraCostByRC value

The valid values of this variable range between 0 and 2. The default is 0.

EXAMPLE

To compute extra layer cost, enter

```
set route_layerExtraCostByRC 1
```

routeopt_allow_min_buffer_with_size_only

Allows the post-route hold fixing to add buffers even in size-only mode

TYPE

Boolean

DEFAULT

false

GROUP

routeopt_variables

DESCRIPTION

By the definition of size-only mode, the optimization stage is not supposed to add any buffers. If this variable is set to true, even if the post-route optimization is in size-only mode, post-route hold fix adds buffers in order to fix hold time violation. Thus, buffering is allowed only for hold fixing.

SEE ALSO

route_opt(2)

routeopt_checkpoint

Writes an intermediate CEL at intervals during the route_opt

TYPE

Boolean

DEFAULT

false

GROUP

routeopt_variables

DESCRIPTION

When the variable is set to true, route_opt will save intermediate CEL at each major stage. For the multiple runs of route_opt, each intermediate CEL will be overwritten. The checkpoint CEL names are : **design_name_RT** for after initial route stage **design_name_ORPRT** for after optimize_wire_via stage **design_name_OR_number** for after each optimization stage **design_name_ECORT_number** for after each eco route stage **design_name_RCRED** for after xtalk reduction stage **design_name_POR** for after power optimization stage **design_name_PECORT** for after power optimization eco route stage **design_name_HOLD_PRE** for after pre route based hold optimization stage **design_name_HOLD** for after global route based hold optimization stage **design_name_INCOR** for after optimization stage during route_opt -incremental **design_name_INCECORT** for after eco route stage during route_opt -incremental

SEE ALSO

route_opt(2)

routeopt_density_limit

The maximum cell density threshold for performing optimization tricks in a window around the location of the given cell or pin.

TYPE

Float

DEFAULT

0.95

GROUP

routeopt_variables

DESCRIPTION

It sets the density limit for checking a window around a location where an onroute optimization trick will be performed. The window size is set internally and based on the size of a default cell. If the density in the window area is greater than or equal to this limit, the density check will fail, and the trick will not be performed in that location.

The check is performed for dynamic buffering, max length buffering, min buf, move, phase and size tricks. For size tricks, it is only checked if the candidate library cell is larger than the candidate cell.

SEE ALSO

route_opt(2)

routeopt_disable_cpulimit

The internally defined threshold for the number of changes in one optimization will be disabled.

TYPE

Boolean

DEFAULT

false

GROUP

routeopt_variables

DESCRIPTION

Inside `route_opt`, there is upper limit for the number of changes in one optimization stage to help convergence better. Once the optimization reaches the limit, it will stop optimization and move on to the next stage.

SEE ALSO

`route_opt(2)`

routeopt_drc_over_timing

Specifies the cost proirity between max_design_rule cost and max_delay cost during DRC fixing inside route_opt.

TYPE

Boolean

DEFAULT

false

GROUP

routeopt_variables

DESCRIPTION

This variable specifies the cost proirity between max_design_rule cost and max_delay cost during DRC fixing inside route_opt. By default, max_delay cost has higher priority but when it set to true, max_design_rule cost will have higher priority than max_delay cost. This variable works only with -only_design_rule option in route_opt.

SEE ALSO

route_opt(2)

routeopt_preserve_routes

The slight route disturbances caused by routeopt optimization will be reconnected in the appropriate metal layers and the reconnected routes written to the database.

TYPE

Boolean

DEFAULT

true

GROUP

routeopt_variables

DESCRIPTION

When route_opt changes a cell during optimization, the net identities can change. For example, inserting a buffer creates a new net. Although route_opt optimization seeks to place new cells along the route and maintain route topology, it does not simultaneously reassign the net identity of route metallization geometries associated with the new net. Route preservation performs this task in a process executed after the optimization phase finishes and before ECO routing begins. Small segments are also inserted, where necessary, to reconnect pins displaced by legalization. The presence of the route segments bound to the nets assist the ECO router to find a similar solution to the one obtained before optimization. In this way, preserving the routes improves correlation between pre and post-optimization routing and therefore acts to improve convergence in timing numbers pre-ECO versus post-ECO.

If this variable is set to false, route shapes stay with the net which takes the original name, and the routes are removed from the other net(s). ECO routing will later perform all of the reconnections, but it can arrive at a significantly different solution (topology, metallization layer, detour, etc.) than the pre-optimization one.

SEE ALSO

route_opt(2)

routeopt_skip_report_qor

Skip QoR reports in the last stage during the route_opt

TYPE

Boolean

DEFAULT

false

GROUP

routeopt_variables

DESCRIPTION

When the variable is set to true, route_opt will skip QoR reports in the last stage, and print the information "Skip Report QoR" instead.

SEE ALSO

route_opt(2)

routeopt_xtalk_reduction_setup_threshold

The threshold of setup delta delay to perform cross talk reduction

TYPE

Float

DEFAULT

0.1

GROUP

routeopt_variables

DESCRIPTION

The nets with delta delay more than this threshold are selected for crosstalk reduction during route_opt. The threshold MUST be specified in "ns" irrespective of library time units.

SEE ALSO

route_opt(2)

rp_shift_column_for_fixed_cells

Determines whether the tool allows the horizontal shifting of relative placement columns in the presence of single tap cells.

TYPE

Boolean

DEFAULT

false

GROUP

physopt

DESCRIPTION

The value you specify for the **rp_shift_column_for_fixed_cells** variable determines whether the tool performs horizontal relative placement column shifting for single tap cells. The default value of this variable is **false**. The default behavior is to horizontal shift the relative placement column only when a tap cell array is present, not for a single tap cell.

To see the current value of this variable, type **printvar rp_shift_column_for_fixed_cells**.

SEE ALSO

place_opt(2)

schematic_variables

Variables that affect **create_schematic**.

SYNTAX

```
string bus_dimension_separator_style =    "]"["
string bus_naming_style =                "%s[%d]"
string bus_range_separator_style =        ":"
string default_schematic_options = "-size infinite"
Boolean duplicate_ports = "false"
Boolean gen_bussing_exact_implicit = "false"
string gen_cell_pin_name_separator = "/"
Boolean gen_create_netlist_busses =        "false"
Boolean gen_dont_show_single_bit_busses = "false"
Boolean gen_match_ripper_wire_widths = "false"
integer gen_max_compound_name_length      256
integer gen_max_ports_on_symbol_side = 0
string gen_open_name_prefix = "Open" ;
string gen_open_name_postfix = "" ;
Boolean gen_show_created_busses = "false"
Boolean gen_show_created_symbols = "false"
Boolean gen_single_osc_per_name = "false"
string generic_symbol_library = "generic.sdb"
Boolean single_group_per_sheet = "false"
string sort_outputs = "false"
string symbol_library = {"your_library.sdb"}
Boolean use_port_name_for_oscs = "true"
```

DESCRIPTION

These variables affect **create_schematic**. Defaults are specified above, under Syntax.

For a list of **schematic** variables and their current values, type **print_variable_group schematic**. To view this manual page online, type **help schematic_variables**. To view an individual variable description, type **help var**, where *var* is the name of the variable.

bus_dimension_separator_style

This variable affects the **read** command with the **verilog**, **vhdl** or **edif** format options. In conjunction with the **bus_naming_style** variable, **bus_dimension_separator_style** controls naming of individual bit-blasted ports derived from multi-dimensional arrays. This variable also affects the naming of bit-blasted multi-dimensional instance arrays and bit-blasted multi-dimensional net arrays in exactly the same way as for ports.

bus_naming_style

This variable affects the **read**, **write**, and **create_schematic** commands. For the **read** command with the **vhdl** or **verilog** format options, this variable controls naming of bit-blasted ports in **dc_shell** when they are created from multi-dimensional busses in the original source.

For the **write** command with the **edif** format option, this variable controls naming of individual members of each bus in the **edif** output. Also, together

with the **bus_range_separator_style** variable, this variable controls how ranged names of busses are written to the edif output. For the **create_schematic** command, this variable controls naming of bus rippers that rip off bits from bussed nets. Together with the **bus_range_separator_style** variable, it also controls naming of bussed nets, bussed ports, and bussed rippers in the schematic. Works the same as for **write -f edif**.

bus_range_separator_style

This variable affects the **write** and **create_schematic** commands. For the **write** command with the **edif** format option, this variable is used together with the **bus_naming_style** variable to generate the style for naming bus ranges. For the **create_schematic** command, this variable, together with the **bus_range_separator_style** variable, also controls naming of bussed nets, bussed ports and bussed rippers in the schematic. Works the same as for **write -f edif**.

default_schematic_options

Specifies options to use when schematics are generated. When set to *-size infinite* (the default value), the schematic for a design is displayed on a single page. Used by the Design Analyzer.

duplicate_ports

A partitioning option that determines whether ports are to be drawn on every sheet for which an input or output signal appears. When *true*, no off-sheet connectors are used for input and output signals, and signal ports are duplicated where indicated on each sheet. When *false* (the default value), off-sheet connectors are used and signal ports are not duplicated.

gen_bussing_exact_implicit

When *true*, specifies that schematics generated with the **-implicit** option should contain no bus rippers. All bussed connections should be shown with implicit bus names. The default is *false*.

gen_cell_pin_name_separator

A value that is to be used to separate the cell and pin names in the bus names generated by **create_schematic**. By default, "/" is used to separate the cell and pin names.

gen_create_netlist_busses

When *true*, **create_schematic** will create netlist busses whenever it creates busses on the schematic. Usually this happens when **create_schematic** creates busses to connect to bussed pins on the schematic, but it may also happen when there are bussed ports on the schematic. The default is *false*.

gen_dont_show_single_bit_busses

When this variable is *true* and the **gen_show_created_busses** variable is also *true*, the names of single bit busses are not printed. Only schematic busses that have more than one bit are printed. The default is *false*.

gen_match_ripper_wire_widths

When *true*, specifies that **create_schematic** generates rippers such that the width of the ripper always equals the width of the ripped net. Any rippers whose wire ends are connected to scalar nets will be of unit width. The default is *false*.

`gen_max_compound_name_length`

Controls the maximum length for compound names of bus bundles for **create_schematic -sge**. Any busses with names longer than the maximum length are decomposed into their individual members in the schematic.

`gen_max_ports_on_symbol_side`

Specifies the maximum allowed size of a symbol created by **create_schematic**.

`gen_open_name_prefix`

Specifies the prefix to be used by **create_schematic -sge** when creating placeholder net names for unconnected pins. The default is "Open". The format of the net names is "%s%d%s", where the first "%s" is replaced by the value of **gen_open_name_prefix**, the second "%s" is replaced by the value of **gen_open_name_postfix**, and the "%d" is replaced by an integer whose value is generated automatically by **create_schematic -sge**.

`gen_open_name_postfix`

Specifies the postfix to be used by **create_schematic -sge** when creating placeholder net names for unconnected pins. The default is "". The format of the net names is "%s%d%s", where the first "%s" is replaced by the value of **gen_open_name_prefix**, the second "%s" is replaced by the value of **gen_open_name_postfix**, and the "%d" is replaced by an integer whose value is generated automatically by **create_schematic -sge**.

`gen_show_created_busses`

When *true*, a message is printed out every time a schematic bus is created from cell pins for which no equivalent net bus exists in the netlist. The default is *false*.

`gen_show_created_symbols`

When *true*, **create_schematic** prints a warning message every time it generates a new symbol for a cell because an appropriate symbol could not be found in the symbol libraries. The default is *false*.

`gen_single_osc_per_name`

When *true*, in cases where there could potentially be more than one off sheet connector with the same name on any schematic page, only one connector is drawn and the others just have their net segments appear as unconnected stubs. The default is *false*.

`generic_symbol_library`

The name of the **db** file that contains generic symbols, templates, and layers used for schematics. The default is *generic.sdb*.

`single_group_per_sheet`

A partitioning option that, when *true*, specifies that only one logic group is put on a sheet. This eliminates the possibility of more than one off-sheet connector with the same name on a single sheet. The default is *false*.

`sort_outputs`

When *true*, sorts output ports on the schematic by port name. The default is *false*.

`symbol_library`

A list of symbol library names to use during schematic generation.

`use_port_name_for_oscs`

A partitioning option that, when *true* (the default value), specifies that off-sheet connectors for nets that also have ports on them are given the name of the port. When *false*, the connectors are given the name of the net.

SEE ALSO

`create_schematic` (2), `read_lib` (2); `view_variables` (3).

sdc_write_unambiguous_names

Ensures that cell, net, pin, lib_cell, and lib_pin names that are written to the SDC file are not ambiguous.

TYPE

Boolean

DEFAULT

true

DESCRIPTION

Ensures that cell, net, pin, lib_cell, and lib_pin names that are written to the SDC file are not ambiguous. The default value is *true*.

When hierarchy has been partially flattened, embedded hierarchy separators can make names ambiguous. It is not clear which hierarchy separator characters are part of the name and which are real separators.

Beginning with SDC Version 1.2, hierarchical names can be made nonambiguous using the **set_hierarchy_separator** SDC command and/or the **-hsc** option on the **get_cells**, **get_lib_cells**, **get_lib_pins**, **get_nets**, and **get_pins** SDC object access commands. By default, PrimeTime and Design Compiler write an SDC file, using these features to create nonambiguous names.

It is wise to write SDC files that contain names that are not ambiguous. However, if you are using a third-party application that does not fully support SDC 1.2 or later versions (that is, it does not support the nonambiguous hierarchical names features of SDC), you can suppress these features by setting the variable **sdc_write_unambiguous_names** to *false*. The **write_sdc** command issues a warning if you have set this variable to *false*.

To determine the current value of this variable, use **printvar sdc_write_unambiguous_names**.

SEE ALSO

printvar(2)
write_sdc(2)

search_path

Specifies directories that the tool searches for files specified without directory names.

TYPE

list

DEFAULT

`{search_path + .}`

GROUP

system_variables

DESCRIPTION

Specifies directories that the tool searches for files specified without directory names. The search includes looking for technology and symbol libraries, design files, and so on. The value of this variable is a list of directory names and is usually set to a central library directory.

To determine the current value of this variable, use **printvar search_path**. For a list of all **system** variables and their current values, use the **print_variable_group system** command.

SEE ALSO

system_variables(3)

sh_command_log_file

Specifies the name of the file to which is written a log of the initial values of variables and executed commands.

TYPE

string

DEFAULT

command.log

DESCRIPTION

Specifies the name of the file to which is written a log of the initial values of variables and executed commands.

The default is command.log. If the value is an empty string, a command log file is not created.

To determine the current value of this variable, use **printvar sh_command_log_file**.

SEE ALSO

printvar(2)
view_command_log_file(3)
view_log_file(3)

sh_enable_line_editing

Enables the command line editing capabilities. This variable is for use in Tcl mode only.

TYPE

Boolean

DEFAULT

true

DESCRIPTION

If set to true it enables advanced UNIX-like shell capabilities. This variable is for use in Tcl mode only.

This variable needs to be set in the `.synopsys_dc.setup` file to take effect.

Key Bindings

The **sh_list_key_bindings** command displays current key bindings and the edit mode. To change the edit mode, use the **sh_line_editing_mode** variable on the shell.

Command Completion

The editor is able to complete commands, options, variables, and files given a unique abbreviation. You need to type only a part of a word and press the tab key to get the complete command, variable, or file. For command options, type '-' and press the tab key to get the options list.

If no match is found, the terminal bell rings. If the word is already complete a space is added to the end, if it is not already there to speed up typing and provide a visual indicator of successful completion. Completed text pushes the rest of the line to the right. If there are multiple matches then all the matching commands, options, files, or variables are autolisted.

Completion works in following context sensitive way:

The first token of a command line	:	completes commands
Token that begins with "-" after a command	:	completes command arguments
After a ">", " " or a "sh" command	:	completes filenames
After a set, unset or printvar command	:	completes the variables
After '\$' symbol	:	completes the variables
After the help command	:	completes command

After the man command : completes commands or variables

Any token which is not the first token
and does not match any of the above rules : completes filenames

SEE ALSO

sh_line_editing_mode(3)

sh_line_editing_mode

Enables vi or emacs editing mode. This variable is for use in Tcl mode only.

TYPE

String

DEFAULT

emacs

DESCRIPTION

This variable can be used to set the command line editor mode to either vi or emacs. Valid values are emacs or vi.

Use **sh_list_key_bindings** command to display the current key bindings and edit mode.

This variable is for use in Tcl mode only.

This variable can be set on the shell or inside .synopsys_dc.setup file to take effect.

SEE ALSO

sh_enable_line_editing(3)

sh_source_uses_search_path

Causes the **search** command to use the **search_path** variable to search for files. This variable is for use in **dc_shell-t** (Tcl mode of dc_shell) only.

TYPE

Boolean

DEFAULT

true

DESCRIPTION

Causes the **search** command to use the **search_path** variable to search for files, when **sh_source_uses_search_path** is *true* (the default). When *false*, the **source** command considers this variable's file argument literally. This variable is for use in **dc_shell-t** (Tcl mode of dc_shell) only.

To determine the current value of this variable, use **printvar sh_source_uses_search_path**.

SEE ALSO

printvar(2)
source(2)
search_path(3)

shape_attributes

Contains attributes related to shape.

DESCRIPTION

Contains attributes related to shape.

You can use **get_attribute** to determine value of an attribute, and use **report_attribute** to get a report of all attributes on specified object. Specified with **list_attribute -class shape -application**, the definition of attributes can be listed.

Shape Attributes

bbox

Specifies the bounding-box of a shape. The **bbox** is represented by a **rectangle**. The format of a *rectangle* specification is {{llx lly} {urx ury}}, which specifies the lower-left and upper-right corners of the rectangle. The data type of **bbox** is string. This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

bbox_ll

Specifies the lower-left corner of the bounding-box of a shape. The **bbox_ll** is represented by a **point**. The format of a *point* specification is {x y}. You can get the **attr_name** of a shape, by accessing the first element of its **bbox**. The data type of **bbox_ll** is string. This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

bbox_llx

Specifies x coordinate of the lower-left corner of the bounding-box of a shape. The data type of **bbox_llx** is integer. This attribute is read-only.

bbox_lly

Specifies y coordinate of the lower-left corner of the bounding-box of a shape. The data type of **bbox_lly** is integer. This attribute is read-only.

bbox_ur

Specifies the upper-right corner of the bounding-box of a shape. The **bbox_ur** is represented by a **point**. The format of a *point* specification is {x y}. You can get the **bbox_ur** of a shape, by accessing the second element of its **bbox**. The data type of **bbox_ur** is string. This attribute is writable. You can use **set_attribute** to modify its value on

a specified object.

bbox_urx

Specifies x coordinate of the upper-right corner of the bounding-box of a shape.

The data type of **bbox_urx** is integer.

This attribute is read-only.

bbox_ury

Specifies y coordinate of the upper-right corner of the bounding-box of a shape.

The data type of **bbox_ury** is integer.

This attribute is read-only.

cell_id

Specifies Milkyway design ID in which a shape object is located.

The data type of **cell_id** is integer.

This attribute is read-only.

datatype_number

Specifies GDSII datatype number of a shape object.

The data type of **datatype_number** is integer.

This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

endcap

Specifies alignment type of a wire or path end.

The data type of **endcap** is string.

Its valid values are:

- **square_ends**
- **round_ends**
- **square_ends_by_half_width**
- **octagon_ends_by_half_width**

This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

layer

Specifies layer name of a shape object.

The data type of **layer** is string.

This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

layer_name

Specifies layer name of a shape object.

The data type of **layer_name** is string.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

layer_number

Specifies layer number of a shape object.
The data type of **layer_number** is integer.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

length

Specifies length of a wire or path object in user units.
The data type of **length** is float.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

name

Specifies name of a shape object.
The data type of **name** is string.
This attribute is read-only.

net_id

Specifies object ID of the net associated with a shape object.
The data type of **net_id** is integer.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

net_type

Specifies type of net associated with a shape object.
The data type of **net_type** is string.
This attribute is read-only.

object_class

Specifies object class name of a shape, which is **shape**.
The data type of **object_class** is string.
This attribute is read-only.

object_id

Specifies object ID in Milkyway design file.
The data type of **object_id** is integer.
This attribute is read-only.

object_type

Specifies object type name, which can be **RECTANGLE**, **POLYGON**, **TRAPEZOID**, **PATH**, **HWIRE**, and **VWIRE**.
The data type of **object_type** is string.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

owner

Specifies Milkyway design file name in which a terminal is located.
The data type of **owner** is string.
This attribute is read-only.

shape_attributes

owner_net

Specifies net name which a shape object is connected to.
The data type of **owner_net** is string.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

points

Specifies point list of a shape's boundary.
The data type of **points** is string.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

route_type

Specifies route type of a shape object.
The data type of **route_type** is string.
Its valid values are:

- **User Enter** or **user_enter**
- **Signal Route** or **signal_route**
- **Signal Route (Global)** or **signal_route_global**
- **P/G Ring** or **pg_ring**
- **Clk Ring** or **clk_ring**
- **P/G Strap** or **pg_strap**
- **Clk Strap** or **clk_strap**
- **P/G Macro/IO Pin Conn** or **pg_macro_io_pin_conn**
- **P/G Std. Cell Pin Conn** or **pg_std_cell_pin_conn**
- **Zero-Skew Route** or **clk_zero_skew_route**
- **Bus** or **bus**
- **Shield (fix)** or **shield**

- **Shield (dynamic)** or **shield_dynamic**
- **Fill Track** or **clk_fill_track**
- **Unknown** or **unknown**

It is determined by Tcl variable `mw_attr_value_no_space` whether **get_attribute** or **report_attribute** returns `route_type` containing spaces or underscores. This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

width

Specifies width of a wire or path object in user units.

The data type of **width** is float.

This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

SEE ALSO

`get_attribute(2)`,
`list_attribute(2)`,
`report_attribute(2)`,
`set_attribute(2)`.

si_use_partial_grounding_for_min_analysis

Affects the behavior of **report_timing** and **compile** with crosstalk effect is enabled.

TYPE

Boolean

DEFAULT

false

GROUP

si_variables

DESCRIPTION

Affects the behavior, runtime, and CPU usage of **report_timing** and **compile**. When set to *true*, min crosstalk delta delay will be calculated with coupling capacitance partially grounded. When set to *false* (the default value), min crosstalk delta delay will be calculated with coupling capacitance fully grounded. To obtain the more accurate behavior of crosstalk timing analysis, set this variable to *true*.

To determine the current value of this variable, type **printvar fBsi_use_partial_grounding_for_min_analysis**. For a list of all **si** variables and their current values, type **print_variable_group si**.

SEE ALSO

report_timing(2)

si_variables(3)

si_variables

Variables that affect signal integrity analysis.

SYNTAX

Boolean **si_use_partial_grounding_for_min_analysis** = false

DESCRIPTION

These variables directly affect signal integrity analysis in **icc_shell**. Defaults are shown under Syntax.

For a list of si_variables, type **print_variable_group si**. To view an individual variable description, type **help var**, where *var* is the name of the variable.

si_use_partial_grounding_for_min_analysis

This variable is used to obtain more accurate crosstalk delay for min timing analysis. By default, this variable is false. When set to *true*, min crosstalk delta delay will be calculated with coupling capacitance partially grounded.

SEE ALSO

compile (2), **set_si_options** (2), **si_use_partial_grounding_for_min_analysis** (3).

si_xtalk_reselect_delta_and_slack

Reselect nets that satisfy both delta delay and slack reselection criteria.

TYPE

Boolean

DEFAULT

false

DESCRIPTION

When true, the intersection of sets of nets reselected by delta delay and slack based criteria is used. For a net to be reselected the following must be true: - The net is reselected by absolute delta delay AND - The net is reselected by relative delta delay AND - The net is reselected by setup OR hold slack

When true, the nets that satisfy only one of the above criteria (e.g., absolute delta) but not others (e.g., slack) are not reselected in the second iteration of SI analysis.

When false, the union of sets of nets reselected by delta delay and slack based criteria is used. For a net to be reselected the following must be true: - The net is reselected by absolute delta delay OR - The net is reselected by relative delta delay OR - The net is reselected by setup OR hold slack OR borrowing OR

To determine the current value of this variable, type **printvar si_xtalk_reselect_delta_and_slack**.

.

SEE ALSO

si_xtalk_reselect_max_mode_slack(3)
si_xtalk_reselect_min_mode_slack(3)
si_xtalk_reselect_delta_delay(3)
si_xtalk_reselect_delta_delay_ratio(3)

si_xtalk_reselect_delta_delay

Specifies the threshold of net delay change caused by crosstalk analysis, above which IC Compiler reselects the net for subsequent delay calculations.

TYPE

float

DEFAULT

5

DESCRIPTION

This variable specifies a reselection threshold in terms of absolute delta delay. Nets that have at least one net arc with a crosstalk-annotated delta delay above this threshold are selected for the next iteration of PrimeTime-SI delay calculations. The units are the time units of the main library of the design.

This variable is one of a set of four variables that determine net reselection criteria. The other three variables are as follows:

si_xtalk_reselect_delta_delay_ratio
si_xtalk_reselect_max_mode_slack
si_xtalk_reselect_min_mode_slack

To determine the current value of this variable, type **printvar si_xtalk_reselect_delta_delay**.

SEE ALSO

si_xtalk_reselect_delta_delay_ratio(3)
si_xtalk_reselect_max_mode_slack(3)
si_xtalk_reselect_min_mode_slack(3)

si_xtalk_reselect_delta_delay_ratio

Specifies the threshold of the ratio of net delay change caused by crosstalk analysis to the total stage delay, above which IC-Compiler reselects a net for subsequent delay calculations.

TYPE

float

DEFAULT

0.95

DESCRIPTION

This variable specifies a reselection threshold in terms of the delta delay ratio. Nets that have at least one net arc with a crosstalk-annotated delta delay, where the ratio of the annotated delta to the stage delay is above this threshold, are selected for the next iteration of SI delay calculations.

If a net has multiple stage delays (because of a net fanout greater than one or multiple cell arcs), IC-Compiler considers the stage delta delay and stage delay that result in higher delta to stage delay ratio, thus making reselection conservative.

This variable is one of a set of four variables that determine net reselection criteria. The other three variables are as follows:

```
si_xtalk_reselect_delta_delay  
si_xtalk_reselect_max_mode_slack  
si_xtalk_reselect_min_mode_slack
```

To determine the current value of this variable, type **printvar si_xtalk_reselect_delta_delay_ratio**.

SEE ALSO

```
si_xtalk_reselect_delta_delay(3)  
si_xtalk_reselect_max_mode_slack(3)  
si_xtalk_reselect_min_mode_slack(3)
```

si_xtalk_reselect_max_mode_slack

Specifies the max mode pin slack threshold, below which IC-Compiler reselects a net for subsequent delay calculations.

TYPE

float

DEFAULT

0

DESCRIPTION

This variable specifies the pin slack threshold in the max mode. Nets that have at least one pin with a max mode slack below this threshold are selected for the next iteration of SI delay calculations. Max-mode pin slack is the slack of the worst max-mode (setup) path through the pin. The units are the time units of the main library of the design.

This variable is one of a set of four variables that determine net reselection criteria. The other three variables are as follows:

- si_xtalk_reselect_delta_delay**
- si_xtalk_reselect_delta_delay_ratio**
- si_xtalk_reselect_min_mode_slack**

All four variables are ignored if the variable **si_xtalk_reselect_critical_path** is true.

To determine the current value of this variable, type **printvar si_xtalk_reselect_max_mode_slack**.

SEE ALSO

- si_xtalk_reselect_delta_delay(3)
- si_xtalk_reselect_delta_delay_ratio(3)
- si_xtalk_reselect_min_mode_slack(3)

si_xtalk_reselect_min_mode_slack

Specifies the min mode pin slack threshold, below which IC-Compiler reselects a net for subsequent delay calculations.

TYPE

float

DEFAULT

0

DESCRIPTION

This variable specifies the pin slack threshold in the min mode. Nets that have at least one pin with a min mode slack below this threshold are selected for the next iteration of SI delay calculations. Min-mode pin slack is the slack of the worst min-mode (hold) path through the pin. The units are the time units of the main library of the design.

This variable is one of a set of four variables that determine net reselection criteria. The other three variables are as follows:

si_xtalk_reselect_delta_delay
si_xtalk_reselect_delta_delay_ratio
si_xtalk_reselect_max_mode_slack

All four variables are ignored if the variable **si_xtalk_reselect_critical_path** is true.

To determine the current value of this variable, type **printvar si_xtalk_reselect_min_mode_slack**.

SEE ALSO

si_xtalk_reselect_delta_delay(3)
si_xtalk_reselect_delta_delay_ratio(3)
si_xtalk_reselect_max_mode_slack(3)

single_group_per_sheet

Specifies to the tool to put only one logic group on a sheet.

TYPE

Boolean

DEFAULT

false

GROUP

schematic_variables

DESCRIPTION

Specifies to the tool to put only one logic group on a sheet. Using this partitioning option set to *true* eliminates the possibility of more than one off-sheet connector with the same name being on a single sheet. The default value is *false*.

To determine the current value of this variable, type **printvar single_group_per_sheet**. For a list of all **schematic** variables and their current values, type **print_variable_group schematic**.

SEE ALSO

schematic_variables(3)

site_info_file

Contains the path to the site information file for licensing.

TYPE

string

DEFAULT

" "

DESCRIPTION

Contains the path to the site information file for licensing. The default is the empty string.

site_row_attributes

Contains attributes related to site row.

DESCRIPTION

Contains attributes related to site row.

You can use **get_attribute** to determine value of an attribute, and use **report_attribute** to get a report of all attributes on specified site row. Specified with **list_attribute -class site_row -application**, the definition of attributes can be listed.

Site Row Attributes

cell_id

Specifies Milkyway design ID in which a site row object is located.
This attribute is read-only.

name

Specifies name of a site row object.
This attribute is read-only.

object_class

Specifies object class name of a site row object, which is **site_row**.
This attribute is read-only.

object_id

Specifies object ID in Milkyway design file.
This attribute is read-only.

bbox

Specifies the bbox of a site row object.
This attribute is read-only.

bbox_ll

Specifies the lower-left of a site row object.
This attribute is read-only.

bbox_llx

Specifies x coordinate of the lower_left of the bbox a site row object.
This attribute is read-only.

bbox_lly

Specifies y coordinate of the lower_left of the bbox a site row object.
This attribute is read-only.

bbox_ur

Specifies the upper-right of the bbox of a site row object.
This attribute is read-only.

bbox_urx

Specifies x coordinate of the upper-right of the bbox a site row object.

site_row_attributes

This attribute is read-only.

bbox_ury

Specifies y coordinate of the upper-right of the bbox a site row object.
This attribute is read-only.

site_type

Specifies the type of site being defined.
This attribute is read-only.

orientation

Specifies the orientation of the sites. The value can be N, W, S, E, FN, FW, FS, FE.
This attribute is read-only.

direction

Specifies the direction of the row. The value can be v, h, vertical and horizontal.
This attribute is read-only.

site_count

Specifies the number of the sites in the row.
This attribute is read-only.

site_space

Specifies the space for each site, from the lower left corner of the site to the lower left corner of the next site. The value is specified in microns.
This attribute is read-only.

origin

Specifies the lower left corner of the row, regardless of orientation.
This attribute is read-only.

allowable_pattern

Specifies the restricted orientations of placed cells on a specified row, which are based on what direction of row is, whether row is flipped and what direction of unit tile is.
This attribute is read-only.

row_type

It is just a positive integer associated with site rows. Later on set_cell_row_type can be used to associate one particular cell with some particular rows of corresponding row_type.
This attribute can be read, set and removed.

is_ignored

TRUE: ignore specified site row FALSE: The specified site row is not ignored
The attribute can be read and set.

SEE ALSO

get_attribute(2),
list_attribute(2),
report_attribute(2).

skew_opt_skip_clock_balancing

Controls whether the **skew_opt** tcl solution file applies **set_inter_clock_delay_options** commands when sourced.

TYPE

Boolean

DEFAULT

false

GROUP

skew_opt_variables

DESCRIPTION

The **skew_opt** command makes relative changes in clock network latencies (skews) to increase timing slack in a design. The changes are written to an output file, also referred to as the "solution file", which contains three types of settings:

```
command group controlling variable -----
----- set_clock_latency skew_opt_skip_ideal_clocks set_clock_tree_exceptions
skew_opt_skip_propagated_clocks set_inter_clock_delay_options
skew_opt_skip_clock_balancing
```

Each type of command is grouped together and is applied only when the associated controlling variable is either *false* or undefined. Note that the controlling variables only affect which pieces of the solution file are active, not any behavior of the **skew_opt** command itself.

To determine the current value of the **skew_opt** variables, type **printvar skew_opt***.

SEE ALSO

skew_opt(2)

skew_opt_skip_ideal_clocks

Controls whether the **skew_opt** tcl solution file applies **set_clock_latency** commands when sourced.

TYPE

Boolean

DEFAULT

false

GROUP

skew_opt_variables

DESCRIPTION

The **skew_opt** command makes relative changes in clock network latencies (skews) to increase timing slack in a design. The changes are written to an output file, also referred to as the "solution file", which contains three types of settings:

```
command group controlling variable -----
----- set_clock_latency skew_opt_skip_ideal_clocks set_clock_tree_exceptions
skew_opt_skip_propagated_clocks set_inter_clock_delay_options
skew_opt_skip_clock_balancing
```

Each type of command is grouped together and is applied only when the associated controlling variable is either *false* or undefined. Note that the controlling variables only affect which pieces of the solution file are active, not any behavior of the **skew_opt** command itself.

To determine the current value of the **skew_opt** variables, type **printvar skew_opt***.

SEE ALSO

skew_opt(2)

skew_opt_skip_propagated_clocks

Controls whether the **skew_opt** tcl solution file applies **set_clock_tree_exceptions** commands when sourced.

TYPE

Boolean

DEFAULT

false

GROUP

skew_opt_variables

DESCRIPTION

The **skew_opt** command makes relative changes in clock network latencies (skews) to increase timing slack in a design. The changes are written to an output file, also referred to as the "solution file", which contains three types of settings:

```
command group controlling variable -----
----- set_clock_latency skew_opt_skip_ideal_clocks set_clock_tree_exceptions
skew_opt_skip_propagated_clocks set_inter_clock_delay_options
skew_opt_skip_clock_balancing
```

Each type of command is grouped together and is applied only when the associated controlling variable is either *false* or undefined. Note that the controlling variables only affect which pieces of the solution file are active, not any behavior of the **skew_opt** command itself.

To determine the current value of the **skew_opt** variables, type **printvar skew_opt***.

SEE ALSO

skew_opt(2)

sort_outputs

Sorts output ports on the schematic by port name.

TYPE

string

DEFAULT

false

GROUP

schematic_variables

DESCRIPTION

Sorts output ports on the schematic by port name.

To determine the current value of this variable, use **printvar sort_outputs**. For a list of all **schematic** variables and their current values, use the **print_variable_group schematic** command.

suffix_variables

Variables that define the standard suffixes for files used by the design and dft compilers.

SYNTAX

```
string view_analyze_file_suffix = {"v", "vhd", "vhdl"}
list view_execute_script_suffix = {".script", ".scr", ".dcs", ".dcsh", ".dc", ".con",
    ".wscr", ".rscr"}
list view_read_file_suffix = {"db", "sdb", "edif", "eqn", "fnc", "lsi", "mif", "NET",
    "pla", "st",
                                "tdl", "v", "vhd", "vhdl"}
list view_write_file_suffix = {"db", "sdb", "do", "edif", "eqn", "fnc", "lsi", "NET",
    "neted",
                                "pla", "st", "tdl", "v", "vhd", "vhdl", "xnf"}
```

DESCRIPTION

These variables define the standard suffixes for files used by the Synopsys design and dft compilers. File names with these suffixes are used by the Synopsys commands and **read** and **write** menus of the Design Analyzer viewer. Defaults are listed above, under Syntax.

For a list of these variables and their current values, type **print_variable_group suffix**. To view this manual page online, type **help suffix_variables**. To view an individual variable description, type **help var**, where *var* is the variable name.

view_analyze_file_suffix

A list of file extensions that specifies the files that are shown in the File/Analyze dialog.

view_execute_script_suffix

Used by the "Execute Script" option of the Setup menu and displays only files with these suffixes from directories you select in the option window.

view_read_file_suffix

Used by the "Read" option of the Design Analyzer File menu and displays only files with these suffixes from directories selected in the option window.

view_write_file_suffix

Used by the "Save As" option of the File menu and displays only files with these suffixes from directories selected in the option window.

SEE ALSO

design_analyzer (1).

suppress_errors

Specifies a list of error codes for which messages are to be suppressed during the current Design Analyzer/dc_shell session.

TYPE

list

DEFAULT

PWR-18 OPT-932 OPT-317 RCCALC-010 RCCALC-011

GROUP

system_variables

DESCRIPTION

Specifies a list of error codes for which messages are to be suppressed during the current Design Analyzer/dc_shell session. Default is set to no error message being suppressed.

To determine the current value of this variable, use **printvar suppress_errors**. For a list of all **system** variables and their current values, use the **print_variable_group system** command.

symbol_library

Specifies the symbol libraries to use during schematic generation.

TYPE

string

DEFAULT

your_library.sdb

GROUP

schematic_variables

DESCRIPTION

Specifies the symbol libraries to use during schematic generation. This variable is a list of symbol library names.

To determine the current value of this variable, use **printvar symbol_library**. For a list of all **schematic** variables and their current values, use the **print_variable_group schematic** command.

synlib_variables

SYNTAX

```
string cache_dir_chmod_octal = "777"
string cache_file_chmod_octal = "666"
list cache_read = {"/remote/release/v3.1/libraries/syn", "~"}
Boolean cache_read_info = "false"
string cache_write = "~"
Boolean cache_write_info = "false"
Boolean mgc_scratch_directory "designware_generator"
Boolean synlib_disable_limited_licenses = "true"
list synlib_dont_get_license = {}
Boolean synlib_evaluation_mode = "false"
string synlib_model_map_effort = "low"
Boolean synlib_optimize_non_cache_elements = "true"
Boolean synlib_prefer_ultra_license = "false"
string synlib_sequential_module = "default"
list synlib_wait_for_design_license = {}
list synthetic_library = {}
Boolean synlib_dwgen_smart_generation = "true"
Boolean compile_report_dp = "false"
```

DESCRIPTION

Cache files are created with their mode bits set to the value of **cache_file_chmod_octal**. These variables directly affect the **cache_ls** command.

For a list of these variables and their current values, type **print_variable_group synlib**. To view this manual page online, type **help synlib_variables**. To view an individual variable description, type **help var**, where *var* is the variable name.

cache_dir_chmod_octal

A string that is translated to an octal number and sets the mode for the cache directory. There are separate variables for directories and files to allow the sticky bit to be set.

cache_file_chmod_octal

A string that is translated to an octal number and sets the mode for the cache file.

cache_read

A list of directories. Each directory can contain a cache that will be read from whenever a cache entry is needed.

cache_read_info

When *true*, an informational message will be printed each time a cache element is read. The default is *false*.

cache_write

The name of the directory where optimized and unoptimized synlib parts are written, if they are not already in the cache.

cache_write_info

When *true*, an informational message will be printed each time a cache element is written. The default is *false*.

mgi_scratch_directory

Specifies a directory in which to store the intermediate files created by external generator(s). The default is *designware_generator* in the current directory.

synlib_disable_limited_licenses

When *true* (the default), limited licenses for synthetic library parts are not considered. No limited licenses will be checked out automatically. Limited licenses will not enable synthetic library parts.

synlib_dont_get_license

Specifies a list of synthetic library part licenses that are not automatically checked out. By default, all synthetic library part licenses are automatically checked out if there is a possibility that they will be used.

synlib_evaluation_mode

When no Designware-Basic or Designware-FPGA-Basic keys are available, you can still evaluate synthetic library parts by setting this variable to "true". When this variable is set, you will be authorized for almost the same capabilities that Designware-Basic would provide. The only difference is that all DesignWare parts and the level of hierarchy that contains them will automatically be given a limited license. This means that it will be impossible to write out any DesignWare part (including standard parts) or any design that contains a DesignWare part. You will still be able to print reports that show the timing (*report_timing*) and the implementation selections made (*report_resource*).

synlib_model_map_effort

Determines the **map_effort** used during the modeling of synthetic library parts. Allowed values are *low* (the default value), *medium*, and *high*.

synlib_optimize_non_cache_elements

When *true* (the default value), creates and optimizes part descriptions of non-cached models (that is, models that cannot be retrieved from the cache). When *false*, the non-cached part description is created and used in an unoptimized form.

synlib_sequential_module

Controls the amount of processing to be done during resource sharing and implementation selection by **compile** on synthetic library modules that have implementations with sequential elements. Allowed values are *default* (the default), *iis_processing*, *one_implementation_choice*, and *multiple_implementation_choices*. These values are described in the **synlib_sequential_module** manual page.

synlib_prefer_ultra_license

When *true*, any use of Foundation library parts sets the Design Compiler ultra optimization mode and checks out the DesignWare-Foundation-Ultra license instead of the DesignWare-Foundation license. When *false* (the default), the DesignWare-Foundation license is used when Design Compiler is not in the

synlib_variables

ultra optimization mode.

synlib_wait_for_design_licenses

Specifies a list of authorized synthetic library part licenses to be waited for. By default, Design Compiler terminates the command when none of the required design licenses are available. When this variable is *true*, Design Compiler waits for the licenses on the list to become available and continues with the process instead of terminating the command.

synlib_dwgen_smart_generation

When *true*, DesignWare arithmetic generators try to use a *smart* strategy to build implementations of arithmetic parts or datapath blocks. The exact strategy used depends on the variable **synlib_dwgen_smart_generation_options**. When *false*, a simple strategy is used.

synlib_dwgen_smart_generation_options

The value of this variable controls the different *smart* generation strategies in the DesignWare arithmetic generators. Specific values are described in the **synlib_dwgen_smart_generation_options.3** manual page.

synthetic_library

A list of synthetic libraries to use when compiling.

compile_report_dp

Generates a detailed datapath extraction report during compile. This feature is available only in DC Ultra flow.

SEE ALSO

cache_ls (2).

syntax_check_status

Reports whether the **syntax_check** mode is enabled.

TYPE

Boolean

DEFAULT

false

GROUP

system_variables

DESCRIPTION

Reports whether the **syntax_check** mode is enabled. This is a read-only variable and the user cannot set it. This variable is one of a pair of status variables, **syntax_check_status** and **context_check_status**, whose values are set by the syntax checker and not by the user. You examine these variables to determine the status of the **syntax_check** or **context_check** mode of the syntax checker.

A value of *true* indicates that the mode is enabled. A value of *false* (the default) indicates that the mode is disabled. For example, a value of **syntax_check_status = true** indicates that the **syntax_check** mode is enabled. The two modes cannot be enabled simultaneously. These two status variables, **syntax_check_status** and **context_check_status**, allow you to determine whether one mode is enabled before you attempt to enable the other mode.

You enable or disable the **syntax_check** and **context_check** modes by executing the commands **syntax_check** or **context_check**. Alternatively, you can invoke **dc_shell**, **design_compiler**, and **dp_shell** in either the **context_check** or **syntax_check** mode by using the **-syntax_check** or **-context_check** options when you invoke the tool. For more information, refer to the manual pages of these commands or to the *Design Compiler Reference Manual*.

To determine the value of this variable, type **printvar syntax_check_status** or **echo syntax_check_status**. For a list of **system** variables and their current values, type **print_variable_group system**.

SEE ALSO

dc_shell(1)
design_analyzer(1)
dp_shell(1)
syntax_check(2)
context_check_status(3)
system_variables(3)

syntax_check_status

synthetic_library

Specifies a list of synthetic libraries to use when compiling.

TYPE

list

DEFAULT

" "

GROUP

system_variables, synlib_variables

DESCRIPTION

Specifies a list of synthetic libraries to use when compiling. Default is {}.

The **synthetic_library** variable works much like the **target_library** variable does for technology libraries. This variable can be set to be a list of zero or more sldb files that you wish to use in the **compile** or **replace_synthetic** commands. When synthetic operators or modules are processed in compile, the operators, bindings, modules, and implementations of the specified library or libraries are used. Synthetic libraries are processed in order. So, if two modules in different libraries have the same name, the module in the first listed library is used.

As with target technology libraries, it is sometimes necessary to include your synthetic library as part of the link_library set. This is especially important when you instantiate synthetic modules.

Because HDL files automatically insert synthetic operators in a netlist, it is important to have a synthetic library defined that supports these operators. For this reason the standard Synopsys library **standard.sldb** is automatically inserted as the first entry in the **synthetic_library** variable list. Then if a synthetic library is specified to be an empty list, the insertion of **standard.sldb** provides default definitions.

There is no way to disable the standard synthetic library, but you can disable individual modules or implementations by using the **dont_use** command. To replace a particular implementation, disable it with **dont_use**, and use a replacement from your own synthetic library.

To determine the current value of this variable, use **printvar synthetic_library**. To see a list of all **system** variables and their current values, use the **print_variable_group system** command.

SEE ALSO

target_library(3)

system_variables

SYNTAX

```
Boolean auto_link_disable = "false"
string auto_link_options = "-all"
Boolean change_names_dont_change_bus_members = "false"
string command_log_file = "./command.log"
string company = ""
string compatibility_version = ""
Boolean context_check_status = true/false
string current_design = "<<undefined>>"
string current_instance = "<<undefined>>"
(any type) dc_shell_status = 1
string default_name_rules = ""
string designer = ""
Boolean echo_include_commands = "true"
Boolean enable_page_mode = "true"
string exit_delete_filename_log_file = "true"
string filename_log_file = "filenames.log"
Boolean find_convert_name_lists = "false"
string link_force_case = "check_reference"
list link_library = {your_library.db}
list search_path = { . synopsys_root + "/libraries" }
list suppress_errors = {}
Boolean syntax_check_status = true/false
list synthetic_library = {}
list target_library = {your_library.db}
string uniquify_naming_style = "%s_%d"
Boolean verbose_messages = "false"
```

DESCRIPTION

These variables directly affect Synopsys Design Compiler and DFT Compiler commands.

For a list of these variables and their current values, type **print_variable_group system**. To view this manual page online, type **help system_variables**. To view an individual variable description, type **help var**, where *var* is the variable name.

auto_link_disable

when *true*, disables automatic linking of the design. Several Design Compiler and DFT Compiler commands (including **create_schematic** and **compile**) issue the **link** command automatically. During the execution of scripts containing thousands of **set_load** and **set_resistance** commands, the overhead of automatic linking can be significant. This variable can be used in this situation to speed up the execution of such scripts. The default is *false*.

auto_link_options

Specifies the **link** command options to be used when **link** is invoked automatically by various Design Compiler and DFT Compiler commands (for example, **create_schematic** and **compile**). The default is **-all**. To find the available options, refer to the **link** command manual page.

`change_names_dont_change_bus_members`

This variable is for the **change_names** command. It affects bus members only of bussed ports or nets. When *false* (the default), **change_names** gives bus members the base name from their owning bus. For example, if BUS A has range 0 to 1 with the first element NET1 and the second element NET2, **change_names** changes NET1 to A[0] and NET2 to A[1]. When this variable is set to *true*, **change_names** does not change the names of bus members, so that NET1 and NET2 remain unchanged.

`command_log_file`

Names the file to which a log of the initial values of variables and commands executed is to be written. If the value is an empty string, a command log file is not created.

`company`

Names the company where Synopsys software is installed. The company name is displayed on the schematics.

`compatibility_version`

The name of the Synopsys software version to which the default behavior of the system should be set. This provides compatibility for script command files written in previous software versions. The scripts actually are run on the current version of the software, so results are usually better. However, the script performs the same default actions as it did on the specified software version.

`context_check_status`

One of a pair of status variables, **syntax_check_status** and **context_check_status**, whose values are set by the Syntax Checker and not by the user. A value of *true* indicates that the context_check mode is currently enabled; a value of *false* indicates that the mode is disabled.

`current_design`

The name of the design to be worked on. This variable is used by most of the Synopsys commands. Until a design is read into the system as the **current_design**, the value of **current_design** is "<<undefined>>". When one or more designs are read into the system, any of them can be made current by assigning the design name to this variable.

`current_instance`

The name of the instance to be worked on. Until a design is read into the system as the **current_design**, the value of the **current_instance** is "<<undefined>>". When a design is read into the system at the top hierarchical level, the value of **current_instance** is the top design name followed by a slash.

`dc_shell_status`

Contains the return value of the previously executed command. Therefore, the variable can be of any type. Most commands return the integer 0 to indicate failure or 1 to indicate successful execution. This variable is most often used as the conditional expression of an **if** or **while** command.

`default_name_rules`

Contains the name of a name_rules file to be used as a default by **change_names** if a name_rules file is not specified using the **-rules name_rules** option.

change_names changes the names of ports, cells, and nets to conform to the rules contained in the file specified by **default_name_rules**. For information on the format and creation of a name_rules file, refer to the **change_names** manual page.

designer

The name of the current user. This name is displayed on the schematics.

echo_include_commands

When *true* (the default value), the **include** command prints the contents of files that it executes. When *false*, contents are not printed.

enable_page_mode

When *true* (the default value), long reports are displayed one page at a time (similar to the UNIX **more** command). Commands affected by this variable include the **list**, **help**, and **report** commands.

exit_delete_filename_log_file

When *true* (the default value), causes the file specified by the variable **filename_log_file** to be deleted after **design_analyzer** or **dc_shell** exits normally. Set **exit_delete_filename_log_file** to *false* if you want the file to be retained.

filename_log_file

Specifies the name of the filename log file to be used in case a fatal error occurs during the execution of **design_analyzer** or **dc_shell**. The file specified by **filename_log_file** will contain all the filenames read in by **design_analyzer** or **dc_shell**, including db, script, verilog, vhdl or include files for one invocation of the program. If there is a fatal error, you can easily identify the data files needed to reproduce the fatal error. If this variable is not specified, the default filename **files.log** will be used. This file will be deleted if the program exits normally, unless **exit_delete_filename_log_file** is set to *false*.

find_converts_name_lists

When *true*, directs the **find** command to convert the *name_list* string to a list of strings before searching for design objects. In addition, when this variable is *true*, all commands that use the implicit **find** will convert appropriate strings to lists of strings before searching for objects. When the variable is *false* (the default value), strings are not converted to lists of strings.

link_force_case

Controls the case-sensitive or case-insensitive behaviour of the **link** command. Values are *case_sensitive*, *case_insensitive*, or *check_reference*. The default is *check_reference*, which causes **link** to check and enforce the case sensitivity of the input format that created the reference.

link_library

Specifies the list of design files and libraries used during linking. The **link** command looks at those files and tries to resolve references in the order of specified files. If file names do not include directory names, files are searched for in the directories in **search_path**. The default is {your_library.db}. You should change this to reflect your library name.

system_variables

`search_path`

Specifies directories searched by the Design Compiler and DFT Compiler for files specified without directory names. This includes looking for technology and symbol libraries, design files, and so forth. This variable is a list of directory names and is usually set to a central library directory.

`suppress_errors`

Specifies a list of error codes for which messages are to be suppressed during the current Design Analyzer/**dc_shell** session. The default is set to no error message being suppressed.

`syntax_check_status`

One of a pair of status variables, **syntax_check_status** and **context_check_status**, whose values are set by the Syntax Checker and not by the user. A value of *true* indicates that the `syntax_check` mode is currently enabled; a value of *false* indicates that the mode is disabled.

`synthetic_library`

Specifies a list of synthetic libraries to use when compiling. The default is {}.

`target_library`

Specifies the list of technology libraries of components used when compiling a design. The default is {your_library.db}. You should change this to reflect your library name.

`uniquify_naming_style`

Specifies the naming convention used by **uniquify**. The variable string must contain only one %s (percent s) and %d (percent d) character sequence. To use a percent sign in the design name, two are needed in the string (%%).

`verbose_messages`

When *true*, causes more explicit system messages to be displayed during the current Design Analyzer/**dc_shell** session. The default is *false*.

SEE ALSO

dc_shell (1), **change_names** (2), **compile** (2), **context_check** (2), **create_schematic** (2), **current_instance** (2), **current_design** (2), **find** (2), **help** (2), **if** (2), **include** (2), **link** (2), **list** (2), **report** (2), **syntax_check** (2), **uniquify** (2), **while** (2).

systemcout_debug_mode

TYPE

Boolean

DEFAULT

false

GROUP

scc_variables

DESCRIPTION

This variable is to be used only when the **systemcout_levelize** variable is set to *true*, to generate debug information.

When **systemcout_debug_mode** is *true*, and if **systemcout_levelize** is also *true*, Behavioral Compiler, when generating levelized RTL SystemC code for simulation, inserts additional code to write out debugging information during the RTL simulation run. When **systemcout_debug_mode** is *false* (the default), Behavioral Compiler does not insert this additional code.

The debugging information written out during simulation includes the following:

1. A SystemC process tracing the execution of the state machine in the RTL design. This process contains variables that can be monitored within the debugger/simulator, to obtain the following information:
 - o The current state of the state machine
 - o Which loop in the behavior is currently being executed
 - o The number of clock cycles used so far in the current loop
2. Assertion warnings about registers that are being set to unknown values.
3. Assertion warnings about multiplexers whose control inputs have invalid values.
4. A trace of all memory reads and writes, which includes the address and data being read or written. For memory locations being set to unknown values, a warning is issued.
5. A trace of all I/O operations, which includes the design name, the port name, the scheduled control step, the value read or written, and the simulation cycle.
6. When an input port has had automatic register allocation disabled using the **bc_dont_register_input_port** command, a value on that port is supposed to remain constant. Therefore, if the value on such a port changes, a warning message is issued.

Note: To enable features 5 and 6, you must set this variable to *true* before invoking the **schedule** command.

EXAMPLES

The following example shows a section of the process tracing the state machine execution.

```
// Calculate the state of the FSM
state_bits[5] = n219 ;
state_bits[4] = n220 ;
state_bits[3] = n221 ;
state_bits[2] = n222 ;
state_bits[1] = n223 ;
state_bits[0] = n224 ;

if ( state_bits == "100000" ) {
    state = "s_0_0";
}
.
.
.
} else {

    cout << "FSM 'entry_ctl_state' is in an unknown state"\
    << " at simulation time : " << sc_time_stamp() << endl;
    state = "UNKNOWN";
}
```

Use *state* to monitor the current state of the state machine, *current_loop* to monitor the current loop being executed, and the variable named after the current loop (for example, **reset_loop**) to monitor the clock cycles used in the loop.

The following example shows an assertion warning about a register being set to an unknown value.

Register 'out_valuel_reg_Q' has been set to X's

The following example shows a warning about invalid multiplexer settings.

Control lines of selector s_out_valid_reg_controls have non 0/1 values

The following example shows a report of a memory write.

```
r1_Q is writing to memory RAM_A[seq_cell_5_ADDR]
seq_cell_5_ADDR = 0
```

```
RAM_A[seq_cell_5_ADDR] = 506  r1_Q = 506 at simulation time: 190
```

The following is an example of I/O tracing.

```
if1: (cycle: 75)  READin_valid@cstep0x11
if1: (cycle: 76)  READin_value2@cstep0x356
if1: (cycle: 76)  READcontrol_in@cstep0x31
if1: (cycle: 77)  WRITEout_value1@cstep0x428
if1: (cycle: 77)  WRITEout_valid@cstep0x40
```

The following is an example of the warning on the value change on port `in_value1`, for which automatic register allocation has been disabled using the **`bc_dont_register_input_port`** command.

```
Warning: The value on port in_value1 (w/
bc_dont_register_input_port set) has changed.
```

SEE ALSO

```
systemcout_levelize(3)
```

systemcout_levelize

Levelizes and flattens the netlist and replaces standard DesignWare operations with simulatable SystemC, before writing out the netlist, during **write -f systemc** command activity.

TYPE

string

DEFAULT

true

GROUP

scc_variables

DESCRIPTION

Levelizes and flattens the netlist (when true) and replaces standard DesignWare operations with simulatable SystemC, before writing out the netlist, during **write -f systemc** command activity.

In a levelized netlist, combinational gates are written before any combinational gates that they feed. Thus the netlist can be written out as SC_METHOD processes sensitive to the clock, generating fewer simulation events to be processed by the simulator. Because the processing of simulation events is very time-consuming, reducing the number of these events results in faster simulation time. Note that the hierarchical levels in the design are removed.

The command **write -f systemc** does not produce a synthesizable (nonlevelized) output written in the SystemC language. To generate synthesizable RTL level output, use the **write -f verilog** or **write -f vhd1** commands.

NOTE: Setting this variable to true has no effect if the design has not been run through SystemC/Behavioral Compiler, or if the design has been mapped. Also, designs that contain combinational feedback cannot be levelized.

To determine the current value of this variable, type **printvar systemcout_levelize**.

SEE ALSO

`write(2)`
`systemcout_debug_mode(3)`

target_library

Specifies the list of technology libraries of components to be used when compiling a design.

TYPE

list

DEFAULT

your_library.db

GROUP

system_variables

DESCRIPTION

Specifies the list of technology libraries of components to be used when compiling a design. The default is {your_library.db}. Change this value to reflect your library name.

To determine the current value of this variable, use **printvar target_library**. For a list of all **system** variables and their current values, use the **print_variable_group system** command.

SEE ALSO

system_variables(3)

template_naming_style

Generates automatically a unique name when a module is built.

TYPE

string

DEFAULT

GROUP

hdl_variables

DESCRIPTION

Generates automatically a unique name when a module is built. This variable is one of three string variables that determine the naming conventions for parameterized modules (templates) built into a design through the **elaborate** command or automatically instantiated from an HDL file. The unique name automatically generated uses the module name, parameter names, and parameter values.

The **template_naming_style** variable determines what character or characters appear between the design name and the parameter name. The string value must contain %s, which stands for the name of the original design, and %p, which stands for the name and value of the parameter or parameters. You can optionally include any ASCII character or characters, or none, between %s and %p. For example, for a design named *DesignName* that has a parameter *parm1*, the default %s_%p causes the name **DesignName_parm1** to be generated.

Further, %s\$p, %s*_%p, and %s%p would generate respectively the names **DesignName\$parm1**, **DesignName_*_parm1**, and **DesignNameparm1**.

If a design has a noninteger parameter (or if **template_naming_style** = ""), the following definitions are locked down for these variables:

```
template_naming_style = %s_%p
template_parameter_style = %d
template_separator_style = _
```

To determine the current value of this variable, type **printvar template_naming_style**. For a list of all **hdl** variables and their current values, type **print_variable_group hdl**.

SEE ALSO

```
hdl_variables(3)
template_parameter_style(3)
template_separator_style(3)
```

template_parameter_style

Generates automatically a unique name when a module is built.

TYPE

string

DEFAULT

GROUP

hdl_variables

DESCRIPTION

Generates automatically a unique name when a module is built. This variable is one of three string variables that determine the naming conventions for parameterized modules (templates) built into a design through the **elaborate** command or automatically instantiated from an HDL file. The unique name automatically generated uses the module name, parameter names, and parameter values.

The **template_parameter_style** variable determines what character or characters appear between the parameter name and its value.

The string must contain %s, which stands for the name of the parameter, and %d, which stands for the value of the parameter. You can optionally include any ASCII character or characters, or none, between %s and %d. For example, for a parameter named *parm* that has a value of *1*, the default %s%d causes the name **parm1** to be generated.

Other examples:

```
template_naming_style = "%s$p"  
template_parameter_style = %s_%d    results in DesignName$parm_1
```

```
template_naming_style = "%s_%p"  
template_parameter_style = %s@%d    results in DesignName_parm@1
```

If a design has a noninteger parameter (or if **template_naming_style** = ""), the following definitions are locked down for these variables:

```
template_naming_style = %s_%p  
template_parameter_style = %d  
template_separator_style = _
```

To determine the current value of this variable,
type **printvar template_parameter_style**.

For a list of all **hdl** variables and their current values,
type **print_variable_group hdl**.

SEE ALSO

`hdl_variables(3)`
`template_naming_style(3)`
`template_separator_style(3)`

template_separator_style

Generates automatically a unique name when a module is built.

TYPE

string

DEFAULT

—

GROUP

hdl_variables

DESCRIPTION

Generates automatically a unique name when a module is built. This variable is one of three string variables that determine the naming conventions for parameterized modules (templates) built into a design through the **elaborate** command or automatically instantiated from an HDL file. The unique name automatically generated uses the module name, parameter names, and parameter values.

The **template_separator_style** variable determines what character or characters appear between parameter names for templates that have more than one parameter. You can designate any ASCII character or characters, or none. The default value is an underscore (_).

For example, for a design called *DesignName* that has parameters named *parm1*, *parm2*, and *parm3*, if **template_naming_style** = "**%s_%p**" (the default value), and **template_separator_style** = "_", the name **DesignName_parm1_parm2_parm3** is generated.

Other examples:

```
template_naming_style = "%s$p"
template_separator_style = "_"      results in DesignName$parm1_parm2_parm3
```

```
template_naming_style = "%s#p"
template_separator_style = "/"      results in DesignName#parm1/parm2/parm3
```

If a design has a noninteger parameter (or if **template_naming_style** = ""), the following definitions are locked down for these variables:

```
template_naming_style = %s_%p
template_parameter_style = %d
template_separator_style = _
```

To determine the current value of this variable,
type **printvar template_separator_style**.

template_separator_style

For a list of all **hdl** variables and their current values,
type **print_variable_group hdl**.

SEE ALSO

`hdl_variables(3)`
`template_naming_style(3)`
`template_parameter_style(3)`

terminal_attributes

Contains attributes related to terminal.

DESCRIPTION

Contains attributes related to terminal.

You can use **get_attribute** to determine value of an attribute, and use **report_attribute** to get a report of all attributes on specified object. Specified with **list_attribute -class terminal -application**, the definition of attributes can be listed.

Terminal Attributes

access_direction

Specifies allowable access directions for a terminal object.
The data type of **access_direction** is string.
Its valid values are:

- **right**
- **left**
- **up**
- **down**
- **unknown**

This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

bbox

Specifies the bounding-box of a terminal. The **bbox** is represented by a **rectangle**.

The format of a *rectangle* specification is {{llx lly} {urx ury}}, which specifies the lower-left and upper-right corners of the rectangle.

The data type of **bbox** is string.

This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

bbox_ll

Specifies the lower-left corner of the bounding-box of a terminal.

The **bbox_ll** is represented by a **point**. The format of a *point* specification is {x y}.

terminal_attributes

You can get the **attr_name** of a terminal, by accessing the first element of its **bbox**.

The data type of **bbox_ll** is string.

This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

bbox_llx

Specifies x coordinate of the lower-left corner of the bounding-box of a terminal.

The data type of **bbox_llx** is double.

This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

bbox_lly

Specifies y coordinate of the lower-left corner of the bounding-box of a terminal.

The data type of **bbox_lly** is double.

This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

bbox_ur

Specifies the upper-right corner of the bounding-box of a terminal.

The **bbox_ur** is represented by a **point**. The format of a *point* specification is {x y}.

You can get the **bbox_ur** of a terminal, by accessing the second element of its **bbox**.

The data type of **bbox_ur** is string.

This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

bbox_urx

Specifies x coordinate of the upper-right corner of the bounding-box of a terminal.

The data type of **bbox_urx** is double.

This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

bbox_ury

Specifies y coordinate of the upper-right corner of the bounding-box of a terminal.

The data type of **bbox_ury** is double.

This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

cell_id

Specifies Milkyway design ID in which a terminal object is located.

The data type of **cell_id** is integer.

This attribute is read-only.

constrained_status

Specifies constrained status of a terminal object.

The data type of **constrained_status** is string.

Its valid values are:

- **manual_created**

- **side**

- **location**

- **order**

- **unknown**

This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

direction

Specifies direction of a terminal object.
The data type of **direction** is string.
Its valid values are:

- **in**

- **out**

- **inout**

- **tristate**

- **unknown**

- **input**

- **output**

This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

eeq_class

Specifies electrically equivalent class of a terminal object.
The data type of **eeq_class** is integer.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

terminal_attributes

is_fixed

Specifies whether a terminal object is marked as fixed.
The data type of **is_fixed** is boolean.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

layer

Specifies layer name of a terminal object.
The data type of **layer** is string.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

must_join_class

Specifies must-join class of a terminal.
The data type of **must_join_class** is integer.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

name

Specifies name of a terminal object.
The data type of **name** is string.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

number_of_points

Specifies the number of points to illustrate the boundary of a terminal object.
The data type of **number_of_points** is integer.
You can refer to the attribute **points**. The list length of **points** is the value of **number_of_points**.
This attribute is read-only.

object_class

Specifies object class name of a terminal, which is **terminal**.
The data type of **object_class** is string.
This attribute is read-only.

object_id

Specifies object ID in Milkyway design file.
The data type of **object_id** is integer.
This attribute is read-only.

owner

Specifies Milkyway design file name in which a terminal is located.
The data type of **owner** is string.
This attribute is read-only.

owner_port

Specifies port name which a terminal object is associated with.
The data type of **owner_port** is string.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

points

Specifies points of the boundary of a terminal. A terminal can be a rectangle,

a rectilinear polygon, or multiple rectangles.

When a terminal is either a rectangle or a rectilinear polygon, its **points** is represented by a list of points. The last element of the list is the same as the first element.

When a terminal consists of multiple rectangles, its **points** is represented by a list of points of rectangles. Every five points represent one rectangle. The data type of **points** is string.

This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

side_status

Specifies constrained side name.

The data type of **side_status** is string.

Its valid values are:

- **left**
- **right**
- **bottom**
- **top**
- **unknown**

This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

status

Specifies PR status of a terminal object.

The data type of **status** is string.

Its valid values are:

- **fixed**
- **placed**
- **cover**
- **unplaced**

This attribute is writable. You can use **set_attribute** to modify its value on

a specified object.

SEE ALSO

`get_attribute(2)`,
`list_attribute(2)`,
`report_attribute(2)`,
`set_attribute(2)`.

test_variables

SYNTAX

```
string test_allow_clock_reconvergence = "true"
string test_capture_clock_skew = "small_skew"
Boolean test_check_port_changes_in_capture = true
float test_default_bidir_delay = 5.000000
float test_default_delay = 5.000000
float test_default_period = 100.000000
string test_default_scan_style = "multiplexed_flip_flop"
float test_default_strobe = 95.000000
float test_default_strobe_width = 0.000000
string test_infer_slave_clock_pulse_after_capture = "infer"
Boolean test_mbc_memory_driven_spec = "false"
string test_protocol_add_cycle = true
Boolean test_setup_additional_clock_pulse = "false"
Boolean test_dft_drc_ungate_clocks = "false"
Boolean test_stil_multiclock_capture_procedures = "false"
string test_stil_netlist_format = "db"
Boolean test_write_four_cycle_stil_protocol "false"
```

DESCRIPTION

These variables directly affect the **set_test_methodology**, **read_test_protocol**, **check_test**, **create_test_patterns**, **insert_dft**, and **write_test** commands.

For a list of these variables and their current values, type **print_variable_group test**. To view this manual page online, type **help test_variables**. To view an individual variable description, type **help var**, where var is the name of the variable.

test_allow_clock_reconvergence

When *true* (the default), **check_test** allows reconvergent nets that originate from the same top-level clock port; that is, it does not generate an X when multiple edges reconverge at a net, unless the edges actually conflict. When *false*, **check_test** automatically assigns an X (unknown) whenever multiple edges meet at a gate or net.

test_capture_clock_skew

Allows the user to specify a qualitative measure of clock skew. Values are **no_skew**, **small_skew** (the default), or **large_skew**. For definitions of these values, refer to the **test_capture_clock_skew** manual page.

Because **check_test** does not take into account the delays through capture paths or the skew between clocks, DFT Compiler may inadvertently merge capture groups that should remain disjointed, resulting in bad generated patterns. The variable **test_capture_clock_skew** provides coarse control over the inference process by letting the user specify the amount of clock skew to be assumed.

test_check_port_changes_in_capture

When *true* (the default), **check_test** checks for changes in values applied to bidirectional ports in the parallel measure cycle, which can cause an

unreliable capture in sequential cells. When *false*, these checks are disabled.

`test_default_bidir_delay`

A positive real number in nanoseconds, which defines the default switching time of bidirectional ports in a tester cycle. This variable is used by both ATPG and TestSim. For ATPG, **`test_default_bidir_delay`** defines for the design under test the default time at which values are applied (driven) to the bidirectional ports in input mode during parallel measure cycle, and the time at which bidirectional ports are released (undriven) during capture cycle. The value of **`test_default_bidir_delay`** must be less than the output strobe time, and greater than the capture clock active edge value. For TestSim, **`test_default_bidir_delay`** defines the default input delay for bidirectional ports in input mode. You should set this variable to the value that was actually used to generate the vectors being input to TestSim; however, the value of this variable must be less than the test clock period.

`test_default_delay`

A positive real number in nanoseconds, which defines the default time in a tester cycle to apply values to input ports. This variable is used by both ATPG and TestSim. For ATPG, **`test_default_delay`** defines for the design under test the default time at which values are applied (driven) to the primary inputs. The value of **`test_default_delay`** must be less than the output strobe time, and less than the capture clock edge value. For TestSim, **`test_default_delay`** defines the default input delay for primary inputs. You should set this variable to the value that was actually used to generate the vectors being input to TestSim; however, the value of this variable must be less than the clock period.

`test_default_period`

A nonzero value, in nanoseconds, that defines the default length of a test vector cycle. This value translates directly to the speed of application of the test vectors on ATE.

`test_default_scan_style`

Defines the default **`insert_dft`** scan style, to use if a scan style is not specified using **`set_scan_style`**. The variable must identify a supported scan style; currently one of *multiplexed_flip_flop*, *clocked_scan*, *lssd*, *aux_clock_lssd*, *combinational*, or *none*. The default is *multiplexed_flip_flop*.

`test_default_strobe`

A positive real number in nanoseconds, which defines the default strobe time in a tester cycle for output and bidirectional ports in output mode. This variable is used by both ATPG and TestSim. For ATPG, **`test_default_delay`** defines for the design under test the default time at which values are strobed on the primary outputs and bidirectional ports in output mode. The value of this variable must be less than or equal to the clock period value. For TestSim, **`test_default_strobe`** defines the default output strobe time for primary outputs and bidirectional ports acting as outputs. The value of this variable must be less than the clock period.

`test_default_strobe_width`

A nonzero value, in nanoseconds, that defines the default strobe pulse width; that is, the default time that specifies how long the strobe pulse needs to be held active after invocation. The sum of this value and the strobe time

value must be less than or equal to the clock period value.

`test_infer_slave_clock_pulse_after_capture`

When set to *infer* (the default value), **check_test** protocol inference will be based on an analysis of the scan cell states instead of the scan style as it was previously done (1997.01 and earlier releases). The other values are *pulse* and *no_pulse*. If you set the variable to *pulse*, all slave clocks are pulsed after capture. If you set it to *no_pulse*, no slave clocks are pulsed after capture.

`test_mbc_memory_driven_spec`

When set to true, memory-driven spec mode is enabled for MBIST Tech2. This takes the synthesized test specification away from the user and puts it in the hands of the memory model provider.

`test_protocol_add_cycle`

When *true* (the default), if you specify design bidirectional ports as inputs during the scan shift, **check_test** adds an extra cycle after the shift cycle in the test protocol. In the extra cycle, all bidirectional ports are set to output mode. If you do not want **check_test** to add the extra cycle, set this variable to **false**.

`test_setup_additional_clock_pulse`

When this variable is set to true, an extra clock cycle is added to all clocks in the design in the initialization procedure during execution of the **create_test_protocol** command. The extra cycle ensures that all clock gating latches are at a known state at the end of the initialization procedure.

`test_stil_multiclock_capture_procedures`

When *true*, the **write_test_protocol -format stil** command creates capture procedures in the STIL protocol with multiple clocks active in each procedure. The groups of clocks (capture clock groups) are determined by **check_test**. When *false* (the default), **write_test_protocol** places only one clock pulse in each capture clock procedure.

`test_stil_netlist_format`

Specifies the netlist format to be used by the **write_test_protocol** command when writing out STIL protocol files. Allowed values are *db* (the default), *verilog*, or *vhdl*.

`test_write_four_cycle_stil_protocol`

When *true*, the **write_test_protocol -format stil** command inserts in the output STIL protocol file a dummy cycle between all measure and capture cycles in the STIL protocol. When *false* (the default), no additional cycle is inserted.

SEE ALSO

check_test (2), **create_test_patterns** (2), **insert_dft** (2), **read_test_protocol** (2), **set_min_fault_coverage** (2), **set_test_methodology** (2), **write_test** (2).

text_attributes

Contains attributes related to text.

DESCRIPTION

Contains attributes related to text.

You can use **get_attribute** to determine value of an attribute, and use **report_attribute** to get a report of all attributes on specified object. Specified with **list_attribute -class text -application**, the definition of attributes can be listed.

Text Attributes

anchor

Specifies the anchor position for text from its **origin**.
The data type of **anchor** is string.
Its valid values are:

- **lb** - Left Bottom
- **cb** - Center Bottom
- **rb** - Right Bottom
- **lc** - Left Center
- **c** - Center Center
- **rc** - Right Center
- **lt** - Left Top
- **ct** - Center Top
- **rt** - Right Top

This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

bbox

Specifies the bounding-box of a text. The **bbox** is represented by a **rectangle**. The format of a *rectangle* specification is {{llx lly} {urx ury}}, which specifies the lower-left and upper-right corners of the rectangle. The data type of **bbox** is string. This attribute is read-only.

bbox_ll

Specifies the lower-left corner of the bounding-box of a text. The **bbox_ll** is represented by a **point**. The format of a *point* specification is {x y}. You can get the **attr_name** of a text, by accessing the first element of its **bbox**. The data type of **bbox_ll** is string. This attribute is read-only.

bbox_llx

Specifies x coordinate of the lower-left corner of the bounding-box of a text. The data type of **bbox_llx** is double. This attribute is read-only.

bbox_lly

Specifies y coordinate of the lower-left corner of the bounding-box of a text. The data type of **bbox_lly** is double. This attribute is read-only.

bbox_ur

Specifies the upper-right corner of the bounding-box of a text. The **bbox_ur** is represented by a **point**. The format of a *point* specification is {x y}. You can get the **bbox_ur** of a text, by accessing the second element of its **bbox**. The data type of **bbox_ur** is string. This attribute is read-only.

bbox_urx

Specifies x coordinate of the upper-right corner of the bounding-box of a text. The data type of **bbox_urx** is double. This attribute is read-only.

bbox_ury

Specifies y coordinate of the upper-right corner of the bounding-box of a text. The data type of **bbox_ury** is double. This attribute is read-only.

cell_id

Specifies Milkyway design ID in which a text object is located. The data type of **cell_id** is integer. This attribute is read-only.

height

Specifies height of a text object. The data type of **height** is float.

text_attributes

This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

layer

Specifies layer name of a text object.

The data type of **layer** is string.

This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

name

Specifies name of a text object.

The data type of **name** is string.

This attribute is read-only.

object_class

Specifies object class name of a text, which is **text**.

The data type of **object_class** is string.

This attribute is read-only.

object_id

Specifies object ID in Milkyway design file.

The data type of **object_id** is integer.

This attribute is read-only.

orientation

Specifies orientation of a text object.

The data type of **orientation** is string.

Its valid values are:

- **N**
- **E**
- **S**
- **W**
- **FN**
- **FE**
- **FS**
- **FW**

This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

origin

Specifies origin of a text object.

The **origin** is represented by a **point**. The format of a *point* specification is {x y}.

The data type of **origin** is string.

This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

text

Specifies the text string to create and display.

The data type of **text** is string.

This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

SEE ALSO

get_attribute(2),
list_attribute(2),
report_attribute(2),
set_attribute(2).

timing_ccs_load_on_demand

Enables or disables incremental loading of Composite Current Source (CCS) libraries.

TYPE

Boolean

DEFAULT

true

GROUP

timing_variables

DESCRIPTION

This variable enables incremental (or on-demand) loading of CCS data for libraries. Because of the requirement to frequently load many libraries, cell libraries that contain CCS timing data can quickly consume all available memory. At read time, the library is analyzed so that the timer can later load CCS data for only the library cells that require it. There is a small upfront cost in runtime at the library loading phase in exchange for a significant saving of memory.

You must have some temporary disk space available in either /tmp or the directory pointed to by the TMPDIR environment variable. It is recommended that you have at least as much free space as the size of the original library files for the libraries that are to be read. All temporary files created for this purpose are deleted at program exit time. For best performance, temporary directories should be located on a disk that is mounted as a local filesystem.

Note that commands like **report_lib** and **write_lib**, which require CCS information for all library cells, will still operate correctly. However, while these commands are running, they might negate memory savings obtained by using the **timing_ccs_load_on_demand** variable for the library they are analyzing.

SEE ALSO

timing_check_defaults

define the default check list in check_timing command.

TYPE

string

DEFAULT

generated_clock loops no_input_delay unconstrained_endpoints pulse_clock_cell_type
no_driving_cell partial_input_delay

DESCRIPTION

This variable defines the default checks to be performed when the check_timing command is executed without any options. The default check list defined by this variable can be overridden by redefining it. The check list modified by using the -override_defaults/-include/-exclude option in check_timing is just valid in one command. Note this variable will not check if the value is correct or not, the check will be done by check_timing command. Each element in check list can be one of the following strings: loops, no_input_delay, unconstrained_endpoints, generated_clock, pulse_clock_cell_type, clock_crossing, data_check_multiple_clock, data_check_no_clock, multiple_clock, generic, gated_clock, ideal_timing, retain, clock_no_period.

EXAMPLE

The following example defines the value of timing_check_defaults variable:

```
prompt> set timing_check_defaults {clock_crossing loops}
```

SEE ALSO

check_timing(2)

timing_clock_gating_propagate_enable

Allow the gating enable signal delay to propagate through the gating cell.

TYPE

Boolean

DEFAULT

false

DESCRIPTION

When *true*, the tool allows the delay and slew from the data line of the gating check to propagate. When *false*, the tool blocks the delay and slew from the data line of the gating check from propagating; only the delay and slew from the clock line is propagated.

If the output goes to a clock pin of a latch, setting this variable to *false* produces the most desirable behavior.

If the output goes to a data pin, setting this variable to *true* produces the most desirable behavior.

To determine the current value of this variable, type **printvar timing_clock_gating_propagate_enable** or **echo \$timing_clock_gating_propagate_enable**.

SEE ALSO

timing_crpr_remove_clock_to_data_crp

Allows the removal of Clock Reconvergence Pessimism (CRP) from paths that fan out directly from clock source to the data pins of sequential devices.

TYPE

Boolean

DEFAULT

false

DESCRIPTION

When this variable is set to *true* then CRP will be removed for all paths that fan out directly from clock source pins to the data pins of sequential devices.

It should be noted that when this variable is set to *true* all sequential devices that reside in the fanout of clock source pins must be handled separately in the subsequent timing update. This may cause a severe performance degradation to the timing update.

```
dc_shell-t> echo $timing_crpr_remove_clock_to_data_crp
or
dc_shell-t> printvar timing_crpr_remove_clock_to_data_crp
```

SEE ALSO

timing_remove_clock_reconvergence_pessimism(3)

timing_crpr_threshold_ps

Specifies amount of pessimism that clock reconvergence pessimism removal (CRPR) is allowed to leave in the report.

TYPE

float

DEFAULT

20

DESCRIPTION

Specifies amount of pessimism that clock reconvergence pessimism removal (CRPR) is allowed to leave in the report. The unit is in pico seconds (ps), regardless of the units of the main library.

The threshold is per reported slack: setting the this variable to the *TH1* value means that reported slack is no worse than $S - TH1$, where *S* is the reported slack when **timing_crpr_threshold_ps** is set close to zero (the minimum allowed value is **2e-5** picosecond).

The variable has no effect if CRPR is not active (**timing_remove_clock_reconvergence_pessimism** is false). The larger the value of **timing_crpr_threshold_ps**, the faster the runtime when CRPR is active. The recommended setting is about half stage (gate plus net) delay of a typical gate in the clock network. It provides a reasonable trade-off between accuracy and runtime in most cases. You may want to use different settings throughout the design cycle: larger during the design phase, smaller for sign-off. You might have to experiment and set a different value when moving to a different technology.

SEE ALSO

timing_remove_clock_reconvergence_pessimism(3)

timing_disable_cond_default_arcs

Disable the default, non-conditional timing arc between pins that do have conditional arcs.

TYPE

Boolean

DEFAULT

false

DESCRIPTION

When *true*, disables nonconditional timing arcs between any pair of pins that have at least one conditional arc. When *false* (the default), these nonconditional timing arcs are not disabled. This variable is primarily intended to deal with the situation between two pins that have conditional arcs, where there is always a default timing arc with no condition.

Set this variable to *true* when the specified conditions cover all possible state-dependent delays, so that the default arc is useless. For example, consider a 2-input XOR gate with inputs as A and B and with output as Z. If the delays between A and Z are specified with 2 arcs with respective conditions 'B' and 'B~', the default arc between A and Z is useless and should be disabled.

To determine the current value of this variable, type **printvar timing_disable_cond_default_arcs** or **echo \$timing_disable_cond_default_arcs**.

SEE ALSO

report_disable_timing(2)

timing_edge_specific_source_latency

Controls whether the generated clock source latency computation will consider edge relationship or not.

TYPE

Boolean

DEFAULT

false

DESCRIPTION

When this variable is set to *true*, only the paths with the same sense relationship derived from generated clock definition will be considered. When false, all paths fanout to generated clock source pin will be considered and the worst path will be selected for generated clock source latency computation.

For the current value of this variable, type `printvar timing_edge_specific_source_latency`.

SEE ALSO

`create_generated_clock(2)`

timing_enable_multiple_clocks_per_reg

Enables or disables analysis of multiple clocks that reach a single register.

TYPE

Boolean

DEFAULT

false

GROUP

timing_variables

DESCRIPTION

This variable enables or disables analysis of multiple clocks that reach a register clock pin. When true, all clocks reaching the register are costed simultaneously. Since some of the clock interactions might not be present in actual operation, you should use the **set_false_path** command to remove false interactions between mutually exclusive clocks. If there are four or more clocks per register and the design contains level sensitive registers, high impact on runtime might occur. To avoid this, it is recommended that you use the **set_false_path** command to disable false interactions between mutually exclusive clocks or to disable multiple clocks per register.

When false (the default), only one of the clocks reaching the register pin is used.

For the current value of this variable, type the following:

```
printvar timing_enable_multiple_clocks_per_reg.
```

SEE ALSO

```
check_timing(2)
create_clock(2)
create_generated_clock(2)
printvar(2)
set_false_path(2)
```

timing_enable_non_sequential_checks

Enables or disables library non_sequential checks in the design.

TYPE

Boolean

DEFAULT

false

DESCRIPTION

This variable enables or disables analysis of library non_sequential checks in the design. The non_sequential arcs defined in library will not be used for constraint checking unless this variable is set to true. This variable does not affect the data checks defined by set_data_check command. Enabling the non_sequential checks may cause big delays if the signals reaching the related pin and constrained pin do not belong to the same clock domain. You can use set_multicycle_path command to put appropriate constraints on such paths.

SEE ALSO

set_data_check(2)
set_multicycle_path(2)
printvar(2)

timing_gclock_source_network_num_master_registers

The maximum number of register clock pins clocked by the master clock allowed in generated clock source latency paths.

TYPE

int

DEFAULT

1

DESCRIPTION

This variable allows the user to control the maximum number of register clock pins clocked by the master clock allowed in generated clock source latency paths. The variable does not effect the number of register traversed in a single path that do not have a clock assigned or are clocked by another generated clock that has the same primary master as the generated clock in question.

Register clock pins or transparent-D pins of registers clocked by unrelated clocks are not traversed in determining generated clock source latency paths. An unrelated clock is any clock that primary master clock differs from the generated clock who source latency paths are being computed.

To determine the current value of this variable, type **printvar timing_gclock_source_network_num_master_registers** or **echo \$timing_gclock_source_network_num_master_registers**.

SEE ALSO

timing_input_port_default_clock

Determines whether a default clock is assumed at input ports for which you have not defined a clock-specific input external delay.

TYPE

Boolean

DEFAULT

true

GROUP

timing_variables

DESCRIPTION

This Boolean variable affects the behavior of the synthesis timing engine when timing a path from an input port with no clocked input external delay. When *true* (the default value), all such input ports are given one imaginary clock so that the inputs are constrained. This also causes the clocks along the paths driven by these input ports to become related. When *false*, no such imaginary clock is assumed.

To determine the current value of this variable use **printvar timing_input_port_default_clock**.

SEE ALSO

report_timing(2)

timing_remove_clock_reconvergence_pessimism

Enables or disables clock reconvergence pessimism removal.

TYPE

Boolean

DEFAULT

false

DESCRIPTION

When this variable is set to *true*, the synthesis timing engine removes clock reconvergence pessimism from slack calculation and minimum pulse width checks.

Clock reconvergence pessimism (CRP) is a difference in delay along the common part of the launching and capturing clock paths. The most common causes of CRP are reconvergent paths in the clock network, and different minimum and maximum delay of cells in the clock network.

Any effective change in the value of the **timing_remove_clock_reconvergence_pessimism** variable causes full **update_timing**. You cannot perform one **report_timing** operation that considers CRP and one that does not without full **update_timing** in between.

To run compile with CRP removal, the clock network must be `dont_touched`.

```
prompt> set timing_remove_clock_reconvergence_pessimism true
true
```

```
prompt> report_timing
```

SEE ALSO

`report_timing(2)`
`timing_crpr_threshold_ps(3)`

timing_report_attributes

Specifies the list of attributes to be reported with the **report_timing -attributes** command.

Note: This variable will be obsolete in the next release. Please adjust your scripts accordingly.

TYPE

list

DEFAULT

{dont_touch dont_use map_only size_only ideal_net}

GROUP

timing_variables

DESCRIPTION

Specifies the list of attributes to be reported with the **report_timing -attributes** command. Attributes currently supported are **dont_touch**, **dont_use**, **map_only**, **size_only**, and **ideal_net**.

The default value for this attribute is set in the system .synopsys_dc.setup file.

To determine the current value of this variable, type **printvar timing_report_attributes**. For a list of all timing variables and their current values, type **print_variable_group timing**.

SEE ALSO

compile(2)
report_timing(2)
timing_variables(3)

timing_self_loops_no_skew

Affects the behavior, runtime, and CPU usage of **report_timing** and **compile**.

Note: This variable will be obsolete in the next release. Please adjust your scripts accordingly.

TYPE

Boolean

DEFAULT

false

GROUP

timing_variables

DESCRIPTION

Affects the behavior, runtime, and CPU usage of **report_timing** and **compile**. When set to *true*, clock skew is eliminated for a path that starts and ends at the same register. When set to *false* (the default value), clock skew is not eliminated. Thus, the timing for such paths is pessimistic. To obtain the more accurate behavior of no clock skew (uncertainty) for such paths, set this variable to *true*. However, note that runtime and memory usage might increase significantly.

To determine the current value of this variable, type **printvar timing_self_loops_no_skew**. For a list of all **timing** variables and their current values, type **print_variable_group timing**.

SEE ALSO

report_timing(2)
timing_variables(3)

timing_separate_clock_gating_group

Specifies if a separate cost group is used for clock gating checks in timing analysis, reports, and optimization.

TYPE

Boolean

DEFAULT

false

GROUP

timing

DESCRIPTION

When set to true, a separate cost group named *****clock_gating_default***** is created for all the clock gating checks; when false, the clock gating check is applied to the cost group of the clock being gated. The default value is false. If multiple scenarios exist, a cost group is created for clock gating checks for each scenario when this variable is true.

You can change the weight and critical_range settings for this cost group by using the **group_path** command with **-name ***clock_gating_default*****.

SEE ALSO

get_path_groups(2)
group_path(2)
report_clock_gating(2)
report_clock_gating_check(2)
report_constraint(2)
report_path_group(2)
report_qor(2)
report_timing(2)

timing_use_clock_specific_transition

Propagate the transition from the specific clock path for latency calculation

TYPE

Boolean

DEFAULT

true

DESCRIPTION

When set to true (the default value), ICC only propagates the transition of the clock path, for the purpose of clock latency calculation. If there are multi input gates on the clock network, the transition of non-clock inputs are ignored during clock latency calculation.

For generated clocks defined on an output of a gate, ICC propagates the transition from the path connected to its master clock, and uses that transition value for the purpose of calculation clock latency for the generated clock.

When set to false, ICC will allow transition from the non-clock input of multi-input gates along the clock path to be used for clock latency calculation

In addition, when set to false, generated clock defined at the output of a gate will use zero transition at the generated clock source.

To determine the current value of this variable, type **printvar timing_use_clock_specific_transition** or **echo \$timing_use_clock_specific_transition**.

SEE ALSO

timing_use_driver_arc_transition_at_clock_source

Uses the backward cell arc to compute a realistic driver model at the driver pin for primary clock sources and also generated clock that can not trace back to its master clock

TYPE

Boolean

DEFAULT

true

DESCRIPTION

When set to true (the default value), ICC use the backward cell arcs, when at least one does exist, to compute a worst-case driver model. This behavioral applies to the primary clock sources, which are defined by `create_clock`, and generated clock sources (defined by `create_generated_clock`) that can not trace back to its master clock.

When set to false, ICC asserts a zero-transition, ideal ramp model at the driver pin.

To determine the current value of this variable, type **printvar timing_use_driver_arc_transition_at_clock_source** or **echo \$timing_use_driver_arc_transition_at_clock_source**.

SEE ALSO

timing_use_enhanced_capacitance_modeling

Specifies the use of the following attributes found on a library pin:
rise_capacitance_range(low, high), fall_capacitance_range(low, high),
rise_capacitance, and fall_capacitance.

TYPE

Boolean

DEFAULT

false

DESCRIPTION

When this environment variable is set to true, different capacitance values for rise and fall will be used in delay calculation, if such values are specified in the library. If no such attributes are found, it will use the default capacitance attribute.

With the bc/wc analysis type, the (low, high) values from the worst condition will be used for the setup analysis, and the (low, high) value from the best condition will be used for the hold analysis.

If the analysis type is on_chip_variation, the high value from the max condition will be used in computing the late arrivals, and at the same time the low value from the min condition will be used in the early arrivals.

SEE ALSO

set_operating_conditions(2)

timing_variables

Variables that affect timing.

SYNTAX

```
Boolean create_clock_no_input_delay = false
Boolean disable_library_transition_degradation = false
Boolean disable_auto_time_borrow = false
Boolean timing_self_loops_no_skew = false
int true_delay_prove_false_backtrack_limit = 1000
int true_delay_prove_true_backtrack_limit = 1000
list timing_report_attributes = {"dont_touch" "dont_use" "map_only" "size_only"}
Boolean disable_case_analysis = false
Boolean case_analysis_with_logic_constants = false
String case_analysis_log_file = ""
Boolean enable_slew_degradation = "false"
Boolean high_fanout_net_threshold = "1000"
```

DESCRIPTION

These variables directly affect timing aspects in **dc_shell**. Defaults are shown under Syntax.

For a list of timing_variables, type **print_variable_group timing**. To view this manual page online, type **help timing_variables**. To view an individual variable description, type **help var**, where *var* is the name of the variable.

create_clock_no_input_delay

Affects delay propagation characteristics of clock sources created using **create_clock**. When **create_clock_no_input_delay** is *false* (the default value), clock sources used in the data path are established as timing startpoints. The clock sources in the design will propagate rising delays on every rising clock edge, and will propagate falling delays on every falling clock edge. You can disable this behavior by setting **create_clock_no_input_delay** to *true*.

disable_auto_time_borrow

Affects automatic time borrowing. When **disable_auto_time_borrow** is *false* (the default value), automatic time borrowing balances the slack along back-to-back latch paths to reduce the overall delay cost. When *true*, no slack balancing will occur during time borrowing.

disable_library_transition_degradation

When *false* (the default), **report_timing** and other commands that use timing in **dc_shell** use the transition degradation table in the library to determine the net transition time. When *true*, the timing commands behave as though there were no transition degradation across the net.

disable_library_transition_degradation

When *false* (the default), **report_timing** and other commands that use timing in **dc_shell** try to balance the slack between paths. When *true*, the cycle time is portioned such that the first path attempts to make timing and the second path only gets the remainder of the delay.

timing_self_loops_no_skew

This Boolean variable affects the behavior, runtime, and cpu usage of **report_timing** and **compile**. When *true*, register. When *false* (the default value), clock skew is not eliminated; thus, the timing for such paths is pessimistic. To obtain the more accurate behavior of no clock skew (uncertainty) for such paths, set the variable to *true*, but note that runtime and memory usage may increase significantly.

true_delay_prove_false_backtrack_limit

An integer variable that specifies the number of backtracks to be used by **report_timing -true** in searching for false paths; **-1** specifies unlimited backtracking. The default is 1000. One of a pair of variables that includes **true_delay_prove_true_backtrack_limit**.

true_delay_prove_true_backtrack_limit

An integer variable that specifies the number of backtracks to be used by **report_timing -true** in searching for true paths; **-1** specifies unlimited backtracking. The default is 1000. One of a pair of variables that includes **true_delay_prove_false_backtrack_limit**.

timing_report_attributes

Specifies the list of attributes to be reported with **report_timing -attributes**. The current list of attributes supported are *dont_touch*, *dont_use*, *map_only*, and *size_only*.

disable_case_analysis

Determines whether constant propagation is performed in the design from pins either that are tied to a logic constant value, or for which a **case_analysis** command is specified. By default, constant propagation happens if the **set_case_analysis** is specified or if the variable *case_analysis_with_logic_constants* is set to *true*, unless the variable *disable_case_analysis* is set to *false*.

case_analysis_with_logic_constants

Determines whether constant propagation will be preformed if there are only logic constants in the circuit and there is no *set_case_analysis* command used. By default, logic constants are not propagated in the absense of *set_case_analysis* commands or *case_analysis_with_logic_constants* being set to *true*.

case_analysis_log_file

Specifies the name of a log file to be generated during propagation of constant values from case analysis or from nets tied to logic zero or to logic one. The log file contains the list of all ports and pins that propagate constants.

enable_slew_degradation

When *false* (the default setting), optimization with physical information does not consider transition degradation across a net and only tries to fix transition violations on a per net basiss. Setting this variable to *true* will cause optimization with physical information to consider transition degradation across a net and try to fix transition violations on a per cell basis.

`high_fanout_net_threshold`

Specifies the minimum number of loads for a net to be classified as a high-fanout net, the default is 1000. The delays and loads of high-fanout are computed using a simplified model assuming a fixed fanout number. The rationale behind this is that delays of high-fanout nets are expensive to compute but such nets are often unconstrained (as in the case of global reset nets, scan enable nets, and so on). So detailed delay calculations on such nets are expensive and usually unnecessary.

`timing_disable_internal_inout_net_arcs`

This variable is used to disable bidirectional feedback paths that involve more than one cell. No path segmentation is required. By default this variable is true. If the variable is set false, then bidirectional feedback loop would be enabled.

`timing_disable_internal_inout_cell_paths`

This variable is used to disable bidirectional feedback paths that are present within a cell. By default, the variable is true. If the variable is set false, then bidirectional feedback path would be present.

SEE ALSO

```
compile (2), create_clock(2), report_timing (2); create_clock_no_input_delay(3),  
disable_library_transition_degradation(3), timing_self_loops_no_skew(3),  
true_delay_prove_false_backtrack_limit(3), true_delay_prove_true_backtrack_limit(3),  
timing_report_attributes(3), disable_case_analysis(3),  
case_analysis_with_logic_constants(3), case_analysis_log_file(3),  
enable_slew_degradation(3), high_fanout_net_threshold(3).
```

trackAssign_XTalkParam

DESCRIPTION

The **trackAssign_XTalkParam** variable defines the cost for crosstalk prevention. Use this variable when `is enabled`.

SYNTAX

set trackAssign_XTalkParam value

The valid values of this variable range between 1 and 4. The default is 1.

EXAMPLE

To define the cost for crosstalk prevention, enter

```
set trackAssign_XTalkParam 3
```


trackAssign_densityDriven

DESCRIPTION

The **trackAssign_densityDriven** variable specifies the mode of density driven for track assignment.

SYNTAX

set trackAssign_densityDriven value

Value

Description

-1

Tries to spread wires looking at one extra track if timing or crosstalk is enabled (the default)

0

Does not perform spreading

1

Tries to spread wires looking at one extra track

2

Should only be set when design is lower than 60% utilization because this will use more CPU. Misusing this when design is not sparse can cause negative impact.

```
'|0's
(331'|
(TWu(ul's0 &
'|
(40u'
'|
(41u'
```

```
f2.a+
.mk 32
```

```
f2.b+  
.mk 32
```

```
'|0's  
(331'|  
(TWu(u1's0 &  
'|  
(40u'  
'|  
(41u'
```

```
'|0's  
(331'|  
(TWu(u1's0 &  
'|  
(40u'  
'|  
(41u'
```

```
'|0's  
(331'|  
(TWu(u1's0 &  
'|  
(40u'  
'|  
(41u'
```

```
'|0's  
(331'|  
(TWu(u1's0 &  
'|  
(40u'  
'|  
(41u'
```

EXAMPLE

To spread wires looking at one extra track, enter

```
set trackAssign_densityDriven 1
```

trackAssign_evenSpaceAdjustment

DESCRIPTION

The **trackAssign_evenSpaceAdjustment** variable specifies the mode of cost calculation for wire spreading.

SYNTAX

set trackAssign_evenSpaceAdjustment value

Value

Description

1

Tries every track sequentially.

2

Tries every other track first (the default)

3

Tries every third track first

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'

f2.a+
.mk 32
f2.b+
.mk 32
```

```
'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
```

```
' |  
(41u'
```

```
' | 0's  
(331' |  
(TWu(u1's0  
' |  
(40u'  
' |  
(41u'
```

&

```
' | 0's  
(331' |  
(TWu(u1's0  
' |  
(40u'  
' |  
(41u'
```

&

EXAMPLE

To try every third track first, enter

set trackAssign_evenSpaceAdjustment 3

trackAssign_minimizeJog

DESCRIPTION

The **trackAssign_minimizeJog** variable specifies the mode to minimize jogs.

SYNTAX

set trackAssign_minimizeJog value

Value

Description

0

Normal operation (the default).

1

Minimizes jogs near nonstandard-cell pins.

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'
                                f2.a+
                                .mk 32
                                f2.b+
                                .mk 32
```

```
'|0's
(331'|
(TWu(ul's0                                &
'|
(40u'
'|
(41u'
```

```
'|0's
(331'|
```

```
(TWu(ul's0  
'|  
(40u'  
'|  
(41u'&
```

EXAMPLE

To minimize jogs near the nonstandard-cell pins, enter

```
set trackAssign_minimizeJog 1
```

trackAssign_noOffGridRouting

DESCRIPTION

The **trackAssign_noOffGridRouting** variable specifies the switch for off-grid routing on macro pins.

SYNTAX

set trackAssign_noOffGridRouting value

Value

Description

0

Automatically uses off grid for macro pins (the default)

1

Puts all the wires on grid

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'

                                f2.a+
                                .mk 32
                                f2.b+
                                .mk 32
```

```
'|0's
(331'|
(TWu(ul's0                                &
'|
(40u'
'|
(41u'
```

'|0's

```
(331' |  
(TWu(u1's0 &  
' |  
(40u'  
' |  
(41u'
```

EXAMPLE

To put all the wires on grid, enter

```
set trackAssign_noOffGridRouting 1
```


trackAssign_noiseThreshold

DESCRIPTION

The **trackAssign_noiseThreshold** variable specifies the noise threshold for track assignment.

SYNTAX

set trackAssign_noiseThreshold value

The valid values of this variable range between 0.000 and 1.000. The default is 0.450.

EXAMPLE

To specify the noise threshold for track assignment as 0.350, enter

```
set trackAssign_noiseThreshold 0.350
```

trackAssign_parallelLimit

DESCRIPTION

The **trackAssign_parallelLimit** variable is used to specify parallel lengths limit. Use this variable when `parallel` is enabled.

SYNTAX

```
set trackAssign_parallelLimit value
```

The valid values of this variable range between 0 and 10000000. The default is 0.

EXAMPLE

To specify parallel length limit as 500, enter

```
set trackAssign_parallelLimit 500
```

trackAssign_parallelLimitMode

DESCRIPTION

The **trackAssign_parallelLimitMode** variable is set to break long wire mode on or off. When it is on, track assignment breaks the long wire if it exceeds the parallel length or the capacitance limit.

SYNTAX

set trackAssign_parallelLimitMode value

Value

Description

0

Does not check parallel lengths (the default).

1

Limits the parallel length of any two wires to 'n' user unit.

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'
                                     f2.a+
                                     .mk 32
                                     f2.b+
                                     .mk 32
```

```
'|0's
(331'|
(TWu(ul's0                                     &
'|
(40u'
'|
(41u'
```

```
'|0's
(331'|
(TWu(u1's0
'|
(40u'
'|
(41u'
&
```

EXAMPLE

To ignore breaking long wires even when parallel length or capacitance limit is exceeded, enter

```
set trackAssign_parallelLimitMode 0
```

trackAssign_runTimingMode

DESCRIPTION

The **trackAssign_runTimingMode** variable turns enables or disables the timing-driven track assignment. A value set to timing cost decides the importance of timing relative to wire length during track assignment. By default timing-driven track assignment is disabled.

SYNTAX

```
set trackAssign_runTimingMode value
```

Value

Description

0

Does not perform timing-driven track assignment (the default)

1

Performs timing-driven track assignment

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'
f2.a+
.mk 32
f2.b+
.mk 32
```

```
'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'
```

```
'|0's
(331'|
(TWu(u1's0      &
'|
(40u'
'|
(41u'
```

EXAMPLE

To perform timing-driven track assignment, enter

```
set trackAssign_runTimingMode 1
```

trackAssign_runXTalkIter

DESCRIPTION

The **trackAssign_runXTalkIter** variable allows you to specify the number of extra iterations for crosstalk during track assignment. The default number of iterations are determined automatically. Use this variable when `is enabled`.

SYNTAX

set trackAssign_runXTalkIter value

The valid values of this variable range between -1 and 5. The default is -1.

EXAMPLE

To specify the number of extra iterations for crosstalk in track assignment, enter
axSetIntParam "trackAssign" "trackAssign_runXTalkIter" 4

trackAssign_runXTalkMode

DESCRIPTION

The **trackAssign_runXTalkMode** variable is used to enable or disable the crosstalk mode during track assignment.

SYNTAX

set trackAssign_runXTalkMode value

Value

Description

0

Does not try to minimize crosstalk (the default).

1

Minimizes crosstalk-induced delay and noise.

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'
f2.a+
.mk 32
f2.b+
.mk 32
```

```
'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'
```

'|0's


```

(33l' |
(TWu(u1's0
'|
(40u'
'|
(41u'

```

EXAMPLE

To minimize crosstalk-induced delay and noise, enter

```
set trackAssign_runXTalkMode 1
```

trackAssign_timingCost

DESCRIPTION

The **trackAssign_timingCost** variable sets the weight given to timing relative to the wire length during track assignment. This variable is effective only when `is` is set to 1, which runs track assignment in timing-driven mode.

SYNTAX

```
set trackAssign_timingCost value
```

The valid values of this variable range between 1 and 10. The default is 1.

EXAMPLE

To specify the cost for timing optimization, enter

```
set trackAssign_timingCost 6
```

trackAssign_tryGlobalLayerFirst

DESCRIPTION

The **trackAssign_tryGlobalLayerFirst** variable specifies the mode to use global layer first.

SYNTAX

set trackAssign_tryGlobalLayerFirst value

Value

Description

0

Do not try to use global layer.

1

Try to use global layer in the first iteration (the default).

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'

f2.a+
.mk 32
f2.b+
.mk 32
```

```
'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
'|
(41u'
```

'|0's

```
(33l' |  
(TWu(ul's0  
' |  
(40u'  
' |  
(41u' &
```

EXAMPLE

To ignore using global layer, enter

```
set trackAssign_tryGlobalLayerFirst 0
```

trackAssign_tryGlobalLayerOnly

DESCRIPTION

The **trackAssign_tryGlobalLayerOnly** variable specifies the mode to use only global layer during track assignment.

SYNTAX

set trackAssign_tryGlobalLayerOnly value

Value

Description

-1

Try the global layers only if timing or crosstalk is enabled (the default)

0

Allow to try layers other than global layers in second phase.

1

Try only the global layers.

```
'|0's
(331'|
(TWu(ul's0  &
'|
(40u'
'|
(41u'

f2.a+
.mk 32
f2.b+
.mk 32
```

```
'|0's
(331'|
(TWu(ul's0      &
'|
(40u'
```

' |
(41u'

' | 0's
(331' |
(TWu (ul's0
' |
(40u'
' |
(41u'

&

' | 0's
(331' |
(TWu (ul's0
' |
(40u'
' |
(41u'

&

EXAMPLE

trackAssign_variableWidthAdjustment

DESCRIPTION

The **trackAssign_variableWidthAdjustment** variable specifies the width adjustment for fat wire tracks. The calculation of number of tracks for a fat wire will occupy is sometime too conservative, that is, track assignment will reserve too many tracks for each fat wire. The **trackAssign_variableWidthAdjustment** variable can help reduce the demand and pack the fat wires more tightly.

SYNTAX

```
set trackAssign_variableWidthAdjustment value
```

Value

Description

0

Uses the track count from detail route(the default).

1

Uses the track count from detail route -1

2

Uses the track count from detail route -2

3

Uses the track count from detail route -3

4

Uses the track count from detail route -4

5

Uses the track count from detail route -5

```
'|0's
(331'|
(TWu(u1's0  &
'|
(40u'
'|
(41u'

f2.a+
.mk 32
f2.b+
.mk 32
```

```
'|0's
(331'|
(TWu(u1's0      &
'|
(40u'
'|
(41u'
```

```
'|0's
(331'|
(TWu(u1's0      &
'|
(40u'
'|
(41u'
```

```
'|0's
(331'|
(TWu(u1's0      &
'|
(40u'
'|
(41u'
```

```
'|0's
(331'|
(TWu(u1's0      &
'|
(40u'
'|
(41u'
```



```
'|0's
(331'|
(TWu(u1's0      &
'|
(40u'
'|
(41u'
```

```
'|0's
(331'|
(TWu(u1's0      &
'|
(40u'
'|
(41u'
```

EXAMPLE

To specify the width adjustment for fat wire tracks, enter

```
set trackAssign_variableWidthAdjustment 2
```

track_attributes

Contains attributes related to track.

DESCRIPTION

Contains attributes related to track.

You can use **get_attribute** to determine value of an attribute, and use **report_attribute** to get a report of all attributes on specified track. Specified with **list_attribute -class track -application**, the definition of attributes can be listed.

Track Attributes

bbox

Specifies the bounding-box of a track. The **bbox** is represented by a **rectangle**. The format of a *rectangle* specification is {{llx lly} {urx ury}}, which specifies the lower-left and upper-right corners of the rectangle. The *bbox* of a track is calculated by the **origin** and **orientation** of its cell and the actual **bbox** of its corresponding terminal from the child MW design. This attribute is read-only.

bbox_ll

Specifies the lower-left corner of the bounding-box of a track. The **bbox_ll** is represented by a **point**. The format of a *point* specification is {x y}. You can get the **bbox_ll** of a track by accessing the first element of its **bbox**. This attribute is read-only.

bbox_llx

Specifies x coordinate of the lower-left corner of the bounding-box of a track. The data type of **bbox_llx** is double. This attribute is read-only.

bbox_lly

Specifies y coordinate of the lower-left corner of the bounding-box of a track. The data type of **bbox_lly** is double. This attribute is read-only.

bbox_ur

Specifies the upper-right corner of the bounding-box of a track. The **bbox_ur** is represented by a **point**. The format of a *point* specification is {x y}. You can get the **bbox_ur** of a track by accessing the second element of its **bbox**. This attribute is read-only.

bbox_urx

Specifies x coordinate of the upper-right corner of the bounding-box of a track.

track_attributes

The data type of **bbox_urx** is double.
This attribute is read-only.

bbox_ury

Specifies y coordinate of the upper-right corner of the bounding-box of a track.

The data type of **bbox_ury** is double.
This attribute is read-only.

cell_id

Specifies Milkyway design ID in which a track object is located.
This attribute is read-only.

count

Specifies the number of grid of a track.
The data type of **count** is integer.
This attribute is read-only.

direction

Specifies the routing direction of a track.
The valid values can be: X, Y.
This attribute is read-only.

layer

Specifies the layer name where a track object is located on.
This attribute is read-only.

name

Specifies the object name of a track.
This attribute is read-only.

object_class

Specifies object class name of a track, which is **track**.
This attribute is read-only.

object_id

Specifies object ID in Milkyway design file.
This attribute is read-only.

space

Specifies track step of a track.
The data type of **space** is integer.
This attribute is read-only.

start

Specifies start position of a track.
The data type of **start** is coordinate point.
This attribute is read-only.

stop

Specifies end position of a track.
The data type of **stop** is coordinate point.
This attribute is read-only.

SEE ALSO

`get_attribute(2)`,
`list_attribute(2)`,
`report_attribute(2)`.

ungroup_keep_original_design

Controls ungroup and compile command to keep the original design when a design is ungrouped in XG mode.

TYPE

Boolean

DEFAULT

false

GROUP

none

DESCRIPTION

By default, **ungroup** and **compile** in XG, will delete the original design if all the instances of a design has be ungrouped and there are no other references to the design from anywhere else.

When set to true, the original design is preserved.

For example, if are two instances of design mid named mid1 and mid2 and **ungroup -flatten -all** is issued, after ungroup collapses the hierarchies, the design called mid is deleted from memory if there are no other references to the design from elsewhere. This variable is used to change the behaviour. When this variable is set to true explicitly, the ungrouped design will be preserved.

SEE ALSO

ungroup(2)
set_ungroup(2)

uniquify_keep_original_design

Controls uniquify command to keep the original design when a multiply instantiated design is uniquified in XG mode.

TYPE

Boolean

DEFAULT

false

GROUP

none

DESCRIPTION

By default, **uniquify** in XG, will delete the original design if all the instances of a design has been uniquified and there are no other references to the design from anywhere else.

When set to true, the original design is preserved.

For example, if are two instances of design mid, uniquify creates two new designs mid_1 and mid_2. By default the original design "mid" is deleted in XG. This variable is used to change the behaviour.

SEE ALSO

uniquify(2)

uniquify_naming_style

Specifies the naming convention to be used by the **uniquify** command.

TYPE

string

DEFAULT

GROUP

system_variables

DESCRIPTION

Specifies the naming convention to be used by the **uniquify** command. The variable string must contain only one %s (percent s) and one %d (percent d) character sequence. To use a percent sign in the design name, two are needed in the string (%%).

To determine the current value of this variable, type **printvar** **uniquify_naming_style**. For a list of all **system** variables and their current values, use the **print_variable_group system** command.

SEE ALSO

uniquify(2)
system_variables(3)

upf_extension

Sets the variable to false to disable writing of UPF extension commands in `save_upf`.

TYPE

Boolean

DEFAULT

true

GROUP

mv

DESCRIPTION

This variable controls whether the **save_upf** command writes UPF extension commands such as **set_related_supply_net** into UPF files. By default, UPF extension commands are written by **save_upf** in the following format:

```
if {[info exists upf_extension] && upf_extension} {  
  <upf_extension_command>  
}
```

If **upf_extension** is set to false, these lines are not written by **save_upf**. The UPF extension command itself continues to be written by **write_script**, and continues to be readable by the **source** and **load_upf** commands.

All tools, including third party tools, that need to support the UPF extension commands must predefine the **upf_extension** Tcl variable as true.

SEE ALSO

`set_related_supply_net(2)`

use_port_name_for_oscs

Specifies that when off-sheet connectors for nets also have ports on them, they are given the name of the port.

TYPE

Boolean

DEFAULT

false

GROUP

schematic_variables

DESCRIPTION

Specifies that when off-sheet connectors for nets also have ports on them, they are given the name of the port. The value of *true* is the default for this partitioning option. When the value is set to *false*, the connectors are given the name of the net.

To determine the current value of this variable, type **printvar use_port_name_for_oscs**. For a list of all **schematic** variables and their current values, use the **print_variable_group schematic** command.

SEE ALSO

schematic_variables(3)

verbose_messages

Causes more explicit system messages to be displayed during the current Design Analyzer dc_shell session.

TYPE

Boolean

DEFAULT

true

GROUP

system_variables

DESCRIPTION

Causes more explicit system messages to be displayed during the current Design Analyzer dc_shell session. The default is *true*.

To determine the current value of this variable, type **printvar verbose_messages**. For a list of all **system** variables and their current values, type **print_variable_group system**.

SEE ALSO

system_variables(3)

verilogout_equation

Writes Verilog "assign" statements (Boolean equations) for combinational gates, rather than gate instantiations.

TYPE

Boolean

DEFAULT

false

GROUP

hdl_variables

DESCRIPTION

Writes Verilog "assign" statements (Boolean equations) for combinational gates, rather than gate instantiations. The default value is *false*.

To determine the current value of this variable, use **printvar verilogout_equation**. For a list of all **hdl** variables and their current values, use the **print_variable_group hdl** command.

SEE ALSO

hdl_variables(3)

verilogout_higher_designs_first

Writes Verilog "modules" so that the higher level designs come before lower level designs, as defined by the design hierarchy.

TYPE

Boolean

DEFAULT

false

GROUP

hdl_variables

DESCRIPTION

Writes Verilog "modules" so that higher level designs come before lower level designs, as defined by the design hierarchy. The default is to write lower level designs first.

To determine the current value of this variable, use **printvar verilogout_higher_designs_first**. For a list of all **hdl** variables and their current values, use the **print_variable_group hdl** command.

SEE ALSO

hdl_variables(3)

verilogout_ignore_case

Instructs the compiler not to consider case when comparing identifiers to Verilog reserved words.

TYPE

Boolean

DEFAULT

false

GROUP

hdl_variables

DESCRIPTION

Instructs the compiler not to consider case when comparing identifiers to Verilog reserved words.

When an identifier is equal to a reserved word, the identifier is "escaped" by putting a backslash (``\`) in front of it. When this variable is set to *false*, case is considered. When set to *true*, case is ignored in the comparison.

Therefore, if **verilogout_ignore_case** is set to *true*, the default allows an identifier BUF to pass unchanged, BUF becoming \BUF.

To determine the current value of this variable, type **printvar verilogout_ignore_case**. For a list of all **hdl** variables and their current values, type **print_variable_group hdl**.

SEE ALSO

hdl_variables(3)

verilogout_include_files

Specifies to the **write -f verilog** command to write an include statement that will have the name of the value you set for this variable.

TYPE

list

DEFAULT

" "

GROUP

hdl_variables

DESCRIPTION

Specifies to the **write -f verilog** command to write an include statement that will have the name of the value you set for this variable. For example, when **verilogout_include_files**={"my_header.v"}, you see an include "my_header.v" in your Verilog output.

To determine the current value of this variable, type **printvar verilogout_include_files**. For a list of all **hdl** variables and their current values, type **print_variable_group hdl**.

SEE ALSO

write(2)
hdl_variables(3)

verilogout_no_tri

Declares three-state nets as Verilog "wire" instead of "tri." This variable is useful in eliminating "assign" primitives and "tran" gates in the Verilog output.

TYPE

Boolean

DEFAULT

false

GROUP

hdl_variables

DESCRIPTION

Declares three-state nets as Verilog "wire" instead of "tri." This variable is useful in eliminating "assign" primitives and "tran" gates in the Verilog output.

To determine the current value of this variable, use **printvar verilogout_no_tri**. For a list of all **hdl** variables and their current values, use the **print_variable_group hdl** command.

SEE ALSO

hdl_variables(3)

verilogout_show_unconnected_pins

Instructs the Verilog writer in `dc_shell` to write out all of the unconnected instance pins, when connecting module ports by name. For example, modb b1 (`.A(in),.Q(out),.Qn()`).

TYPE

Boolean

DEFAULT

false

GROUP

hdl_variables

DESCRIPTION

Instructs the Verilog writer in `dc_shell` to write out all of the unconnected instance pins, when connecting module ports by name. For example, modb b1 (`.A(in),.Q(out),.Qn()`).

When this variable is set to *false* (the default), the Verilog writer does not write out any unconnected pins. For example, modb b1 (`.A(in),.Q(out)`).

To determine the current value of this variable, use **printvar verilogout_show_unconnected_pins**. For a list of all **hdl** variables and their current values, use the **print_variable_group hdl** command.

SEE ALSO

hdl_variables(3)

verilogout_single_bit

Instructs the compiler not to output vectored ports in the Verilog output. All vectors are written as single bits.

TYPE

Boolean

DEFAULT

false

GROUP

hdl_variables

DESCRIPTION

Instructs the compiler not to output vectored ports in the Verilog output. All vectors are written as single bits.

To determine the current value of this variable, use **printvar verilogout_single_bit**. For a list of all **hdl** variables and their current values, use the **print_variable_group hdl** command.

SEE ALSO

hdl_variables(3)

verilogout_unconnected_prefix

Instructs the Verilog writer in dc_shell to use the name SYNOPSYS_UNCONNECTED_ to create unconnected wire names. The general form of the name is SYNOPSYS_UNCONNECTED_%d.

TYPE

string

DEFAULT

SYNOPSYS_UNCONNECTED_

GROUP

hdl_variables

DESCRIPTION

Instructs the Verilog writer in dc_shell to use the name (SYNOPSYS_UNCONNECTED_) to create unconnected wire names. The general form of the name is SYNOPSYS_UNCONNECTED_%d.

The purpose of this variable is to avoid conflict with the name already used in the design.

To determine the current value of this variable, use **printvar verilogout_unconnected_prefix**. For a list of all **hdl** variables and their current values, use the **print_variable_group hdl** command.

SEE ALSO

hdl_variables(3)

vhdlio_variables

SYNTAX

```
string vhdllib_architecture = "VITAL"
Boolean vhdllib_glitch_handle = "true"
Boolean vhdllib_logic_system = "ieee-1164"
Boolean vhdllib_logical_name = ""
Boolean vhdllib_negative_constraint = "false"
string vhdllib_pulse_handle = "use vhdllib_glitch_handle"
Boolean vhdllib_sdf_edge = "false"
Boolean vhdllib_tb_compare = "0"
Boolean vhdllib_tb_x_eq_dontcare = "false"
Boolean vhdllib_timing_checks = "true"
Boolean vhdllib_timing_mesg = "true"
Boolean vhdllib_timing_xgen = "false"
Boolean vhdllib_vital_99 = "false"
string vhdllout_architecture_name = "SYN_%a_%u"
string vhdllout_bit_type = "std_logic"
Boolean vhdllout_bit_type_resolved = "true"
string vhdllout_bit_vector_type = "std_logic_vector"
list vhdllout_conversion_functions = {}
Boolean vhdllout_dont_create_dummy_nets = "false"
Boolean vhdllout_dont_write_types = "FALSE"
Boolean vhdllout_equations = "FALSE"
Boolean vhdllout_follow_vector_directions = "true"
Boolean vhdllout_lower_design_vector = "TRUE"
string vhdllout_one_name = "'1'"
string vhdllout_package_naming_style = "CONV_PACK_%d"
string vhdllout_preserve_hierarchical_types = "VECTOR"
Boolean vhdllout_separate_scan_in = "FALSE"
string vhdllout_single_bit = "USER"
Boolean vhdllout_synthesis_off = "TRUE"
string vhdllout_target_simulator = ""
string vhdllout_three_state_name = "'Z'"
string vhdllout_three_state_res_func = ""
float vhdllout_time_scale = "1.0"
string vhdllout_top_configuration_arch_name = "A"
string vhdllout_top_configuration_entity_name = "E"
string vhdllout_top_configuration_name = "CFG_TB_E"
string vhdllout_unknown_name = "'X'"
list vhdllout_use_packages = "IEEE.std_logic_1164"
string vhdllout_wired_and_res_func = ""
string vhdllout_wired_or_res_func = ""
Boolean vhdllout_write_architecture = "TRUE"
Boolean vhdllout_write_components = "TRUE"
Boolean vhdllout_write_entity = "TRUE"
Boolean vhdllout_write_top_configuration = "FALSE"
string vhdllout_zero_name = "'0'"
string write_test_vhdlout = "textio"
```

DESCRIPTION

Variables that directly affect the **write**, **write_lib**, and **write_test** commands for VHDL format.

The VHDL library variables (**vhdl-lib**) determine the timing violation behavior (for example, hazards and forbidden timing events) of the generated VHDL library. For more information on VHDL library variables, refer to the *Library Compiler Reference Manual: VHDL Libraries*.

The VHDL output variables (**vhdl-out**) determine the format of the VHDL design output file. For more information on VHDL output variables, refer to the *VHDL Compiler Reference Manual: VHDL Libraries* and the **hdl_variables** and **io_variables** manual pages.

To view this manual page online, type **man vhdlio_variables**. To view an individual variable description, type **man var_name**.

vhdl-lib-architecture

Determines the VHDL model types for the **write_lib** command to generate. **VITAL** selects VITAL models.

vhdl-lib-glitch-handle

When **true** (the default value), timing hazards have glitch-forced (glitch on detect) **Xs**. When **false**, **Xs** are spike-forced (glitch on event).

vhdl-lib-logic-system

Selects the logic system in which to create the VHDL libraries. The default value (ieee-1164) is the only valid choice available. It represents the IEEE Std 1164.1 logic system. Do not change the value of this variable to anything other than ieee-1164.

vhdl-lib-logical-name

Defines the logical name to be used by the VHD libraries.

vhdl-lib-negative-constraint

When **true**, all cells in the generated VITAL library can handle negative timing constraints, ignoring the cell attribute **handle_negative_constraint** value set in the technology library. When **false** (the default), only cells in the generated VITAL library whose cell attribute **handle_negative_constraint** is **true** can handle negative timing constraints.

vhdl-lib-pulse-handle

Specifies whether timing hazards are to have glitch_forced (glitch on detect) or spike_forced (glitch on event) **Xs**. Default value is **true**.

vhdl-lib-sdf-edge

Determines whether edge information is to be added to delay generics in VITAL libraries. The default value is **false**.

vhdl-lib-tb-compare

Controls library testbench generation. No testbenches are created if this variable is set to **0** (the default). Otherwise, **vhdl-lib-tb-compare** specifies the default value for the testbench's **Cmp_Algorithm** generic integer flag. The greater the number from 1 to 5, the more rigorous the verification.

vhdlio_variables

vhdllib_tb_x_eq_dontcare
 Specifies the default value for the **X_Eq_DontCare** generic Boolean flag of the testbenches. If **X_Eq_DontCare** is **true**, X states are ignored during output comparisons. The default is **false**.

vhdllib_timing_checks
 Determines the default value of the cell **TimingChecksOn** generic Boolean flag in VITAL model. The default value is **true**.

vhdllib_timing_mesg
 Determines the value of GlitchMode parameter for VitalPropagatePathDelay procedure in VITAL model. The default is *true*.

vhdllib_timing_xgen
 Determines the default value for the **XGenerationOn** generic Boolean flag in the VITAL model. The default is *false*.

vhdllib_vital_99
 Determines whether VITAL libraries are to incorporate changes for VITAL 99. The default is **false**.

vhdlout_architecture_name
 Determines the name that will be used for the architecture the **write -f vhd1** command writes out.

vhdlout_bit_type
 Sets the basic bit type in a design written to VHDL. This is useful when your design methodology is based on a logic value system that is not *std_logic*. The default is *std_logic*.

vhdlout_bit_type_resolved
 When **true** (the default value), prevents **VHDLout** from creating new bus resolution functions when writing wired logic. When **false**, **vhdlout** creates bus resolution functions for signals with more than one driver. Set this variable to **true** if the **vhdlout_bit_type** is a resolved type.

vhdlout_bit_vector_type
 Sets the basic bit_vector type in a design written to VHDL. This is useful when your design methodology is based on a logic value system that is not *std_logic*.

vhdlout_conversion_functions
 Overrides conversion functions that are written out. The value of this variable is a list of lists. Each lower level list is a list of three strings representing the "from type," the "to type," and the function used for the conversion.

vhdlout_dont_create_dummy_nets
 When *true*, the vhd1 writer does not create any dummy nets for connecting unused pins or ports.

vhdlout_dont_write_types
 When *true*, and if **vhdlout_single_bit** is *false* (the default value), type declarations for any types that are declared in the original VHDL are not written. Only special types needed by **vhdlout** are declared, and are given

unique names. Other types should be declared in a user-defined package using **vhdlout_use_packages**.

vhdlout_equations

When *true*, combinational logic is written as technology-independent Boolean equations, and sequential logic is written as technology-independent wait statements. When *false* (the default value), all logic is written as technology-specific netlists.

vhdlout_follow_vector_direction

When **true** (the default value), the VHDL writer writes out correct array range direction. For example, 10 down to 0, if the original is 10 down to 0.

vhdlout_lower_design_vector

Determines the way in which the **write -f vhd1** command writes out ports on lower-level designs. The default value is **true**.

vhdlout_one_name

Determines the literal name for constant bit value '1' in a design written to VHDL. This is useful when your design methodology is based on a more general logic value than "BIT". This variable is used with **vhdlout_bit_type**.

vhdlout_package_naming_style

Determines the name used for the type conversion packages written out by vhdout.

vhdlout_preserve_hierarchical_types

Affects how ports on lower-level designs are written out with **write -f vhd1**. A lower-level design is instantiated by any of the designs being written out. In contrast, ports on top-level designs are controlled by **vhdlout_single_bit**. Allowed values are *USER*, *VECTOR* (the default), and *BIT*. For definitions of the allowed values, refer to the **vhdlout_preserve_hierarchical_types** manual page.

vhdlout_separate_scan_in

Affects how the scan chain is written out in VHDL. When **true**, the scan chain is written out as a separate file from the design; when *false* (the default value), the scan chain is written out in the same file as the design.

vhdlout_single_bit

Affects how ports on the top-level design are written out. Lower level design ports are controlled by **vhdlout_preserve_hierarchical_types**. A design is considered lower level if it is instantiated by any of the designs being written out.

vhdlout_synthesis_off

This variable has an effect only if **vhdlout_write_top_configuration** is **true**. When **vhdlout_synthesis_off** is **true** (the default), if **vhdlout_write_top_configuration** is also **true**, **write -format vhd1** writes out "synthesis_off" and "synthesis_on" at the beginning and at the end of the configuration statement. When **vhdlout_synthesis_off** is *false*, **write -format vhd1** does not write out these strings.

vhdlout_target_simulator

Names the target simulator to which the VHDL file is written. Currently, the

only valid value is *xp*.

`vhdlout_three_state_name`

Names the high impedance bit value used for three-state device values. The default is *Z*.

`vhdlout_three_state_res_func`

Names a user-supplied three-state resolution function, which must be in one of the packages specified by **`vhdlout_use_packages`**. If this variable is set to an empty string, a default three-state resolution function is written out, if needed. The default three-state resolution function drives a signal to "unknown" if the signal is driven more than once by logic zero or logic one.

`vhdlout_time_scale`

Specifies the scaling of the delays the tool writes to timing files, in Synopsys VHDL format. The **`write_timing`** command writes delays from the tool to timing files.

`vhdlout_top_configuration_arch_name`

Determines the name of the outside architecture. Depending on the setting of **`vhdlout_write_top_configuration`**, a configuration statement is written out by `vhdlout`.

`vhdlout_top_configuration_entity_name`

Determines the name of the outside entity. Depending on the setting of **`vhdlout_write_top_configuration`**, a configuration statement is written by `vhdlout`.

`vhdlout_top_configuration_name`

Determines the name of the configuration that is written out under control of **`vhdlout_write_top_configuration`**.

`vhdlout_top_design_vector`

Affects the way in which the **`write -f vhd1`** command writes out ports on the top-level design.

`vhdlout_unconnected_pin_prefix`

Affects the way in which the **`write -f vhd1`** command writes out unconnected pin names.

`vhdlout_unknown_name`

Specifies the value used to drive a signal to the unknown state. The default for this variable is *X*.

`vhdlout_use_packages`

A list of package names. A "use" clause is written into the VHDL file for each of these packages for all entities. If this variable is not set, or is set to an empty list (`{}`), it has no effect on the **`write`** command.

`vhdlout_wired_and_res_func`

Specifies the name of a wired AND resolution function. This user-supplied function must be in one of the packages specified by **`vhdlout_use_packages`**. If this variable is set to an empty string, a default wired AND resolution function is written out, if needed.

`vhdlout_wired_or_res_func`

Specifies the name of a wired OR resolution function. This user-supplied function must be in one of the packages specified by **`vhdlout_use_packages`**. If this variable is set to an empty string, a default wired OR resolution function is written out, if needed.

`vhdlout_write_architecture`

When **`true`** (the default value), **`vhdlout`** writes architecture declarations. When *false*, no architecture declarations are written. This variable may be used with **`vhdlout_write_entity`** and **`vhdlout_write_top_configuration`** to control what information will be written out by the **`write -format vhd1`** command.

`vhdlout_write_components`

When **`true`** (the default value), **`vhdlout`** writes component declarations for cells mapped to a technology library. When *false*, no component declarations are written. Component declarations are required by VHDL. If you set this variable to *false*, make sure that **`vhdlout_use_packages`** includes a package containing the necessary component declarations.

`vhdlout_write_entity`

When **`true`** (the default value), **`vhdlout`** writes entity declarations. When *false*, no entity declarations are written. This variable may be used with **`vhdlout_write_architecture`** and **`vhdlout_write_top_configuration`** to control the information that will be written out by the **`write -format vhd1`** command.

`vhdlout_write_top_configuration`

When **`true`**, **`vhdlout`** writes a configuration statement, if necessary. It is necessary when ports on the topmost design are written as vectors instead of user types. When *false*, no configuration statement is written.

`vhdlout_zero_name`

Determines the literal name for constant bit value '0' in a design written to VHDL. This is useful when your design methodology is based on a more general logic value than BIT. Used with **`vhdlout_bit_type`**. The default is 0.

`write_test_vhdlout`

Determines whether the **`write_test -format vhd1`** command generates a VHDL test program in TEXTIO format.

SEE ALSO

`write(2)`
`write_lib(2)`
`write_test(2)`
`hdl_variables(3)`
`io_variables(3)`

vhdlout_local_attributes

This variable is obsolete.

SYNTAX

GROUP

DESCRIPTION

via_attributes

Contains attributes related to via.

DESCRIPTION

Contains attributes related to via.

You can use **get_attribute** to determine value of an attribute, and use **report_attribute** to get a report of all attributes on specified object. Specified with **list_attribute -class via -application**, the definition of attributes can be listed.

Via Attributes

array_size

Specifies array size of a via object. Its format is **{col row}**.
The data type of **array_size** is string.
This attribute is read-only.

bbox

Specifies the bounding-box of a via. The **bbox** is represented by a **rectangle**. The format of a *rectangle* specification is **{{llx lly} {urx ury}}**, which specifies the lower-left and upper-right corners of the rectangle.
The data type of **bbox** is string.
This attribute is read-only.

bbox_ll

Specifies the lower-left corner of the bounding-box of a via.
The **bbox_ll** is represented by a **point**. The format of a *point* specification is **{x y}**.
You can get the **bbox_ll** of a via, by accessing the first element of its **bbox**.
The data type of **bbox_ll** is string.
This attribute is read-only.

bbox_llx

Specifies x coordinate of the lower-left corner of the bounding-box of a via.
The data type of **bbox_llx** is integer.
This attribute is read-only.

bbox_lly

Specifies y coordinate of the lower-left corner of the bounding-box of a via.
The data type of **bbox_lly** is integer.
This attribute is read-only.

bbox_ur

Specifies the upper-right corner of the bounding-box of a via.
The **bbox_ur** is represented by a **point**. The format of a *point* specification is **{x y}**.
You can get the **bbox_ur** of a via, by accessing the second element of its **bbox**.
The data type of **bbox_ur** is string.
This attribute is read-only.

bbox_urx
Specifies x coordinate of the upper-right corner of the bounding-box of a via.
The data type of **bbox_urx** is integer.
This attribute is read-only.

bbox_ury
Specifies y coordinate of the upper-right corner of the bounding-box of a via.
The data type of **bbox_ury** is integer.
This attribute is read-only.

cell_id
Specifies Milkyway design ID in which a via object is located.
The data type of **cell_id** is integer.
This attribute is read-only.

center
Specifies the center position of a via object.
The data type of **center** is string.
This attribute is read-only.

col
Specifies number of horizontal columns of a via object.
The data type of **col** is integer.
This attribute is read-only.

layer
Specifies layer name list with which a via object is associated. Its format is {**via_layer lower_layer upper_layer**}.
The data type of **layer** is string.
This attribute is read-only.

lower_layer
Specifies lower layer name.
The data type of **lower_layer** is string.
This attribute is read-only.

name
Specifies name of a via object.
The data type of **name** is string.
This attribute is read-only.

net_id
Specifies object ID of the net associated with a via object.
The data type of **net_id** is integer.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

net_type
Specifies type of net associated with a via object.
The data type of **net_type** is string.
This attribute is read-only.

object_class
Specifies object class name of a via object, which is **via**.
The data type of **object_class** is string.

This attribute is read-only.

object_id

Specifies object ID in Milkyway design file.
The data type of **object_id** is integer.
This attribute is read-only.

object_type

Specifies object type name, which can be **via**, **via_array** or **via_cell**.
The data type of **object_type** is string.
This attribute is read-only.

orientation

Specifies orientation of a via object.
The data type of **orientation** is string.
Its valid values are:

- **N**
- **E**
- **S**
- **W**
- **FN**
- **FE**
- **FS**
- **FW**

This attribute is writable. You can use **set_attribute** to modify its value on a specified object. However when object type is **via_cell**, you can't change its **orientation**.

owner

Specifies Milkyway design file name in which a via is located.
The data type of **owner** is string.
This attribute is read-only.

owner_net

Specifies net name which a via is connected to.
The data type of **owner_net** is string.

via_attributes

This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

route_type

Specifies route type of a via.
The data type of **route_type** is string.
Its valid values are:

- **User Enter** or **user_enter**
- **Signal Route** or **signal_route**
- **Signal Route (Global)** or **signal_route_global**
- **P/G Ring** or **pg_ring**
- **Clk Ring** or **clk_ring**
- **P/G Strap** or **pg_strap**
- **Clk Strap** or **clk_strap**
- **P/G Macro/IO Pin Conn** or **pg_macro_io_pin_conn**
- **P/G Std. Cell Pin Conn** or **pg_std_cell_pin_conn**
- **Zero-Skew Route** or **clk_zero_skew_route**
- **Bus** or **bus**
- **Shield (fix)** or **shield**
- **Shield (dynamic)** or **shield_dynamic**
- **Fill Track** or **clk_fill_track**
- **Unknown** or **unknown**

It is determined by Tcl variable `mw_attr_value_no_space` whether **get_attribute** or **report_attribute** returns `route_type` containing spaces or underscores. This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

`row`

Specifies number of vertical rows in a via object.
The data type of **row** is integer.
This attribute is read-only.

`upper_layer`

Specifies upper layer name.
The data type of **upper_layer** is string.
This attribute is read-only.

`via_layer`

Specifies via layer name.
The data type of **via_layer** is string.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

`via_master`

Specifies the via master,Â’s name defined in the library,Â’s technology file; for `via_cell`, it is the library cell’s name.
The data type of **via_master** is string.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

`x_pitch`

Specifies the center-to-center spacing of a via object in the horizontal direction.
The data type of **x_pitch** is float.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

`y_pitch`

Specifies the center-to-center spacing of a via object in the vertical direction.
The data type of **y_pitch** is float.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

SEE ALSO

```
get_attribute(2),  
list_attribute(2),  
mw_attr_value_no_space(3),  
report_attribute(2),  
set_attribute(2).
```

view_arch_types

Sets the contents of the architecture option menu. Contains a list of host machine architectures you can use for background jobs from the Design Analyzer viewer.

TYPE

list

DEFAULT

sparcOS5 hpux10 rs6000 sgimips

GROUP

view_variables

DESCRIPTION

Sets the contents of the architecture option menu. Contains a list of host machine architectures you can use for background jobs from the Design Analyzer viewer.

To determine the current value of this variable, use **printvar view_arch_types**. For a list of all **view** variables and their current values, use the **print_variable_group view** command.

SEE ALSO

view_variables(3)

view_background

Specifies the background color of the Design Analyzer viewer.

TYPE

string

DEFAULT

black

GROUP

view_variables

DESCRIPTION

Specifies the background color of the Design Analyzer viewer. Valid settings are *white* (the default) and *black*.

To determine the current value of this variable, type **printvar view_background**. For a list of all **view** variables and their current values, type **print_variable_group view**.

SEE ALSO

view_variables(3)

view_command_log_file

Names a file and its location that is to contain all text written to the Design Analyzer Command window.

TYPE

string

DEFAULT

"./view_command.log"

GROUP

view_variables

DESCRIPTION

Names a file and its location that is to contain all text written to the Design Analyzer Command window. The default is to set this variable.

To determine the current value of this variable, use **printvar view_command_log_file**. For a list of all **view** variables and their current values, type **print_variable_group view**.

SEE ALSO

command_log_file(3)

view_log_file(3)

view_execute_script_suffix

Displays only files with the stated suffixes, from directories you select in the Execute Script option window of the Setup menu of Design Analyzer.

TYPE

list

DEFAULT

".script .scr .dcs .dcv .dc .con .tcl"

GROUP

suffix_variables

DESCRIPTION

Displays only files with the stated suffixes, from directories you select in the Execute Script option window of the Setup menu of Design Analyzer.

To determine the current value of this variable, type **printvar view_execute_script_suffix**. For a list of all **suffix** variables and their current values, type **print_variable_group suffix**.

SEE ALSO

suffix_variables(3)

view_read_file_suffix

Displays only files with the stated suffixes, from directories you select with the Read option of the File menu of Design Analyzer.

TYPE

list

DEFAULT

db gdb sdb edif eqn fnc lsi mif NET pla st tdl v vhd vhd1 xnf

GROUP

suffix_variables

DESCRIPTION

Displays only files with the stated suffixes, from directories you select with the Read option of the File menu of Design Analyzer.

To determine the current value of this variable, type **printvar view_read_file_suffix**. For a list of all **suffix** variables and their current values, type **print_variable_group suffix**.

SEE ALSO

suffix_variables(3)

view_report_append

Specifies to the tool to append to the specified file the reports the Design Vision menus generate.

TYPE

Boolean

DEFAULT

true

GROUP

view_variables

DESCRIPTION

Specifies to the tool to append to the specified file the reports the Design Vision menus generate. To achieve this result, set the value of this variable to *true* (the default).

For a list of all **view** variables and their current values, type **print_variable_group view**.

To determine the current value of this variable, enter one of the following commands, depending on which mode you are using:

```
prompt> printvar view_report_append
or
dc_shell-t> printvar view_report_append
```

SEE ALSO

view_variables(3)

view_report_interactive

Specifies to the tool to send to the command line view the reports generated by Design Vision menus.

TYPE

Boolean

DEFAULT

true

GROUP

view_variables

DESCRIPTION

Specifies to the tool to send to the command line view the reports generated by Design Vision menus. To achieve this result, set the value of this variable to *true*.

For a list of all **view** variables and their current values, type **print_variable_group view**.

To determine the current value of this variable, type one of the following commands, depending on which mode you are using:

```
prompt> printvar view_report_interactive
or
dc_shell-t> printvar view_report_interactive
```

SEE ALSO

view_variables(3)

view_report_output2file

Specifies to the tool to send to the specified file the reports generated by Design Vision menus.

TYPE

Boolean

DEFAULT

false

GROUP

view_variables

DESCRIPTION

Specifies to the tool to send to the specified file the reports generated by Design Vision menus.

To achieve this result, set the value of this variable to *true*. The default is *false*.

For a list of all **view** variables and their current values, type **print_variable_group view**.

To determine the current value of this variable, type one of the following commands, depending on which mode you are using:

```
prompt> printvar view_report_output2file
or
dc_shell-t> printvar view_report_output2file
```

SEE ALSO

view_variables(3)

view_variables

Directly affect the graphic display used by the Design Analyzer viewer.

SYNTAX

```
string default_schematic_options = "-size infinite"
string test_design_analyzer_uses_insert_scan = "true"
string text_editor_command = "xterm -fn 8x13 -e vi %s &"
string text_print_command = "lpr -Plw"
string view_analyze_file_suffix = {"v", "vhd", "vhdl"}
list view_arch_types = {"apollo", "decmlps", "hp700", "mips", "necmips", "rs6000",
                          "sgimips", "sonymips", "sparc"}

string view_background = "black"
string view_cache_images = "true"
string view_command_log_file = "./view_command.log"
integer view_command_win_max_lines = 1000
Boolean view_dialogs_modal = true
Boolean view_disable_cursor_warping = "true"
Boolean view_disable_error_windows = "false"
Boolean view_disable_output = "false"
integer view_error_window_count = 6
list view_execute_script_suffix = {".script", ".scr", ".dcs", ".dcsh", ".dc",
                                     ".con", ".wscr", ".rscr"}

string view_info_search_cmd = "/remote/src/syn/ice/cbu.slot3/infosearch/scripts/
InfoSearch"
string view_log_file = ""
string view_on_line_doc_cmd = ""
list view_read_file_suffix = {"db", "sdb", "edif", "eqn", "fnc", "lsi", "mif",
                              "NET", "pla", "st", "tdl", "v", "vhd", "vhdl"}

string view_script_submenu_items = {"DA to SGE Transfer", "write_sge"}
list view_tools_menu_items = {}
string view_use_small_cursor = ""
string view_use_x_routines = "true"
list view_write_file_suffix = {"db", "sdb", "do", "edif", "eqn", "fnc", "lsi",
                              "NET", "neted", "pla", "st", "tdl", "v", "vhd", "vhdl",
                              "xnf"}

string x11_set_cursor_background = ""
string x11_set_cursor_foreground = ""
integer x11_set_cursor_number = "-1"

Boolean view_report_interactive = "true"
Boolean view_report_output2file = "false"
Boolean view_report_append = "false"
```

DESCRIPTION

Directly affect the graphic display used by the Design Analyzer viewer. Defaults are shown above, under "Syntax."

For a list of **view** variables and their current values, type **print_variable_group view**. To view this manual page online, type **help view_variables**. To view an individual variable description, type **help var**, where *var* is the name of the

variable.

`default_schematic_options`

Specifies options to use when schematics are generated. When set to "-size infinite" (default), the schematic for a design is displayed on a single page. Used by the Design Analyzer.

`test_design_analyzer_uses_insert_scan`

When *true* (the default), **design_analyzer** executes **insert_scan** when the Tools/Test Synthesis.../Insert Internal Scan Circuitry... menu is selected in the Design Analyzer text window and the OK button is pushed. When *false*, **design_analyzer** executes **insert_dft** instead of **insert_scan**.

`text_editor_command`

Specifies the command that executes when the **Edit/File** menu is selected in the Design Analyzer text window.

`text_print_command`

Specifies the command that executes when the **File/Print** menu is selected in the Design Analyzer text window.

`view_analyze_file_suffix`

This variable is a list of file extensions that specifies the files that are shown in the File/Analyze dialog. Its default value is "{.vhd, .v, .vhdl}".

`view_arch_types`

List of host machine architectures that can be used for background jobs from the Design Analyzer viewer. This variable is used to set the contents of the architecture option menu.

`view_background`

Specifies the background color of the Design Analyzer viewer. The valid settings are "black" (default) and "white".

`view_cache_images`

Specifies whether bit maps are to be cached for fast schematic drawing. Default value is *true*.

`view_command_log_file`

When set, all text written to the Design Analyzer Command Window is written to the specified file.

`view_command_win_max_lines`

The maximum number of lines to be saved in the Design Analyzer command window. When a larger number of lines of output are added to the command window, the older lines at the top of the list are removed.

`view_dialogs_modal`

When *true*, the question and error dialogs in Design Analyzer require a confirmation before you can continue to enter commands. The default is *true*.

`view_disable_cursor_warping`

When *false*, the cursor is automatically "warped" (or moved) to dialogs when they are posted. Default is *true*.

`view_variables`

`view_disable_error_windows`

When *true*, error windows are not posted when errors occur. Default is *false*.

`view_disable_output`

This variable specifies whether output to the Design Analyzer Command Window is to be disabled. This is useful when running the Design Analyzer over slow networks, like telephone lines. The default value is *false*.

`view_error_window_count`

Maximum number of errors that Design Analyzer reports for a command. If more than the specified number of errors occurs, you are informed that additional errors can be seen in the command window. The error window is suppressed until the end of the command. Default is 6.

`view_execute_script_suffix`

Used by the "Execute Script" option of the Setup menu, it displays only files with these suffixes from directories selected in the option window.

`view_info_search_cmd`

If this variable is set, the optional menu item "On-Line Information" allows you to invoke the online information viewer. The value of this variable should be set to the UNIX pathname to the online information viewer.

`view_log_file`

Specifies the file where events that occur in the viewer are stored. This file is useful for error reporting and can be executed with the "Execute Script" option of the Setup menu, or inserted with the **include** command in the Design Analyzer.

`view_on_line_doc_cmd`

If this variable is set, the optional menu item, called "On-Line Documentation," allows you to invoke the on-line documentation viewer. The value of this variable should be set to the UNIX command to invoke the on-line documentation view.

`view_read_file_suffix`

Used by the "Read" option of the Design Analyzer File menu. Displays only files with these suffixes from directories that you select in the option window.

`view_script_submenu_items`

A **.synopsys_dc.setup** file variable that permits partial configuration of the Setup pulldown menu to add a new menu item for invoking user scripts.

`view_tools_menu_items`

A **.synopsys_dc.setup** file variable that permits partial configuration of the Tools pulldown menu to add a new menu item for invoking user scripts. Contains a list of strings, grouped into pairs. The first member of the pair is the text that will appear in the submenu. The second member is the string that is sent to the **dc_shell** command line for execution.

`view_use_small_cursor`

Is *true* if the X-display supports only 16-bit (small) cursors.

`view_use_x_routines`

When *false*, internal arc-drawing routines (instead of X routines) are used. If there is a math co-processor chip on the same machine that the X server is on, X arc-drawing routines are faster. Otherwise, internal arc-drawing routines are faster. Default is *true*.

`view_write_file_suffix`

Used by the "Save As" option of the File menu. Displays only files with these suffixes from directories selected in the option window.

`x11_set_cursor_background`

Specifies background color of the cursor in the Design Analyzer menus and viewer. This variable can be set in the **.synopsys_dc.setup** initialization file. Any color in **/usr/lib/X11/rgb.txt** is valid.

`x11_set_cursor_foreground`

Specifies foreground color of the cursor in the Design Analyzer menus and viewer. This variable can be set in the **.synopsys_dc.setup** initialization file. Any color in **/usr/lib/X11/rgb.txt** is valid.

`x11_set_cursor_number`

Specifies the cursor from the standard X cursor font used by the Design Analyzer menus and viewer. If this variable is not set, or is set to "-1", the cursor used by the X background is also used for all windows and menus. This variable can be set in the **.synopsys_dc.setup** initialization file.

`view_report_interavtive`

When set to *true*, reports generated via Design Vision's menus are sent to the command line view.

`view_report_output2file`

When set to *true*, reports generated via Design Vision's menus are sent to the file specified via the report dialog box.

`view_report_append`

`view_report_append`: When set to *true*, reports generated via Design Vision's menus are appended to the file specified via the report dialog box.

SEE ALSO

design_analyzer (1); **create_schematic** (2).

view_write_file_suffix

Displays only files with the stated suffixes, from directories you select with the Save As option of the File menu of Design Analyzer.

TYPE

list

DEFAULT

gdb db sdb do edif eqn fnc lsi NET neted pla st tdl v vhd vhd1 xnf

GROUP

suffix_variables

DESCRIPTION

Displays only files with the stated suffixes, from directories you select with the Save As option of the File menu of Design Analyzer.

To determine the current value of this variable, type **printvar view_write_file_suffix**. For a list of all **suffix** variables and their current values, type **print_variable_group suffix**.

SEE ALSO

suffix_variables(3)

voltage_area_attributes

Contains attributes related to voltage area.

DESCRIPTION

Contains attributes related to voltage area.

You can use **get_attribute** to determine value of an attribute, and use **report_attribute** to get a report of all attributes on specified object. Specified with **list_attribute -class voltage_area -application**, the definition of attributes can be listed.

Voltage Area Attributes

bbox

Specifies the bounding-box of a voltage area. The **bbox** is represented by a **rectangle**.

The format of a *rectangle* specification is {{llx lly} {urx ury}}, which specifies the lower-left and upper-right corners of the rectangle.

The data type of **bbox** is string.

This attribute is read-only.

bbox_ll

Specifies the lower-left corner of the bounding-box of a voltage area.

The **bbox_ll** is represented by a **point**. The format of a *point* specification is {x y}.

You can get the **attr_name** of a voltage area, by accessing the first element of its **bbox**.

The data type of **bbox_ll** is string.

This attribute is read-only.

bbox_llx

Specifies x coordinate of the lower-left corner of the bounding-box of a voltage area.

The data type of **bbox_llx** is double.

This attribute is read-only.

bbox_lly

Specifies y coordinate of the lower-left corner of the bounding-box of a voltage area.

The data type of **bbox_lly** is double.

This attribute is read-only.

bbox_ur

Specifies the upper-right corner of the bounding-box of a voltage area.

The **bbox_ur** is represented by a **point**. The format of a *point* specification is {x y}.

You can get the **bbox_ur** of a voltage area, by accessing the second element of its **bbox**.

The data type of **bbox_ur** is string.

This attribute is read-only.

bbox_urx

Specifies x coordinate of the upper-right corner of the bounding-box of a voltage area.
The data type of **bbox_urx** is double.
This attribute is read-only.

bbox_ury

Specifies y coordinate of the upper-right corner of the bounding-box of a voltage area.
The data type of **bbox_ury** is double.
This attribute is read-only.

cell_id

Specifies Milkyway design ID in which a voltage area object is located.
The data type of **cell_id** is integer.
This attribute is read-only.

color

Specifies the color for a voltage area and its leaf cells.
The data type of **color** is string.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

guardband

Specifies the guardband of a voltage area.
Its format is {**guardband_x** **guardband_y**}.
Guardband is the spacing along the boundary of a voltage area where cells cannot be placed because of the lack of power supply rails.
The data type of **guardband** is string.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

guardband_x

Specifies the guardband width in the horizontal direction.
The data type of **guardband_x** is integer.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

guardband_y

Specifies the guardband width in the vertical direction.
The data type of **guardband_y** is integer.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

is_fixed

Specifies whether a voltage area is in a fixed location, and the shaping will ignore it.
The data type of **is_fixed** is boolean.
This attribute is writable. You can use **set_attribute** to modify its value on a specified object.

modules

Specifies collection of the top node cells inside a voltage area.
The data type of **modules** is collection.
This attribute is read-only.

name

Specifies name of a voltage area object.
The data type of **name** is string.
This attribute is read-only.

object_class

Specifies object class name of a voltage area, which is **voltage_area**.
The data type of **object_class** is string.
This attribute is read-only.

object_id

Specifies object ID in Milkyway design file.
The data type of **object_id** is integer.
This attribute is read-only.

points

Specifies point list of a voltage area's boundary.
The data type of **points** is string.
This attribute is read-only.

utilization

Specifies utilization of a voltage area.
The data type of **utilization** is float.
This attribute is read-only.

SEE ALSO

get_attribute(2),
list_attribute(2),
report_attribute(2),
set_attribute(2).

wildcards

Describes supported wildcard characters and ways to escape them.

DESCRIPTION

Design Compiler supports following characters as wildcards.

Asterisks (*) substitute for a string of characters of any length.
Question marks (?) substitute for a single character.

Following commands support wildcards.

```
find
get_cells
get_clocks
get_designs
get_lib_cells
get_lib_pins
get_libs
get_multibits
get_nets
get_pins
get_ports
get_references
list_designs
list_instances
list_libs
trace_nets
untrace_nets
```

In addition to these, commands that perform an implicit find also support wildcarding feature.

Escaping Wildcards

Wildcard characters must be escaped using double backslashes (\\) to remove their special regular expression meaning. Refer to EXAMPLES section of this manual page for more information.

Escaping Escape Character (\)

This is similar to that of escaping wildcard characters, but needs one escape character each to escape the escape character. Refer to EXAMPLES section of this manual page for more information.

EXAMPLES

Using Wildcards

The following example finds all nets in the current design which are prefixed by in and followed by any two characters.

```
dc_shell> find(net, in??)
{"in11", "in21"}
```

The equivalent command in Tcl-based dc_shell is:

```
dc_shell-t> get_nets in??
{"in11", "in21"}
```

The following example finds all cells in the current design which are prefixed by U and followed by a string of characters of any length.

```
dc_shell> find(cell, "U*")
{"U1", "U2", "U3", "U4"}
```

The equivalent command in Tcl-based dc_shell is:

```
dc_shell-t> get_cells U*
{"U1", "U2", "U3", "U4"}
```

Escaping Wildcards

The following example finds design test?1 in the system.

```
dc_shell> find(design, "test\\?1")
{"test?1"}
```

The equivalent command in Tcl-based dc_shell is:

```
dc_shell-t> get_designs {test\\?1}
{"test?1"}
```

The same above example can be used in Tcl-based dc_shell using the Tcl **list** command.


```
dc_shell-t> get_designs [list {test\?1}]  
{"test?1"}
```

If neither curly braces nor **list** is used in Tcl-based dc_shell, then the syntax is as below:

```
dc_shell-t> get_designs test\\\\?1  
{"test?1"}
```

Escaping Escape Character (\)

The following example finds design test\1 in the system.

```
dc_shell> find(design, "test\\\\1")  
{"test\1"}
```

The equivalent command in Tcl-based dc_shell is:

```
dc_shell-t> get_designs {test\\\\1}  
{"test\1"}
```

The same above example can be used in Tcl-based dc_shell using the Tcl **list** command.

```
dc_shell-t> get_designs [list {test\\1}]  
{"test\1"}
```

If neither curly braces nor **list** is used in Tcl-based dc_shell, then the syntax is as below:

```
dc_shell-t> get_designs test\\\\\\\\\\\\1  
{"test\1"}
```

write_name_nets_same_as_ports

Specifies to the tool that nets are to receive the same names as the ports the nets are connected to.

TYPE

Boolean

DEFAULT

false

GROUP

edif_variables, io_variables

DESCRIPTION

Specifies to the tool that nets are to receive the same names as the ports the nets are connected to. To achieve this result, set the value of this variable to *true*. This variable affects nets in design descriptions written in EDIF, LSI, or TDL format. (Other nets might be renamed to avoid creating shorts.) The default value of this variable is *false*.

Note: In the EDIF format, even if the **edifout_power_and_ground_representation** variable is set to *port*, the power and ground nets will not be named the same as the power and ground ports that are written in the interface construct of each cell construct.

Net names in the design database are unchanged; that is, only the file being written out is affected and not the original design data.

To determine the current value of this variable, type **printvar write_name_nets_same_as_ports**. For a list of all **edif** or **io** variables and their current values, type **print_variable_group edif** or **print_variable_group io**.

SEE ALSO

edif_variables(3)
io_variables(3)

write_sdc_output_lumped_net_capacitance

Determines whether or not the **write_sdc** command outputs net loads.

TYPE

Boolean

DEFAULT

true

DESCRIPTION

When true, the write_sdc command outputs net loads. When false, write_sdc does not output net loads. The net loads are output thru set_load statements during write_sdc.

The default value of the variable is true. That is, by default all net loads will be output during write_sdc execution.

SEE ALSO

set_load(2)
write_sdc(2)

write_sdc_output_net_resistance

Determines whether or not the **write_sdc** command outputs net resistance.

TYPE

Boolean

DEFAULT

true

DESCRIPTION

When true, the write_sdc command outputs net resistance. When false, write_sdc does not output net resistance. The net resistance are output thru set_resistance statements during write_sdc.

The default value of the variable is true. That is, by default all net resistance will be output during write_sdc execution.

SEE ALSO

set_resistance(2)
write_sdc(2)

write_test_variables

SYNTAX

```
list write_test_formats = {"synopsys", "tssi_ascii", "tds", "verilog", "vhdl", "wgl"}
string write_test_include_scan_cell_info = "true"
string write_test_input_dont_care_value = "X"
int write_test_max_cycles = 0
int write_test_max_scan_patterns = 0
string write_test_pattern_set_naming_style = "TC_Syn_%d"
string write_test_round_timing_values = "true"
string write_test_scan_check_file_naming_style = "%s_schk.%s"
string write_test_vector_file_naming_style = "%s_%d.%s"
string write_test_vhdlout = "textio"
string write_test_new_translation_engine = "false"
```

DESCRIPTION

These variables directly affect the **write_test** command.

To view this manual page online, type **man write_test_variables**. To view an individual variable description, type **man var**, where *var* is the variable name.

write_test_formats

Specifies the test vector formats recognized and created by the **write_test** command.

write_test_include_scan_cell_info

Provides a mechanism to specify that the scan-chain/cell/inversion information should not be included in vector files. By default, this variable is set TRUE.

write_test_input_dont_care_value

Controls the logic value output by the **write_test** command when you have an input with a "don't-care" condition.

write_test_max_cycles

Allows the user to control the automatic partitioning of long test sets across multiple files by specifying the maximum number of tester cycles to be contained in any one vector file.

write_test_max_scan_patterns

Allows the user to control the automatic partitioning of long test sets across multiple files by specifying the maximum number of scan-test patterns to be contained in any one vector file.

write_test_pattern_set_naming_style

Specifies how pattern sets are named when long test sets are partitioned across multiple files.

write_test_round_timing_values

When *true* (the default), **write_test** rounds all timing values (for example,

input delay, output strobe time, bidir delay, clock period and clock edge times) to the nearest integer. If you do not want the timing values to be rounded to the nearest integer, set the value of this variable to *false*.

`write_test_scan_check_file_naming_style`

Specifies how to name the file containing the vectors which test the scan chain logic.

`write_test_vector_file_naming_style`

Specifies how scan vector file names are derived, especially when long test sets must be split across multiple files.

`write_test_vhdlout`

Determines whether or not **`write_test -format vhdl`** generates a VHDL test program in TEXTIO format. When this variable has the value of *textio*, the VHDL test program is written in TEXTIO format. When the variable has the value *inline* (the default), TEXTIO format is not used.

`write_test_verilogout`

Determines whether or not **`write_test -format verilog`** or **`write_test -format verilog -parallel`** generates an LSI Logic- specific serial or parallel Verilog vector format. When this variable has the value *lsi*, the generated Verilog format will be specific to LSI Logic's test protocol. When the variable is unset (the default) or is set to any other value, the generated Verilog format will conform to the currently loaded test protocol.

`write_test_wglout`

Determines whether or not **`write_test -format wgl`** generates LSI Logic-specific WGL vector format. When this variable has the value *lsi*, the generated WGL vector format will be specific to LSI Logic's test protocol. When the variable is unset (the default) or is set to any other value, the generated WGL format will conform to the currently loaded test protocol.

`write_test_new_translation_engine`

Choose to use the new translation engine or the old one to do test program format translation. By default, this variable is set FALSE.

SEE ALSO

`write_test(2)`