




Auto Focus System for Microscopy **AFC-6**

Auto Focus Controller AFC-6

INSTRUCTION MANUAL

– Operation Box –



CHUO PRECISION INDUSTRIAL CO., LTD.

Introduction

Thank you for purchasing our Auto Focus Controller AFC.

AFC is an exclusive controller for our Auto Focus Microscopes and Auto Focus Units. This INSTRUCTION MANUAL provides specifications, operational methods and precautions for AFC. Please read this manual thoroughly before using this product. In order to deliver sufficient information for the full understandings of the functions and performance of this product, we hope the users find this manual helpful.

Outline of this manual

AFC-6 instruction manual consists of following five sections.

Section 1	AFC Main Unit
Section 2	Parameters
Section 3	Communication Commands
Section 4	I/O Ports
Section 5	Operation Box

Please read each section carefully to understand the product and for the proper use before using AFC for the first time.

Section 1	AFC Main Unit	Describes product specifications and main functions of AFC-6.
Section 2	Parameters	Describes control parameters of AFC-6.
Section 3	Communication Commands	Description for controlling AFC-6 with communication.
Section 4	I/O Ports	Description for controlling AFC-6 with I/O port connection. Only limited functions are controllable.
Section 5	Operation Box	Description for controlling AFC-6 with operation box.

Expressions used in this manual

■ Abbreviations

Following abbreviations are used in this manual. Please refer to the following list and replace as appropriate.

AF	: Auto Focus
AFC	: Auto Focus controller
Auto Focus mode	: Collective term for following Auto Focus movements; SC0, SC1, SC2, SC3, SC4, SC5, SC6, SC7, AF0, AF2, PF, PFH, PN and PNH
AF mode	: Auto Focus mode
Search	: Search for AF signal
Peak detection	: Peak detection of AF signal
AF driving section	: Driving section to move lens tube to z-axis direction
Pattern driving section	: Driving section to project AF patterns (*not included in some models)

■ Typestyle

Bold (gothic) typefaces are used to call attention or emphasize in this instruction manual.

■ Numerical values

Decimal values are used in principle. "0x" is added before the first digit of a numerical value when hexadecimal values are used. For instance, "1000" in a decimal system are expressed as "0x03E8" in a hexadecimal system.

■ Hardware

Hardware, such as keys, LED and switches of AFC, Auto Focus Microscope, Auto Focus Unit, are expressed in the following ways: [...] **KEY**, [...] **LED**, and [...] **SWITCH**.

Examples :	[Home] KEY
	[A] LED
	[POWER] SWITCH

■ Communications


Communications are performed via RS-232C. In RS-232C communications, data sent from an external device to AFC is referred to as "**command**." Data sent from AFC to an external device is simply referred to as "**data**". For expressions of commands and data, special characters are used in addition to regular alphanumeric characters. These are control characters called delimiters which indicate the break (end) of commands or data. Delimiters used in AFC are ASCII code characters 10 (0x0A) and 13 (0x0D), which are referred to as "Line Feed" (L_F) and "Carriage Return" (C_R) respectively.

■ I/O ports


The I/O ports of AFC are normally maintained at TTL level (+5V). This state is called TTL level (+ 5V) or H level in this manual. When keeping input port at COMMON level (0V), it is referred to as input to I / O port or setting to L level.

⚠ Precautions


Never do the following actions as it may cause a malfunction.




- Do not use other than the provided power cable.
- Never disconnect the connector while the power is turned on. Turn off the power before connecting and disconnecting the connector.
- Place the device where AC inlet is accessible when connecting.




- Use the AC100-240V (50/60Hz) power source.
- Do not use the product near a large generator or heavy electrical appliances, or equipment radiating strong electro-magnetic fields in the neighborhood, as it may cause a malfunction to the product.
- As this product is composed of precision parts, avoid physical impact and minimize vibration when in use.




- The product generates considerable heat while it is charged with electricity. Never block the heat discharge slit. Do not use in a place where ventilation is insufficient.
- Use the product at least 100 mm away from surrounding objects.



- Do not disassemble or modify the product.
- To prevent scratches, use soft cloth to wipe only the surface when cleaning the device.
- Do not open the cabinet. Do not modify the product by replacing parts. It may cause a fire, electric shock or malfunction.



- Install on a flat surface.
- Avoid contact with water. It is extremely dangerous when the device gets wet.



- The motor that can be used with this product is 2-phase stepper motor. Any motor different from this type (e.g. 5-phase stepper motor, servomotor) cannot be driven.

Section 5

Operation Box

Contents

1. Outline	3
2. Part names and main functions	4
3. Activation operation	5
■ Operation for activation.....	5
■ Initial screen after activation	8
4. Operation box screen	9
■ TOP execution screen.....	10
■ TOP setting screen.....	12
■ Menu screen.....	14
5. Limit sensors.....	15
6. Operate AFC from operation box.....	16
■ AFC operable items from operation box	16
■ Parameter settings for driving unit operations and Auto Focus operations.....	16
■ JOG travel.....	27
■ STEP travel (traveling specified number of pulses)	28
■ Travel to specified coordinates.....	30
■ Execute Auto Focus operation	31
■ HOME return.....	33
■ Auto adjustment	34
■ Reading/writing parameters	43
7. Save setting.....	46
■ When to save	46
■ How to save	46
8. Change operation box preferences	47
■ Key functions of SET screen	47
■ Change operation box preferences	47
Warranty and repair	49

1. Outline

Manual operation will be available when operation box AFC-K is connected to AF controller AFC-6. Operation box mainly performs Auto Focus operation, travel, operation stop, HOME return and parameter setting.

Operation box is capable of processing Auto Focus operations SC0, SC1, SC2, SC3, SC4, SC5, SC6, SC7, AF0 and AF2. Travel operation includes JOG travel, STEP travel, travel to specified coordinates and HOME return. Forced stop of AFC operation and reading/writing all parameters are other functions available. Changing color saturation and sound of operation box display are also modifiable as preference setting.

Caution!!

Please turn off 8-pole Dip switch No.3 of AFC-6 when using operation box.

2. Part names and main functions

This section describes names and main functions of each part of operation box. Each key functions differ depending on screen. This section describes **typical applications**. Detailed functions are explained in each section.

Panel

Displays information of port, coordinate, Auto Focus operation and settings.

Status display LED

Displays AF status.

[Search] key

Executes currently selected Auto Focus operation.

[Z/P] key

Switches travel target to AF driving unit or pattern driving unit.

[Menu] key

Displays menu screen.

[Port] key

Switches ports.

A→B→C→D→E→F (Returns to A after F)

[Far] key, [Near] key

Travel key.

Currently selected driving unit travels slowly to [FAR] or [NEAR] direction.

[High] key

Press and use simultaneously with travel keys ([Far] key, [Near] key).

JOG mode: high speed JOG travel (only supports AF driving unit).

STP mode: performs STEP travel operation for number of steps set.

[Stop] key


Stops all operation (same as communication command Q).

[Home] key

Performs HOME return.

[Ent] key

Works as enter key.



3. Activation operation

■ Operation for activation

AF controller automatically performs HOME return for pattern driving unit and AF driving unit upon power on. Operation box screen after activation is displayed as ①-④. Key operations other than [Stop] key will be rejected during this activation operation although it completes in brief instant.

① Version display

Displays version for 1 second after power is turned ON.

```
AFC-6  VX.XX
AFC-K  VX.XX
```

② Pattern driving unit HOME return

Travels to [FAR] limit from current position, resets position information to 512 and moves to coordinate set in parameter No.023: Pattern-INF.

(a) Starts HOME return

Pattern driving unit travels to [FAR] direction, Coordinates are decremented from maximum value (65535).

(b) Reaches [FAR] limit

Stops after detecting [FAR] limit. Sets coordinate of pattern driving unit to 512.

(c) Travels to coordinate in parameter No.023: Pattern-INF

Travels to coordinate 900 for initial value status.

```
POT:1A P:65535
Z00000000 HOM
```

```
POT:1A P:00512
Z00000000 HOM
```

```
POT:1A P:00900
Z00000000 HOM
```

Following display will be shown in cases of incorrect setting of limit logic or incorrect cable connection for pattern driving unit. Please restart after setting and installing correctly.

Displays coordinate of pattern driving unit as 00000 ±

```
POT:1A P:00000±
Z00000000 HOM
```

Start process continues but is invalid.

Coordinates of pattern driving unit continues to decrement from maximum value to 0

```
POT:1A P:65535
Z00000000 HOM
```

Press [Stop] key.

HOME return is not performed with setting not to use pattern driving unit. Coordinate information of pattern driving unit is displayed as shown on the right.

```
POT:1A P:-----
Z00000000 HOM
```

③ AF driving unit HOME return

Travels to [FAR] limit from current position, resets position information to 512 and moves to coordinate set in parameter No.002: STOP.

(a) Starts HOME return

AF driving unit travels to [FAR] direction, Coordinates are decremented from maximum value (16777215).

(b) Reaches [FAR] limit

Stops after detecting [FAR] limit. Sets position coordinate of AF driving unit to 512.

(c) Travels to coordinate set in parameter No.002: STOP

Travels to coordinate 12800 for initial value status.

```
POT:1A P:00900
Z16777215 HOM
```

```
POT:1A P:00900
Z00000512 HOM
```

```
POT:1A P:00900
Z00012800 HOM
```

Following display will be shown in cases of incorrect setting of limit logic or incorrect cable connection for AF driving unit. Please restart after setting and installing correctly.

```
POT:1A P:00900
Z00000000±HOM
```

Displays AF driving unit coordinate as 00000000±

Start process continues but is invalid

```
POT:1A P:00900
Z16777215 HOM
```


Coordinates of AF driving unit continues to decrement from maximum value to 0

Press [Stop] key.

④ **Completing activation operation**

Travel mode display① and Auto Focus operation display② changes as one of following display.

- ① Jo, St
- ② SC0, SC1, SC2, SC3, SC4, SC5, SC6, SC7, AF0, AF2




Following display will be shown when failing to HOME return pattern driving unit while succeeding to terminate normally in AF driving unit HOME return. Please restart after setting and installing correctly.

POT:1A P:00000±o
Z00012800 SC0

“o” of “Jo” remains at right side of 00000± for coordinates pattern driving unit. “t” remains for “St”.

■ Initial screen after activation

Initial screen to perform operation will be displayed after completing activation operation. This initial screen is called “TOP execution screen”.




*Cursor position display: Underlined characters are displayed with gray background.

Without cursor : Z

With cursor : Z


4. Operation box screen

Operation box has three screens; TOP execution screen to mainly perform Auto Focus operation and driving unit travel, TOP setting screen to select settings of TOP execution screen for operations and menu screen to select/set operation modes and various parameters.



■ TOP execution screen

(1) Screen













- ① Displays selected port. Please refer to “(3)Key functions of TOP execution screen (P11)” as for selecting ports of TOP execution screen.
- ② Displays current coordinates of pattern driving unit. Value changes while traveling.
- ③ Displays selected travel mode. Two travels modes are JOG mode (displays Jo) and STEP mode (displays St). Please refer to “JOG travel (P27)” and “STEP travel (traveling specified number of pulses) (P28)” for travel mode settings.
- ④ Displays current coordinates of AF driving unit. Value changes while traveling.
- ⑤ Displays selected Auto Focus operation.
Selectable from SC0, SC1, SC2, SC3, SC4, SC5, SC6, SC7, AF0 and AF2. Please refer to “(3)Key functions of TOP setting screen (P13)” for Auto Focus operation settings.
- ⑥ Display Auto Focus status. Please refer to “(4)Auto Focus operation status (P32)” for status.

(2) LED of TOP execution screen

LED	Contents
	Just focused
	Low
	High

*White indicates OFF and colored indicates ON.

(3) Key functions of TOP execution screen

Key	Contents
	Executes selected Auto Focus operation
	Switches travel target to AF driving unit or pattern driving unit
	Switches ports (A-F) A→B→C→D→E→F (Returns to A after F)
	Stops executing travel or Auto Focus operation
	Displays menu screen
	Press and use simultaneously with travel keys ([Far] key, [Near] key)
	Performs HOME return
	Moves driving unit to [FAR] direction
	Moves driving unit to [NEAR] direction
	Displays TOP setting screen

■ TOP setting screen

(1) Screen

The diagram illustrates the TOP setting screen layout with four labeled fields:











- ① Selecting port group:** POT : 1 A
- ② Destination coordinates of pattern driving unit:** P : 0 1 0 0 0
- ③ Destination coordinates of AF driving unit:** Z 0 0 0 1 5 0 0 0
- ④ Selecting Auto Focus operation:** S : S C 0

- ① Selects port group.
- ② Sets destination coordinates of pattern driving unit. Parameter No.23: Pattern-INF is updated to setting value.
- ③ Sets destination coordinates of AF driving unit.
- ④ Selects Auto Focus operation. Selectable operations are SC0, SC1, SC2, SC3, SC4, SC5, SC6, SC7, AF0 and AF2.

(2) LED of TOP setting screen

Not in use.

(3) Key functions of TOP setting screen

Key	Contents
	Not in use
	Not in use
	Switches ports (A-F) A→B→C→D→E→F (Returns to A after F)
	Cancels all entered settings and returns to TOP execution screen
	Not in use
	Uses to travel digits when entering destination coordinates Used with [Far] key or [Near] key [High] + [Far]: Moves cursor to left digit (moves to the smallest digit after the largest digit) [High] + [Near]: Moves cursor to right digit (moves to the largest digit after the smallest digit)
	Not in use
	Port group : Increments port value (1 comes after 5) Destination coordinates: Increments value of cursor position (0 comes after 9) Autofocus operation : Displays Auto Focus operations in following order SC0, SC1, SC2, SC3, SC4, SC5, SC6, SC7, AF0, AF2 (SC0 comes after AF2)
	Port group : Decrements port value (5 comes after 1) Destination coordinates: Decrements value of cursor position (9 comes after 0) Autofocus operation : Displays Auto Focus operations in following order SC0, AF2, AF0, SC7, SC6, SC5, SC4, SC3, SC2, SC1 (SC0 comes after SC1)
	Temporary sets items of ①-③ Returns to TOP execution screen when [Ent] key is pressed at ④ reflecting all settings

■ Menu screen

(1) Menu screen

Menu screen consists of 2 pages.











<u>J</u>	O	G	S	T	P	A	R	E	A	F	S
E	P	S	S	P	D	A	D	J	P	R	M

<u>S</u>	E	T
----------	---	---

(2) LED of menu screen

Not in use.

(3) Key functions of menu screen

Key	Contents
	Not in use
	Cursor moves to item on right (left end on next row when it is on right end) Page changes to SET after PRM and page changes to JOG after SET
	Not in use
	Returns to TOP execution screen
	Not in use
	Cursor moves to item on left (right end on previous row when it is on left end) Page changes to SET after JOG and page changes to PRM after SET
	Not in use
	Not in use
	Not in use
	Displays selected menu screen

5. Limit sensors

Driving unit is unable to travel towards limit direction when it detects limit sensor and displays limit detection.

- Pattern driving unit

Detecting [NEAR] side limit sensor

POT:1A P:00900+o
Z00012800 SC0

Displays "+o"

Detecting [FAR] side limit sensor

POT:1A P:00900-o
Z00012800 SC0

Displays "-o"

- AF driving unit

Detecting [NEAR] side limit sensor

POT:1A P:00900+o
Z00012800+SC0

Displays "+"

Detecting [FAR] side limit sensor

POT:1A P:00900-o
Z00012800-SC0

Displays "-"

Caution!!

"±" will be displayed in cases of incorrect setting of limit logic, disconnected cables or cables not connected for driving unit.

6. Operate AFC from operation box

■ AFC operable items from operation box

Performs following 7 operations.

- JOG travel
- STEP travel
- Traveling to specified coordinates
- Executing Auto Focus operations
- HOME return
- Auto adjustment
- Reading/writing parameters

■ Parameter settings for driving unit operations and Auto Focus operations

Parameters are easily set for JOG travel, STEP travel, traveling to specified coordinates and AF driving unit during Auto Focus operation. Checking parameter values is also available. Parameters to be set are as follows.

- Parameter for travel speed
- Parameter for travel range coordinates and HOME
- Parameter for AF trace operation
- Parameter for AF just focus determination factor

(1) Parameter for travel speed

Checks and sets following 4 types of travel speed and Speed_Table.

Parameter No.041: Home_Speed

Parameter No.042: Jog_Speed

Parameter No.043: S-Speed


Parameter No.044: P-Speed

Check and set parameters as follows.

- ① Press [Menu] key on TOP execution screen
- ② Move cursor to "SPD" using [Z/P] key or [High] key and press [Ent] key on menu screen

JOG	STP	ARE	AFS
EPS	SPD	ADJ	PRM


- ③ Use [Z/P] key or [High] key to move cursor to “SpSel” and press [Ent] key to check and set speed table on SPD screen



SpSel
Speed






- (a) Check or change port group

Currently selected port group will be displayed. Change port when cursor is on "P" of "POT".




POT:1A Jog Spd12
HomeSpd12

Perform following key operations to change port group.

Key	Contents
	Switches ports (A-F) A→B→C→D→E→F (Returns to A after F)
	Increments group value (1 comes after 5)
	Decrements group value (5 comes after 1)
	Returns to TOP execution screen
	Temporary sets port group and cursor moves to lower digit of number for “JogSpd”






- (b) Check or change table number of Jog_Speed

Change Jog_Speed table number when cursor is at number after “JogSpd”.



POT:1A Jog Spd12
HomeSpd12

Perform following key operations to change table number.

Key	Contents
	Returns to TOP execution screen Cancels all changed settings
	Uses to press travel keys ([Far] key, [Near] key) while pressing [High] key [Far] + [High]: Moves cursor to left digit (moves to the smallest digit after the largest digit) [Near] + [High]: Moves cursor to right digit (moves to the largest digit after the smallest digit)
	Increments value of cursor position (0 comes after 9) Setting range is 0-31
	Decrements value of cursor position (9 comes after 0) Setting range is 0-31
	(b) - (d) : Temporarily sets parameter and cursor moves to lower digit of next item (e) : Returns to (a) after confirming parameters for (b) - (e)

*Please press [Ent] key even parameter values are not changed.

- (c) Check and change table number of Home_Speed

Change Home_Speed table number when cursor is at number after "HomeSpd".

```
P0T:1A Jog Spd12
      HomeSpd12
```

Please refer to (b) for key operations to change table number.

- (d) Check and change table number of S-Speed

Change S-Speed table number when cursor is at number after "S-Speed".

```
P0T:1A S-Speed12
      P-Speed12
```

Please refer to (b) for key operations to change table number.

- (e) Check and change table number of P-Speed

Change P-Speed table number when cursor is at number after "P-Speed".

```
P0T:1A S-Speed12
      P-Speed12
```

Please refer to (b) for key operations to change table number.

- ④ Use the [Z/P] key or [High] key to move cursor to “Speed” and press [Ent] key to check and set speed for each speed table number on “SPD” screen






SpSel
Speed

- (a) Check speed of table number

Number after “SpTb” indicates table number. Displays speed of indicated table number. L shows low speed, H shows high speed and T for acceleration/deceleration time. Change table number when cursor is at number after “SpTb”. Table number is 0-31.

SpTb12 L006400
H019200 T1000

Perform following key operations to change table number, speed and acceleration/deceleration time.

Key	Contents
	Returns to TOP execution screen Cancels all changed settings
	Uses to press travel keys ([Far] key, [Near] key) while pressing [High] key [Far] + [High]: Moves cursor to left digit (moves to the smallest digit after the largest digit) [Near] + [High]: Moves cursor to right digit (moves to the largest digit after the smallest digit)
	Increments value of cursor position (0 comes after 9)
	Decrements value of cursor position (9 comes after 0)
	(a) - (c) : Temporarily sets parameter and cursor moves to lower digit of next item (d) : Returns to (a) after confirming parameters for (a) - (d)

*Please press [Ent] key even parameter values are not changed.

- (b) Change table number of low speed

Change settings of low speed for displayed table number when cursor is at number after “L”.
Setting range is 10-500,000pps.

SpTb12 L006400
H019200 T1000

Please refer to (a) for key operations to change settings of low speed.

Caution!!**Unable to perform speed setting when following relationship is not satisfied.****Low speed \leq High speed**

- (c) Change table number of high speed

Change settings of high speed for displayed table number when cursor is at number after "H".

Setting range is 10-500,000pps

SpTb12	L006400
H019200	T1000

Please refer to (a) for key operations to change settings of high speed.

Caution!!**Unable to perform speed setting when following relationship is not satisfied.****Low speed \leq High speed**

- (d) Change table number of acceleration/deceleration time

Change settings of acceleration/deceleration time for displayed table number when cursor is at number after "T". Setting range is 1-1,000ms.

SpTb12	L006400
H019200	T1000

Please refer to (a) for key operations to change settings of acceleration/deceleration time.

(2) Parameter for travel range coordinates and HOME

Checks and sets following 4 coordinates.

Parameter No.001: FSP

Parameter No.002: STOP

Parameter No.003: MSP

Parameter No.004: NSP

Check and set parameters as follows.

- ① Press [Menu] key on TOP execution screen
- ② Move cursor to "ARE" using [Z/P] key or [High] key and press [Ent] key on menu screen

JOG	STP	ARE	AFS
EPS	SPD	ADJ	PRM


- ③ Use [Z/P] key or [High] key to move cursor to “ARE1” and press [Ent] key to check and set FSP and NSP on “ARE” screen



ARE1
ARE2

- (a) Check or change port group


Same as “Parameter for travel speed”. Please refer to “(a)Check or change port group (P17)”.



POT:1A F00011200
ARE1 N00014400






- (b) Check/Change FSP of specified port group

Change FSP coordinate when cursor is at number after “F”. Setting range is 512-16,777,215.



POT:1A F00011200
ARE1 N00014400

Perform following key operations to change coordinates.

Key	Contents
	Returns to TOP execution screen Cancels all changed settings
	Uses to press travel keys ([Far] key, [Near] key) while pressing [High] key [Far] + [High]: Moves cursor to left digit (moves to the smallest digit after the largest digit) [Near] + [High]: Moves cursor to right digit (moves to the largest digit after the smallest digit)
	Increments value of cursor position (0 comes after 9)
	Decrements value of cursor position (9 comes after 0)
	(b) : Temporarily sets parameter and cursor moves to lower digit of next item (c) : Returns to (a) after confirming parameters for (b) and (c)

Caution!!

Unable to perform range setting when following relationship is not satisfied.

FSP < NSP

- (c) Check/Change NSP of specified port

Change NSP coordinate when cursor is at number after “N”. Setting range is 513-16,777,215.

```
POT:1A F00011200
ARE1   N00014400
```

Please refer to (b) for key operations to change NSP.

Caution!!

Unable to perform range setting when following relationship is not satisfied.

FSP < NSP

- ④ Use the [Z/P] key or [High] key to move cursor to “ARE2” and press [Ent] key to check and set STOP and MSP on “ARE” screen.

```
ARE1
ARE2
```

- (a) Check or change port group

Same as “Parameter for travel speed”.

```
POT:1A H00012800
ARE2   M00458752
```






Please refer to “(a)Check or change port group (P17)”.

- (b) Check/Change STOP of specified port

Change STOP coordinate when cursor is at number after “H”. Setting range is 512-16,777,215.

```
POT:1A H00012800
ARE2   M00458752
```

Perform following key operations to change coordinates.

Key	Contents
	Returns to TOP execution screen Cancels all changed settings
	Uses to press travel keys ([Far] key, [Near] key) while pressing [High] key [Far] + [High]: Moves cursor to left digit (moves to the smallest digit after the largest digit) [Near] + [High]: Moves cursor to right digit (moves to the largest digit after the smallest digit)
	Increments value of cursor position (0 comes after 9)
	Decrements value of cursor position (9 comes after 0)
	(b) : Temporarily sets parameter and cursor moves to lower digit of next item (c) : Returns to (a) after confirming parameters for (b) and (c)

- (c) Check/Change MSP of specified port

Change MSP coordinate when cursor is at number after "M". Setting range is 512-16,777,215.

```
POT:1A H00012800
ARE2   M00458752
```

Please refer to (b) for key operations to change MSP.

- (3) Parameter for AF trace operation

Checks and sets following 2 parameters.

Parameter No.045: AF-Speed

Parameter No.046: AF-Step

Check and set parameters as follows.

- ① Press [Menu] key on TOP execution screen
- ② Move cursor to "AFS" using [Z/P] key or [High] key and press [Ent] key on menu screen

```
JOG STP ARE AFS
EPS SPD ADJ PRM
```

③ Check or change port group

Same as “Parameter for travel speed”.

POT: 1A	STP=	4
AFS	ASP=	04






Please refer to “(a)Check or change port group (P17)”.

④ Check/Change AF-Step of specified port

Change table number of AF-Step when cursor is at number after “STP”. Setting range is 0-7.

POT: 1A	STP=	<u>4</u>
AFS	ASP=	04

Perform following key operations to change table number.

Key	Contents
	Returns to TOP execution screen Cancels all changed settings
	Uses to press travel keys ([Far] key, [Near] key) while pressing [High] key [Far] + [High]: Moves cursor to left digit (moves to the smallest digit after the largest digit) [Near] + [High]: Moves cursor to right digit (moves to the largest digit after the smallest digit)
	Increments value of cursor position AF-Step : 0 comes after 7 AF-Speed: 0 comes after 9
	Decrements value of cursor position AF-Step : 7 comes after 0 AF-Speed: 9 comes after 0
	④: Temporarily sets parameter and cursor moves to lower digit of next item ⑤: Returns to ③ after confirming parameters for ④ and ⑤

⑤ Check/Change AF-Speed of specified port

Change table number of AF-Speed when cursor is at number after “ASP”. Setting range is 0-31.

POT: 1A	STP=	4
AFS	ASP=	0 <u>4</u>

Please refer to ④ for key operations to change AF-Speed (ASP).

(4) Parameter AF just focus determination factor

Checks and sets following 3 parameters.

Parameter No.051: Epsilon

Parameter No.052: 2nd_Epsilon

Parameter No.053: 3rd_Epsilon

Check and set parameters as follows.

- ① Press [Menu] key on TOP execution screen
- ② Move cursor to “EPS” using [Z/P] key or [High] key and press [Ent] key on menu screen

```
JOG STP ARE AFS
EPS SPD ADJ PRM
```

- ③ Check or change port group
Same as “Parameter for travel speed”.





```
POT:1A   EPS1=4
EPS2=3   EPS3=2
```

Please refer to “(a)Check or change port group(P17)”.

- ④ Check/Change Epsilon of specified port
Change Epsilon value when cursor is at number after “EPS1”. Setting range is 1-7.

```
POT:1A   EPS1=4
EPS2=3   EPS3=2
```

Perform following key operations to change AF just focus determination factor.

Key	Contents
	Returns to TOP execution screen Cancels all changed settings
	Increments value of cursor position (1 comes after 7)
	Decrements value of cursor position (7 comes after 1)
	④-⑤ : Temporarily sets parameter and cursor moves to lower digit of next item ⑥ : Returns to ③ after confirming parameters ④-⑥

⑤ Check/Change 2nd_Epsilon of specified port

Change 2nd_Epsilon value when cursor is at number after “EPS2”. Setting range is 1-7.

POT: 1A	EPS1=4
EPS2= <u>3</u>	EPS3=2

Please refer to ④ for key operations to change 2nd_Epsilon (EPS2).

⑥ Check/Change 3rd_Epsilon of specified port

Change 3rd_Epsilon value when cursor is at number after “EPS3”. Setting range is 1-7.

POT: 1A	EPS1=4
EPS2=3	EPS3= <u>2</u>

Please refer to ④ for key operations to change 3rd_Epsilon (EPS3).

Caution!!

Unable to perform the setting when following relationship is not satisfied.

$$\text{EPS1} \geq \text{EPS2} \geq \text{EPS3}$$

■ JOG travel






JOG travel is available on TOP execution screen. Driving unit keeps traveling while travel key is pressed in JOG travel operation. Use parameter No.042: Jog_Speed for travel speed.

POT:1A P:00900Jo
Z00012800 SC0

JOG travel mode when “Jo” is displayed.
Please set JOG mode when “Jo” is not displayed.

Pattern driving unit is operable when cursor is at “P” and AF driving unit when it is at “Z”.

(1) Key operations of JOG travel

Key	Contents
	Switches travel target to AF driving unit or pattern driving unit
	Switches ports (A-F) A→B→C→D→E→F (Returns to A after F)
	Uses with pressing travel keys ([Far] key, [Near] key) together Switches travel speed to high speed while pressing (Only effective for AF driving unit)
	Driving unit travels to FAR direction in low speed while pressing (Displayed value decrements) *Do not press with [Near] key
	Driving unit travels to Near direction in low speed while pressing (Displayed value increments) *Do not press with [Far] key

(2) JOG mode settings

- Check and set parameter Jog_Speed
Please refer to “(1)Parameter for travel speed (P16)” for details.
- Set JOG mode
 - ① Press [Menu] key on TOP execution screen
 - ② Press [Ent] key when cursor is at “JOG” on menu screen

↓JOG STP ARE AFS
EPS SPD ADJ PRM


- ③ Return to TOP execution screen and operate in JOG mode
Check JOG mode is displayed.

POT:1A P:00900Jo
Z00012800 SC0

JOG mode

■ STEP travel (traveling specified number of pulses)

STEP travel operation is available on TOP execution screen. STEP travel is to travel number of pulses and travel distance per pulse depends on driving unit and parameter No.643: Motor-Div. Use parameter No.042: Jog_Speed for travel speed.



Pattern driving unit is operable when cursor is at “P” and AF driving unit when it is at “Z”.

(1) Travel distance

Switch Motor-Div setting to change travel distance of AF driving unit per 1 pulse. Travel distance of pattern driving unit per 1 pulse is fixed to 5 μ m.

Motor_Div	Travel distance for 1 pulse	
	CHUO standard driving unit (except AF-261ZA)	AF-261ZA
0, 1, 2	0.3125 μ m	0.15625 μ m
3	0.15625 μ m	0.078125 μ m
4	0.078125 μ m	0.0390625 μ m

(2) Key operations for STEP travel

Key	Contents
	Stops executing travel
	Switches travel target to AF driving unit or pattern driving unit
	Switches ports (A-F) A→B→C→D→E→F (Returns to A after F)
	Uses to press travel keys ([Far] key, [Near] key) while pressing [High] key [Far] : Press once to travel 1 pulse to FAR direction (Displayed value decrements) [Near] : Press once to travel 1 pulse to NEAR direction (Displayed value increments)
	Press once to travel specified number of steps to FAR direction (Displayed value decrements)
	Press once to travel specified number of steps to NEAR direction (Displayed value increments)

(3) STEP mode settings

- Check and set Jog_Speed

Please refer to “(1)Parameter for travel speed (P16)” for details.

- Set STEP mode

- ① Press [Menu] key on TOP execution screen
- ② Move cursor to “STP” using [Z/P] key or [High] key and press [Ent] key on menu screen






JOG	STP	ARE	AFS
EPS	SPD	ADJ	PRM

- ③ Set number of steps for pattern driving unit

Change number of steps for pattern driving unit when cursor is at number after “P”.

P:0010	STP
Z:0050	SET

Key operations for setting number of steps

Key	Contents
	Returns to TOP execution screen Cancels all changed settings
	Uses to press travel keys ([Far] key, [Near] key) while pressing [High] key [Far] + [High]: Moves cursor to left digit (moves to the smallest digit after the largest digit) [Near] + [High]: Moves cursor to right digit (moves to the largest digit after the smallest digit)
	Increments value of cursor position (0 comes after 9)
	Decrements value of cursor position (9 comes after 0)
	③: Temporarily sets parameter and cursor moves to lower digit of next item ④: Returns to ③ after confirming parameters for ③ and ④


- ④ Set number of steps for AF driving unit

Change number of steps for AF driving unit when cursor is at number after “Z”.

P:0010	STP
Z:0050	SET

Please refer to ③ for key operations to change number of steps for AF driving unit.

- ⑤ Return to TOP execution screen by pressing [Stop] key and operate in STEP mode
Check STEP mode is displayed.




■ Travel to specified coordinates


Traveling to specified coordinates is operable on TOP setting screen.

Travel speed is parameter No.041: Home_Speed.

- ① Check and set Home_Speed
Please refer to “(1)Parameter for travel speed (P16)” for details.
- ② Press [Ent] key on TOP execution screen



- ③ Enter destination coordinates on TOP setting screen
Please refer to “TOP setting screen (P12)” for entering coordinates.




- ④ Press [Ent] key when cursor is at “S”
Return to TOP execution screen to start traveling. When both pattern driving unit and AF driving unit are traveling, AF driving unit travels after pattern driving unit.
Press [Stop] key to cancel travel

■ Execute Auto Focus operation


(1) Auto Focus operation procedure

Specified Auto Focus operation is operable on TOP execution screen.

- ① Check and set parameters related to Auto Focus operation (menu screens)
 - Check and set travel speed of AF driving unit
Please refer to “(1)Parameter for travel speed (P16)”.
 - Check and set travel range coordinates and HOME of AF driving unit
Please refer to “(2)Parameter for travel range coordinates and HOME (P20)”.
 - Check and set AF trace step and AF trace speed
Please refer to “(3)Parameter for AF trace operation (P23)”.
 - Check and set AF just focus determination factor
Please refer to “(4)Parameter AF just focus determination factor (P25)”.
- ② Check and set Auto Focus operation
Resume to ⑤ when desired Auto Focus mode is already set.
Press [Ent] key in other cases to transit to ③ TOP setting screen.



- ③ Select Auto Focus operation on TOP setting screen
Please refer to “TOP setting screen (P12)” for operating TOP setting screen.












- ④ Confirm input items on TOP setting screen ([Ent] key operation), return to TOP execution screen
- ⑤ Execute Auto Focus operation by pressing [Search] key

(2) Key operations of Auto Focus operation

Key	Contents
	Executes selected Auto Focus operation
	Switches ports (A-F) A→B→C→D→E→F (Returns to A after F)
	Stops travel or Auto Focus operation under execution
	Displays TOP setting screen


(3) Status of Just Focus

LED	Contents
  	Just focused
  	Low signal level (low intensity) status during AF trace operation
  	High signal level (high intensity) status during AF trace operation

*White indicates OFF and colored indicates ON

(4) Auto Focus operation status

Displays Auto Focus status on TOP execution screen.



Display	Contents
J (JUST FOCUS)	Just Focused and signal level is stable
L (LOW)	AF signal not satisfying Low level determination voltage
H (High)	AF signal exceeding High level determination voltage
B (BUSY)	Under control for AF trace operation
FE (FOCUS Error)	Unable to detect appropriate AF signal during search operation
PE (Peak Error)	Unable to detect peak value of AF signal during peak detection

■ HOME return

Perform HOME return on TOP execution screen


(1) HOME return procedure

Press [Home] key on TOP execution screen.


Unable to perform during Auto Focus operation or while traveling.

① and ② will be executed continuously.

- ① Starts HOME return of pattern driving unit (Section① will be skipped if there is no pattern driving unit)



- ② Starts HOME return of AF driving unit



*Press [Stop] key to interrupt HOME return operation. Driving unit stops near the interrupted timing when operation is interrupted. Displayed coordinate may not be accurate at this point. Please perform HOME return again after preparing to perform HOME return correctly.

(2) Key operations for HOME return

Key	Contents
Port	Switches ports (A-F) A→B→C→D→E→F (Returns to A after F)
Stop	Interrupts HOME return operation under execution
Home	Performs HOME return operation

■ Auto adjustment

Please refer to “Main Unit” for auto adjustment function. Following parameters are adjusted automatically in auto adjustment function.

Parameter No.021: BPF

Parameter No.022: Balance

Parameter No.023: Pattern-INF

Adjust Pattern-INF by executing AJP, Balance by AJB and BPF by executing AJF mode. Available auto adjustment mode will differ depending on whether pattern driving unit is used or not.

- Pattern driving unit is used
 - Adjusting Pattern-INF (AJP)
 - Adjusting BPF value (AJF)
- Pattern driving unit is not in use
 - Adjusting Balance value (AJB)
 - Adjusting BPF value (AJF)

Caution!!

Some parameters will be updated when auto adjustment is performed. It is recommended to create backup file with the adjustment software in advance.

- Updated parameters
 - Parameter No.001: FSP
 - Parameter No.004: NSP
 - Parameter No.021: BPF
 - Parameter No.022: Balance
 - Parameter No.023: Pattern-INF
 - Parameter No.101: Target_Point
 - Parameter No.102: Pattern_Step
 - Parameter No.103: In-position_Area
 - Parameter No.104: Agc
 - Parameter No.105: BpfSrch

(1) Preparation

Prepare following before performing auto adjustment.







- Set port group
 - Please refer to “(3)Key functions of TOP setting screen (P13)”.
- Adjust focus position

Focus manually to the point where blur image is visible. Please do not move AF driving unit (Due to put target focus position into travel range of AF driving unit).

Use operation box to move AF driving unit upward/downward after adjusting manually. Fine-tune focus position and adjust precisely to desired just focus position of observation sample.

(2) TOP screen of auto adjustment (ADJ)

● Key operations of ADJ

Key	Contents
	Switches JOG and STEP of travel mode
	Returns to TOP execution screen
	<p>Uses to press travel keys ([Far] key, [Near] key) while pressing [High] key</p> <p>Operation of target focus position: :</p> <p>[Far] + [High]: Moves selected driving unit at high speed to FAR direction</p> <p>[Near] + [High]: Moves selected driving unit at high speed to NEAR direction</p> <p>Input of coordinates: :</p> <p>[Far] + [High]: Moves cursor to left digit (moves to the smallest digit after the largest digit)</p> <p>[Near] + [High]: Moves cursor to right digit (moves to the largest digit after the smallest digit)</p>
	<p>Operation of target focus position: :</p> <p>Moves selected driving unit at low speed to FAR direction</p> <p>Input of coordinates: :</p> <p>Increments value of cursor position (0 comes after 9)</p>
	<p>Operation of target focus position: :</p> <p>Moves selected driving unit at low speed to NEAR direction</p> <p>Input of coordinates: :</p> <p>Decrements value of cursor position (9 comes after 0)</p>
	Confirms settings and moves to next item

● Operation of ADJ

Set common parameters necessary for auto adjustment.


- ① Press [Menu] key on TOP execution screen
- ② Move cursor to "ADJ" using [Z/P] key or [High] key and press [Ent] key on menu screen

JOG	STP	ARE	AFS
EPS	SPD	ADJ	PRM

③ Set target focus of auto adjustment


Switches to ADJ screen. Cursor is at "Z" and port group set on TOP execution screen will be displayed on POT. Travel mode will be displayed on upper right corner to set JOG mode or STEP mode.

Move AF driving unit by JOG or STEP travel to determine focus position. Coordinate value at this point will be saved in parameter No.101: Target_Point by pressing [Ent] key. This coordinate becomes target focus position (TrgP).



④ Set FSP of search area


Cursor will be displayed on right end of the lower row to set FSP. Press [Ent] key to fix FSP after entering coordinates. Unable to set FSP < 512.



Please set FSP on FAR side from Target_Point.

⑤ Set NSP of search area

Cursor will be displayed on right end of the lower row to set NSP. Press [Ent] key to fix NSP after entering coordinates. Values of parameter No.001: FSP and parameter No.004: NSP will be saved at this point. Unable to set NSP ≤ 512. Error will be displayed when values of FSP > NSP are input. Please try again from FSP input.




Please set NSP on NEAR side from Target_Point.

⑥ Select auto adjustment mode

There are 3 modes in auto adjustment modes. Available auto adjustment mode will differ depending on whether pattern driving unit is used or not.

- Pattern driving unit is used
AJP, AJF
- Pattern driving unit is not in use
AJB, AJF



Press [Ent] after selecting auto adjustment mode to be executed.


(3) Adjust Pattern-INF (AJP)

Adjust parameter No.023: Pattern-INF in AJP mode. Set following parameters to execute AJP.

- Parameter No.021: BPF
- Parameter No.022: Balance
- Parameter No.102: Pattern_Step
- Parameter No.103: In-position_Area

Following are AJP execution procedure.


- ① Move cursor to “AJP” using [Z/P] key or [High] key and press [Ent] key on ADJ auto adjustment mode selection screen.



```

AJP  AJB  AJF
POT:1A
  
```


- ② Upper left block starting with P displays selected port group. Initial position of cursor is at BPF. Enter BPF value and press [Ent] key to save the value.



```

P1A BPF31 BAL63
PaSt100 InW±1000
  
```


- ③ Cursor position changes to BAL (Balance). Enter Balance value and press [Ent] key to save the value.



```

P1A BPF31 BAL63
PaSt100 InW±1000
  
```


- ④ Cursor position changes to PaSt (Pattern_Step). Enter Pattern_Step value and press [Ent] key to save the value.



```

P1A BPF31 BAL63
PaSt100 InW±1000
  
```


- ⑤ Cursor position changes to InW (In-position_Area). Enter In-position_Area value and press [Ent] key to save the value.



```


P1A BPF31 BAL63
PaSt100 InW±1000
  
```

- ⑥ Changes to AJP execution screen. Press [Ent] key to execute AJP or [Stop] key to transit to ADJ auto adjustment mode selection screen




Symbol	Contents
Rn	Executing
So	[Stop] key was pressed during execution
Er	Terminated with error (auto adjustment failed)
OK	Normal termination

- ⑦ Please return to ADJ auto adjustment mode selection screen with [Stop] key when “So” or “Er” is displayed



Decrease Pattern_Step or increase In-position_Area and try again when “Er” is displayed.

- ⑧ “OK” will be displayed upon normal termination. Returns to ADJ auto adjustment mode selection screen after pressing [Ent] key and saves coordinate values of pattern driving unit upon termination to Pattern-INF. Returns to ADJ auto adjustment mode selection screen if [Stop] key is pressed without saving to Pattern-INF.



- Ent Save parameter Pattern-INF with pattern driving unit coordinate value and transit to ADJ selection screen
- Stop Transit to ADJ selection screen without saving pattern driving unit coordinate value to Pattern-INF

(4) Adjust Balance (AJB)

Adjust Balance in AJB mode. Set following parameters and execute AJB.

- Parameter No.021: BPF
- Parameter No.022: Balance (Initial value is sufficient for temporary setting)

Following are AJB execution procedure.

- ① Move cursor to “AJB” using [Z/P] key or [High] key and press [Ent] key on ADJ auto adjustment mode selection screen.

```
AJP  AJB  AJF
POT:1A
```


- ② Upper left block starting with “P” displays selected port group. Initial position of cursor is at BPF. Enter BPF value and press [Ent] key to save the value.

```
P1A BPF31 BAL63
```

- ③ Cursor position changes to BAL (Balance). Enter Balance value and press [Ent] key to save the value.


```
P1A BPF31 BAL63
```

- ④ Changes to AJB execution screen. Press [Ent] key to execute AJB or [Stop] key to transit to ADJ auto adjustment mode selection screen




Symbol	Contents
Rn	Executing
So	[Stop] key was pressed during execution
Er	Terminated with error (auto adjustment failed)
OK	Normal termination

- ⑤ Please return to ADJ auto adjustment mode selection screen with [Stop] key when “So” or “Er” is displayed



Decrease BPF value when “Er” is displayed.

- ⑥ “OK” will be displayed upon normal termination. Returns to ADJ auto adjustment mode selection screen after pressing [Ent] key and saves BAL values upon termination to parameter Balance. Returns to ADJ auto adjustment mode selection screen if [Stop] key is pressed without saving to Balance.



- (Ent) Save BAL value in parameter Balance and transit to ADJ selection screen
 (Stop) Transit to ADJ selection screen without saving


(5)Adjust BPF (AJF)

Adjust BPF value in AJF mode. Set following parameters and execute AJF.

- Parameter No.021: BPF (Initial value is sufficient for temporary setting)
- Parameter No.104: Agc
- Parameter No.105: BpfSrch

Following are AJF execution procedure.

- ① Move cursor to “AJF” using [Z/P] key or [High] key and press [Ent] key on ADJ auto adjustment mode selection screen.



- ② Upper left block starting with P displays selected port group. Initial position of cursor is at BPF. Enter BPF value and press [Ent] key to save the value.

```
P1A BPF31 BS:SC0
Agc1 INT1&AGC4
```


- ③ Cursor position changes to BS (BpfSrch). Select BpfSrch and press [Ent] key to save the value.

```
P1A BPF31 BS:SC0
Agc1 INT1&AGC4
```

- ④ Cursor position changes to Agc. Select Agc value (0 or 1) and press [Ent] key to save the value.


```
P1A BPF31 BS:SC0
Agc1 INT1&AGC4
```

- ⑤ Changes to AJF execution screen. Press [Ent] key to execute AJF or [Stop] key to transit to ADJ auto adjustment mode selection screen.



Symbol	Contents
Rn	Executing
So	[Stop] key was pressed during execution
Er	Terminated with error (auto adjustment failed)
OK	Normal termination



- ⑥ Please return to ADJ auto adjustment mode selection screen with [Stop] key when “So” or “Er” is displayed.



Brighten AF illumination when “Er” is displayed. Please contact CHUO if it still does not terminate normally without executing auto adjustment.






- ⑦ “OK” will be displayed upon normal termination. Returns to ADJ auto adjustment mode selection screen after pressing [Ent] key and saves BPF values upon termination to parameter BPF. Returns to ADJ auto adjustment mode selection screen if [Stop] key is pressed without saving to BPF.



-  Save BPF value in parameter BPF and transit to ADJ selection screen
-  Transit to ADJ selection screen without saving

■ Reading/writing parameters

● Key operations of reading/writing parameters

Key	Contents
	Returns to TOP execution screen Cancels all changed settings
	Uses to press travel keys ([Far] key, [Near] key) while pressing [High] key [Far] + [High]: Moves cursor to left digit (moves to the smallest digit after the largest digit) [Near] + [High]: Moves cursor to right digit (moves to the largest digit after the smallest digit)
	Increments value of cursor position (0 comes after the largest digit)
	Decrements value of cursor position (the largest digit comes after 0)
	Confirms or temporarily sets selected item or input value

● Reading and writing parameters

All AFC-6 parameters can be read and written using operation box. Please follow the steps below.

- ① Press [Menu] key on TOP execution screen
- ② Move cursor to "PRM" using [Z/P] key or [High] key and press [Ent] key on menu screen

```
JOG STP ARE AFS
EPS SPD ADJ PRM
```

- ③ Enter parameter number and press the [Ent] key


```
No GNo A00011200
001 1 B00011200
```

Input value will be rejected when corresponding parameter does not exist. Input parameters will be processed differently for port parameters and system parameters.

④ Display and rewrite parameters

• For port parameters

- (a) Displays initial screen of parameter number for input port parameter. Cursor locates on group (GNo) displaying current group.




```

No  GNo  A00011200
001  1   B00011200
  
```

Group can be changed within setting range of 1-5.

Press [Ent] key to continue reading/writing parameters and transit to (b). Press [Stop] key to terminate and return to TOP execution screen.

- (b) Cursor position moves to first digit of A port and A port data will be rewritable




```

No  GNo  A00011200
001  1   B00011200
  
```

Port

Change value and press [Ent] key to temporarily set the value. Press [Ent] key directly to change value of other ports without changing A port value and transit to (c). Press [Stop] key to terminate and return to TOP execution screen.

- (c) Cursor position moves to first digit of B port and B port data will be rewritable (same operation as A port)




```

No  GNo  A00011200
001  1   B00011200
  
```

Press [Ent] key to change to C and D port setting screen after setting B port

- (d) Cursor position moves to first digit of C port and C port data will be rewritable (same operation as A port)




```

No  GNo  C00011200
001  1   D00011200
  
```

Press [Ent] key to change to E and F port setting screen after setting C and D ports.

- (e) Cursor position moves to first digit of E port and E port data will be rewritable (same operation as A port)




```

No  GNo  E00011200
001  1   F00011200
  
```

Press [Ent] key to move cursor to first digit of F port after entering E port.

- (f) Cursor position moves to first digit of F port and F port data will be rewritable (same operation as A port)


A screenshot of a terminal window showing two lines of text. The first line is "No GNo E00011200" and the second line is "001 1 F00011200". A cursor is positioned at the end of the second line, after the last zero.

```
No GNo E00011200
001 1 F00011200
```

Press [Ent] key to set parameters for A-F and move cursor position to parameter number. Transits to TOP execution screen by pressing [Stop] key.

- For system parameter

Displays initial screen of parameter number for input system parameter. Cursor is positioned at first digit of data

A screenshot of a terminal window showing two lines of text. The first line is "No SX_Speed" and the second line is "644 630". A cursor is positioned at the end of the second line, after the last zero.

```
No SX_Speed
644 630
```

Press [Ent] key after changing value to set parameter and move cursor position to parameter number. Transits to TOP execution screen by pressing [Stop] key

7. Save setting

Currently set parameter values can be saved. Operation can be resumed upon next activation if setting values are saved.

■ When to save


Save timing is when various settings input has completed. This timing can be determined with LED lights.

LED	Contents
▶ ● ◀	Saving available
▶ ○ ◀	Saving not available

* White indicates OFF and colored indicates ON

■ How to save

Save process starts with pressing [Menu] key while LED is turned ON. Save confirmation will be displayed. Executes save with [Ent] key or cancel save process with [Stop] key. Returns to TOP execution screen after saving process has completed.










* The settings are valid without even saving. However, in this case, the original setting will be restored when the power is rebooted (or "RESTA" command).

8. Change operation box preferences

Following settings of operation box can be changed.


- Screen brightness
- Screen contrast
- Backlight off time
- Key operation buzzer sound (tone)

■ Key functions of SET screen

Key	Contents
	Transits to TOP execution screen with SET status
	Starts saving SET setting when pressed LED is turned ON
	Uses to press travel keys ([Far] key, [Near] key) while pressing [High] key [Far] + [High] : Press once to increment value by 10 [Near] + [High] : Press once to decrement the value by 10
	Reset settings of SET screen to initial values
	Press once to increment the value by 1 (fix the value)
	Press once to decrement the value by 1 (fix the value)
	Transits SET setting items

■ Change operation box preferences

- ① Press [Menu] key on TOP execution screen
- ② Move cursor to "SET" using [Z/P] key or [High] key and press [Ent] key on menu screen



*"SET" will be displayed after "PRM"

③ Change screen brightness

Enter brightness value when cursor is at "BLB". Press [Ent] key after input to move cursor to "CRB".

```
BLB=080 CRB=050
BLT=00  BZZ=1
```

Changing BLB value affects screen brightness. Check brightness while setting to adjust from 0 to 100. 0 is backlight off.

④ Change screen contrast

Enter contrast value when cursor is at "CRB". Press [Ent] key after input to move cursor to "BLT".

```
BLB=080 CRB=050
BLT=00  BZZ=1
```

Changing CRB value affects screen contrast. Check contrast while setting to adjust from 0 to 100.

⑤ Change backlight off time

Enter backlight off time value when cursor is at "BLT". Press [Ent] key after input to move cursor to "BZZ".

```
BLB=080 CRB=050
BLT=00  BZZ=1
```

Set time of backlight to turn off from the last operation of operation box. Unit is minutes and set from 0 to 60. It does not turn off when it is set at 0.

⑥ Change key operation buzzer sound (tone)

Enter key operation buzzer value for operation box when cursor is at "BZZ". Press [Ent] key after input to return cursor to "BLB".

```
BLB=080 CRB=050
BLT=00  BZZ=1
```

4 types of buzzer sounds can be set from 0 to 3. 0 is muted.

Caution!!

Press [Home] key when characters are invisible and unable to operate. All preferences will be reset to initial values.

Warranty and repair

■ Warranty period

Repair services are available for free of charge in the event of technical failure under warranty period in accordance with CHUO regulations.

Warranty period	1 year from shipment
------------------------	-----------------------------

Repair costs will not be covered for following cases.

- Due to improper use, inappropriate repair or remodeling the product
- Due to applying external shock after purchasing the product
- Due to fire, earthquake, flood, lightning or other natural disasters
- Due to environmental pollution or by applying abnormal voltage
- For defects predetermined by CHUO not to apply this warranty
- Due to any use not following this instruction manual

■ Repair service during warranty period

Please contact the authorized distributors or company of purchase for repair service.

■ Repair service for out-of-warranty products

Contact the authorized distributors or company of purchase for out-of-warranty products. Repair services will be provided with charges depending on conditions. Please provide the following information in order to prepare and deliver effective repair services.

- Date of purchase, product name and manufacturing number
- Details of how the product is used
- Specific description of defects
- Matters that may be the cause of defect

Please note in advance that there may be cases that CHUO is unable to provide repair services.

All descriptions and specifications in this manual are subject to change without prior notice.
Please note in advance that products are also subject to change without prior notice.

Auto Focus Controller AFC-6 INSTRUCTION MANUAL

- Operation Box - Ver. 1.0

Oct. 31, 2019 YUA.



CHUO PRECISION INDUSTRIAL CO.,LTD.

Sales Division

Oikawa Bldg 3F, 1-5 Kanda Awajicho, Chiyoda-ku, Tokyo, 101-0063, Japan

TEL: +81-3-3257-1911 FAX: +81-3-3257-1915