

Position Control and Counters Section 6.10

Add a new function

@Name

_8154_escape_home – leaving from the home position

@Description

_8154_escape_home:

This function is used to leave from the home position. The direction of positive or negative move is set by the MaxVel.

@Syntax

C/C++(Windows2000/XP)

I16 _8154_escape_home (I16 AxisNo, F64 StrVel, F64 MaxVel, F64 Tacc);

VisualBasic(Windows2000/XP)

B_8154_escape_home (ByVal AxisNo As Integer, ByVal StrVel As Double, ByVal MaxVel As Double, ByVal Tacc As Double) As Integer