


## How to Use?

1. Fully charge the spot welder with the USB cable.
2. Connect 2 welding pens to the spot welder.



3. Long press the white button to power on.
4. Place the nickel strip on the object to be welded.
5. Put 2 welding pens on the nickel strip, and then it will weld automatically.

**Note:** You may need to adjust parameters to get the best effect.



6. If the welding effect is not good enough, please adjust the parameters and try again.



**PreH:** Time of preheating.

**Gap:** Time between preheating and welding.

**Gear:** Time of welding.

**Numb:** Number of repeated welding.

### Button description:

Press the white button to switch to the next option.  
Press the black button to change the parameters.  
Long press the white button to power on or off.  
Press both buttons at the same time to rotate the screen.

### Parameter settings reference:

Nickel strip*	PreH	Gap	Gear	Numb
0.1mm	2ms	2ms	5ms	1
0.12mm	2ms	2ms	10ms	1
0.15mm	4ms	4ms	22ms	1
0.2mm	5ms	10ms	28ms	1

\* Test with Freeove brand nickel strip (FNK0088).

\* The nickel strip comes with this product is 0.12mm.

**Note:** This table is for reference only. It may not be applicable regarding different welding objects, please adjust according to the actual effect.

7. Select the gear icon on the main interface and you can set more parameters.



8. Select the USB icon on the main interface and you can also view the power status.
9. After use, long press the white button to power off.

## Troubleshooting

### Cannot power on:

- Charge the welder with USB cable.
- Use a thin stick to poke the reset hole.

### Cannot weld:

- Charge the welder with USB cable.
- Clean residues on the tip of the welding pens.

## Get Support

### Having problems?

Download the latest tutorial and troubleshooting:  
<http://freenove.com/fnk0087>

### Need further help?

Contact our technical support via email:  
[support@freenove.com](mailto:support@freenove.com)