



syncAXIS Viewer V1.6

syncAXIS control

SCANLAB GmbH
Siemensstr. 2a
82178 Puchheim
Germany

Tel. +49 (89) 800 746-0
Fax +49 (89) 800 746-199

info@scanlab.de
www.scanlab.de

© SCANLAB GmbH 2021
(Doc. Rev. 1.1 e - June 21, 2021)

SCANLAB GmbH reserves the right to change the information in this document without notice.

No part of this document may be processed, reproduced or distributed in any form (photocopy, print, microfilm or by any other means), electronic or mechanical, for any purpose without the written permission of SCANLAB GmbH.

RTC and syncAXIS are registered trademarks of SCANLAB GmbH.

Other mentioned trademarks are hereby acknowledged as properties of their respective owners.



Contents

1	syncAXIS Viewer V1.6	4
1.1	Manufacturer	4
1.2	Scope of Delivery	4
1.3	System Requirements	4
1.4	Related Documents	4
1.5	Intended Use	4
1.6	Program Start	5
1.7	Loading a Simulation File	5
1.8	Content of a Simulation File	5
1.9	Graphical User Interface (GUI)	6
1.9.1	Zoom and Scaling	7
1.9.2	Exceedance of Limits	7
1.9.3	Color Map	9
1.9.4	Functions of the Toolbar	10
1.9.5	Functions of the Controls	14
1.9.6	Dialog Loading Options	17
1.10	syncAXIS Viewer Basic Procedure (Principle of Use)	19

1 syncAXIS Viewer V1.6

This manual describes the tool syncAXIS Viewer V1.6 from SCANLAB.

1.1 Manufacturer

SCANLAB GmbH
Siemensstr. 2a
82178 Puchheim
Germany
Tel. +49 (89) 800 746-0
Fax +49 (89) 800 746-199
info@scanlab.de
www.scanlab.de

1.2 Scope of Delivery

- syncAXIS Viewer
- This manual

1.3 System Requirements

- As with syncAXIS control.

1.4 Related Documents

- Manual “syncAXIS-DLL – Application Programming Interface”

1.5 Intended Use

syncAXIS Viewer V1.6 is a tool (with GUI) for visualizing unmodified simulation files (see Manual “syncAXIS-DLL – Application Programming Interface” and [Chapter 1.8 “Content of a Simulation File”, page 5](#)) generated by syncAXIS control V1.6.

One or even several simulation files at once can be imported. Several plots are available. Depending on the plot, some of the data displayed originate directly (unprocessed) from the specified simulation file, others are derived from calculations in syncAXIS Viewer.

syncAXIS Viewer V1.6 is able to indicate exceedances of positioning stage and scan head in the plots (affected curve sections are then drawn in orange and a corresponding information is shown in the status bar, see [“Exceedance of Limits”, page 7](#)).

Notice: syncAXIS Viewer *does not* provide any support for interpreting the content of the plots. This requires exclusively the expertise of the user and is his sole responsibility.

1.6 Program Start

- Start **syncAXIS_Viewer.exe**.
The program opens.

Alternatively, you can start the program via command line arguments. Here you also can configure the graphical user interface and the simulation files to be loaded. You have the following possibilities:

- Argument in commando line:
syncAXIS_Viewer.exe [OPTION]... [FILE]...
Options:
 - With no [FILE] syncAXIS Viewer opens in default screen and ignore options (multiple files are allowed).
 - **-h --help**: Opens a help window with descriptions of the command arguments.
 - **-r N, --read-each N**: Reads only each N-th line.
 - **-a, --accurate-position**: Calculates positions of marks and jumps with a higher precision due to laser delays.
 - **-l, --accurate-limits**: Only allowed if --read-each N is also set, values exceeding the limit are displayed in orange, see [“Exceedance of Limits”, page 7](#).

1.8 Content of a Simulation File


For the content of a simulation file, see [Manual “syncAXIS-DLL – Application Programming Interface”](#).

1.7 Loading a Simulation File

- Click **File > Open** and choose your desired simulation file. For a description of the loading options, see [“Dialog Loading Options”, page 17](#).
Alternatively you can drag a simulation file in the program window.

Note: Before loading, syncAXIS Viewer checks how much space is available in the working memory. If this is not sufficient for the complete simulation file, the program loads only up to a certain time index. A corresponding message appears in the main window.

1.9 Graphical User Interface (GUI)



Legend

1. Button to hide or display the controls
2. Title bar (with version info)
3. Toolbar (see [page 10](#))
4. Diagram title consisting of diagram type, number of the scan head and name of the imported simulation file(s)
5. Legend of the curves
6. Axis on the right (if Active Channel(s) are selected, see [page 14](#))
7. Selection of the exceeded limits
8. Area for graphical display (with diagram area)
9. Areas with controls (see [page 14](#))
10. Status bar (with information on imported files and the applied import options, operating tips, for any exceeding of limit values)
11. Tracker (optional; shows the values at that curve point; see [page 11](#)).
12. Curves

syncAXIS Viewer V1.6: main window (overview).

1.9.1 Zoom and Scaling

- To zoom in a whole diagram:
Use mouse wheel.
- To zoom specific areas:
Click and hold left mouse button and mark the specific area. syncAXIS Viewer zooms in the selected area.
Note: If necessary, the scale division is changed (not in Data type Position 2D).
- To reset the zoom:
Click **Fit screen**


1.9.2 Exceedance of Limits

From the currently loaded simulation file, syncAXIS Viewer V1.6 reads out the working field size, max. velocity, max. acceleration and max. jerk of the positioning stage⁽¹⁾. These limits are read out from the configuration in the simulation file. If the working field size is not determined in the configuration, it will taken from the correction file specified via the `DefaultCorrectionFile`⁽¹⁾ tag. If this is also not successful, 54 mm × 54 mm are used⁽²⁾.

syncAXIS Viewer V1.6 uses the currently loaded simulation file to indicate exceedances of positioning stage working field boundaries and dynamic limits as well as scan head working field boundaries in the plots. Affected curve sections are drawn in **orange** and corresponding information is shown in the status bar. [Figure 2, page 8](#) shows an example of exceeded limits.

When limits are exceeded, the drop down list **Limits breached** appears on the right hand side of the status bar.

- Click **Limits breached**. The selection of the exceeded limits to be displayed is shown.



In this example, the x and y position values are exceeded. In general, following options are available, depending of the exceeded limits:


- Position scanner X
- Position scanner Y
- Position stage X
- Position stage Y

If no limits are exceeded, the drop down box **Limits breached** is not shown.

- Tip: To determine “where” in the marking result the problem would occur, set:
 - **Data type: Position 2D**
 - **Device type: Combined** and then click
 - **Isometric 2D**

(1) See also Manual “syncAXIS-DLL – Application Programming Interface”.

(2) A corresponding message opens.
Furthermore, subsequently the status bar shows
“Correction File: Not found - using default limits”.




syncAXIS Viewer V1.6: Display of exceeded limits

1.9.3 Color Map




It is possible to overlay the displayed curves with a color map. This color map shows selected values colored, see [figure 3](#). Depending on the height of the value, another color is displayed. Note the color scale on the right.

- Click **Color Map** in the toolbar and choose the value to be displayed in color. For each selection, the norm is displayed. It can be shown (each for scanner and stage):
 - position
 - velocity
 - acceleration
 - jerk
 and the job function.
- Click the color scale on the right, hold the mouse button and drag the mouse to adjust the scale.
- Choose **Limits breached** to end the colored display.



Display of a color map of the scanner (Norm position scanner)

1.9.4 Functions of the Toolbar

	<p>File</p> <ul style="list-style-type: none"> • To open a simulation file (*.txt). For more details, see Chapter 1.9.6 "Dialog Loading Options", page 17. • To export header(s) of the currently loaded simulation file(s) in XML format.
	<p>Fit screen</p> <p>To reset the zoom factor or the scaling and to adjust the size of the diagram to the screen.</p>
	<p>Isometric 2D</p> <p>Only appears, when diagram type Position 2D is selected (for example, if circles are not represented as circles, but as ellipses due to different scale divisions):</p> <p>Fits the entire diagram into the diagram area. Thereby, the same scale division is applied to the X-axis and Y-axis.</p>

Tracker options

Tracker options

To open the tracker settings.


- Choose the information to show in the tracker when moving the cursor over a curve or
- clear **Enable Tracker**. The tracker is not shown anymore.

Items to display on tracker

- ☒ Path Velocity
- ☒ Active Channel 1
- ☒ Active Channel 2
- ☒ Laser On
- ☒ Job function

☒ Enable Tracker

With options chosen as shown above, the tracker shows following information when moving over a curve:



Scan field limits

Scan field limits

To set the limits of the working field. The default values are the limits indicated in the simulation file (*.txt).

- Type in the desired values and click **Apply**.

X Axis Minimum: mm

X Axis Maximum: mm

Y Axis Minimum: mm

Y Axis Maximum: mm

Apply

Tracker options

Tracker options

To open the tracker settings.


- Choose the information to show in the tracker when moving the cursor over a curve or
- clear **Enable Tracker**. The tracker is not shown anymore.

Items to display on tracker

- ☒ Path Velocity
- ☒ Active Channel 1
- ☒ Active Channel 2
- ☒ Laser On
- ☒ Job function

☒ Enable Tracker

With options chosen as shown above, the tracker shows following information when moving over a curve:



Scan field limits





Scan field limits

To set the limits of the working field. The default values are the limits indicated in the simulation file (*.txt).

- Type in the desired values and click **Apply**.

X Axis Minimum: mm
 X Axis Maximum: mm
 Y Axis Minimum: mm
 Y Axis Maximum: mm

Apply

 Color Map	Color Map To display of color maps of several values, see "Color Map", page 9 . <ul style="list-style-type: none">Select the norm to display.																
 Config Info	Config Info To display configuration information.																
 Guides	Guides To show/delete (not: hide) of two guides. <ul style="list-style-type: none">Click Guides. The configuration panel appears in the status bar. <div><table><tr><td><input checked="" type="checkbox"/> Horz</td><td>guide1:</td><td>-14.88</td><td>guide2:</td><td>13.59</td><td>diff:</td><td>28.47</td><td>mm</td></tr><tr><td><input checked="" type="checkbox"/> Vert</td><td>guide1:</td><td>0.09</td><td>guide2:</td><td>0.29</td><td>diff:</td><td>0.20</td><td>s</td></tr></table></div> <ul style="list-style-type: none">Choose, if horizontal or vertical guides (or both) should appear.Click the guide, hold the left mouse button and drag it to the desired position. Alternatively you can enter exact values for each guide in the configuration panel. The distance between both guides is shown on the right hand side.	<input checked="" type="checkbox"/> Horz	guide1:	-14.88	guide2:	13.59	diff:	28.47	mm	<input checked="" type="checkbox"/> Vert	guide1:	0.09	guide2:	0.29	diff:	0.20	s
<input checked="" type="checkbox"/> Horz	guide1:	-14.88	guide2:	13.59	diff:	28.47	mm										
<input checked="" type="checkbox"/> Vert	guide1:	0.09	guide2:	0.29	diff:	0.20	s										
 About	About To show the version number and information about the programmer.																

1.9.5 Functions of the Controls

<div data-bbox="191 481 507 828"> <p>Data Type</p> <p><input checked="" type="radio"/> Position</p> <p><input type="radio"/> Position 2D</p> <p><input type="radio"/> Velocity</p> <p><input type="radio"/> Acceleration</p> <p><input type="radio"/> Jerk</p> <p><input type="radio"/> None</p> </div>	<p>Group Data type for selecting the diagram type (plot) to be shown in the diagram area. The selected option is used as diagram title (4 in figure 1, page 6).</p> <div data-bbox="574 548 1520 1164"> <p>Position x,y [mm] vs. Time [s]</p> <p>Position 2D y [mm] vs. x [mm]</p> <p>Velocity vx, vy [m/s] vs. Time [s] (laser spot speed; square root of $(v_x^2 + v_y^2)$)</p> <p>Acceleration ax, ay [m/s²] vs. Time [s]</p> <p>Jerk jx, jy [m/s³] vs. Time [s]</p> <p>None None of the above diagram types. Nevertheless, Active Channel curves are shown, if these are selected.</p> </div>
<div data-bbox="191 1198 507 1332"> <p>Channel type</p> <p><input checked="" type="checkbox"/> Active channel 1 (*)</p> <p><input checked="" type="checkbox"/> Active channel 2 (*)</p> </div> <p>(*) Actual Active channel names are shown here after the simulation file has been loaded.</p>	<p>Group Channel type to select which Active Channel curves are to be shown in the diagram area.</p> <ul style="list-style-type: none"> • Disabled, if Position 2D is selected. • Even available, if None is selected. • The screenshot on the left shows the check box labels immediately after <code>syncAXIS Viewer.exe</code> start. After the simulation file has been loaded, the labels are changed according to the Active Channels entered there. That is, for example, "Active Channel 1" is changed to "Analog out 2" and "Active Channel 2" is changed to "Spot distance". <div data-bbox="574 1512 1520 1731"> <p>Active channel 1 (for example, Analog out 2) If the check box is selected, the corresponding curve is shown in the diagram. The curve is shown in addition to other curves.</p> <p>Active channel 2 (for example, Spot distance) See Active channel 1.</p> </div>

<p>Axis Type</p> <p><input checked="" type="radio"/> X</p> <p><input type="radio"/> Y</p> <p><input type="radio"/> X/Y</p> <p><input type="radio"/> Absolute</p>	Group Axis type to select which axes are to be shown as curves.
	<p>X</p> <p>Shows curve of x values.</p>
	<p>Y</p> <p>Shows curve of y values.</p>
	<p>X/Y</p> <p>Shows curves of both axes.</p>
	<p>Absolute</p> <p>Shows the absolute value of the X/Y vector.</p>
<p>Device type</p> <p><input checked="" type="radio"/> Scanner</p> <p><input type="radio"/> Stage</p> <p><input type="radio"/> Combined</p>	Group Device type to select which motion portions (scan head and/or positioning stage) are to be included in the shown curves.
	<p>Scanner</p> <p>Shown curves shall include scan head portions only.</p>
	<p>Stage</p> <p>Shown curves shall include positioning stage portions only.</p>
<p>Scan head</p> <p>1</p>	<p>Combined</p> <p>Shown curves shall include scan head portions and positioning stage portions.</p>
	<p>Group Scan head to select from which scan head the data to be shown as curves (on multi head systems).</p> <p>Click the drop down list and select your desired scan head number. The number of entries can vary here. For default, data of scan head 1 is shown after loading a simulation file.</p>
<p>Segment type</p> <p><input checked="" type="radio"/> Show jumps</p> <p><input type="radio"/> Hide jumps</p> <p><input type="radio"/> Visualize jumps</p>	Group Segment type to select which vectors (mark vectors, jump vectors) are to be included in the shown curves.
	<p>Show jumps</p> <p>Shown curves shall include mark vectors and jump vectors. Each curve is uniformly colored.</p>
	<p>Hide jumps</p> <p>Shown curves shall include mark vectors only (no jump vectors). Each curve is uniformly colored.</p>
	<p>Visualize jumps</p> <p>Jump vectors in all curves are highlighted (grey).</p>

Meta data

173859 data points

Min(x) : -34.7 mm

Max(x) : 40.9 mm

Min(y) : -34 mm

Max(y) : 40.6 mm

Spot distance : 5 μm

Group that shows read-only information on imported data records, extrema and laser spot distance.

*Important: all data shown here base on the selected import options, see [Chapter 1.9.6 "Dialog Loading Options"](#), page 17 as well as **Cancel**. Actual values may therefore differ (for example, the number of data points does not necessarily have to be the total number of lines in the simulation file)!*

<n> data points: number of simulation file lines that has been imported to syncAXIS Viewer.

Extrema (always 4 lines): depending on the current diagram type, up to 4 values (including unit) are shown.


Extrema Available with diagram type

Min(x)	Position, Position 2D
Max(x)	Position, Position 2D
Min(y)	Position, Position 2D
Max(y)	Position, Position 2D
Min(v)	Laser spot speed
Max(v)	Laser spot speed
Min(vx)	Velocity
Max(vx)	Velocity
Min(vy)	Velocity
Max(vy)	Velocity
Min(ax)	Acceleration
Max(ax)	Acceleration
Min(ay)	Acceleration
Max(ay)	Acceleration
Min(jx)	Jerk
Max(jx)	Jerk
Min(jy)	Jerk
Max(jy)	Jerk

Spot distance: NaN ("not a number") indicates that the simulation file does not contain such data (prerequisite: in the simulation file, SpotDistance must have been defined as Active Channel).

1.9.6 Dialog Loading Options

The dialog “Loading Options” opens, when you have selected a simulation file, see “[Loading a Simulation File](#)”, page 5.



Dialog Loading Options

No reduction

Import option for the simulation file: To load all simulation file lines.

Reduction Tolerance

This function performs data reduction during loading. The advantage is, that fewer position points are loaded and the display of the curve in the syncAXIS Viewer is significantly faster when scrolling or zooming. The shape of the curve is preserved. In particular, all laser switching times and all sections in which a dynamic violation is present are not reduced.

Enter the reduction tolerance in mm (default is 0.01).

Show Laser Pre-Trigger

This function shows the time shift of the laser signals by the argument `LaserPreTriggerTime`.

Show Laser Switch Offset

This function shows the time shift of the laser signals by the argument `LaserSwitchOffsetTime`.

Data Cropping Options

This function allows only certain sections to be imported. Select the section you want to import by entering the start and end values.

Load

Starts the import of the simulation file according to the settings in the "Import Options" section.

Note: after the import process is completed, the status bar (see [figure 1, page 6](#), No. 10) shows the settings most recently made in the "Import Options" dialog.

Append

This button is disabled immediately after starting the program. It is enabled after a simulation file has been imported. Usage is as with **Load**. Difference: the selected simulation file(s) are imported and shown *in addition* to the already imported ones.

Notes:

- The limits of the last loaded file are valid.
- If you use **Append** and select import options (see above) different to the already imported simulation file, then the status bar (see [figure 1, page 6](#), No. 10) even *only* displays the settings that has been most recently made in the "Import Options" section after the import process has been completed.


Cancel

To cancel a file import (starting from **Load**). Data loaded by then can still be displayed.

1.10 syncAXIS Viewer Basic Procedure (Principle of Use)

Step	
(1) To start syncAXIS Viewer.	<ul style="list-style-type: none"> Double-click syncAXIS Viewer.exe. syncAXIS Viewer opens^(a), see figure 1, page 6.
(2) To set the import option and specify the desired simulation file(s).	<p>(1) In the main window, click File > Open.</p> <p>(2) Navigate to the desired simulation file and click Open.</p> <p>(3) In the “Loading Options” dialog (see page 17), set the desired option with which the simulation file is to be imported. Then, click Load.</p>
(3) To choose a diagram type (plot).	<ul style="list-style-type: none"> Click the desired diagram type (see page 14, for example, Position 2D).
(4) Optional: to show curve(s) of Active Channel in diagram (if applicable, these are shown in addition to other curves).	<ul style="list-style-type: none"> Select the desired check boxes (see page 14).
(5) To set which axes curves are to be shown in the diagram.	<ul style="list-style-type: none"> Click the desired option (see page 15, for example, X/Y).

(a) syncAXIS Viewer.exe is designed to be executed as 32-bit application on MS Windows 32-bit variants and as 64-bit application on MS Windows 64-bit variants.

Step (cont'd)	
(6) To set which motion portion(s) the curves shall show in the diagram.	<ul style="list-style-type: none"> Click the desired option (see page 15, for example, Combined).
(7) To choose a scan head (available on multi head systems).	<ul style="list-style-type: none"> Click the desired scan head number from the drop down list. (see page 15, for example, scan head 1).
(8) To set which vectors the curves shall show in the diagram.	<ul style="list-style-type: none"> Click the desired option (see page 15, for example, Show jumps for mark vectors and jump vectors; here, even color details are marked).
(9) Visual inspection of individual points in curves (in the diagram area).	<p>(1) Setup the Tracker according to your needs, see page 11.</p> <p>(2) Position the mouse pointer onto a curve in order to see details of this data point.</p>
(10) Visual inspection of extrema.	<ul style="list-style-type: none">  Caution! The accuracy of the shown values depend on the options you have selected for import. For exact results, you must use No reduction in step (2). Then, the status bar indicates "Selected import options: No Data Reduction". Check the values in the group for information display (see page 16) in regards to limit exceedances of the utilized XL SCAN systems.
(11) Optional: Export of suitable settings.	<ul style="list-style-type: none"> Click File > Export Header(s) and choose the directory to save the XML file.