

**Note:** For TMC2209, TMC2130, TMC5160 and TMC5161 (any Driver Board that supports sensor-less homing) if you install it on the extruder and you want to [use a filament runout sensor](#), remove the DIAG/DIAG1/DIAG0 PIN to allow the filament runout sensor to work properly.