



Replace DUO_SW1 with a Pulldown if you want the ATmega32U4 chip to run when this circuit is loaded.
Replace DUO_SW1 with a Pullup if you want to disable the ATmega32U4 chip when this circuit is loaded.