



H250 M40 Handbook

Variable area flowmeter

**FOR COMPLETE HANDBOOK SEE SEPARATE DOCUMENT:
Y5-1 KROHNE H250 M40 MANUAL**

All rights reserved. It is prohibited to reproduce this documentation, or any part thereof, without the prior written authorisation of KROHNE Messtechnik GmbH.

Subject to change without notice.

Copyright 2016 by
KROHNE Messtechnik GmbH - Ludwig-Krohne-Str. 5 - 47058 Duisburg (Germany)

1 Safety instructions	5
1.1 Intended use	5
1.2 Certifications	6
1.3 Pressure equipment directive	6
1.4 Safety instructions from the manufacturer	8
1.4.1 Copyright and data protection	8
1.4.2 Disclaimer	8
1.4.3 Product liability and warranty	9
1.4.4 Information concerning the documentation	9
1.4.5 Warnings and symbols used	10
1.5 Safety instructions for the operator	10
2 Device description	11
2.1 Scope of delivery	11
2.2 Device version	12
2.2.1 Indicator versions	13
2.2.2 Float damping	15
2.2.3 Pointer damping	15
2.3 Nameplate	16
2.4 Description code	17
2.5 Electronic revision	18
3 Installation	19
3.1 Notes on installation	19
3.2 Storage	19
3.3 Installation conditions	20
3.3.1 Tightening torques	22
3.3.2 Magnetic filters	22
3.3.3 Heat insulation	23
4 Electrical connections	24
4.1 Security information	24
4.2 Electrical connection indicator M40	25
4.2.1 Limit switches K1/K2	25
4.2.2 ESK4 / ESK4A current output	28
4.2.3 ESK4-T limit outputs	31
4.2.4 ESK4-T pulse output	33
4.2.5 ESK4-T binary input	34
4.2.6 ESK4-FF / ESK4-PA fieldbus communication	35
4.2.7 Harting HAN 7D connection	36
4.3 Grounding connections	37
4.4 Ingress protection	37

5	Start-up	38
5.1	Standard device	38
5.2	Indicator ESK4-T	38
6	Operation	39
6.1	ESK4 / ESK4A - Loop Check Mode	39
6.2	Operating elements ESK4-T	40
6.3	Basic principles of operation ESK4-T	41
6.3.1	Description of the operating keys	41
6.3.2	Navigation within the menu structure	41
6.3.3	Change the settings in the menu	42
6.4	Overview of the units ESK4-T	43
6.5	Error messages ESK4-T	44
6.6	ESK4-T menu	46
6.6.1	Factory settings	46
6.6.2	Menu structure	47
6.6.3	Menu description	49
7	Service	56
7.1	Maintenance	56
7.2	Replacement and retrofitting	56
7.2.1	Replacing floats	56
7.2.2	Retrofitting float damping	57
7.2.3	Retrofitting limit switch	57
7.2.4	Replacement - Retrofitting ESK4 / ESK4A	58
7.2.5	Replacement - Retrofitting add-on module ESK4-T / PA / FF	59
7.3	Spare parts availability	59
7.3.1	List of spare parts	59
7.4	Availability of services	63
7.5	Returning the device to the manufacturer	63
7.5.1	General information	63
7.5.2	Form (for copying) to accompany a returned device	64
7.6	Disposal	64
8	Technical data	65
8.1	Functional principle	65
8.2	Technical data	66
8.3	Dimensions and weights	73
8.4	Measuring ranges	76