



LC Display

reset switch

in system
programming header

USB port for
host computer

external I/O
connector

power supply

Laser connector

select power supply:

- external:



- USB:



- from alser:



use MAX3232
(default)

bypass MAX3232