

Raspberry pi setup

Set up serial0

Start **sudo raspi-config** and find serial in the Interfaces menu.

Answer NO to the question about login shell.

Answer YES to the question about serial hardware port.

Reboot.

The serial port device name will be **/dev/serial0**

Guide for raspi5: <https://forums.raspberrypi.com/viewtopic.php?t=362821>

Access serial:

minicom -b 115200 -D /dev/serial0 (or different name for raspi 5)

Test scripts are in the GRASP repo

RealVNC

https://help.realvnc.com/hc/en-us/articles/360002249917-RealVNC-Connect-and-Raspberry-Pi?lai_p=1&lai_sl=l&lai_sr=25-29&lai_vid=eeGE1r18JfqQR