

Telegesis		TG-ETRX-R301-AT-Commands	1
ETRX2		AT-Command Dictionary	3.01

TG-ETRX-R301-AT-Commands

ETRX2 ZigBee® Modules

AT-Command Dictionary



Current Firmware R301

Telegesis

Telegesis		TG-ETRX-R301-AT-Commands	2
ETRX2		AT-Command Dictionary	3.01

Table of Contents

1	INTRODUCTION.....	3
1.1	Document Overview.....	3
1.2	A Note on ZigBee® Compliance	4
1.3	Important notes	4
1.3.1	Hardware compatibility	4
1.3.2	Unexpected start-up in bootloader mode.....	4
1.3.3	Compatibility with other devices.....	4
2	AT STYLE COMMAND CONVENTIONS	5
2.1	Parameters.....	6
2.2	Prompt Overview.....	6
2.3	Device Overview.....	7
2.4	AT Command Overview.....	7
2.4.1	Module Control & Configuration Commands.....	9
2.4.2	Network Control & Configuration Commands	14
2.5	Messaging.....	19
3	LIST OF ERROR CODES.....	32
4	S-REGISTERS.....	33
4.1	Recovery of the Factory Default Settings.....	35
4.2	S-Registers for Network Setup	36
4.3	S-Registers for Module Setup.....	41
4.4	I/O related S-Registers.....	47
4.5	S-Registers Defining the Functionality of the Module.....	54
4.6	Advanced Messaging Settings	63
5	BUILT IN FUNCTIONALITY	67
6	POWER CONSUMPTION.....	69
6.1	ETRX2 Power Consumption.....	69
7	NOTES ON ENERGY LEVELS AND LQI	70
7.1	Interpreting LQI on the ETRX2.....	70
7.2	Interpreting RSSI Energy Levels on the ETRX2	70
8	UPGRADING FROM R2XX TO R300.....	71
9	TRADEMARKS.....	72
10	DISCLAIMER.....	72
11	CONTACT INFORMATION	72
12	REFERENCES.....	72

Telegesis		TG-ETRX-R301-AT-Commands	3
ETRX2		AT-Command Dictionary	3.01

1 Introduction

This document describes the AT-Command interface firmware of the ETRX2, ZigBee PRO wireless meshing modules.

The Telegesis ETRX2 modules have been designed to be built into any device and provide a low cost, low power ZigBee solution based on the industry leading EmberZNet ZigBee stack. Integration into a wide range of applications is made easy using a simple AT-style software interface and advanced hardware design.

No RF experience or expertise is required to add this powerful wireless networking capability to your products. The ETRX2 offers fast integration opportunities and the shortest possible time to market for your product.

Important note

Using the AT-Command interface described in this document can shorten the time to market significantly, however customers using the ETRX2 range of Telegesis modules also have the option of using Ember's EZSP over UART interface or of developing custom firmware using the Ember Development tools.

1.1 Document Overview

This document is meant as an AT-Command and S-Register reference for R3xx revisions of the firmware based on EmberZNet3.x. In order to learn how your products can profit from wireless mesh networking please also refer to the following documents:

- ETRX2 Product Manual
- R3xx Firmware User Guide
- Migration guide for existing R2xx firmware customers
- ETRX2 Development Kit User Guide
- Application notes from www.telegesis.com

The ETRX2 Product Manual concentrates on the hardware specification of the modules. The Development Kit User Guide contains all of the information required to set up your development kit and run firmware upgrades where necessary.

Telegesis		TG-ETRX-R301-AT-Commands	4
ETRX2		AT-Command Dictionary	3.01

1.2 A Note on ZigBee® Compliance

The Telegesis R300 firmware has been tested and certified for MSP (manufacturer specific profile) compliance by a test house appointed by the ZigBee Alliance.

This certification includes tests guaranteeing that:

- Modules running the Telegesis AT-Command set won't interfere with existing ZigBee Networks in a malicious way
- Modules running the Telegesis AT-Command set can join a 3rd party ZigBee PRO network and use its routing capabilities
- Modules running the Telegesis AT-Command set can allow 3rd party nodes to join into a network consisting of Telegesis nodes and use its routing capabilities

In addition to implementing a manufacturer specific application profile the AT-Command set allows for a certain level of transparency allowing to communicate with 3rd party nodes running any public application profile.

If you want to use the term ZigBee or the ZigBee Logo in your product documentation the current regulations state that you have to

- i) Be at least an adopting member of the ZigBee Alliance in the year you release your product
- ii) Re-certify for MSP compliance with an approved testhouse

If you intend to get your product re-certified feel free to contact Telegesis for additional information. Also if you intend to build a product compliant to a public application profile (e.g. Home Automation, Smart Energy) feel free to contact us to discuss your options.

1.3 Important notes

1.3.1 Hardware compatibility

R3xx firmware will not run on the STRX2 module.

1.3.2 Unexpected start-up in bootloader mode

The bootloader which runs on the ETRX2 can be triggered using the command AT+BLOAD as described in Section 3, but it can also be triggered in hardware. If the A/D2 pin is pulled low during the boot-up of the module, the module will also enter the bootloader, so exercise caution when doing hardware design and ensure that this pin is not grounded during start-up and reset. If unused the pad can be left floating and a pull-up is not required.

1.3.3 Compatibility with other devices

The R3xx Telegesis AT-Command line Interpreter is a Manufacturer Specific Profile using the ZigBee PRO feature set of ZigBee 2007. Interoperability with other devices that use the ZigBee PRO feature set is extremely limited at the moment, and R3xx is not compatible with earlier version of ZigBee, including Telegesis R2xx firmware.

Telegesis		TG-ETRX-R301-AT-Commands	5
ETRX2		AT-Command Dictionary	3.01

2 AT Style Command Conventions

To simplify the communication with the ETRX2 modules, an AT-style command set, similar to the industry standard Hayes modem control language, is used.

Each command must be preceded by the "AT" or "at" prefix. To terminate a command enter <CR>. Any data not following this pattern is either not accepted by the module or will cause an error message in response.

Commands are followed by an optional response that includes <CR><LF><Response><CR><LF> and/or a prompt <CR><LF><Prompt><CR><LF> where the prompt could also be an error message.

Example:

```
ATS00?<CR>
<CR><LF>FFFF<CR><LF>
<CR><LF>OK<CR><LF>
```

It is recommended to wait for an "OK" or "ERROR:XX" prompt before issuing the next command.

Any data which is prompted to the user is delivered in the format <CR><LF><prompt><CR><LF>. Unless disabled in S0E or S0F prompts may appear whenever the corresponding event occurs.

Example:

```
<CR><LF><BCAST:000D6F000005A666,04=test><CR><LF>
```

A prompt intersecting a command being entered will not affect the command itself.

Throughout this document, only the responses and prompts are presented, <CR><LF> are omitted intentionally. Sequences of AT commands in a single line are not supported.

The ETRX2 features a 128-byte FIFO to buffer incoming characters which is sufficient to hold even the longest possible command. To prevent a buffer overflow in serial link mode XON/XOFF handshaking is used. Optional hardware handshaking can be enabled as described in the register description of S12 in section 4.

Read Command ATXXX?	Commands ending with a '?' return the currently set value of the parameter or parameters
Write Command ATXXX=<...>	This command sets user-definable parameters as indicated by the '=' sign.
Execute Command ATXXX	This command executes routines of the module and returns parameters

Table 1: Types of AT commands

When bit 7 of S12 is set any reply or prompt is additionally started with the STX and ended with the ETX character to aid the interpretation of the incoming strings on a host processor.

Telegesis		TG-ETRX-R301-AT-Commands	6
ETRX2		AT-Command Dictionary	3.01

2.1 Parameters

Usually there are no optional parameter sets, so each parameter must be entered in the correct format.

XX	8-bit hexadecimal number. Valid characters are 0-9, a-f and A-F
XXXX	16-bit hexadecimal number. Valid characters are 0-9, a-f and A-F
n	Number from 0-9
s	Sign
b	Bit (0 or 1)
c	character
<PID>	16-bit hexadecimal PAN ID (0000 to FFFF)
<EPID>	64-bit hexadecimal extended PAN ID
<channel>	decimal channel (802.15.4 channel 11-26)
<password>	8 character password
<EUI64>	64-bit IEEE 802.15.4 address in hexadecimal

Table 2: Different formats of parameters

2.2 Prompt Overview

The following prompts can show up during the operation of the ETRX2 modules. Most of the prompts can be disabled using register S0E and S0F.

Prompt Overview	
ACK:XX	Acknowledgement for message no XX was received
NACK:XX	Acknowledgement for message no XX was not received
SR:XX,<EUI>,<NodeID>,...	Source Record received
BCAST:[<EUI64>,<XX>=<text>	A Broadcast with XX characters has been received
MCAST:[<EUI64>,<XX>=<text>	A Multicast with XX characters has been received
UCAST:[<EUI64>,<XX>=<text>	A Unicast with XX characters has been received
SDATA:[<EUI64>,<Ioread>,<A/D1>,<A/D2>,<sequence number>,<Vcc>	A data message has been received at the sink
COO:<EUI64>,<NodeID>	A coordinator identifying itself
FFD:<EUI64>,<NodeID>	A router identifying itself
SED:<EUI64>,<NodeID>	A sleepy end device identifying itself
MED:<EUI64>,<NodeID>	A mobile sleepy end device identifying itself
OK	OK terminator
ERROR:XX	Error number XX occurred
NEWNODE: <NodeID>,<EUI64>,<Parent NodeID>	Shown on Coordinator: New node has joined the PAN
LeftPAN	Local Node has left the PAN
JPAN:<channel>,<PID>,<EPID>	Local Node has joined PAN with given parameters
ADSK:<EUI64>,<NodeID>	Received Sink Advertisement

Table 3: Prompt Overview

Telegesis		TG-ETRX-R301-AT-Commands	7
ETRX2		AT-Command Dictionary	3.01

2.3 Device Overview

Table 4 gives an overview of the ZigBee device types mentioned in this document.

Device Types		ZigBee Naming Convention
COO	Coordinator	ZigBee Coordinator (ZC)
FFD	Router	ZigBee Router (ZR)
SED	Sleepy End Device	ZigBee End Device (ZED)
MED	Mobile Sleepy end Device	

Table 4: Device Overview

2.4 AT Command Overview

The following table gives a quick reference of all commands available.

Command Overview	
ATI	Display Product Identification Information
ATZ	Software Reset
AT&F	Restore Factory Defaults
AT+BLOAD	Enter The Bootloader Menu
AT+CLONE	Clone Local Node To Remote Node
AT+RECOVER	Recover From A Failed Clone Attempt
ATS	S-Register Access
ATREMS	Remote S-Register Access
ATSALL	Remote S-Register Access
AT+TOKDUMP	Display All S-Registers
AT+ESCAN	Scan The Energy Of All Channels
AT+PANSCAN	Scan For Active Pans
AT+EN	Establish Personal Area Network
AT+JN	Join Network
AT+JPAN	Join Specific Pan
AT+DASSL	Disassociate Local Device From Pan
AT+DASSR	Disassociate Remote Node From PAN
AT+N	Display Network Information
AT+SN	Scan Network
AT+NTABLE	Display Neighbour Table
AT+ATABLE	Display Address Table
AT+ASET	Set Address Table Entry
AT+MTABLE	Display Multicast Table
AT+MSET	Set Multicast Table Entry
AT+PING	Indicate Presence In The Network
AT+BCAST	Transmit A Broadcast
AT+BCASTB	Transmit A Broadcast Of Binary Data
AT+UCAST	Transmit A Unicast
AT+UCASTB	Transmit A Unicast Of Binary Data
AT+SCAST	Transmit Data To The Sink
AT+SCASTB	Transmit Binary Data To The Sink
AT+SSINK	Search For A Sink

Telegesis		TG-ETRX-R301-AT-Commands	8
ETRX2		AT-Command Dictionary	3.01

Command Overview (continued)

AT+MCAST	Transmit A Multicast
AT+MCASTB	Transmit A Multicast Of Binary Data
AT+FNDSR	Find The Source Route To A Remote Device
AT+SR	Set Source Route To Remote Device
AT+POLL	Poll For Data From Parent
AT+REJOIN	Rejoin The Network
AT+IDENT	Play A Tune On Remote Devboard
AT+RDATAB	Send Binary Raw Data

Table 5: Command Overview

Telegesis		TG-ETRX-R301-AT-Commands	9
ETRX2		AT-Command Dictionary	3.01

2.4.1 Module Control & Configuration Commands

I – Display Product Identification Information

Execute Command ATI	Response Telegesis <DeviceName> R<Firmware Revision> <EUI64> OK
Note On modules manufactured before summer 2007 an invalid <DeviceName> is displayed. This does not affect the functionality of the module.	Where <DeviceName> is the order code of the device, <Firmware Revision> is the firmware revision and <EUI64> is the Device's IEEE 802.15.4 identifier
SW release	R300

Z – Software Reset

Execute Command ATZ	Response Module Performs a software reset All non-volatile S Registers keep the user defined values, if the module was part of a PAN it will remain part of it.
SW release	R300

&F – Restore Factory Defaults

Execute Command AT&F	Response Module Performs a factory reset All non-volatile S Registers are updated with their factory defaults and the node leaves the network it is currently joined to.
SW release	R300

+BLOAD – Enter The Bootloader Menu

Execute Command AT+BLOAD	Response <entering bootloader> The device leaves the AT command line and enters the bootloader menu for downloading new firmware. A description of the bootloading process can be found in the Development Kit Product Manual. Please note that the bootloader will run at a baudrate of 115k2, no parity, 8 data bits regardless of the current serial port settings.
SW release	R300

Telegesis		TG-ETRX-R301-AT-Commands	10
ETRX2		AT-Command Dictionary	3.01

+CLONE – Clone Local Node To Remote Node

Execute Command AT+CLONE:<EUI64>,<password>	Response Cloning...
Use on: All devices	or ERROR<errorcode>
Note The default password for R3xx nodes is "password".	Where <errorcode> represents the error code explained in section 3. This command clones the firmware of the local node to a remote node within the same PAN, which address is given by <EUI64>. <password> represents the remote node's 8-character password. After completion a soft reset is caused on the remote end.
SW release	R300

+RECOVER – Recover From A Failed Clone Attempt

Execute Command AT+RECOVER	Response Recovering...
Use on: All devices. PAN must use channel 13.	or ERROR<errorcode>
Note Use this command in cases where the cloning operation was interrupted and the remote device therefore remains in the bootloader. For more information on over-the-air firmware upgrading please refer to the Development Kit Manual.	Where <errorcode> represents the error code explained in section 3. Clones the firmware of the local node to a remote node which is already in the bootloader.
SW release	R300

Telegesis		TG-ETRX-R301-AT-Commands	11
ETRX2		AT-Command Dictionary	3.01

S – S-Register Access

Read Command

ATSXX[x]?

Response

<data>

OK

or **ERROR:<errorcode>**

The module displays the contents of S-register xx or an error message, where <errorcode> represents the error code explained in section 3.

All 16-bit registers can also be accessed bit by bit. In order to do this [x] may specify the bit which is to be read. The result when reading a single bit will always be 0 or 1.

Write Command

ATSXX[x]=<data>

Response

OK or **ERROR:<errorcode>**

Notes

Some S-Registers require a password for write access. See S-Register description for details. **The default password for R3xx is “password”.**

Some S-Registers are read-only and will return an error if you are trying to write to them

The data is written to S-register number XX and if applicable stored in non-volatile memory. The data format for each individual S Register is given in the S-Register description.

<errorcode> represents the error code explained in section 3.

For all 16-bit registers individual bits can also be set or cleared by specifying the bit using [x] and setting it to either 0 or 1.

SW release

R300

Telegesis		TG-ETRX-R301-AT-Commands	12
ETRX2		AT-Command Dictionary	3.01

REMS – Remote S-Register Access

<p>Read Command ATREMS:<address>,XX[X]?</p> <p>Where <address> can be the remote node's EUI64, NodeID or address table index</p>	<p>Response <data> OK</p> <p>or ERROR:<errorcode></p> <p>The module displays the contents of the remote S-register XX or an error message, where <errorcode> represents the error code explained in section 3.</p> <p>All 16-bit registers can also be accessed bit by bit. In order to do this [x] may specify the bit which is to be read. The result when reading a single bit will always be 0 or 1.</p>
<p>Write Command ATREMS:<address>,XX[X]=<data></p> <p>Notes Some S-Registers require a password for write access. See S-Register description for details. The default password for R3xx is “password”. Some S-Registers are read-only and will return an error if you are trying to write to them</p>	<p>Response OK or ERROR:<errorcode></p> <p>The data is written to the remote S-register number XX and if applicable stored in non-volatile memory. The data format for each individual S Register is given in the S-Register description. <errorcode> represents the error code explained in section 3.</p> <p>For all 16-bit registers individual bits can also be set or cleared by specifying the bit using [x] and setting it to either 0 or 1.</p>
SW release	R300

SALL – Remote S-Register Access

<p>Write Command ATSALL:<group ID>,XX[X]=<data></p> <p>Where group IDs are remote node's multicast IDs or FFFF - Broadcast to all devices FFFE - Broadcast to all non-sleepy devices</p> <p>Notes Some S-Registers require a password for write access. See S-Register description for details. The default password for R3xx is “password”. Some S-Registers are read-only and will return an error if you are trying to write to them</p>	<p>Response OK or ERROR:<errorcode></p> <p>The data is written to the remote S-register number XX on all nodes addressed by the multicast group ID. The data format for each individual S Register is given in the S-Register description. <errorcode> represents the error code explained in section 3.</p> <p>For all 16-bit registers individual bits can also be set or cleared by specifying the bit using [x] and setting it to either 0 or 1.</p>
SW release	R300

Telegesis		TG-ETRX-R301-AT-Commands	13
ETRX2		AT-Command Dictionary	3.01

TOKDUMP – Display All S-Registers

Execute Command AT+TOKDUMP	Response <data> OK
Notes Only used on the local node. You cannot display all the registers of a remote device.	The module displays the contents of all local S-Registers. The data format for each individual S Register is given in the S-Register description in section 4.
SW release	R300

Telegesis		TG-ETRX-R301-AT-Commands	14
ETRX2		AT-Command Dictionary	3.01

2.4.2 Network Control & Configuration Commands

+ESCAN – Scan The Energy Of All Channels

Execute Command AT+ESCAN	Response +ESCAN: 11:XX 12:XX ... 26:XX OK or ERROR:<errorcode>
Use on: All nodes	
Note Scanning all channels can take up to 16 seconds.	<errorcode> represents the error code explained in section 3. XX represents the average energy on the respective channel (see description in Section 8). Channels masked out in S00 are not scanned.
SW release	R300

+PANSCAN – Scan For Active PANs

Execute Command AT+PANSCAN	Response +PANSCAN:<channel>,<PID>,<EPID>,XX,b OK or ERROR:<errorcode>
Use on: All nodes	
Note Scanning for active PANs can take up to 16 seconds.	<errorcode> represents the error code explained in section 3. The node gives a list of all PANs found. <channel> represents the channel, <PID> the PAN ID, <EPID> the extended PAN ID, XX the ZigBee stack profile (00 = Custom, 01 = ZigBee, 02 = ZigBee PRO) and b indicates whether the network is allowing additional nodes to join (1 = joining permitted). The node does not join any of the PANs found.
SW release	R300

Telegesis		TG-ETRX-R301-AT-Commands	15
ETRX2		AT-Command Dictionary	3.01

+EN – Establish Personal Area Network

Execute Command AT+EN	Response JPAN:<channel>,<PID>,<EPID> OK or ERROR:<errorcode>
Use on: All nodes which are not part of a PAN	<errorcode> represents the error code explained in section 3.
Note When issuing this command the local device becomes a Coordinator (and Trust Centre). Establishing a PAN can take up to 16 seconds. This command can only be executed if the local node is not part of a PAN already.	The local node becomes a coordinator and performs an energy scan on all channels selected in S00. It then starts a PAN with a random unused PAN ID and extended PAN ID on the quietest channel. If a PAN ID and/or extended PAN ID is specified in S02 or S03 the provided IDs are used instead of random ones, given the selected IDs are not already in use by other networks within range
SW release	R300

+JN – Join Network

Execute Command AT+JN	Response JPAN:<channel>,<PID>,<EPID> OK or ERROR:<errorcode>
Use on: All nodes which are not part of a PAN	<errorcode> represents the error code explained in section 3.
Note Joining a PAN can take up to 8 seconds, depending on the number of channels which need scanning. This command can only be executed if the local node is not part of a PAN already.	The local node scans all channels selected in register S00 for the existence of a PAN. When finding any PAN which allows joining it will automatically join in via the remote node with the highest RSSI. In case registers S02 and S03 differ from the default value of all zeros the node will only join a PAN with the specified Pan ID and/or extended PAN ID.
Remote Action On the Trust Centre / Coordinator	Prompt NEWNODE:<node EUI64>,<NodeID>,<parent EUI64>
SW release	R300

Telegesis		TG-ETRX-R301-AT-Commands	16
ETRX2		AT-Command Dictionary	3.01

+JPAN – Join Specific PAN

Execute Command

AT+JPAN:<channel>,<PID or EPID>

Examples

AT+JPAN:20,1234

AT+JPAN:24,0793E14FFB220A38

Use on

All nodes which are not part of a PAN

Notes

This command can only be executed if the local node is not part of a PAN already.

The JPAN command overrides the channel mask in register S00 and the PID and EPID in S02 and S03.

Remote Action

On the Trust Centre / Coordinator

Response

JPAN:<channel>,<PID>,<EPID>

OK

or **ERROR:<errorcode>**

<errorcode> represents the error code explained in section 3.

The local node joins a particular PAN on <CHANNEL> with the specified <PID> or <EPID> via the remote node with the highest RSSI.

Prompt

NEWNODE:<node EUI64>,<NodeID>,<parent EUI64>

SW release

R300

Telegesis		TG-ETRX-R301-AT-Commands	17
ETRX2		AT-Command Dictionary	3.01

+DASSL – Disassociate Local Device From PAN

Execute Command AT+DASSL	Response OK or ERROR<errorcode>
Use on All Devices	Prompt LeftPAN
Note Use with care on a Coordinator. It will not be able to rejoin the PAN	<errorcode> represents the error code explained in section 3. Instruct local device to leave the PAN.
SW release	R300

+DASSR – Disassociate Remote Node from PAN

(ZDO)

Execute Command AT+DASSR:<address>	Response SEQ:XX OK or ERROR:<errorcode>
Where <address> can be a node's EUI64, NodeID or address table index	
Use on All Devices	<errorcode> represents the error code explained in section 3. Instruct device to leave the PAN.
Note Use with care on a Coordinator. It will not be able to rejoin the PAN	
Remote Action	Prompt LeftPAN
SW release	R300

+N – Display Network Information

Read Command AT+N?	Response +N=<devicetype>=<channel>,<power>,<PID>,<EPID> or +N=NoPAN
Use on All Devices	followed by OK <devicetype> represents the node's functionality in the PAN (FFD,COO,SED,MED), <power> the node's output power in dBm, <channel> the IEEE 802.15.4 radio channel (11-26), <PID> the node's PAN ID and <EPID> the node's extended PAN ID.
SW release	R300

Telegesis		TG-ETRX-R301-AT-Commands	18
ETRX2		AT-Command Dictionary	3.01

+SN – Scan Network

Execute Command

AT+SN[:nn]

All Telegesis devices which are up to nn hops away are listed. If nn = 01 only direct neighbours will reply and nn = 00 will search the entire network.

Use on
All Devices

Note

In case no parameter is specified 30 is used by default.

SW release

Response

OK or ERROR<errorcode>

Prompts

**FFD:<EUI64>,<NodeID>[,syy,zz]
SED:<EUI64>,<NodeID>[,syy,zz]
MED:<EUI64>,<NodeID>[,syy,zz]
COO:<EUI64>,<NodeID>[,syy,zz]**

Parameters

nn ranging from 00 to 30

<errorcode> represents the error code explained in section 3. In case bit C of register S10 is set the RSSI level (syy in dBm) and LQI (zz in hexadecimal) of the last hop are displayed. For a description of the LQI reading please see section 7. Source route messages may also be displayed.

R300

+NTABLE – Display Neighbour Table

(ZDO)

Read Command

AT+NTABLE:index,<address>

Where <address> can be the remote node's EUI64, NodeID or address table index

Note: Also the local node can be the target of this command (e.g. use address table index FF as the address)

Use on
All Devices

Response

SEQ:XX

OK or ERROR<errorcode>

This command requests the target node to respond by listing its neighbour table starting from the requested index. Can be used to find the identity of all ZigBee devices in the network including non Telegesis devices.

Prompt (example)

NTable: 03

No.	Type	EUI	ID	LQI
0.	FFD	000D6F000015896B	BC04	FF
1.	FFD	000D6F00000B3E77	739D	FF
2.	FFD	000D6F00000AAD11	75E3	FF

In this example the neighbour table contains three entries, which are displayed. In case the table contains more than three entries it may be required to repeat this command and increase the index count until the full table is derived.

SW release

R300

Telegesis		TG-ETRX-R301-AT-Commands	19
ETRX2		AT-Command Dictionary	3.01

2.5 Messaging

+ATABLE – Display Address Table

Read Command AT+ATABLE	Response												
Use on All Devices	<table><tr><th>No.</th><th>Active</th><th>ID</th><th>EUI</th></tr><tr><td>00</td><td>N</td><td>0000</td><td>000D6F0000012345</td></tr><tr><td>(...)</td><td></td><td></td><td></td></tr></table> OK	No.	Active	ID	EUI	00	N	0000	000D6F0000012345	(...)			
No.	Active	ID	EUI										
00	N	0000	000D6F0000012345										
(...)													
Note: Entry 05 contains the address of the node's sink. The user can overwrite it to manually select a different sink.	The Address Table contains nodes which can be addressed by referring to the corresponding address table entry.												
SW release	R300												

+ASET – Set Address Table Entry

Read Command AT+ASET:XX,<NodeID>,<EUI64>	Response
Where XX is the entry number of the address table entry which is to be written. If the NodeID is unknown, the NodeID <u>must</u> be substituted with "FFFF".	<p>OK</p> <p>or ERROR:<errorcode></p> <p><errorcode> represents the error code explained in section 3.</p>
Use on All Devices	
SW release	R300

+MTABLE – Display Multicast Table

Read Command AT+MTABLE	Response																		
Use on All Devices	<table><tr><th>No.</th><th>ID</th><th>EP</th></tr><tr><td>00</td><td>1234</td><td>01</td></tr><tr><td>01</td><td>0000</td><td>00</td></tr><tr><td>02</td><td>0000</td><td>00</td></tr><tr><td>03</td><td>0000</td><td>00</td></tr><tr><td>04</td><td>0000</td><td>00</td></tr></table> OK	No.	ID	EP	00	1234	01	01	0000	00	02	0000	00	03	0000	00	04	0000	00
No.	ID	EP																	
00	1234	01																	
01	0000	00																	
02	0000	00																	
03	0000	00																	
04	0000	00																	
<u>Note:</u> For Multicasts to be displayed using the MCAST prompt, endpoint 01 must be selected as the target endpoint.	The multicast-table contains all multicast IDs which will be received by the local node.																		
SW release	R300																		

Telegesis		TG-ETRX-R301-AT-Commands	20
ETRX2		AT-Command Dictionary	3.01

+MSET – Set Multicast Table Entry

Read Command AT+MSET:XX,<ID>,<endpoint> Where XX is the index number of the multicast-table entry which is to be written. For the AT-Command interface operation the endpoint should always be set to 01. Use on All Devices SW release	Response OK or ERROR:<errorcode> <errorcode> represents the error code explained in section 3.
	R300

+PING – Indicate Presence In The Network

Execute Command AT+PING Use on All Devices	Response OK or ERROR<errorcode> <errorcode> represents the error code explained in section 3.
Remote Action	Prompt FFD:<EUI64>,<NodeID> [,syy,zz] SED:<EUI64>,<NodeID> [,syy,zz] MED:<EUI64>,<NodeID> [,syy,zz] COO:<EUI64>,<NodeID> [,syy,zz] The prompt above will be displayed on all nodes which can hear the ping. In case bit C of register S10 is set the RSSI level (syy dBm) and LQI (zz in hexadecimal) of the last hop are displayed. For a description of the LQI reading please see section 7. <EUI64> is the identifier and <NodeID> the NodeID of the sending device
SW release	R300

Telegesis		TG-ETRX-R301-AT-Commands	21
ETRX2		AT-Command Dictionary	3.01

+BCAST – Transmit A Broadcast

<p>Execute Command AT+BCAST:nn,<data></p> <p>Example AT+BCAST:00,Hello world</p> <p>Use on: All devices</p> <p>Note: Use broadcasts sparingly! The ZigBee specification only allows any node to repeat or originate up to 8 broadcasts in every 8 second interval. Broadcasts use a lot of bandwidth.</p>	<p>Response OK or ERROR<errorcode></p> <p>Where <errorcode> represents the error code explained in section 3.</p> <p>Parameters nn ranging from 00 to 30</p> <p>A Maximum of 82 bytes are sent (with attached EUI only 74 bytes). The response OK shows successful transmission. Successful transmission does not guarantee successful reception. To make sure data has been received by a specific node use a unicast message. Only neighbours which are up to nn hops away will receive the broadcast. If nn = 01 only direct neighbours will receive the broadcast and if n = 00 the entire network will (max. 30 hops).</p>
Remote action	<p>Prompt BCAST:[<EUI64>,<length>=<data></p> <p>Every node in the PAN which has received the broadcast message will prompt the above message where <EUI64> is the address of the sender, <length> is the length of the payload and <data> is the data which was attached to the broadcast. The EUI64 is only displayed if it is part of the network header (set bit 0 of S10 to disable attaching the EUI64 to outgoing messages).</p>
SW release	R300

Telegesis		TG-ETRX-R301-AT-Commands	22
ETRX2		AT-Command Dictionary	3.01

+BCASTB – Transmit A Broadcast Of Binary Data

Execute Command

AT+BCASTB:nn,XX

Where nn is the number of hops the message will travel and XX is the number (in hexadecimal) of data bytes to be sent.

Use on

All Devices

Note

This command is particularly useful if the data may contain <CR> and <Backspace> characters.

Response

**> <data being entered>
OK**

or **ERROR:<errorcode>**

After the ‘>’ prompt a number of XX characters are expected to be entered. <errorcode> represents the error code explained in section 3.

(In case bit D of S08 is set a timeout error is generated if no character is received for 1 second.)

Parameters

XX ranging from 00 to 52 (hexadecimal)

nn ranging from 00 to 30 (decimal)

A maximum of 82 bytes are sent (with attached EUI only 74 bytes). The response OK shows successful transmission. Successful transmission does not guarantee successful reception. To make sure data has been received by a specific node use a unicast message. Only neighbours which are up to nn hops away will receive the broadcast. If nn=01 only direct neighbours will receive the broadcast and if n = 00 the entire network will (max 30 hops).

Remote action

Prompt

BCAST:<EUI64>,<length>=<data>

Every node in the PAN which has received the broadcast message will prompt the above message where <EUI64> is the address of the sender and <length> is the length of the message in hexadecimal. The EUI64 is only displayed if it is part of the network header (set bit 0 of S10 to disable attaching the EUI64 to outgoing messages).

SW release

R300

Telegesis		TG-ETRX-R301-AT-Commands	23
ETRX2		AT-Command Dictionary	3.01

+UCAST – Transmit A Unicast

Execute Command

AT+UCAST:<address>=<data>

Example

AT+UCAST:000D6F0000012345,Hello

Where <address> can be the remote node's EUI64, NodeID or address table index

Use on

All Devices

Note

Unicasts can be addressed either by referencing the recipient's EUI64, NodeID or an entry in the address table.

The maximum payload is 82 bytes. It gets reduced by 8 bytes when appending the EUI to the network header (default) and also it gets reduced by 2 bytes per hop in case a source route is known. The later event can neither be suppressed nor foreseen.

Remote action

Response

SEQ:XX
OK

or

ERROR:<errorcode>

Where <errorcode> represents the error code explained in section 4.

Prompt

ACK:XX

or **NAK:XX**

Up to 82 bytes are sent to the node up to 30 hops away. On successful transmission the user is given the transmissions sequence number followed by "OK". The user is then prompted "ACK" on receipt of an acknowledgement or "NAK" in case the message was not acknowledged. A NACK does not guarantee that the message has not reached its destination.

Prompt

UCAST:[<EUI64>,<length>=<data>

Where <EUI64> is the address of the sender and <length> is the length of the message in hexadecimal. The EUI64 is only displayed if it is part of the network header (set bit 0 of S10 to disable attaching the EUI64 to outgoing messages).

SW release

R300

Telegesis		TG-ETRX-R301-AT-Commands	24
ETRX2		AT-Command Dictionary	3.01

+UCASTB – Transmit A Unicast Of Binary Data

<p>Execute Command AT+UCASTB:XX,<address></p> <p>Where <address> can be the remote node's EUI64, NodeID or address table index and XX is the number (in hexadecimal) of data bytes to be sent.</p> <p>Use on All Devices</p> <p>Notes This command is particularly useful if the data may contain <CR> and <Backspace> characters. The ACK and/or NACK prompt can be disabled in S0E Unicasts can be addressed either by referencing the recipient's EUI64, NodeID or an entry in the address table. The maximum payload is 82 bytes. It gets reduced by 8 bytes when appending the EUI to the network header (default) and also it gets reduced by 2 bytes per hop in case a source route is known. The later event can neither be suppressed nor foreseen.</p>	<p>Response > <data being entered> SEQ:XX OK</p> <p>or ERROR:<errorcode></p> <p>Prompt ACK:XX</p> <p>or NAK:XX</p> <p>Parameters XX ranging from 00 to 52 (hex)</p> <p>After the '>' prompt a number of XX characters are expected to be entered. Up to 82 bytes are sent to the node with address <EUI64>. In case bit 9 of S10 is set a timeout error is generated if no character is received for 1 second. On successful transmission the user is given a transmission number followed by "OK". After that the user is prompted "ACK" on receipt of an acknowledgement or "NACK" in case the message was not acknowledged. A NACK does not guarantee that the message has not reached its destination.</p>
Remote action	<p>Prompt</p> <p>UCAST:[<EUI64>,<length>=<data></p> <p>Where <EUI64> is the address of the sender and <length> is the length of the message in hexadecimal. The EUI64 is only displayed if it is part of the network header (set bit 0 of S10 to disable attaching the EUI64 to outgoing messages).</p>
SW release	R300

Telegesis		TG-ETRX-R301-AT-Commands	25
ETRX2		AT-Command Dictionary	3.01

+SCAST – Transmit Data To The Sink

<p>Execute Command AT+SCAST:<data></p> <p>Example AT+SCAST:Hello world</p> <p>Use on All Devices</p> <p>Notes</p> <ul style="list-style-type: none"> - If a sink cannot be reached for three consecutive transmissions the sink is assumed unavailable and a new one is sought - The ACK and/or NACK prompt can be disabled in S0E - When attaching the node's EUI64 to the network frame the maximum payload reduces to 76 bytes 	<p>Response SEQ:XX OK</p> <p>or ERROR<errorcode></p> <p>Where <errorcode> represents the error code explained in section 3.</p> <p>Prompt ACK:XX</p> <p>or NAK:XX</p> <p>Parameters Up to 82 bytes are sent to the node's sink. On successful transmission the user is given the sequence number followed by "OK". After that the user is prompted "ACK" on receipt of an acknowledgement or "NACK" in case the message was not acknowledged. A NACK does not guarantee that the message has not reached its destination.</p>
Remote action	<p>Prompt UCAST:[<EUI64>,<length>=<data></p> <p>Where <EUI64> is the address of the sender and <length> is the length of the message in hexadecimal. The EUI64 is only displayed if it is part of the network header (set bit 0 of S10 to disable attaching the EUI64 to outgoing messages).</p>
SW release	R300

Telegesis		TG-ETRX-R301-AT-Commands	26
ETRX2		AT-Command Dictionary	3.01

+SCASTB – Transmit Binary Data To A Sink

Execute Command
AT+SCASTB:XX

Where XX is the number (in hexadecimal) of data bytes to be sent.

Use on
All Devices

Notes

- If a sink cannot be reached for three consecutive transmissions the sink is assumed unavailable and a new one is sought.
- The ACK and/or NACK prompt can be disabled in S0E
- When attaching the node's EUI64 to the network frame the maximum payload reduces to 76 bytes

Response
> <data being entered>
SEQ:XX
OK

or **ERROR<errorcode>**

Parameters

XX ranging from 00 to 52 (hex)

After the '>' prompt a number of XX characters are expected to be entered. A maximum of 82 bytes are sent to the network's sink.
(In case bit 9 of S10 is set a timeout error is generated if no character is received for 1 second.)
On successful transmission the user is given a transmission number followed by "OK". After that the user is prompted "ACK" on receipt of an acknowledgement or "NAK" in case the message was not acknowledged. A NAK does not guarantee that the message has not reached its destination.

Remote action

Prompt
UCAST:[<EUI64>],XX=<data>

Where <EUI64> is the address of the sender and <length> is the length of the message in hexadecimal. The EUI64 is only displayed if it is part of the network header (set bit 0 of S10 to disable attaching the EUI64 to outgoing messages).

SW release

R300

+SSINK – Search For A Sink

Read Command
AT+SSINK

Search for a sink on the network
If a sink is already known and no better sink is found, no prompt will be displayed.
A sink, which is already known can be found at index 05 of the address table.

Use on
All Devices

SW release

Response
OK or **ERROR<errorcode>**

Prompt
SINK:<EUI64>,<NodeID>

<errorcode> represents the error code explained in section 3.

R300

Telegesis		TG-ETRX-R301-AT-Commands	27
ETRX2		AT-Command Dictionary	3.01

+MCAST – Transmit A Multicast

<p>Execute Command AT+MCAST:nn,<ID>,<data></p> <p>Use on: All devices</p> <p>Notes</p> <ul style="list-style-type: none"> - When attaching the node's EUI64 to the network frame the maximum payload reduces to 76 bytes - Entries in the multicast table must be set to endpoint 01 to trigger the desired prompt 	<p>Response OK or ERROR<errorcode></p> <p>Where <errorcode> represents the error code explained in section 3.</p> <p>Parameters nn ranging from 00 to 30</p> <p>Up to 82 bytes are sent to the multicast group <ID>. The response OK shows successful transmission. Successful transmission does not guarantee successful reception. To make sure data has been received by a specific node use a unicast message. Only neighbours which are up to nn hops away will receive the broadcast. If nn = 01 only direct neighbours will receive the broadcast and if nn = 00 the entire network will (max. 30 hops).</p>
Remote action	<p>Prompt MCAST:[<EUI64>,<Length>=<data></p> <p>Where <EUI64> is the address of the sender and <length> is the length of the message in hexadecimal. The EUI64 is only displayed if it is part of the network header (set bit 0 of S10 to disable attaching the EUI64 to outgoing messages).</p>
SW release	R300

Telegesis		TG-ETRX-R301-AT-Commands	28
ETRX2		AT-Command Dictionary	3.01

+MCASTB – Transmit A Multicast Of Binary Data

Execute Command

AT+MCASTB:XX,nn,<ID>

Where XX is the number (in hexadecimal) of data bytes to be sent and nn is the number of hops the message will travel.

Use on
All Devices

Notes

When attaching the node's EUI64 to the network frame the maximum payload reduces to 76 bytes

This command is particularly useful if the data may contain <CR> and <Backspace> characters.

Response

**> <data being entered>
OK**

or **ERROR<errorcode>**

After the '>' prompt a number of XX characters are expected to be entered. <errorcode> represents the error code explained in section 3.

In case bit 9 of S10 is set a timeout error is generated if no character is received for 1 second.

Parameters

**XX ranging from 00 to 52 (hex)
nn ranging from 00 to 30**

Up to 82 bytes are sent to devices up to nn hops away. The response OK shows successful transmission. Successful transmission does not guarantee successful reception. To make sure data has been received by a specific node use a unicast message. Only neighbours which are up to nn hops away will receive the broadcast. If nn=01 only direct neighbours will receive the broadcast and if n = 00 the entire network will.

Remote action

Prompt

MCAST:[<EUI64>,<length>=<data>

Where <EUI64> is the address of the sender and <length> is the length of the message in hexadecimal. The EUI64 is only displayed if it is part of the network header (set bit 0 of S10 to disable attaching the EUI64 to outgoing messages).

SW release

R300

Telegesis		TG-ETRX-R301-AT-Commands	29
ETRX2		AT-Command Dictionary	3.01

+FNDSR – Find the Source Route to a remote device

Execute Command AT+FNDSR:<address>	Response OK
Where <address> can be the remote node's EUI64 or address table index	or ERROR<errorcode>
Tries to find source route information to the specified device by sending an acknowledged unicast to the remote device.	Prompt SR:XX,<EUI64>,<NodeID>,<NodeID>...
Use on Sink, COO	Where XX represents the number of hops to the remote node, EUI64 its EUI64 number followed by a list of NodeIDs starting with the remote node listing all nodes along the path to the local node
Use on A Sink	<errorcode> represents the error code explained in section 3.
SW release	R300

+SR – Set Source Route to Remote Device

Execute Command AT+SR:<NodeID>,<NodeID>,...	Response OK
Set the source route of a message sent to a remote device, starting with the NodeID of the remote device followed by all NodeIDs on the route from the remote node to the local node	or ERROR<errorcode>
Use on All Devices	<errorcode> represents the error code explained in section 3.
Note: Setting up invalid routes may lead to listed devices becoming unavailable. To confirm a route use AT+FNDSR.	Stores route information for up to 30 hops which will be used when sending any message to a remote node, which is part of the listed devices.
SW release	R300

+POLL – Poll The Parent Device

Execute Command AT+POLL	Response OK
Poll the parent device for new data.	or
Note: Action 0011 is recommended for periodic polling.	ERROR<errorcode>
Use on SEDs MEDs	<errorcode> represents the error code explained in section 3.
SW release	R300

Telegesis		TG-ETRX-R301-AT-Commands	30
ETRX2		AT-Command Dictionary	3.01

+REJOIN – Rejoin the network

Execute Command

AT+REJOIN:b

If b is set to 0 join without the known network key (unencrypted) and if b is set to 1 join encrypted.

Use on

SED

MED

FFD

Notes

Polling a parent on an end device that has lost its parent will automatically call AT+REJOIN:1. Furthermore functionality 0012 and 0013 make use of this command.

SW release

Response

OK

or

ERROR<errorcode>

If the contact with the network has been lost, because an end device has lost its parent, the network has changed channel, or updated its encryption key the command AT+REJOIN can be used to rejoin the network.

<errorcode> represents the error code explained in section 3.

R300

+IDENT – Play A Tune On Remote Devboard

Execute Command

AT+IDENT:<address>

Where <address> can be the remote node's EUI64, NodeID or address table index

Use on

All Devices

Response

SEQ:XX

OK

or

ERROR<errorcode>

Prompt

ACK:XX

or **NAK:XX**

<errorcode> represents the error code explained in section 3.

Plays a tune on a remote devboard if the Beeper is connected. Useful to identify remote nodes. See devkit manual for details about connecting a beeper to the ETRX2.

SW release

R300

Telegesis		TG-ETRX-R301-AT-Commands	31
ETRX2		AT-Command Dictionary	3.01

+RDATA – Send Binary Raw Data

Execute Command
AT+RDATA:XX

Use on
All Devices

Note
Can be useful to quickly exchange bulk data with neighbouring node. The application needs to handle addressing, error checking, retries and acknowledgements.

Response
> <data being entered>
OK

or **ERROR:<errorcode>**

Parameters
XX ranging from 00 to 67 (hex)

After the ‘>’ prompt a number of XX characters are expected to be entered. Up to 103 bytes of data can be send to all nodes within reach (direct neighbours)

The data is neither encrypted nor error checked. No retries are made and no acknowledgement is received.

<errorcode> represents the error code explained in section 3.

Remote action

Prompt
RAW:snn,<data>

where snn is the RSSI, or

<data>

in case bit 9 of S0E is set. Displaying the data can also be disabled by setting bit D of S0E.

SW release

R300

Telegesis		TG-ETRX-R301-AT-Commands	32
ETRX2		AT-Command Dictionary	3.01

3 List of Error codes

01	Couldn't poll Parent because of Timeout
02	Unknown command
04	Invalid S-Register
05	Invalid parameter
06	Recipient could not be reached
07	Message was not acknowledged
08	No sink known
09	Address Table entry is in use and cannot be modified
0A	Message could not be sent
0B	Local node is not sink
0C	Too many characters
0D	License Problem
0F	Fatal error initialising the network
10	Error bootloading
12	Fatal error initialising the stack
18	Node has run out of Buffers
19	Trying to write read-only register
20	Invalid password
25	Cannot form network
27	No network found
28	Operation cannot be completed if node is part of a PAN
2C	Error leaving the PAN
2D	Error scanning for PANs
33	No response from the remote bootloader
34	Target did not respond during cloning
35	Timeout occurred during xCASTB
39	MAC Transmit Queue is Full
70	Invalid Operation
74	Message too long
91	Operation only possible if joined to a PAN
93	Node is not part of a Network
94	Cannot join network
96	Mobile End Device Move to new Parent Failed
98	Cannot join ZigBee 2006 Network as Router
A1	More than 8 broadcasts were sent within 8 seconds
AB	Trying to join, but no beacons could be heard
AC	Network key was sent in the clear when trying to join secured
AD	Did not receive Network Key
AE	No Link Key received
AF	Preconfigured Key Required

Telegesis		TG-ETRX-R301-AT-Commands	33
ETRX2		AT-Command Dictionary	3.01

4 S-Registers

Most S-Registers of the ETRX2 can be read and written locally as well as remotely. The S-Registers are summarised in the table below.

S-Register Overview		Local R/W	Remote R/W
S00	Channel Mask	(●/●)	(●/●)
S01	Transmit Power Level	(●/●)	(●/●)
S02	Preferred PAN ID	(●/●)	(●/●)
S03	Preferred Extended PAN ID	(●/●)	(●/●)
S04	Local EUI	(●/-)	(●/-)
S05	Local NodeID	(●/-)	(●/-)
S06	Parent's EUI	(●/-)	(●/-)
S07	Parent's NodeID	(●/-)	(●/-)
S08	Network Key ¹	(-/●)	(-/●)
S09	Link Key ¹	(-/●)	(-/●)
S0A	Main Function ¹	(●/●)	(●/●)
S0B	User Readable Name ¹	(●/●)	(●/●)
S0C	Password ¹	(●/●)	(●/●)
S0D	Device Information	(●/-)	(●/-)
S0E	Prompt Enable 1	(●/●)	(●/●)
S0F	Prompt Enable 2	(●/●)	(●/●)
S10	Extended Function	(●/●)	(●/●)
S11	Device Specific	(●/●)	(●/●)
S12	UART Setup	(●/●)	(●/●)
S13	Pull-up enable	(●/●)	(●/●)
S14	Pull-down enable	(●/●)	(●/●)
S15	I/O Configuration (reserved for future use)	(●/●)	(●/●)
S16	Data Direction of I/O Port (volatile)	(●/●)	(●/●)
S17	Initial Value of S16	(●/●)	(●/●)
S18	Output Buffer of I/O Port (volatile)	(●/●)	(●/●)
S19	Initial Value of S18	(●/●)	(●/●)
S1A	Input Buffer of I/O Port (volatile)	(●/-)	(●/-)
S1B	Special Function pin 1 (volatile)	(●/●)	(●/●)
S1C	Initial Value of S1B	(●/●)	(●/●)
S1D	Special Function Pin 2 (volatile)	(●/●)	(●/●)
S1E	Initial Value of S1D	(●/●)	(●/●)
S1F	A/D1	(●/-)	(●/-)
S20	A/D2	(●/-)	(●/-)
S21	A/D3	(●/-)	(●/-)
S22	A/D4	(●/-)	(●/-)
S23	Immediate functionality at IRQ0	(●/●)	(●/●)
S24	Immediate functionality at IRQ1	(●/●)	(●/●)
S25	Immediate functionality at IRQ2	(●/●)	(●/●)
S26	Immediate functionality at IRQ3	(●/●)	(●/●)

Telegesis		TG-ETRX-R301-AT-Commands	34
ETRX2		AT-Command Dictionary	3.01

S-Register Overview (continued)		Local R/W	Remote R/W
S27	Functionality 1 at Boot-up	(●/●)	(●/●)
S28	Functionality 2 at Boot-up	(●/●)	(●/●)
S29	Timer/Counter 0	(●/●)	(●/●)
S2A	Functionality for Timer/Counter 0	(●/●)	(●/●)
S2B	Timer/Counter 1	(●/●)	(●/●)
S2C	Functionality for Timer/Counter 1	(●/●)	(●/●)
S2D	Timer/Counter 2	(●/●)	(●/●)
S2E	Functionality for Timer/Counter 2	(●/●)	(●/●)
S2F	Timer/Counter 3	(●/●)	(●/●)
S30	Functionality for Timer/Counter 3	(●/●)	(●/●)
S31	Timer/Counter 4	(●/●)	(●/●)
S32	Functionality for Timer/Counter 4	(●/●)	(●/●)
S33	Timer/Counter 5	(●/●)	(●/●)
S34	Functionality for Timer/Counter 5	(●/●)	(●/●)
S35	Timer/Counter 6	(●/●)	(●/●)
S36	Functionality for Timer/Counter 6	(●/●)	(●/●)
S37	Timer/Counter 7	(●/●)	(●/●)
S38	Functionality for Timer/Counter 7	(●/●)	(●/●)
S39	Power mode (volatile)	(●/●)	(●/●)
S3A	Initial Power Mode	(●/●)	(●/●)
S3B	Start-up Functionality Plaintext A	(●/●)	(●/●)
S3C	Start-up Functionality Plaintext B	(●/●)	(●/●)
S3D	Supply Voltage	(●/-)	(●/-)
S3E	Multicast Table Entry 00	(●/●)	(●/●)
S3F	Multicast Table Entry 01	(●/●)	(●/●)
S40	Source and Destination Endpoints for xCASTs (volatile)	(●/●)	(●/●)
S41	Initial Value of S40	(●/●)	(●/●)
S42	Cluster ID for xCASTs (volatile)	(●/●)	(●/●)
S43	Initial Value of S42	(●/●)	(●/●)
S44	Profile ID for xCASTs (volatile)	(●/●)	(●/●)
S45	Initial Value of S44	(●/●)	(●/●)
S46	Start-up Functionality 16 bit number (volatile)	(●/●)	(●/●)

Table 6: S-Register Overview

With a few exceptions the S-registers are stored in non-volatile memory and will keep their user defined settings unless reset to the factory defaults using the “AT&F” command. S16, S18, S1A, S1B, S1D and S39 are directly accessing volatile I/O registers to prevent memory corruption due to constant I/O access. Registers S17, S19, S1C, S1E, S3A, S41 and S43 represent the non-volatile registers which define the contents of S16, S18, S1B, S1D, S39, S40 and S42 respectively after booting up or reset.

Telegesis		TG-ETRX-R301-AT-Commands	35
ETRX2		AT-Command Dictionary	3.01

4.1 Recovery of the Factory Default Settings

If the unit seems to be unresponsive to commands on the serial port this is most often due to the unit having been set into a power-down mode or the set-up for the serial connection having been altered. To overcome this a feature has been added which performs a factory reset on any module which seems unresponsive. To factory reset a module, connect it to the PC's serial port and execute the Factory Reset Tool (downloadable from www.telegesis.com). When pressing the Reset button on the Reset Tool you are prompted to cause a hardware reset to the module by pulling the module's reset line low for more than 100ms (done by pressing the reset button on the Development Board). Once completed, the factory default settings of the ETRX2 module are restored.

Telegesis		TG-ETRX-R301-AT-Commands	36
ETRX2		AT-Command Dictionary	3.01

4.2 S-Registers for Network Setup

S00 – Channel Mask

<p>Description</p> <p>The 802.15.4 channel mask.</p> <p>Operations</p> <p>R/W LOCAL</p> <p>R/W REMOTE</p> <p>Becomes effective</p> <p>When Joining, Scanning or establishing a PAN</p> <p>Note</p> <p>The channel mask does not affect the AT+JPAN command</p> <p>Storage</p> <p>Non-Volatile</p> <p>SW release</p>	<p>Parameters</p> <p>XXXX</p> <p>Where XXXX represents a 16-bit decimal number enabling IEEE 802.15.4 channel numbers 11 to 26. Writing a bit to 1 enables a channel and subsequently writing a bit to 0 disables a channel for scanning, joining and establishing networks. e.g. when setting S00 to 0001, only channel 11 will be used for all following operations.</p> <p>Range</p> <p>0001 - FFFF</p> <p>Factory Default</p> <p>3FFC</p> <p>R300</p>
--	--

S01 – Transmit Power Level

<p>Description</p> <p>The device's transmit power level in dBm.</p> <p>Operations</p> <p>R/W LOCAL</p> <p>R/W REMOTE</p> <p>Becomes effective</p> <p>When Joining or establishing a PAN</p> <p>Storage</p> <p>Non-Volatile</p> <p>SW release</p>	<p>Parameters</p> <p>snn</p> <p>Where snn represents a signed 8-bit decimal number.</p> <p>Range</p> <p>4 to -43</p> <p>Setting S02 to 4 enables the radio boost mode increasing both output power as well as sensitivity (the actual radio power setting will remain at 3). Actual values are {4,3, 2, 1, -1, -2, -3, -4, -5, -6, -7, -8, -9, -11, -12, -14, -17, -20, -26, -43} Entering a value not on this list (such as -19) will result in the next lowest output power.</p> <p>Factory Default</p> <p>3</p> <p>R300</p>
---	---

Telegesis		TG-ETRX-R301-AT-Commands	37
ETRX2		AT-Command Dictionary	3.01

S02 – Preferred PAN ID

<p>Description The 802.15.4 PAN ID.</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Becomes effective When Joining or establishing a PAN</p> <p>Notes Two networks operating on the same channel with the same PAN ID, but a different EPID are detected to be in conflict with each other. PAN ID conflicts are detected by the stack and resolved by one of the networks dynamically changing its PAN ID. The preferred PID does not affect the AT+JPAN command</p> <p>Storage Non-Volatile</p> <p>SW release</p>	<p>Parameters <PID></p> <p>Where <PID> represents a 16-bit hexadecimal number</p> <p>Range 0000 – FFFF</p> <p>When establishing a PAN the coordinator will pick a random PAN ID if S02 is set to 0000. If set to any value between 0001 and FFFF this number will be used as PAN ID instead, unless trying to use a PAN ID which already exists on the same channel. In this case a random PAN ID will be used instead.</p> <p>When joining only a PAN with the ID stored in S02 will be joined unless S02 is set to 0000. In this case the next best PAN which allows joining is joined.</p> <p>Factory Default 0000</p> <p>R300</p>
--	--

S03 – Preferred Extended PAN ID

<p>Description The extended PAN ID.</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Becomes effective When Joining or establishing a PAN</p> <p>Note The EPID is used for PAN ID conflict detection. It is therefore recommended to use a random EPID at all times. The preferred EPID does not affect the AT+JPAN command</p> <p>Storage Non-Volatile</p> <p>SW release</p>	<p>Parameters <EPID></p> <p>Where <EPID> represents a 64-bit hexadecimal number</p> <p>Range 0000000000000000 – FFFFFFFFFFFFFFFF</p> <p>When establishing a PAN the coordinator will pick a random EPID if S03 is set to all 0's. If set to any other value this number will be used as EPID instead.</p> <p>When joining only a PAN with the EPID stored in S03 will be joined unless S03 is set to all 0's. In this case the next best PAN which allows joining is joined.</p> <p>Factory Default 0000000000000000</p> <p>R300</p>
---	---

Telegesis		TG-ETRX-R301-AT-Commands	38
ETRX2		AT-Command Dictionary	3.01

S04 – Local EUI64

<p>Description</p> <p>The local nodes unique EUI64 identifier.</p> <p>Operations</p> <p>R LOCAL</p> <p>R REMOTE</p> <p>Storage</p> <p>Non-Volatile</p> <p>SW release</p>	<p>Parameters</p> <p><EUI64></p> <p>Range</p> <p>0000000000000000 – FFFFFFFF</p> <p>Factory Default</p> <p><unique number></p> <p>R300</p>
---	---

S05 – Local 16-Bit NodeID

<p>Description</p> <p>The local node's 16-bit NodeID.</p> <p>Note</p> <p>Reading this register while not associated with a network will result in an undefined return value.</p> <p>Operations</p> <p>R LOCAL</p> <p>R REMOTE</p> <p>Storage</p> <p>Non-Volatile</p> <p>SW release</p>	<p>Parameters</p> <p><NodeID></p> <p>Range</p> <p>0000-FFFF</p> <p>Factory Default</p> <p>n/a</p> <p>R300</p>
---	---

S06 – Parent's EUI64

<p>Description</p> <p>The parent node's unique EUI64 identifier.</p> <p>Note</p> <p>The return value is undefined for nodes without parents (coordinators and nodes that are not joined to a network)</p> <p>Operations</p> <p>R LOCAL</p> <p>R REMOTE</p> <p>Storage</p> <p>Non-Volatile</p> <p>SW release</p>	<p>Parameters</p> <p><EUI64></p> <p>Range</p> <p>0000000000000000 – FFFFFFFF</p> <p>Factory Default</p> <p>n/a</p> <p>R300</p>
---	--

Telegesis		TG-ETRX-R301-AT-Commands	39
ETRX2		AT-Command Dictionary	3.01

S07 – Parent’s 16-Bit NodeID

<p>Description</p> <p>The parent node’s 16-bit NodeID.</p> <p>Operations</p> <p>R LOCAL</p> <p>R REMOTE</p> <p>Note</p> <p>The return value is undefined for nodes without parents (coordinators and nodes that are not joined to a network)</p> <p>Storage</p> <p>Non-Volatile</p> <p>SW release</p>	<p>Parameters</p> <p><NodeID></p> <p>Range</p> <p>0000-FFFF</p> <p>Factory Default</p> <p>n/a</p> <p>R300</p>
---	---

S08 – Network Key

<p>Description</p> <p>The network key which can be written using the password. The default password for R3xx is “password”.</p> <p>Operations</p> <p>W LOCAL</p> <p>W REMOTE</p> <p>Write operation</p> <p>ATS08=<key>:<password></p> <p>ATREMS:<address>,08=<key>:<password></p> <p>Becomes effective</p> <p>Only when establishing a PAN</p> <p>Storage</p> <p>Non Volatile</p> <p>SW release</p>	<p>Range</p> <p>From 0 to 2¹²⁸-1</p> <p>The 128-bit AES network key in hexadecimal representation (32 characters).</p> <p>When set to all 0’s (default) a random network key is generated when establishing a PAN.</p> <p>This key is transmitted to all joining nodes and can be encrypted using the link key.</p> <p>Factory Default</p> <p>00000000000000000000000000000000</p> <p>R300</p>
--	---

Telegesis		TG-ETRX-R301-AT-Commands	40
ETRX2		AT-Command Dictionary	3.01

S09 – Trust Centre Link Key

<p>Description</p> <p>The link key which can be written using the password. The default password for R3xx is “password”.</p> <p>Operations</p> <p>W LOCAL</p> <p>W REMOTE</p> <p>Write operation</p> <p>ATS09=<key>:<password></p> <p>ATREMS:<address>,09=<key>:<password></p> <p>Becomes effective</p> <p>When Joining or establishing a PAN</p> <p>Storage</p> <p>Non Volatile</p> <p>SW release</p>	<p>Range</p> <p>From 0 to 2¹²⁸-1</p> <p>The 128-bit trust centre link key in hexadecimal representation (32 characters).</p> <p>When set to all 0s (default) a random trust centre link key is generated when establishing a PAN.</p> <p>Factory Default</p> <p>00000000000000000000000000000000</p> <p>R300</p>
---	---

Telegesis		TG-ETRX-R301-AT-Commands	41
ETRX2		AT-Command Dictionary	3.01

4.3 S-Registers for Module Setup

S0A – Main Function	
<p>Description Defines the behaviour of the Device.</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Becomes effective Instantly</p> <p>Write operation ATS0A=XXXX:<Password> ATREMS:<address>,0A=XXXX:<Password></p> <p>Note For security reasons this register is password protected. The default password for R3xx is “password”.</p> <p>Storage Non-Volatile</p>	<p>Parameters XXXX</p> <p>Where XXXX represents a 16-bit hexadecimal number.</p> <p>Range 0000 to FFFF</p> <p>Bit F: Set: Mobile End Device (MED). Unset: Sleepy End Device (SED) (Note: bit E must also be set)</p> <p>Bit E: Set: Device is an End Device (bit F specifies Sleepy or Moving End Device)</p> <p>Bit A: Set: When joining don't ask for Trust Centre link key</p> <p>Bit 8: Set: Use Pre-Configured Trust Centre Link Key when joining</p> <p>Bit 7: Set: Trust centre uses hashed link key</p> <p>Bit 5: Set: Don't allow nodes to join</p> <p>Bit 4: Set: Send Network key encrypted with the link key to nodes joining</p> <p>Bit 3: Set: Don't allow nodes to re-join unsecured</p> <p>Bit 2: Set: Send Network key encrypted with the link key to nodes re-joining unsecured</p> <p>Bit 1: Reserved</p> <p>Bit 0: Set: Don't allow other nodes to join the network using this node as their parent</p> <p>Factory Default 0000</p>
SW release	R301

Telegesis		TG-ETRX-R301-AT-Commands	42
ETRX2		AT-Command Dictionary	3.01

S0B – User Readable Name

<p>Description Password protected user defined name which can be used to identify the node</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Write operation ATS0B=<name>:<password> ATREMS:<address>,0B=<name>:<password></p> <p>Becomes effective Instantly</p> <p>Storage Non-Volatile</p> <p>SW release</p>	<p>Parameters cccccccccccccccccccc</p> <p>Name with up to 20 characters.</p> <p>Factory Default Telegesis</p> <p>R300</p>
---	---

S0C – Password

<p>Description The local node's password.</p> <p>Operations W LOCAL W REMOTE</p> <p>Write operation ATS0C=<NEW>:<OLD> ATREMS:<address>,0C=<NEW>:<OLD></p> <p>Becomes effective Instantly</p> <p>Storage Non-Volatile</p> <p>SW release</p>	<p>Parameters cccccccc</p> <p>8 case sensitive characters (8 bytes). Note that the password must have exactly 8 characters.</p> <p>Factory Default password</p> <p>R300</p>
--	--

Telegesis		TG-ETRX-R301-AT-Commands	43
ETRX2		AT-Command Dictionary	3.01

S0D – Device Information

Description String containing the module's order code and firmware revision. Operations R LOCAL R REMOTE Storage Non-Volatile SW release	Parameters ccc...ccc Text string Example ETRX2 R300 Factory Default N/A R300
--	--

S0E – Prompt Enable 1

Description Defines the behaviour of the Device. Operations R/W LOCAL R/W REMOTE Becomes effective Instantly Storage Non-Volatile SW release	Parameters XXXX Where XXXX represents a 16-bit hexadecimal number. Range 0000 to FFFF Bit F: Set: Disable '>' prompt when entering binary data Bit E: Set: Disable UCAST, MCAST,BCAST data Bit D: Set: Disable RAW data Bit C: Set: Disable SEQ prompt Bit B: Set: Disable SINK prompt Bit A: Set: Disable SR: prompt Bit 9: Set: Disable RAW wrapper Bit 8: Set: Disable NEWNODE prompt Bit 7: Set: Disable NAK:XX prompt Bit 6: Set: Disable ACK:XX Bit 5: Set: Disable UCAST, MCAST,BCAST wrapper Bit 4: Set: Disable LeftPAN prompt Bit 3: Set: Disable JPAN prompt Bit 2: Set: Disable PWRCHANGE:nn prompt Bit 1: Set: Disable OK prompt Bit 0: Set: Disable ERROR:XX prompt Factory Default 0000 R300
---	---

Telegesis		TG-ETRX-R301-AT-Commands	44
ETRX2		AT-Command Dictionary	3.01

S0F – Prompt Enable 2

<p>Description Defines the behaviour of the Device.</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Becomes effective Instantly</p> <p>Storage Non-Volatile</p> <p>SW release</p>	<p>Parameters XXXX</p> <p>Where XXXX represents a 16-bit hexadecimal number.</p> <p>Range 0000 to FFFF</p> <p>Bit 3 – Bit F: Reserved Bit 2: <u>Set</u>: Show all Sink Advertisements Bit 1: <u>Set</u>: Disable showing messages received by Endpoints 0 and 2 Bit 0: <u>Set</u>: Disable COO,FFD,SED and MED prompts</p> <p>Factory Default 0006</p> <p>R301</p>
---	--

Telegesis		TG-ETRX-R301-AT-Commands	45
ETRX2		AT-Command Dictionary	3.01

S10 – Extended Function

<p>Description Defines the behaviour of the Device.</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Becomes effective Instantly</p> <p>Storage Non-Volatile</p>	<p>Parameters XXXX</p> <p>Where XXXX represents a 16-bit hexadecimal number.</p> <p>Range 0000 to FFFF</p> <p>Bit C: Set: Display RSSI and LQI of the last hop when devices report to AT+SN or AT+PING Bit B: Set: UCASTs and SCASTs wait for ACK Bit A: Set: Disable playing Tune when receiving AT+IDENT Bit 9: Set: Enable one second character timeout when entering data for xCASTB. Bit 8: Set: Don't actively search for a sink if none is known Bit 7: Set: Node doesn't replace existing sink with better one (lower cost) Bit 6: Set: Node doesn't lose sink if it couldn't be reached for three times Bit 5: Set: Sink won't reply to nodes searching for a sink Bit 4: Set: Node is Sink Bit 3: Changes to S01 take effect instantly Bit 2: Send BCAST[B] messages to routers only Bit 1: Set: Send UCAST[B] and SCAST[B] messages unacknowledged Bit 0: Set: Don't attach EUI64 to NWK frame when sending a message.</p> <p>Factory Default 0000</p>
SW release	R301

Telegesis		TG-ETRX-R301-AT-Commands	46
ETRX2		AT-Command Dictionary	3.01

S11 – Device Specific

<p>Description Defines the behaviour of the Device.</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Becomes effective Instantly</p> <p>Storage Non-Volatile</p>	<p>Parameters XXXX</p> <p>Where XXXX represents a 16-bit hexadecimal number.</p> <p>Range 0000 to FFFF</p> <p>Bit F (MSB): Set: I/O3 is PWM as defined by S2F/S31. <u>Unset:</u> Standard I/O pin.</p> <p>Bit E: Set: Enable Boost mode regardless of setting in S02</p> <p>Bit D: Set: Present A/D-Reference at I/O0 during measurement</p> <p>Bit C: Set: I/O8 turns into A/D3, which can be read from S21</p> <p>Bit B: Set: Pad 38 turns into A/D4, which can be read from S22</p> <p>Bit 9: Set: Enable wakeup on UART activity (1st input character is discarded)</p> <p>Bit 8: Set: Enable debouncing for all IRQs (100ms)</p> <p>Bit 7: Set: IRQ3 on rising edge</p> <p>Bit 6: Set: IRQ3 on falling edge</p> <p>Bit 5: Set: IRQ2 on rising edge</p> <p>Bit 4: Set: IRQ2 on falling edge</p> <p>Bit 3: Set: IRQ1 on rising edge</p> <p>Bit 2: <u>Set:</u> IRQ1 on falling edge</p> <p>Bit 1: Set: IRQ0 on rising edge</p> <p>Bit 0: <u>Set:</u> IRQ0 on falling edge</p> <p>Factory Default 0005</p>
SW release	R301

Telegesis		TG-ETRX-R301-AT-Commands	47
ETRX2		AT-Command Dictionary	3.01

4.4 I/O related S-Registers

S12 – UART Setup

<p>Description The device's RS232 Baudrate and mode. The default setting of 0500 results in: 19200bps, no parity, 1 stop bit, 8 data bits.</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Becomes effective Instantly</p> <p>Note It is not recommended to use continuous data rates above 38400, even using hardware flow control as using higher data rates does not increase the actual throughput. If bit 5 is set, bi-directional Hardware Flow Control is used instead of XON/XOFF flow control. If using Hardware flow control I/O4 becomes the RTS output and the CTS input is assigned to I/O2. Access to these I/Os via S0D,S0F is blocked whilst Hardware Flow control is active. Note that in case the 128-byte output buffer of the ETRX2 is full data will be dropped.</p> <p>Storage Non-Volatile</p> <p>SW release</p>	<p>Parameters XXXX</p> <p>Where XXXX represents a 16-bit hexadecimal number.</p> <p>Range of the most significant byte 00 to 0C</p> <p>00: 1200 baud 01: 2400 baud 02: 4800 baud 03: 9600 baud 04: 14400 baud 05: 19200 baud 06: 28800 baud 07: 38400 baud 08: 50000 baud 09: 57600 baud 0A: 76800 baud 0B: 100000 baud 0C: 115200 baud</p> <p>Range of the least significant byte 00 to FF</p> <p>bit 7 set: Enable STX ETX wrapper bit 6 Reserved bit 5 set: H/W flow control enable bit 4 set: no command echo bit 3 set: 7 data bits instead of 8 bit 2 set: 2 stop bits instead of one bit 1 set: odd parity enabled bit 0 set: even parity enabled</p> <p>Factory Default 0500</p> <p>R300</p>
--	--

Telegesis		TG-ETRX-R301-AT-Commands	48
ETRX2		AT-Command Dictionary	3.01

S13 – Pull-up enable

<p>Description Enables the built-in pull-ups for each individual I/O pin of the ETRX2.</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Becomes effective After Reset</p> <p>Note To achieve ultra low current consumption it is recommended not to use the built-in pull-ups and leave this register in its default state.</p> <p>Storage Non-Volatile</p> <p>SW release</p>	<p>Parameters XXXX</p> <p>Where XXXX represents a 16-bit hexadecimal number.</p> <p>Range 0000 to FFFF</p> <p>representing I/O pins xxxx BA98 7654 3210</p> <p>e.g. setting bit 7 to 1 will enable the pull-up for I/O pin 7</p> <p>Factory Default 0000</p> <p>R300</p>
---	---

S14 – Pull-down enable

<p>Description Enables the built-in pull-downs for each individual I/O pin of the ETRX2.</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Becomes effective After Reset</p> <p>Note To achieve ultra low current consumption it is recommended not to use the built-in pull-downs and leave this register in its default state.</p> <p>Storage Non-Volatile</p> <p>SW release</p>	<p>Parameters XXXX</p> <p>Where XXXX represents a 16-bit hexadecimal number.</p> <p>Range 0000 to FFFF</p> <p>representing I/O pins xxxx BA98 7654 3210</p> <p>e.g. setting bit 7 to 1 will enable the pull-down for I/O pin 7</p> <p>Factory Default 0000</p> <p>R300</p>
---	---

Telegesis		TG-ETRX-R301-AT-Commands	49
ETRX2		AT-Command Dictionary	3.01

S15 – I/O Configuration (not yet in use)

<p>Description</p> <p>Some I/O pins of the ETRX2 have an alternative functionality, which will be enabled using this register</p> <p>Operations</p> <p>R/W LOCAL R/W REMOTE</p> <p>Becomes effective</p> <p>Instantly</p> <p>Storage</p> <p>Non-Volatile</p> <p>SW release</p>	<p>Parameters</p> <p>XXXX</p> <p>Where XXXX represents a 16-bit hexadecimal number.</p> <p>Range</p> <p>0000 to FFFF</p> <p>Bits 0 to F: Reserved</p> <p>Factory Default</p> <p>0000</p> <p>R300</p>
---	--

S16 – Data Direction of I/O Port

<p>Description</p> <p>The data direction of the module's I/O port</p> <p>Operations</p> <p>R/W LOCAL R/W REMOTE</p> <p>Becomes effective</p> <p>Instantly</p> <p>Storage</p> <p>Volatile</p> <p>SW release</p>	<p>Parameters</p> <p>XXXX</p> <p>Where XXXX represents a 16-bit hexadecimal number.</p> <p>Range</p> <p>0000 to FFFF</p> <p>representing I/O pins xxxx BA98 7654 3210</p> <p>e.g. setting bit 7 to 1 will turn I/O pin 7 into an output, setting it to 0 will make it an input respectively.</p> <p>Factory Default</p> <p>Defined in S17</p> <p>R300</p>
---	--

S17 – Initial Setting of S16

<p>Description</p> <p>The initial setting of S0D stored in non volatile memory</p> <p>Operations</p> <p>R/W LOCAL R/W REMOTE</p> <p>Becomes effective</p> <p>After Soft or Hard Reset</p> <p>Storage</p> <p>Non-Volatile</p> <p>SW release</p>	<p>Parameters</p> <p>XXXX</p> <p>Where XXXX represents the initial value of S16 which is loaded after boot-up, soft or hard reset.</p> <p>Factory Default</p> <p>00F8</p> <p>R300</p>
---	---

Telegesis		TG-ETRX-R301-AT-Commands	50
ETRX2		AT-Command Dictionary	3.01

S18 – Output Buffer Of I/O Port

<p>Description The output buffer of the module's I/O port</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Becomes effective Instantly</p> <p>Storage Volatile</p> <p>SW release</p>	<p>Parameters XXXX</p> <p>Where XXXX represents a 16-bit hexadecimal number.</p> <p>Range 0000 to FFFF</p> <p>representing I/O pins xxxx BA98 7654 3210</p> <p>If the I/O pin has been defined as an output in S16 the pin will drive the logic level defined by S18.</p> <p>Factory Default Defined in S19</p> <p>R300</p>
---	--

S19 – Initial Setting of S18

<p>Description The initial setting of S18 stored in non volatile memory</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Becomes effective After Soft or Hard Reset</p> <p>Storage Non-Volatile</p> <p>SW release</p>	<p>Parameters XXXX</p> <p>Where XXXX represents the initial value of S18 which is loaded after boot-up, soft or hard reset.</p> <p>Factory Default 00F0</p> <p>R300</p>
--	---

S1A – Input Buffer of I/O Port

<p>Description The Logical Levels at the I/O Pins</p> <p>Operations R LOCAL R REMOTE</p> <p>Becomes effective Instantly</p> <p>Storage Instant Reading of Port Status</p> <p>SW release</p>	<p>Range 0000 to FFFF</p> <p>representing I/O pins xxxx BA98 7654 3210</p> <p>S11 represents the logic level at each pin of the I/O port.</p> <p>Factory Default n/a</p> <p>R300</p>
---	---

Telegesis		TG-ETRX-R301-AT-Commands	51
ETRX2		AT-Command Dictionary	3.01

S1B – PWM Pin Top Value

<p>Description The mode of operation for the special function pin</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Operations Instantly</p> <p>Storage Volatile</p> <p>Examples See User Guide</p> <p>SW release</p>	<p>Parameters XXXX</p> <p>Range 0000 to FFFF</p> <p>This register represents the top value of the 16-bit counter counting from 0 to top repeatedly incrementing at 12MHz. When reaching top I/O3 is set, given that the PWM is enabled in S2E.</p> <p>Factory Default Defined in S1C</p> <p>R300</p>
---	---

S1C – Initial value of S1B

<p>Description The initial setting of S1B stored in non volatile memory</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Becomes effective After Soft or Hard Reset</p> <p>Storage Non-Volatile</p> <p>SW release</p>	<p>Parameters XXXX</p> <p>Where XXXX represents the initial value of S1B which is loaded after boot-up, soft or hard reset.</p> <p>Factory Default 3A98 (800Hz 50% m/s ratio)</p> <p>R300</p>
--	---

S1D – PWM Pin Compare Value

<p>Description The mode of operation for the special function pin</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Operations Instantly</p> <p>Storage Volatile</p> <p>SW release</p>	<p>Parameters XXXX</p> <p>Range 0000 to FFFF</p> <p>If the special function pin is enabled by setting bit 15 of S2E, this register represents the compare value of the 16-bit counter counting from 0 to top repeatedly incrementing at 12MHz. When reaching compare I/O3 is cleared.</p> <p>Factory Default Defined in S1E</p> <p>R300</p>
--	--

Telegesis		TG-ETRX-R301-AT-Commands	52
ETRX2		AT-Command Dictionary	3.01

S1E – Initial Value S1D

Description The initial setting of S1D stored in non volatile memory	Parameters XXXX
Operations R/W LOCAL R/W REMOTE	Where XXXX represents the initial value of S1D which is loaded after boot-up, soft or hard reset.
Becomes effective After Soft or Hard Reset	
Storage Non-Volatile	Factory Default 1D4C (800Hz 50% m/s ratio)
SW release	R300

S1F – A/D1 Reading

Description The analogue reading of A/D1	Parameters XXXX
Operations R LOCAL R REMOTE	Representation The hexadecimal reading of the analogue input in mV with respect to ground.
Becomes effective Instantly	Range 0000 – 04B0 (0 – 1200)
Storage Instant Reading of analogue input	
SW release	R300

S20 – A/D2 Reading

Description The analogue reading of A/D2	Parameters XXXX
Operations R LOCAL R REMOTE	Representation The hexadecimal reading of the analogue input in mV with respect to ground.
Becomes effective Instantly	Range 0000 – 04B0 (0 – 1200)
Storage Instant Reading of analogue input	
SW release	R300

Telegesis		TG-ETRX-R301-AT-Commands	53
ETRX2		AT-Command Dictionary	3.01

S21 – A/D3 Reading (only when bit C of S11 is set, invalid otherwise)

Description The analogue reading of A/D2	Parameters XXXX
Operations R LOCAL R REMOTE	Representation The hexadecimal reading of the analogue input in mV with respect to ground. The return value will be 0xFFFF in case A/D3 has not been enabled by setting bit C of S11.
Becomes effective Instantly	Range 0000 – 04B0 (0 – 1200)
Storage Instant Reading of analogue input	
SW release	R300

S22 – A/D4 Reading (only when bit B of S11 is set, invalid otherwise)

Description The analogue reading of A/D2	Parameters XXXX
Operations R LOCAL R REMOTE	Representation The hexadecimal reading of the analogue input in mV with respect to ground. The return value will be 0xFFFF in case A/D3 has not been enabled by setting bit D of S11.
Becomes effective Instantly	Range 0000 – 04B0 (0 – 1200)
Storage Instant Reading of analogue input	
SW release	R300

Telegesis		TG-ETRX-R301-AT-Commands	54
ETRX2		AT-Command Dictionary	3.01

4.5 S-Registers Defining the Functionality of the Module

There are 14 events which can trigger a user-selectable action to prevent the need for a host microcontroller for simple applications. Four out of those 14 events are the external interrupts which can be enabled in Register S11. The actions to be performed on those four interrupt events are defined in S23 to S26. The user can pick any of the actions from the list in section 5 of this document and assign them to any event.

Another two consecutive events are triggering when the unit is reset or power cycled and the stack has booted up again.

The remaining 8 events are timed events. Registers S29 to S38 control those 8 timers and their corresponding events. Please note that the first 5 timers are used by default for network management tasks, which can be modified by the user when changing the corresponding registers. A timer will increment every 250ms (4 times a second) and when the timer reaches the value stored in the timer/counter register the corresponding action will be executed.

S23 – Immediate Functionality At IRQ0 (I/O0)

Description Describes the immediate action taken on IRQ0. Transitions on I/O0 generate IRQ0.	Parameters XXXX
Operations R/W LOCAL R/W REMOTE	If set to 0 the functionality is disabled. Please see section 5 for a list of available functionalities.
Becomes effective Instantly	
Storage Non-Volatile	Factory Default 0001 (Wakeup to power mode 0)
SW release	R300

S24 – Immediate Functionality At IRQ1 (I/O1)

Description Describes the immediate action taken on IRQ1. Transitions on I/O1 generate IRQ1.	Parameters XXXX
Operations R/W LOCAL R/W REMOTE	If set to 0 the functionality is disabled. Please see section 5 for a list of available functionalities.
Becomes effective Instantly	
Storage Non-Volatile	Factory Default 0000 (none)
SW release	R300

Telegesis		TG-ETRX-R301-AT-Commands	55
ETRX2		AT-Command Dictionary	3.01

S25 – Immediate Functionality At IRQ2 (I/O10)

Description Describes the immediate action taken on IRQ2. Transitions on I/O10 generate IRQ2.	Parameters XXXX
Operations R/W LOCAL R/W REMOTE	If set to 0 the functionality is disabled. Please see section 5 for a list of available functionalities.
Becomes effective Instantly	
Storage Non-Volatile	Factory Default 0000 (none)
SW release	R300

S26 – Immediate Functionality At IRQ3 (I/O11)

Description Describes the immediate action taken on IRQ3. Transitions on I/O11 generate IRQ3.	Parameters XXXX
Operations R/W LOCAL R/W REMOTE	If set to 0 the functionality is disabled. Please see section 5 for a list of available functionalities.
Becomes effective Instantly	
Storage Non-Volatile	Factory Default 0000 (none)
SW release	R300

S27 – Functionality at Bootup 1

Description Describes the immediate action taken after boot-up.	Parameters XXXX
Operations R/W LOCAL R/W REMOTE	If set to 0 the functionality is disabled. Please see section 5 for a list of available functionalities.
Becomes effective Instantly	
Storage Non-Volatile	Factory Default 0000 (none)
SW release	R300

Telegesis		TG-ETRX-R301-AT-Commands	56
ETRX2		AT-Command Dictionary	3.01

S28 – Functionality at Bootup 2

<p>Description Describes the immediate action taken after boot-up (and the functionality in S27).</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Becomes effective Instantly</p> <p>Storage Non-Volatile</p>	<p>Parameters XXXX</p> <p>If set to 0 the functionality is disabled. Please see section 5 for a list of available functionalities.</p> <p>Factory Default 0000 (none)</p>
SW release	R300

S29 –Timer/Counter 0

<p>Description A multi purpose Timer/Counter whose functionality is defined by S2A</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Becomes effective Instantly</p> <p>Storage Non-Volatile</p>	<p>Parameters XXXX</p> <p>A 16-bit hexadecimal number representing a threshold for either a timer or counter event to be triggered. When reading this register the threshold rather than the actual timer/counter value is displayed. If set to 0 the corresponding functionality is disabled.</p> <p>Factory Default 0004 (1s interval)</p>
SW release	R300

S2A – Functionality For Timer/Counter 0

<p>Description Defines the functionality for Timer/Counter 0 events.</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Becomes effective Instantly</p> <p>Storage Non-Volatile</p>	<p>Parameters XXXX</p> <p>If set to 0 the functionality is disabled. Please see section 5 for a list of the functionality.</p> <p>Factory Default 8010 (end devices poll parent)</p>
SW release	R300

Telegesis		TG-ETRX-R301-AT-Commands	57
ETRX2		AT-Command Dictionary	3.01

S2B –Timer/Counter 1

<p>Description A multi purpose Timer/Counter whose functionality is defined by S2C</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Becomes effective Instantly</p> <p>Storage Non-Volatile</p> <p>SW release</p>	<p>Parameters XXXX</p> <p>A 16-bit hexadecimal number representing a threshold for either a timer or counter event to be triggered. When reading this register the threshold rather than the actual timer/counter value is displayed. If set to 0 the corresponding functionality is disabled.</p> <p>Factory Default 00F0 (1 min interval)</p> <p>R300</p>
--	---

S2C – Functionality For Timer/Counter 1

<p>Description Defines the functionality for Timer/Counter 1 events.</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Becomes effective Instantly</p> <p>Storage Non-Volatile</p> <p>SW release</p>	<p>Parameters XXXX</p> <p>If set to 0 the functionality is disabled. Please see section 5 for a list of the functionality.</p> <p>Factory Default 821E (sink advertisement for 30 hops)</p> <p>R300</p>
--	---

S2D –Timer/Counter 2

<p>Description A multi purpose Timer/Counter whose functionality is defined by S2E</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Becomes effective Instantly</p> <p>Storage Non-Volatile</p> <p>SW release</p>	<p>Parameters XXXX</p> <p>A 16-bit hexadecimal number representing a threshold for either a timer or counter event to be triggered. When reading this register the threshold rather than the actual timer/counter value is displayed. If set to 0 the corresponding functionality is disabled.</p> <p>Factory Default 00F4 (1 min 1s interval)</p> <p>R300</p>
--	--

Telegesis		TG-ETRX-R301-AT-Commands	58
ETRX2		AT-Command Dictionary	3.01

S2E – Functionality For Timer/Counter 2

<p>Description Defines the functionality for Timer/Counter 2 events.</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Becomes effective Instantly</p> <p>Storage Non-Volatile</p> <p>SW release</p>	<p>Parameters XXXX</p> <p>If set to 0 the functionality is disabled. Please see section 5 for a list of the functionality.</p> <p>Factory Default 8014 (leave network if I am alone)</p> <p>R300</p>
--	--

S2F –Timer/Counter 3

<p>Description A multi purpose Timer/Counter whose functionality is defined by S30</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Becomes effective Instantly</p> <p>Storage Non-Volatile</p> <p>SW release</p>	<p>Parameters XXXX</p> <p>A 16-bit hexadecimal number representing a threshold for either a timer or counter event to be triggered. When reading this register the threshold rather than the actual timer/counter value is displayed. If set to 0 the corresponding functionality is disabled.</p> <p>Factory Default 00F2 (1min interval)</p> <p>R300</p>
--	--

S30 – Functionality For Timer/Counter 3

<p>Description Defines the functionality for Timer/Counter 3 events.</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Becomes effective Instantly</p> <p>Storage Non-Volatile</p> <p>SW release</p>	<p>Parameters XXXX</p> <p>If set to 0 the functionality is disabled. Please see section 5 for a list of the functionality.</p> <p>Factory Default 8015 (if not part of a network do AT+JN)</p> <p>R300</p>
--	--

Telegesis		TG-ETRX-R301-AT-Commands	59
ETRX2		AT-Command Dictionary	3.01

S31 –Timer/Counter 4

<p>Description A multi purpose Timer/Counter whose functionality is defined by S32</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Becomes effective Instantly</p> <p>Storage Non-Volatile</p> <p>SW release</p>	<p>Parameters XXXX</p> <p>A 16-bit hexadecimal number representing a threshold for either a timer or counter event to be triggered. When reading this register the threshold rather than the actual timer/counter value is displayed. If set to 0 the corresponding functionality is disabled.</p> <p>Factory Default FFFF (~4.5 hour Interval)</p> <p>R300</p>
--	---

S32 – Functionality For Timer/Counter 4

<p>Description Defines the functionality for Timer/Counter 4 events.</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Becomes effective Instantly</p> <p>Storage Non-Volatile</p> <p>SW release</p>	<p>Parameters XXXX</p> <p>If set to 0 the functionality is disabled. Please see section 5 for a list of the functionality.</p> <p>Factory Default 8011 (Change the Network Key if I am the COO)</p> <p>R300</p>
--	---

S33 –Timer/Counter 5

<p>Description A multi purpose Timer/Counter whose functionality is defined by S34</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Becomes effective Instantly</p> <p>Storage Non-Volatile</p> <p>SW release</p>	<p>Parameters XXXX</p> <p>A 16-bit hexadecimal number representing a threshold for either a timer or counter event to be triggered. When reading this register the threshold rather than the actual timer/counter value is displayed. If set to 0 the corresponding functionality is disabled.</p> <p>Factory Default 0000</p> <p>R300</p>
--	--

Telegesis		TG-ETRX-R301-AT-Commands	60
ETRX2		AT-Command Dictionary	3.01

S34 – Functionality For Timer/Counter 5

<p>Description Defines the functionality for Timer/Counter 5 events.</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Becomes effective Instantly</p> <p>Storage Non-Volatile</p> <p>SW release</p>	<p>Parameters XXXX</p> <p>If set to 0 the functionality is disabled. Please see section 5 for a list of the functionality.</p> <p>Factory Default 0000</p> <p>R300</p>
--	--

S35 –Timer/Counter 6

<p>Description A multi purpose Timer/Counter whose functionality is defined by S36</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Becomes effective Instantly</p> <p>Storage Non-Volatile</p> <p>SW release</p>	<p>Parameters XXXX</p> <p>A 16-bit hexadecimal number representing a threshold for either a timer or counter event to be triggered. When reading this register the threshold rather than the actual timer/counter value is displayed. If set to 0 the corresponding functionality is disabled.</p> <p>Factory Default 0000</p> <p>R300</p>
--	--

S36 – Functionality For Timer/Counter 6

<p>Description Defines the functionality for Timer/Counter 6 events.</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Becomes effective Instantly</p> <p>Storage Non-Volatile</p> <p>SW release</p>	<p>Parameters XXXX</p> <p>If set to 0 the functionality is disabled. Please see section 5 for a list of the functionality.</p> <p>Factory Default 0000</p> <p>R300</p>
--	--

Telegesis		TG-ETRX-R301-AT-Commands	61
ETRX2		AT-Command Dictionary	3.01

S37 –Timer/Counter 7

<p>Description A multi purpose Timer/Counter whose functionality is defined by S38</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Becomes effective Instantly</p> <p>Storage Non-Volatile</p> <p>SW release</p>	<p>Parameters XXXX</p> <p>A 16-bit hexadecimal number representing a threshold for either a timer or counter event to be triggered. When reading this register the threshold rather than the actual timer/counter value is displayed. If set to 0 the corresponding functionality is disabled.</p> <p>Factory Default 0000</p> <p>R300</p>
--	--

S38 – Functionality For Timer/Counter 7

<p>Description Defines the functionality for Timer/Counter 6 events.</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Becomes effective Instantly</p> <p>Storage Non-Volatile</p> <p>SW release</p>	<p>Parameters XXXX</p> <p>If set to 0 the functionality is disabled. Please see section 5 for a list of the functionality.</p> <p>Factory Default 0000</p> <p>R300</p>
--	--

S39 – Power Mode

<p>Description The current power mode of the module</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Becomes effective Instantly</p> <p>Storage Volatile</p> <p>SW release</p>	<p>Parameters XXXX</p> <p>Range 0000 – 0003</p> <p>The modules power level as described in section 6.</p> <p>Factory Default Defined in S3A</p> <p>R300</p>
---	--

Telegesis		TG-ETRX-R301-AT-Commands	62
ETRX2		AT-Command Dictionary	3.01

S3A – Initial Power Mode

<p>Description The module's power mode after start-up and reset.</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Becomes effective After hard or soft reset</p> <p>Storage Non-Volatile</p> <p>SW release</p>	<p>Parameters XXXX</p> <p>Range 0000 – 0003</p> <p>The module's power mode as described in section 6.</p> <p>Factory Default 0000</p> <p>R300</p>
---	--

S3B – Start-up Functionality Plaintext A

<p>Description Contains Text which is used by some of the actions described in section 5.</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Becomes effective Instantly</p> <p>Storage Non-Volatile</p> <p>SW release</p>	<p>Parameters Up to 50 characters</p> <p>Factory Default BUTTON3</p> <p>R300</p>
---	--

S3C – Start-up Functionality Plaintext B

<p>Description Contains Text which is used by some of the actions described in section 5.</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Becomes effective Instantly</p> <p>Storage Non-Volatile</p> <p>SW release</p>	<p>Parameters Up to 50 characters</p> <p>Factory Default BUTTON4</p> <p>R300</p>
---	--

Telegesis		TG-ETRX-R301-AT-Commands	63
ETRX2		AT-Command Dictionary	3.01

S3D – Supply Voltage

Description The Supply voltage of the device in mV.	Parameters nnnn
Operations R LOCAL R REMOTE	Where nnnn represents the supply voltage in mV.
Becomes effective N/A	
Storage Volatile	Factory Default N/A
SW release	R300

4.6 Advanced Messaging Settings

S3E – Multicast Table Entry 00

Description The ID portion of Multicast Table Entry 00	Parameters XXXX
Operations R/W LOCAL R/W REMOTE	If S3E is not set to all 0's multicast table entry 1 to endpoint 1 (the AT command layer's endpoint) is set with the setting of this register is created instantly and after a reset.
Becomes effective After boot-up or reset	
Note Same effect as AT+MSET, but can be set at boot-up by built-in functionality	
Storage Non-Volatile	Factory Default 0000
SW release	R300

S3F – Multicast Table Entry 01

Description The ID portion of Multicast Table Entry 01	Parameters XXXX
Operations R/W LOCAL R/W REMOTE	If S3F is not set to all 0's multicast table entry 2 to endpoint 1 (the AT command layer's endpoint) is set with the setting of this register is created instantly and after a reset.
Becomes effective After boot-up or reset	
Note As for S3E	
Storage Non-Volatile	Factory Default 0000
SW release	R300

Telegesis		TG-ETRX-R301-AT-Commands	64
ETRX2		AT-Command Dictionary	3.01

S40 – Source and Destination Endpoints for xCASTs (volatile)

<p>Description The source and destination endpoints for all messages.</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Becomes effective Instantly</p> <p>Storage Volatile</p> <p>SW release</p>	<p>Parameters ssdd</p> <p>Where ss is the hexadecimal source endpoint and dd is the hexadecimal destination endpoint.</p> <p>Factory Default Defined in S41</p> <p>R300</p>
---	---

S41 – Initial Setting of S40

<p>Description The initial setting of S40 stored in non volatile memory</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Becomes effective After Soft or Hard Reset</p> <p>Storage Non-Volatile</p> <p>SW release</p>	<p>Parameters ssdd</p> <p>Where ss is the hexadecimal source endpoint and dd is the hexadecimal destination endpoint.</p> <p>Factory Default 0101</p> <p>R300</p>
--	---

S42 – Cluster ID for xCASTs (volatile)

<p>Description The Cluster ID any xCAST message is sent to.</p> <p>Operations R/W LOCAL R/W REMOTE</p> <p>Becomes effective Instantly</p> <p>Storage Volatile</p> <p>SW release</p>	<p>Parameters XXXX</p> <p>The cluster ID of any xCAST message</p> <p>Factory Default Defined in S43</p> <p>R300</p>
---	---

Telegesis		TG-ETRX-R301-AT-Commands	65
ETRX2		AT-Command Dictionary	3.01

S43 – Initial Setting of S42

Description The initial setting of S42 stored in non volatile memory Operations R/W LOCAL R/W REMOTE Becomes effective After Soft or Hard Reset Storage Non-Volatile	Parameters XXXX The cluster ID of any xCAST message Factory Default 0002
SW release	R300

S44 – Profile ID for xCASTs (volatile)

Description The profile ID for all messages. Operations R/W LOCAL R/W REMOTE Becomes effective Instantly Storage Volatile	Parameters XXXX The profile ID of any xCAST message Factory Default Defined in S45
SW release	R300

S45 – Initial Setting of S44

Description The initial setting of S44 stored in non volatile memory Operations R/W LOCAL R/W REMOTE Becomes effective After Soft or Hard Reset Storage Non-Volatile	Parameters XXXX The profile ID of any xCAST message Factory Default C091
SW release	R300

Telegesis		TG-ETRX-R301-AT-Commands	66
ETRX2		AT-Command Dictionary	3.01

S46 – Start-up Functionality 16 bit number

Description Volatile 16 bit register which can be used by some of the build in functionality Operations R/W LOCAL R/W REMOTE Storage Volatile	Parameters XXXX Factory Default 0000
SW release	R301

Telegesis		TG-ETRX-R301-AT-Commands	67
ETRX2		AT-Command Dictionary	3.01

5 Built in Functionality

The following table gives an overview of the built-in functionality which can be triggered either by the four external interrupts, boot-up, or by 8 individually programmable timers/counters. If the node is in a low power mode and the action requires the node to wakeup, the node will do so and go back to its original power mode after completion of the action. When triggered by a timer the timer will restart only in case the most significant bit of the action is set to 1 (e.g. instead of 0001 set 8001).

Overview of Actions	
0000	No operation of the corresponding interrupt/timer/counter
0001	Change to power mode 0.
0002	Change to power mode 1.
0003	Change to power mode 2.
0004	Change to power mode 3.
...	Reserved
0010	If I am a Mobile/Sleepy end device Poll Parent for data.
0011	Update the Network key with new random key.
0012	Check for other devices on the network. If no other devices could be found for three consecutive tries, attempt a rejoin using the current network key each time this functionality is triggered. Note: No functionality on COOs.
0013	Check for other devices on the network. If no other devices could be found for three consecutive tries, attempt a rejoin using the current network key. If this is unsuccessful try an unsecured rejoin each time this functionality is triggered from there on. Note: No functionality on COOs.
0014	Check for other devices on the network. If no other devices could be found for three consecutive tries, attempt a rejoin using the current network key. If this is unsuccessful try a rejoin using the current link key the next time this functionality is triggered. If this is unsuccessful leave the current network the next time this action is triggered. Note: No functionality on COOs.
0015	In case I am not joined to a network scan for and join the next best
0016	Reserved
0017	Allow joining for 60 Seconds (in case it is disabled in S0A)
...	Reserved
003x	Toggle I/Ox
004x	Flash I/Ox (pull low) for 250ms
005x	Set I/Ox to 0
006x	Set I/Ox to 1
...	Reserved
0108	The unit sends the contents of S3B to the networks sink.
0109	The unit sends the contents of S3C to the networks sink.
0110	Sends the reading of the I/O, the two analogue ports and V_{cc} as well as an 8-bit transmission counter which increments with every transmission to the network's sink and if no sink is known the unit will search for a sink instead. After 3 unsuccessful transmissions the sink is assumed unavailable and a new sink is searched.
0111	Same as 0110, but to charge an external RC timer I/O7 is pulled high whilst sending the data and left high impedance the rest of the time.
0112	Send a Tracking Message to all nearby routers which will forward this message and the RSSI reading to their nearest sink.

Telegesis		TG-ETRX-R301-AT-Commands	68
ETRX2		AT-Command Dictionary	3.01

Overview of Actions

0113	Same as 0112, but to charge an external RC timer I/O7 is pulled high whilst sending the data and left high impedance the rest of the time.
0120	Sends the contents of S3B as a RAW transmission.
0121	Sends the contents of S3C as a RAW transmission.
02XX	If I am a Sink advertise me for x hops (max. no. of hops: 30). If I am a COO create aggregation routes needed for Trust Centre
...	Reserved
...	Reserved
2000	When triggered the number of times listed in the accompanying counter a message is sent to the sink containing a transmission counter and the reading of the analogue and digital inputs. Note: Can only be triggered by setting S23, S24, S25 or S26 to 24XX .
2001	When enabling this action the command line is disabled and as soon as a number of bytes in excess of the number N specified in the accompanying timer/counter register is received on the serial port, a SCAST containing these characters is sent to the network's sink. Notes: This event is triggered by receiving a character on the serial port. $N \leq 64$.
...	Reserved
2100	The contents of S3B is sent to the local command line followed by carriage return. Note: No AT-Prefix required!
2101	The contents of S3C is sent to the local command line followed by carriage return. Note: No AT-Prefix required!
...	Reserved
24XX	Start timers masked in XX.
25XX	Toggle timers masked in XX.
26XX	Stop timers masked in XX.
...	Reserved
3XXX	Change I/O port to the LSBs.
4XXX	Change data direction of the I/O port to the LSBs.
...	Reserved

Telegesis		TG-ETRX-R301-AT-Commands	69
ETRX2		AT-Command Dictionary	3.01

6 Power Consumption

As the module's power consumption is firmware dependent, the values in the following tables supersede any of the numbers given in previous revisions of the AT command dictionary. Table 7 gives the hardware dependent theoretical figures for the ETRX2 as stated in the current hardware manual, whereas Table 8 shows the firmware dependent average power consumption of an ETRX2 measured with light to medium network traffic.

6.1 ETRX2 Power Consumption

Typical values at 3.3V 25°C.

Parameter	Min.	Typ.	Max.	Units	Condition
Supply Current		36		mA	TX 4dBm
		32		mA	TX -1dBm
		29		mA	TX -10dBm
		28		mA	TX -20dBm
		37		mA	RX
		1.5		µA	Asleep, Timers on
		0.7		µA	Asleep, Timers off

Table 7: Power Consumption

Mode	Router, COO				MED, SED			
	MCU	Radio	Timers	I	MCU	Radio	Timers	I
0	Awake	Awake	User defined	36mA	Awake	Asleep	User defined	9mA
1	Idle	Awake	User defined	32mA	Idle	Asleep	User defined	4.5mA
2	Awake	Awake	User defined	0.7mA ¹	Asleep	Asleep	User defined	0.7mA ¹
3	Asleep	Asleep	Off	0.7µA	Asleep	Asleep	Off	0.7µA

Table 8: Averaged power consumption during operation

Notes:

- Sleep modes 1-3 should not be used on a router or coordinator, however it was found that mode 1 may work on a router with light to medium network traffic. Successful operation of a router in mode 1 cannot be guaranteed and needs to be evaluated carefully for each target application in case the additional energy saving is vital.
- Wakeup from mode 3 is only possible by external interrupt or reset. Make sure never to set the initial power mode (S3A) to mode 03 unless you want the device to always wake up into this mode.
- Modules in power mode 2 and 3 will not respond to commands on the command line, so always make sure you have defined means to wake it up from these modes.
- If no means of waking up from any of the power down modes has been defined and the module appears unresponsive the Telegesis factory default resetter can be used to reset the modules factory defaults via the serial port.
- In order to achieve ultra low power consumption of sub 1µA it is required to either define all I/Os to be outputs, or to pull all inputs to a defined level as floating input pins will increase the current consumption. Furthermore as described in the hardware manual a pull-down of 10kΩ must be attached to the SIF_MOSI pin for lowest possible power consumption.

For more details please refer to the separate application note regarding power consumption, which can be found on www.telegesis.com.

¹ Assuming the unit polls every second. If no polling and other timed actions are performed the power consumption can be as little as 1.5µA in this mode.

Telegesis		TG-ETRX-R301-AT-Commands	70
ETRX2		AT-Command Dictionary	3.01

7 Notes on Energy Levels and LQI

7.1 Interpreting LQI on the ETRX2

On the EM250, which contains the radio for the ETRX2 module, the LQI is closely related to the SNR (signal noise ratio). The graph below shows the relation between the SNR and the LQI reading.




Figure 1: LQI vs. SNR (source : Ember)

From the LQI the stack calculates the cost for a particular link based on the following table:

Cost	LQI
1	254 - 255
3	247 - 253
5	200 - 246
7	0 - 199

Table 9: LQI/Cost relationship

7.2 Interpreting RSSI Energy Levels on the ETRX2

On the ETRX2 the readings from AT+ESCAN represent the hexadecimal readings from the EM250's RSSI register, offset by +127 to make it a positive number.

Telegesis		TG-ETRX-R301-AT-Commands	71
ETRX2		AT-Command Dictionary	3.01

The EM250 calculates the RSSI over an 8-symbol period as well as at the end of a received packet. It utilizes the RX gain settings and the output level of the ADC within its algorithm. The linear range of RSSI is specified to be 40dB over all temperatures. At room temperature, the linear range is approximately 60dB (-90 dBm to -30dBm).

8 Upgrading from R2xx to R300

R300 firmware can be loaded on to an ETRX2 by bootloading through the serial port or by re-flashing with an Ember Insight Adaptor. Cloning over the air is awkward because the new R300 node and the old R2xx node will not join the same PAN. It is possible to clone by using an extra R2xx device, as shown in the step-by-step guide below.




Figure 2. Cloning from an R300 device

Telegesis		TG-ETRX-R301-AT-Commands	72
ETRX2		AT-Command Dictionary	3.01

9 Trademarks

All trademarks, registered trademarks and products names are the sole property of their respective owners.

10 Disclaimer

Product and Company names and logos referenced may either be trademarks or registered trademarks of their respective companies. We reserve the right to make modifications and/or improvements without prior notification. All information is correct at time of issue. Telegesis (UK) Ltd. does not convey any license under its patent rights or assume any responsibility for the use of the described product.

11 Contact Information

Website: www.telegesis.com
E-mail: sales@telegesis.com

Telegesis (UK) Limited
Marlow Business Centre
84 Station Road
Marlow
Bucks. SL7 1NX
UK

Tel: +44 (0)1628 894347
Fax: +44 (0)1628 894333

12 References

Telegesis – www.telegesis.com
Ember – www.ember.com