


# Type 2BP UWB Module EVK

How to Build Pre-Built Binary - Rev. 4.0C



## Table of Contents

1 Differences Between SDK Versions .....	3
1.1 UWBIOT_SR150_v03.15.11_MCUx.....	3
1.1.1 Details of Changes .....	3
1.1.2 Files to be Modified .....	3
1.2 UWBIOT_SR150_v04.02.01_MCUx or Later .....	3
1.2.1 Details of Changes .....	3
1.2.2 Files to be Modified .....	4
2 How to Build the Pre-Built Binary .....	4
2.1 Step 1: Apply the “2bp_prebuilt_xx.xx.xx.patch” to Default SDK.....	4
2.1.1 Using Command User Interface .....	5
2.1.2 Using MUCXpresso IDE .....	5
2.2 Step 2: Modify “UWBIOT_APP_BUILD.h” and Build the SDK .....	8
2.3 Optional: Enable Pairing/Bonding for demo_UWB_ble_sr1xxi.....	8
Revision History.....	9

## Figures

Figure 1: Example of Success Log with Git Bash .....	5
Figure 2: Start to Apply Patch .....	6
Figure 3: Select the Patch to Apply .....	7
Figure 4: Modify Define to Select Target Demo Application .....	8
Figure 5: Modify Define to Enable Pairing/Bonding .....	8

## Tables

Table 1: Document Conventions.....	2
------------------------------------	---

## About This Document

This document provides steps to build pre-built binary for Type 2BP EVK.









## Audience & Purpose

This guide is for developers and RF engineers who will develop software on Murata Type 2BP EVK.

## Document Conventions

**Table 1** describes the document conventions.

**Table 1: Document Conventions**

Conventions	Description
	<b>Warning Note</b> Indicates very important note. Users are strongly recommended to review.
	<b>Info Note</b> Intended for informational purposes. Users should review.
	<b>Menu Reference</b> Indicates menu navigation instructions. <b>Example:</b> Insert→Tables→Quick Tables→Save Selection to Gallery 
	<b>External Hyperlink</b> This symbol indicates a hyperlink to an external document or website. <b>Example:</b> <a href="#">Type 2BP Product Page</a>  Click on the text to open the external link.
	<b>Internal Hyperlink</b> This symbol indicates a hyperlink within the document. <b>Example:</b> <a href="#">Differences Between SDK Versions</a>  Click on the text to open the link.
<code>Console input/output or code snippet</code>	<b>Console I/O or Code Snippet</b> This text <b>Style</b> denotes console input/output or a code snippet.
<code># Console I/O comment // Code snippet comment</code>	<b>Console I/O or Code Snippet Comment</b> This text <b>Style</b> denotes a console input/output or code snippet comment. <ul style="list-style-type: none"> <li>• Console I/O comment (preceded by "#") is for informational purposes only and does not denote actual console input/output.</li> <li>• Code Snippet comment (preceded by "//") may exist in the original code.</li> </ul>

# 1 Differences Between SDK Versions

This section describes the differences between various SDK versions, details of their changes, and files to be modified.

## 1.1 UWBIOT\_SR150\_v03.15.11\_MCUx

### 1.1.1 Details of Changes

#### <Common>

- Enable to print AoA for azimuth and elevation values on debug console
- Apply ToF and AoA calibration values for 2BP EVK

#### <For demo\_ranging\_controlee and demo\_ranging\_controller>

- Apply TX\_POWER and XTAL calibration values for 2BP EVK
- Extend the time limit for ranging from 5 minutes to 30 minutes



Changes are not prepared for demo\_UWB\_ble\_sr1xxi.

### 1.1.2 Files to be Modified

- uwbiot-top/boards/Host/Rhodes4/UWB\_DeviceConfig\_SR1XX.h
- uwbiot-top/demos/SR1XX/demo\_ranging\_controlee/demo\_ranging\_controlee.c
- uwbiot-top/demos/SR1XX/demo\_ranging\_controller/demo\_ranging\_controller.c
- uwbiot-top/demos/common/Demo\_Common\_Config.c
- uwbiot-top/libs/uwb-iot/uwb\_api/PrintUtility/PrintUtility.c

## 1.2 UWBIOT\_SR150\_v04.02.01\_MCUx or Later

### 1.2.1 Details of Changes

#### <Common>

- Enable to print AoA for azimuth and elevation values on debug console
- Apply ToF and AoA calibration values for 2BP EVK

#### <For demo\_ranging\_controlee and demo\_ranging\_controller>

- Apply TX\_POWER and XTAL calibration values for 2BP EVK
- Extend the time limit for ranging from 5 minutes to 30 minutes

## &lt;For demo\_UWB\_ble\_sr1xxi / demo\_nearby\_interaction&gt;

- Enable 3D AoA
- Apply TX\_POWER and XTAL calibration values for 2BP EVK
- WORKAROUND: Modify SPI pin setting for 2BP EVK Rev4.0



This workaround works only in v04.02.01 and is not required in later versions.

## 1.2.2 Files to be Modified

- uwbiot-top/boards/Host/Rhodes4/UWB\_DeviceConfig\_SR1XX.h
- uwbiot-top/boards/Rhodes4\_SPI/pin\_mux.c
- uwbiot-top/demos/SR1XX/demo\_UWB\_ble\_sr1xxi/src/TLV\_Mng.c (v04.02.01)
- uwbiot-top/demos/SR1XX/demo\_nearby\_interaction/src/TLV\_Mng.c (v04.04.03 or later)
- uwbiot-top/demos/SR1XX/demo\_ranging\_controlee/demo\_ranging\_controlee.c
- uwbiot-top/demos/SR1XX/demo\_ranging\_controller/demo\_ranging\_controller.c
- uwbiot-top/demos/common/Demo\_Common\_Config.c
- uwbiot-top/libs/uwb-iot/uwb\_api/PrintUtility/PrintUtility.c
- uwbiot-top/libs/uwb-iot/uwb\_api/PrintUtility\_Proprietary.c(v04.06.00)

## 2 How to Build the Pre-Built Binary

There are two steps for making pre-built binary.

- **Step 1:** Apply the “2bp\_prebuilt\_xx.xx.xx.patch” to Default SDK
- **Step 2:** Modify “UWBIOT\_APP\_BUILD.h” and Build the SDK

### 2.1 Step 1: Apply the “2bp\_prebuilt\_xx.xx.xx.patch” to Default SDK

There are two options to apply “2bp\_prebuilt\_xx.xx.xx.patch”.



The following steps are described on v03.15.11. Please change the commands and patch name according to your SDK version.

## 2.1.1 Using Command User Interface




In case of using MCUXpresso IDE for applying the patch, ignore this step.

Run the commands below on your console. Ex) with Git Bash:

```
$ cd UWBIOT_SR150_v03.15.11_MCUx/uwbiot-top  
$ patch -p0 < 2bp_prebuilt_v03.15.11.patch
```

Example of success log with Git Bash is shown in **Figure 1**.

**Figure 1: Example of Success Log with Git Bash**



```
MINGW64 /c/UWBIOT_SR150_v03.15.11_MCUx/uwbiot-top  
$ patch -p0 < /c/2bp_prebuilt_v03.15.11.patch  
patching file boards/Host/Rhodes4/UWB_DeviceConfig_SR1XX.h  
patching file demos/SR1XX/demo_ranging_controlee/demo_ranging_controlee.c  
patching file demos/SR1XX/demo_ranging_controller/demo_ranging_controller.c  
patching file demos/common/Demo_Common_Config.c  
patching file libs/uwb-iot/uwb_api/PrintUtility/PrintUtility.c
```


## 2.1.2 Using MUCXpresso IDE



In case of using command user interface for applying the patch, ignore this step.


1. Import "UWBIOT\_SR150\_v03.15.11\_MCUx"




For details of how to import the project, please refer to "Starting Software Development Guide" on [Type 2BP Document Site](#) .

2. Right click on **RhodesV4\_SE<Debug>**.
3. Point **Term**.
4. Click **Apply Patch...** (Figure 2).

Figure 2: Start to Apply Patch



5. Click **Browse...**
6. Select your path of **2bp\_prebuilt\_v03.15.11.patch**.
7. Click **Finish**.

**Figure 3: Select the Patch to Apply**

**Apply Patch**

**Patch Input Specification**

Select the patch location.


☐ Clipboard

☒ File

☐ URL

☐ Workspace

Select the location of the patch:

>  RhodesV4\_SE




## 2.2 Step 2: Modify “UWBIOT\_APP\_BUILD.h” and Build the SDK

Modify the define to select your target demo application in “UWBIOT\_APP\_BUILD.h”, as shown in **Figure 4**.



For details of how to build the project, please refer to “Starting Software Development Guide” on [Type 2BP Document Site](#).

**Figure 4: Modify Define to Select Target Demo Application**



```

16 /* !!! AUTO GENERATED FILE !!!!!!!!!!!!!!!!!!!!!!! */
17 /* !!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!! */
18
19 #pragma once
20
21 /* Options for selection of the demos : START */
22
23 /* Uncomment **ONE**, and comment out **rest** of them. */
24
25 // #define UWBIOT_APP_BUILD_DEMO_BINDING
26 // #define UWBIOT_APP_BUILD_DEMO_RANGING_CONTROLLER
27 #define UWBIOT_APP_BUILD_DEMO_RANGING_CONTROLEE
28 // #define UWBIOT_APP_BUILD_DEMO_DATA_TRANSFER_RX
29 // #define UWBIOT_APP_BUILD_DEMO_DATA_TRANSFER_TX
30 // #define UWBIOT_APP_BUILD_DEMO_OTP_STORAGE_FACTORY
31 // #define UWBIOT_APP_BUILD_DEMO_OTP_STORAGE_MAINLINE
  
```


## 2.3 Optional: Enable Pairing/Bonding for demo\_UWB\_ble\_sr1xxi

Modify the definition in “boards/Host/Rhodes4/app\_preinclude.h” as shown in **Figure 5** to enable pairing/bonding on Bluetooth LE. Change the values of gAppUseBonding\_d and gAppUsePairing\_d from 0 to 1. The passkey used for pairing is “999999” as defined as gPasskeyValue\_c.



This demo’s file name is changed to “demo\_nearby\_interaction” in v04.04.03 or later.  
This modification is not included in the patch file.

**Figure 5: Modify Define to Enable Pairing/Bonding**



```

97 /*! Enable/disable use of bonding capability */
98 #define gAppUseBonding_d 1
99
100 /*! Enable/disable use of pairing procedure */
101 #define gAppUsePairing_d 1
102
103 /*! Enable/disable use of privacy */
104 #define gAppUsePrivacy_d 0
105
106 #define gPasskeyValue_c 999999
  
```

## Revision History

Revision	Date	Author	Change Description
3.0	Dec 15, 2022		Initial
4.0	Dec 26, 2022		Update for v04.02.01
4.0A	Apr 21, 2023		Added 2.3, enable pairing/bonding for demo_UWB_ble_sr1xxi
4.0B	Jun 01, 2023		Update for version 04.02.01 or later
4.0C	Mar 18, 2024		Document format changed



Copyright © Murata Manufacturing Co., Ltd. All rights reserved. The information and content in this document are provided “as-is” with no warranties of any kind and are for informational purposes only. Data and information have been carefully checked and are believed to be accurate; however, no liability or responsibility for any errors, omissions, or inaccuracies is assumed.

All brand and product names are trademarks or registered trademarks of their respective owners.

Specifications are subject to change without notice.