

5-4 LOCATION OF CONTROL UNIT

The control unit may be instructed to disconnect the harness or remove the unit itself before work. As a reference for the disconnecting or the removing, location of the control unit is shown below. (The contents is just a location information of the control unit, and part shape in the illustration may differ from the actual one.)

Location of control unit

