

④ Moving the vehicle

- Do not put anything obstacle of the driving operation such as tools and parts.
- Idle rotate the engine, and move the vehicle after confirming all the warning lamps have gone off.
- Follow the instruction of owner's manual when warning lamp does not go off.

⑤ Storing the vehicle

- When storing the vehicle for long term, do not leave the key in starter switch. Small amount of electric current is flowing to each system while the key is in, and keeping this for long term will cause flat battery.