

3-11 DSPV

DSPV(Deceleration Sensing Proportioning Valve) is a device which detects the G of the longitudinal direction at the time of vehicle braking mechanically and controls the braking force.

① Prohibition

- Modifying and relocating DSPV
 - As for this device, a peculiar setting is performed by the vehicle type and the specification. Proper braking power may not be obtained when the installation position, angle of the valve relative to the ground, etc. changed.

② Precaution

- When the DSPV installed to cross member temporarily removed for body installation work, or when remodeling such as additional leaves that cause a change in vehicle posture, adjustment is necessary for restoration. Contact ISUZU distributor or ISUZU dealership for details.

Location of DSPV

