


② Installation position of reinforcement material

- An end of outer reinforcement and cross member should not overlap.
- An end of outer reinforcement and spring bracket should not overlap.

**Prohibited areas for installing reinforcement**



③ Installing reinforcement material

- Install a reinforcement by plug welding. Place them in zigzag alignment.

**Example of installing reinforcement**

