

Source Sensor

Target Sensor

Controller

Stepper Driver

initialization (if necessary)

Calibrate Sensor Command

Calibrate Sensor Command

standard control cycle

loop

[every 100 ms]

Source Sensor Data

Target Sensor Data

if change of position needed

Motor 1 Command

Motor 2 Command

possible asynchronous transmissions

Motor Status