

Source Sensor

Target Sensor

Controller

Stepper Driver

initialization (if necessary)

Calibrate Sensor Command

Calibrate Sensor Command

standard control cycle

loop

[every 100 ms]

Source Sensor Data

loop

[every 100 ms]

Target Sensor Data

loop

[every 1000 ms]

Motor 1 Command

Motor 2 Command

possible asynchronuous transmissions

Motor Status