


PrusaSlicer

Open PrusaSlicer and : → *Menu* → *Files* → *Import* → *Import the configuration*
“PLA_Polaris.ini & PLA_Vase_mode_Polaris.ini”

You should have this :



It has two types of settings, one for prints at the center-radius of the platen, the other for vase mode.

