


## RF66 Communication Example

This chapter will guide the user to carry out a pair of RF66 transmitting and receiving communication experiment through HopeDuino. RF66 is a high performance wireless transceiver chip belonging to HopeRF, with +20dBm transmit power, -123dBm sensitivity and link budget up to 143dB. The RFM series module is designed by the chip, the specific models is RFM66, with small size, high performance, easy for users to debug.

### 1. Tools and software needed to be prepared


- Arduino IDE version 1.0.5
- HopeDuino board (two pieces)  
(If you have not used the HopeDuino board, please refer to the 《AN0002-HopeDuino Platform Construction Guideline》 )
- USB cable(Type A to Type B)
- Module based on RF66 chip design (or RFM66 module)




RFM66

### 2. Hands-on experiment

- The two RFM66 modules (with conversion board) are inserted into the corresponding HopeDuino board.
- Connect the two HopeDuino boards to PC with USB cable.
- Open Arduino IDE interface, Click **【Files】→【Examples】→【HopeRFBasicLib】→【example】→【rfm66\_Tx】** , as shown below.
- Open Arduino IDE interface, Click **【Files】→【Examples】→【HopeRFBasicLib】→【example】→【rfm66\_Rx】** , as shown below.

 Notice: You couldn't find [HopeRFBasicLib] in [Examples] because you didn't install the HSP provided by HopeRF. Please refer to 《AN0002-HopeDuino Platform Construction Guideline》 .



- At this time the Tx program and Rx program have been opened, please compile the download programs according to the corresponding COM port.




Notice:


1. Do not know how to compile the download code, please refer to 《AN0002-HopeDuino Platform Construction Guideline》
2. HopeDuino platform support multiple boards connected to the same PC. But you need to modify the parameters manually. So you need to pay special attention to which COM port when you download the program every time. COM port is in the lower right corner of Arduino interface, as shown below.



- After the two programs are downloaded, the Tx board will transmit a packet of data through module RFM66. The Rx board will receive a packet of data through module RFM66 periodically and upload the data to PC through UART (USB). At this point, you can set the COM of Arduino IDE as the port connected with Rx board. Open the "Serial Monitor", as shown below.



- Click the "Serial Monitor", pop up the serial port assistant interface, as shown below. Window will display the received data message.



Notice:

1. The receiving program enables UART library function. On the description of library function UART, please refer to the "HopeDuino\_UART" library file. It is also stored in the HopeRFLib.

### 3. Program Explanation

➤ rfm66\_Tx.ino Case explanation

```
#include <HopeDuino_RFM66.h>                                // Call the corresponding library file.

rfm66Class radio;                                           // Define variable radio for RF66.
byte str[21] = {'H','o','p','e','R','F',' ','R','F','M',' ','C','O','B','R','F','M','6','6','S'}; //Message to be transmitted
void setup()
{
    radio.Modulation      = FSK;                            //Modulation mode is FSK
    radio.Frequency       = 868000;                         //Target frequency is 868MHz;
                                                            // note that RF66 only supports high frequency segment.

    radio.OutputPower     = 15;                             //Output power is 15dBm
    radio.PreambleLength  = 16;                             //Preamble length is 16 bytes
    radio.FixedPktLength  = true;                           //Message length is fixed
    radio.PayloadLength   = 21;                             //Payload length is 21 bytes
    radio.CrcDisable      = true;                           //Disable CRC for true

    radio.SymbolTime      = 416000;                         //Rate is 2.4Kbps
    radio.Deviation       = 35;                             //Frequency deviation is 35 KHz
    radio.BandWidth       = 100;                            //Received bandwidth is 100 KHz
    radio.SyncLength      = 3;                              //Sync length is 3 bytes, the value is 0xAA2DD4.
    radio.SyncWord[0]     = 0xAA;
    radio.SyncWord[1]     = 0x2D;
    radio.SyncWord[2]     = 0xD4;
    radio.vInitialize();  //Initialize radio
    radio.vGoStandby();   // Enter standby mode
}

void loop()
{
    radio.bSendMessage(str, 21);                            //Transmit a packet of message every one second
    delay(1000);
}
```

➤ rfm66\_Rx.ino Case explanation

```
#include <HopeDuino_RFM66.h>                                // Call the corresponding library file.
                                                            //Calling UART is added because of using UART.

#include <HopeDuino_UART.h>

rfm66Class radio;                                           //Define variable radio for RF66
uartClass uart;                                             //Define variable uart for UART
byte getstr[21];                                           //Define pending data buffer

void setup()
{
```

```

radio.Modulation      = FSK;           // modulation mode is FSK
radio.Frequency       = 868000;        //Target frequency is 868MHz;
                                   // note that RF66 only supports high frequency segment.

radio.OutputPower     = 15;            //Output power is 15dBm
radio.PreambleLength  = 16;           //Preamble length is 16 bytes
radio.FixedPktLength  = true;         //Message length is fixed
radio.PayloadLength   = 21;           //Payload length is 21 bytes
radio.CrcDisable      = true;         //Disable CRC for true

radio.SymbolTime      = 416000;       //Rate is 2.4Kbps
radio.Deviation        = 35;          //Frequency deviation is 35 KHz
radio.BandWidth        = 100;         //Received bandwidth is 100 KHz
radio.SyncLength       = 3;           //Sync length is 3 bytes, the value is 0xAA2DD4.
radio.SyncWord[0]      = 0xAA;
radio.SyncWord[1]      = 0x2D;
radio.SyncWord[2]      = 0xD4;
radio.vInitialize();      //Initialize radio
radio.vGoRx();           // Enter receiving mode
uart.vUartInit(9600, _8N1); //Initialize UART, parameters are 9600 baud rate and 8N1 format.
}

void loop()
{
    if(radio.bGetMessage(getstr)!=0)    //Check radio whether to receive data function,
                                       //analyze data received.
    {
        uart.vUartPutNByte(getstr, 21); // Output the received data to PC via UART
        uart.vUartNewLine();            //UART newline is easy to read.
    }
}

```

#### 4. RF66 Library Function Description

“RFM66.h”and“RFM66.cpp”library files are stored in Arduino IDE files \ libraries \ HopeRFLib.

##### ➤ FreqStruct

**Type:** union type

**Function:** Define frequency register for RF66

**Contents:** Freq, long integer, 4 bytes, frequency value;

FreqL, byte, low 8 bit from splitting Freq value is [0:7]

FreqM, byte, mid 8 bit from splitting Freq value is [8:15]

FreqH, byte, high 8 bit from splitting Freq value is [16:23]

FreqX, byte, redundancy, rounding up 4 bytes, no meaning

##### ➤ modulationType

**Type:** Enumeration type

**Function:** Select modulation mode

Contents: OOK、FSK、GFSK

OOK——On-Off-Key is ASK modulation, a special case of ASK modulation

FSK——Frequency-Shift-Key, relative to the ASK has a stronger anti interference effect. But the current is larger than the ASK under the same power.

GFSK——FSK modulation with Gauss filter.

➤ **Modulation**

**Type:** modulation type

**Function:** Define modulation mode, select one of OOK, FSK and GFSK

➤ **Frequency**

**Type:** lword type, unsigned long

**Function:** working frequency, the unit is KHz, for example: Frequency = 433920, indicates 433.92MHz.

➤ **SymbolTime**

**Type:** lword type, unsigned long

**Function:** working rate, the unit is ns, for example: SymbolTime = 416000, indicates each symbol is 416us, that is 2.4kbps.

➤ **Deviation**

**Type:** lword type, unsigned long

**Function:** frequency deviation for FSK and GFSK transmitting, the unit is KHz, for example: Deviation=45, indicates the frequency deviation is 45KHz.

➤ **BandWidth**

**Type:** word type, unsigned int

**Function:** Target receiver bandwidth for reception, the unit is KHz, for example: BandWidth = 100, indicates the receiver bandwidth is 100KHz.

➤ **OutputPower**

**Type:** unsigned char

**Function:** output power for transmitting, the range is 2~20, the unit is dBm, for example: Set is 10, on behalf of 10 dBm.

➤ **PreambleLength**

**Type:** word type (unsigned int)

**Function:** preamble length for transmitting, the unit is byte.

➤ **CrcDisable**

**Type:** bool type

**Function:** Select whether the data package has CRC function, set true to disable CRC function, set false to enable CRC function.

➤ **FixedPktLength**

**Type:** bool type

**Function:** Define the data packet length is fixed or variable, set true to represent the fixed packet length, set false to represent the variable length.

➤ **SyncLength**

**Type:** byte

**Function:** In wireless packet format, synchronous word length, the setting range is 1~8 bytes. Don't set to 0 bytes.

➤ **SyncWord[8]**

**Type:** byte array

**Function:** In setting packet format, synchronous word contents needs to be consistent with SyncLength settings.

➤ **PayloadLength**

**Type:** byte

**Function:** In fixed packet length mode, define the length of the fixed packet

➤ **vInitialize**

**Type:** function

**Input:** none

**Output:** none

**Function:** Initialize module (chip), applicable to RFM66 module, call it at the start of the program. Before the call, the above related variables are set to complete. After the initialization function configuration is completed (containing call vConfig function), let the module (chip) into the Standby state, that is, non - transmitting, non - receiving, non - sleeping.

➤ **vConfig**

**Type:** function

**Input:** none

**Output:** none

**Function:** Configure parameters to the module (chip), suitable for the occasion needs to re configure the parameters in the working process. The same need to complete the associated variables before the call. If the associated variables are set up, follow-up without modification, only to re configure the parameter, you can call it directly. If you need to switch frequency etc. in the working process, need to re modify the relevant parameters, and then call them again. After the call is completed, you need to use the mode switching function, so that let the chip work accurately in the specific mode. The mode switching functions are vGoRx、vGoStandby and vGoSleep etc.

➤ **vGoRx**

**Type:** function

**Input:** none

**Output:** none

**Function:** Configure module (chip) into the receiving mode

## ➤ vGoStandby

**Type:** function

**Input:** none

**Output:** none

**Function:** Configure module (chip) into the standby mode

## ➤ vGoSleep

**Type:** function

**Input:** none

**Output:** none

**Function:** Configure module (chip) into the sleep mode

## ➤ bSendMessage

**Type:** function

**Input:** **msg[ ]**, unsigned char, the calling entrance (pointer) of array to be transmitted.

**length**, unsigned char, the length of array to be transmitted, the unit is byte.

**Output:** bool type, true indicates the transmitting is successful, false indicates the transmitting is failure, such as: push over time, etc.

**Function:** transmit the data only once (one frame), return to standby mode automatically after completion of the transmission.

## ➤ bGetMessage

**Type:** function

**Input:** **msg[ ]**, unsigned char, the calling entrance (pointer) of array to be received.

**Output:** Returns the length of the received data, 0 indicates that the data is not received;

**Function:** check whether to receive data. The object is the IO state of the chip output. If you do not receive the data, return 0; if you receive the data, return the received data length. After the completion of receiving, the module (chip) is still in the receiving state.

## 5. Pin Assignment Table:

HopeDuino	MCU	RF66
13	PB5	SCK
12	PB4	MISO
11	PB3	MOSI
10	PB2	nCS
9	PB1	POR
8	PB0	DIO0
7	PD7	DIO1 (jumper)
6	PD6	DIO2 (jumper)

5	PD5	DIO3 (jumper)
4	PD4	DIO4 (jumper)

## 6. Version Records:

Version	Revised Contents	Date
1.0	Initial version	2016-03-29
1.1	Add watermarks, program explanations and descriptions	2016-04-06

# HOPERF