

MICROSAR Classic E2E Transformer

Technical Reference

Version 4.36.0

Authors	visssf, vissi, vispnr, visso, visfus, vislsa, jkugler, visgme
Status	Released

Document Information

Reference Documents

No.	Source	Title	Version
[1]	AUTOSAR	Specification of Module E2E Transformer	R20-11
[2]	AUTOSAR	List of Basic Software Modules	R20-11
[3]	AUTOSAR	Specification of Default Error Tracer	R20-11
[4]	AUTOSAR	Specification of SW-C End-to-End Communication Protection Library	R20-11

Scope of the Document

This technical reference describes the general use of the E2E Transformer.



Caution

We have configured the programs in accordance with your specifications in the questionnaire. Whereas the programs do support other configurations than the one specified in your questionnaire, Vector's release of the programs delivered to your company is expressly restricted to the configuration you have specified in the questionnaire.

Contents

1	Introduction.....	6
1.1	Architecture Overview	6
2	Functional Description	8
2.1	Features	8
2.1.1	Deviations	8
2.1.2	Additions/ Extensions.....	8
2.1.2.1	Memory Initialization	9
2.1.2.2	Placement of signals for E2E header at the end of a signal group	9
2.1.2.3	Support E2E Profile J1939-76.....	9
2.1.3	Limitations.....	9
2.2	Initialization	9
2.3	States	9
2.4	Main Functions	9
2.5	Error Handling.....	10
2.5.1	Development Error Reporting.....	10
2.5.2	Production Code Error Reporting	10
3	Integration	11
3.1	Embedded Implementation	11
4	API Description	12
4.1	Type Definitions	12
4.2	Services provided by E2EXf.....	12
4.2.1	E2EXf_GetVersionInfo	12
4.2.2	E2EXf_InitMemory	13
4.2.3	E2EXf_Init.....	14
4.2.4	E2EXf_DeInit	15
4.2.5	E2EXf_<transformerId>	16
4.2.6	E2EXf_Inv_<transformerId>	17
4.3	Services used by E2EXf.....	19
5	Configuration	20
5.1	Configuration Variants.....	20
5.2	Configuration of EndToEndTransformationComSpecProps	20
6	Glossary and Abbreviations	22
6.1	Glossary	22

6.2 Abbreviations 22

7 Additional Copyrights 23

8 Contact..... 24

Illustrations

Figure 1-1	AUTOSAR Architecture Overview	6
Figure 1-2	Interfaces to adjacent modules of the E2EXf	7
Figure 5-1	Configuration of EndToEndTransformationComSpecProps.....	21

Tables

Table 2-1	Supported AUTOSAR standard conform features	8
Table 2-2	Not supported AUTOSAR standard conform features	8
Table 2-3	Features provided beyond the AUTOSAR standard.....	8
Table 2-4	Service IDs	10
Table 2-5	Errors reported to DET	10
Table 3-1	Implementation files.....	11
Table 4-1	E2EXf_ConfigType	12
Table 4-2	E2EXf_GetVersionInfo.....	12
Table 4-3	E2EXf_InitMemory.....	13
Table 4-4	E2EXf_Init	14
Table 4-5	E2EXf_DeInit.....	15
Table 4-6	E2EXf_<transformerId>	16
Table 4-7	E2EXf_Inv_<transformerId>	19
Table 4-8	Services used by the E2EXf	19
Table 6-1	Glossary	22
Table 6-2	Abbreviations.....	22
Table 7-1	Free and Open Source Software Licenses	23

1 Introduction

This document describes the functionality, API and configuration of the AUTOSAR BSW module E2EXf as specified in [1].

Supported Configuration Variants:	pre-compile	
Vendor ID:	E2EXf_VENDOR_ID	30 decimal (= Vector-Informatik, according to HIS)
Module ID:	E2EXf_MODULE_ID	176 decimal (according to ref. [2])

The E2EXf module provides the functionality to ensure a correct communication.

1.1 Architecture Overview

The following figure shows where the E2EXf is located in the AUTOSAR architecture.




Figure 1-1 AUTOSAR Architecture Overview

The next figure shows the interfaces to adjacent modules of the E2EXf. These interfaces are described in chapter 4.




Figure 1-2 Interfaces to adjacent modules of the E2EXf

2 Functional Description

2.1 Features

The features listed in the following tables cover the complete functionality specified for the E2EXf.

The AUTOSAR standard functionality is specified in [1], the corresponding features are listed in the tables

> Table 2-1 Supported AUTOSAR standard conform features

> Table 2-2 Not supported AUTOSAR standard conform features

Vector Informatik provides further E2EXf functionality beyond the AUTOSAR standard. The corresponding features are listed in the table

> Table 2-3 Features provided beyond the AUTOSAR standard

The following features specified in [1] are supported:

Supported AUTOSAR Standard Conform Features	
Protect safety-related data elements	
Check safety-related data elements	

Table 2-1 Supported AUTOSAR standard conform features

2.1.1 Deviations

The following features specified in [1] are not supported:

Category	Description
Functional	Post-build-selectable variant
Functional	E2E profile 04m
Functional	E2E profile 07m
Functional	Protect and check Client-Server communication
Functional	Status forwarding
Functional	Disabling of E2E state machine

Table 2-2 Not supported AUTOSAR standard conform features

2.1.2 Additions/ Extensions

The following features are provided beyond the AUTOSAR standard:

Features Provided Beyond The AUTOSAR Standard	
Memory Initialization	
Placement of signals for E2E header at the end of a signal group	

Table 2-3 Features provided beyond the AUTOSAR standard

2.1.2.1 Memory Initialization

AUTOSAR expects the startup code to automatically initialize RAM. Not every startup code of embedded targets reinitializes all variables correctly. It is possible that the state of a variable may not be initialized as expected. To avoid this problem the Vector AUTOSAR E2EXf provides an additional function to initialize the relevant variables of the E2EXf. See also chapters 2.2 and 4.2.2 for details.

2.1.2.2 Placement of signals for E2E header at the end of a signal group

For signal groups that use data transformation AUTOSAR expects the signals for the transformer headers to be placed at the start of the signal group. The Vector AUTOSAR E2EXf supports also the placement of the E2E header at the end of the signal group. Then the offset attribute in the EndToEndTransformationDescription needs to be configured to point to the start of the E2E header.

2.1.2.3 Support E2E Profile J1939-76

The E2E Transformer Supports E2E Profile J1939-76 with following limitations.

- Only for messages received via COM/LdCom.
- Dynamic addressing not supported.
- No support for E2EPW only E2EXF
- Static length of SDM (1..8 Bytes)

2.1.3 Limitations

There are no known limitations.

2.2 Initialization

The E2E Transformer is initialized by calling `E2EXf_Init()`. This is done by the ECU State Manager (EcuM).

On platforms in which the Random Access Memory (RAM) is not initialized to zero by the startup code the function `E2EXf_InitMemory` has to be called first and then a call to `E2EXf_Init` can be realized.

2.3 States

The E2EXf has no internal state machine, it is operational after initialization. The module uses its initialization state to perform a check if the module has been initialized.

2.4 Main Functions

No main function exists because all functionality is performed within the called API.

2.5 Error Handling

2.5.1 Development Error Reporting

By default, development errors are reported to the DET using the service `Det_ReportError()` as specified in [3], if development error reporting is enabled (i.e. pre-compile parameter `E2EXf_DEV_ERROR_DETECT == STD_ON`).

If another module is used for development error reporting, the function prototype for reporting the error can be configured by the integrator, but must have the same signature as the service `Det_ReportError()`.

The reported E2EXf ID is 176.

The reported service IDs identify the services which are described in 4.2. The following table presents the service IDs and the related services:

Service ID	Service
0x00	E2EXf_GetVersionInfo
0x01	E2EXf_Init
0x02	E2EXf_DeInit
0x03	E2EXf_<transformerId>
0x04	E2EXf_Inv_<transformerId>

Table 2-4 Service IDs

The errors reported to DET are described in the following table:

Error Code	Description
0x01	API service used without module initialization
0x02	Invalid configuration set was selected
0x03	API service called with wrong parameter
0x04	API service called with invalid pointer

Table 2-5 Errors reported to DET

2.5.2 Production Code Error Reporting

No production errors are specified for E2EXf.

3 Integration

This chapter gives necessary information for the integration of the MICROSAR Classic E2EXf into an application environment of an ECU.

3.1 Embedded Implementation

The delivery of the E2EXf consists of:

File Name	Description	Integration Tasks
E2EXf.c	Main implementation file of the E2EXf.	-
E2EXf.h	Main header file of the E2EXf.	-
E2EXf_LCcfg.c	Generated file that contains definitions of structures in link-time variant.	-
E2EXf_LCcfg.h	Generated file that contains declarations of structures in link-time variant.	-
E2EXf_MemMapBase.h	Generated file with template areas that can be adapted by the user. It contains the E2EXf specific part of the memory mapping.	Adapt the dedicated code areas within that file. See hints within that file.
E2EXf_MemMap.h	Generated file with MemMap.h include in case the SIP provides no MemMap generator.	-
E2EXf_Compiler_Cfg.h	Generated file with template areas that can be adapted by the user. It contains the E2EXf specific part of the compiler abstraction.	Adapt the dedicated code areas within that file. See hints within that file.

Table 3-1 Implementation files

4 API Description

For an interfaces overview please see Figure 1-2.

4.1 Type Definitions

The types defined by the E2EXf are described in this chapter.

E2EXf_ConfigType

This structure contains the configuration for the E2E Transformer. Currently it only contains a dummy element since the post-build selectable variant is not yet supported.

Struct Element Name	C-Type	Description	Value Range
E2EXf_dummy	uint8	dummy element	–

Table 4-1 E2EXf_ConfigType

4.2 Services provided by E2EXf

4.2.1 E2EXf_GetVersionInfo

Prototype	
<code>void E2EXf_GetVersionInfo (Std_VersionInfoType *versioninfo)</code>	
Parameter	
versioninfo	Pointer to where to store the version information. Parameter must not be NULL.
Return code	
–	–
Functional Description	
This API can be used to get the version information of the E2EXf.	
Particularities and Limitations	
<ul style="list-style-type: none">> Service ID: see table 'Service IDs'> This function is synchronous.> This function is reentrant.> This API is only available if enabled by the configuration parameter <code>E2EXf_VersionInfoApi</code>.	
Expected Caller Context	
<ul style="list-style-type: none">> No restriction	

Table 4-2 E2EXf_GetVersionInfo

4.2.2 E2EXf_InitMemory

Prototype	
void E2EXf_InitMemory (void)	
Parameter	
-	-
Return code	
-	-
Functional Description	
Initializes the global variables in case an initializing startup code is not used. This function sets the E2EXf into an uninitialized state.	
Particularities and Limitations	
<ul style="list-style-type: none">> This function is synchronous.> This function is non-reentrant.> If this function is used it shall be called before any other E2EXf function after startup.	
Expected Caller Context	
<ul style="list-style-type: none">> Task context	

Table 4-3 E2EXf_InitMemory

4.2.3 E2EXf_Init

Prototype	
void E2EXf_Init (E2EXf_ConfigType *config)	
Parameter	
config	Pointer to a selected configuration structure, in the post-build-selectable variant. NULL in link-time variant.
Return code	
-	-
Functional Description	
Initializes the state of the E2E Transformer. The main part of it is the initialization of the E2E library state structures, which is done by calling all init-functions from the E2E library.	
Particularities and Limitations	
<ul style="list-style-type: none">> Service ID: see table 'Service IDs'> This function is synchronous.> This function is non-reentrant.> This API should be called by the ECU State Manger during the startup phase.> This function needs to be called from trusted context when an E2E transformer is configured for a different nontrusted partition.> This function has to be called before any other E2EXf service function is called (except <code>E2EXf_InitMemory()</code>).	
Expected Caller Context	
<ul style="list-style-type: none">> Task context	

Table 4-4 E2EXf_Init

4.2.4 E2EXf_DeInit

Prototype	
void E2EXf_DeInit (void)	
Parameter	
-	-
Return code	
-	-
Functional Description	
Deinitializes the E2E transformer.	
Particularities and Limitations	
<ul style="list-style-type: none">> Service ID: see table 'Service IDs'> This function is synchronous.> This function is non-reentrant.> This function shall be called only when the E2E transformer is initialized.	
Expected Caller Context	
<ul style="list-style-type: none">> Task context	

Table 4-5 E2EXf_DeInit

4.2.5 E2EXf_<transformerId>

Prototype	
<pre>uint8 E2EXf_<transformerId> (uint8 *buffer, uint32 *bufferLength, const uint8 *inputBuffer, uint32 inputBufferLength)</pre>	
Parameter	
buffer	This is the buffer allocated by the RTE, where the E2E transformer places its output data. If the E2E transformer is configured for in-place transformation, it also contains its input data.
bufferLength	Used length of the output buffer.
inputBuffer	If the E2E transformer is configured for out-of-place transformation, this buffer holds the input data for the transformer. If executeDespiteDataUnavailability is set to true and the transformer is executed without valid input data, the RTE will hand over a NULL pointer to the transformer.
inputBufferLength	This parameter holds the length of the E2E transformer's input data (in the inputBuffer parameter). If executeDespiteDataUnavailability is set to true and the transformer is executed without valid input data, the length will be equal to 0.
Return code	
uint8	0x00 (E_OK): Function performed successfully. 0x77 (E_SAFETY_SOFT_RUNTIMEERROR): A runtime error occurred, safety properties could not be checked (state or status cannot be determined) but non-protected output data could be produced nonetheless. 0xFF (E_SAFETY_HARD_RUNTIMEERROR): A runtime error occurred, safety properties could not be checked and no output data could be produced.
Functional Description	
Protects the data to be transmitted.	
Particularities and Limitations	
<ul style="list-style-type: none">> Service ID: see table 'Service IDs'> This function is synchronous.> This function is reentrant.	
Expected Caller Context	
<ul style="list-style-type: none">> Task or ISR2 context	

Table 4-6 E2EXf_<transformerId>

4.2.6 E2EXf_Inv_<transformerId>

Prototype	
<pre>uint8 E2EXf_Inv_<transformerId> (uint8 *buffer, uint32 *bufferLength, const uint8 *inputBuffer, uint32 inputBufferLength)</pre>	
Parameter	
buffer	<p>This is the buffer allocated by the RTE, where the E2E transformer places its output data.</p> <p>If the E2E transformer is configured for in-place transformation, it also contains its input data.</p>
bufferLength	Used length of the output buffer.
inputBuffer	<p>If the E2E transformer is configured for out-of-place transformation, this buffer holds the input data for the transformer.</p> <p>If executeDespiteDataUnavailability is set to true and the transformer is executed without valid input data, the RTE will hand over a NULL pointer to the transformer.</p>
inputBufferLength	<p>This parameter holds the length of the E2E transformer's input data (in the inputBuffer parameter).</p> <p>If executeDespiteDataUnavailability is set to true and the transformer is executed without valid input data, the length will be equal to 0.</p>
Return code	
uint8	The high nibble represents the state of the E2E state machine, the low nibble represents the status of the last E2E check.
	0x00 (E_OK): The communication is safe.
	0x01 (E_SAFETY_VALID_REP): The data are valid according to safety, although data with a repeated counter were received.
	0x02 (E_SAFETY_VALID_SEQ): The data are valid according to safety, although a counter jump occurred.
	0x03 (E_SAFETY_VALID_ERR): The data are valid according to safety, although the check itself failed.
	0x05 (E_SAFETY_VALID_NND): Communication is valid according to safety, but no new data received.
	0x20 (E_SAFETY_NODATA_OK): No data are available since initialization of transformer.
	0x21 (E_SAFETY_NODATA_REP): No data are available since initialization of transformer because a repeated counter was received.
	0x22 (E_SAFETY_NODATA_SEQ): No data are available since initialization of transformer and a counter jump occurred.

	0x23 (E_SAFETY_NODATA_ERR): No data are available since initialization of transformer. Therefore the check failed.
	0x25 (E_SAFETY_NODATA_NND): No data are available since initialization of transformer.
	0x30 (E_SAFETY_INIT_OK): Not enough data were received to use them.
	0x31 (E_SAFETY_INIT_REP): Not enough data were received to use them but some with a repeated counter were received.
	0x32 (E_SAFETY_INIT_SEQ): Not enough data were received to use them, additionally a counter jump occurred.
	0x33 (E_SAFETY_INIT_ERR): Not enough data were received to use them, additionally a check failed.
	0x35 (E_SAFETY_INIT_NND): Not enough data were received to use them, additionally no new data received.
	0x40 (E_SAFETY_INVALID_OK): The data are invalid and cannot be used.
	0x41 (E_SAFETY_INVALID_REP): The data are invalid and cannot be used because a repeated counter was received.
	0x42 (E_SAFETY_INVALID_SEQ): The data are invalid and cannot be used due to a counter jump.
	0x43 (E_SAFETY_INVALID_ERR): The data are invalid and cannot be used because a check failed.
	0x45 (E_SAFETY_INVALID_NND): Communication is invalid according to safety and no new data received.
	0x77 (E_SAFETY_SOFT_RUNTIMEERROR): A runtime error occurred, safety properties could not be checked (state or status cannot be determined) but non-protected output data could be produced nonetheless.
	0xFF (E_SAFETY_HARD_RUNTIMEERROR): A runtime error occurred, safety properties could not be checked and no output data could be produced.
Functional Description	
Checks the received data. If the data can be used by the caller, then the function returns E_OK.	

Particularities and Limitations
<ul style="list-style-type: none">> Service ID: see table 'Service IDs'> This function is synchronous.> This function is reentrant.
Expected Caller Context
<ul style="list-style-type: none">> Task or ISR2 context

Table 4-7 E2EXf_Inv_<transformerId>

4.3 Services used by E2EXf

In the following table services provided by other components, which are used by the E2EXf are listed. For details about prototype and functionality refer to the documentation of the providing component.

Component	API
DET ([3])	Det_ReportError
E2ELibrary ([4])	E2E_PXXCheck E2E_PXXCheckInit E2E_PXXMapStatusToSM E2E_PXXProtect E2E_PXXProtectInit E2E_SMCheck E2E_SMCheckInit

Table 4-8 Services used by the E2EXf

5 Configuration

In the E2EXf the attributes can be configured with the following tools:

- > Configuration in DaVinci Configurator

Currently, GetVersionInfo API and development error reporting can be enabled/disabled in the E2EXf Ecu configuration.

Moreover the E2E State Machine can be generated according to AUTOSAR 4.4 when the vendor specific LegacyStateMachine parameter is set to true.

The remaining configuration of the E2E transformer is based on the `EndToEndTransformationDescription`, `EndToEndTransformationISignalProps` and `EndToEndTransformationComSpecProps` in the system description.

5.1 Configuration Variants

The E2EXf supports the configuration variants

- > VARIANT-LINK-TIME

The configuration classes of the E2EXf parameters depend on the supported configuration variants. For their definitions please see the `E2EXf_bswmd.arxml` file.

5.2 Configuration of EndToEndTransformationComSpecProps

The `EndToEndTransformationComSpecProps` can be used to configure adjusted/special configuration values valid for the port to which the Receiver ComSpec belongs.

These options can be configured in the Receiver ComSpec of the port properties dialog in the DaVinci Developer (see following Figure).




Figure 5-1 Configuration of EndToEndTransformationComSpecProps

6 Glossary and Abbreviations

6.1 Glossary

Term	Description
DaVinci Configurator	Configuration and generation tool for MICROSAR Classic components

Table 6-1 Glossary

6.2 Abbreviations

Abbreviation	Description
API	Application Programming Interface
AUTOSAR	Automotive Open System Architecture
BSW	Basis Software
DET	Development Error Tracer
ECU	Electronic Control Unit
MICROSAR	Microcontroller Open System Architecture (the Vector AUTOSAR solution)
RTE	Runtime Environment
SIP	Software Integration Package
SRS	Software Requirement Specification
SWC	Software Component
SWS	Software Specification

Table 6-2 Abbreviations

7 Additional Copyrights

The MICROSAR Classic E2EXF Generator contains *Free and Open Source Software* (FOSS). The following table lists the files which contain this software, the kind and version of the FOSS, the license under which this FOSS is distributed and a reference to a license file which contains the original text of the license terms and conditions. The referenced license files can be found in the directory of the RTE Generator.

File	FOSS	License	License Reference
MicrosarE2EXfGen64.exe	Perl 5.30	Artistic License	License_Artistic.txt

Table 7-1 Free and Open Source Software Licenses

8 Contact

Visit our website for more information on

- > News
- > Products
- > Demo software
- > Support
- > Training data
- > Addresses

www.vector.com