



Idle position

Operating position

- 1) Breaker cam
- 2) Plate
- 3) Flyweight
- 4) Pull rod
- 5) Contact breaker cam