

Instant Pop-Up Tent

1. 1. Assembling	3
1.1 Unfolding the Tent	3
1.2 Securing the Tent with Ground Pegs	3
1.3 Attaching the Rainfly	3
1.4 Closing and Storing the Tent	3
2. 2. Features and Benefits	5
2.1 Waterproof Design	5
2.2 Ventilation System	5
2.3 Storage Pockets	5
3. 3. Disassembling	6
3.1 Folding the Tent	6
3.2 Packing the Tent in the Carry Bag	6

1. 1. Assembling

1.1 Unfolding the Tent

To unfold the Shelter Scape Instant Pop-Up Tent, follow these steps:

1. Find a flat and clear area to set up the tent.
2. Take the tent out of the carrying bag and lay it on the ground.
3. Locate the labeled tabs on the tent and grasp them firmly.
4. With a quick and smooth motion, lift the tent while pulling the tabs outward.
5. Continue pulling until the tent is fully expanded and the frame is locked into place.

1.2 Securing the Tent with Ground Pegs

Once the tent is unfolded, use the included ground pegs to secure it in place. Follow these guidelines:

1. Insert the pointed end of each ground peg into the loops on the tent's base.
2. Angle the pegs away from the tent at a 45-degree angle.
3. Use a mallet or the heel of your foot to push the pegs into the ground until they are firmly secure.

1.3 Attaching the Rainfly

If your Shelter Scape Instant Pop-Up Tent includes a rainfly, follow these instructions to attach it:

1. Locate the designated attachment points at the top of the tent.
2. Unfold the rainfly and position it over the tent, aligning the attachment points.
3. Secure the rainfly to the tent using the provided clips or hook-and-loop fasteners.

1.4 Closing and Storing the Tent

When it's time to pack up the tent, follow these steps to close and store it properly:

1. Remove the ground pegs from the tent and store them in a safe place.
2. Release any tension on the tent frame by pressing the release buttons or levers, if applicable.
3. Carefully collapse the tent by pushing down on the top while guiding the sides inward.

4. Fold the tent into a compact size and return it to the carrying bag for storage.

2. 2. Features and Benefits

2.1 Waterproof Design

The Shelter Scape Instant Pop-Up Tent features an advanced waterproof design, ensuring that you stay dry and comfortable during your outdoor adventures. The high-tech materials and innovative construction techniques provide reliable protection against rain and moisture. No need to worry about unexpected showers or wet weather conditions, the Instant Pop-Up Tent has got you covered.

2.2 Ventilation System

The tent is equipped with a state-of-the-art ventilation system that allows for optimal airflow, keeping the interior fresh and breathable. Say goodbye to stuffy, stale air inside your tent. The ventilation system ensures a comfortable and enjoyable camping experience, no matter the weather. Stay cool and comfortable in the great outdoors with the Shelter Scape Instant Pop-Up Tent.

2.3 Storage Pockets

Convenient storage pockets are strategically placed inside the tent, providing easy access to your essential belongings. Keep your phone, flashlight, or other small items within reach at all times. The storage pockets are designed for practicality and convenience, allowing you to organize your gear and keep your personal items safe and secure. Stay organized and clutter-free with the built-in storage pockets of the Shelter Scape Instant Pop-Up Tent.

3. 3. Disassembling

3.1 Folding the Tent

When disassembling the Shelter Scape Instant Pop-Up Tent, it is important to follow proper folding procedures to ensure easy storage and future use.

1. First, remove any stakes or pegs from the ground and clear the area around the tent.
2. Next, locate the two red folding levers on the frame of the tent. These levers are essential for disassembling the tent.
3. Carefully press and hold the red folding levers while simultaneously pushing the top of the tent downwards. This will collapse the frame.
4. Continue to push down until the tent is completely collapsed and folded.
5. Once folded, secure the collapsed tent with the attached elastic bands to keep it in a compact form.

3.2 Packing the Tent in the Carry Bag

After folding the Shelter Scape Instant Pop-Up Tent, it is important to pack it properly for transportation and storage.

1. Before packing, ensure that the tent is completely dry to prevent any mildew or damage to the fabric.
2. Once dry, carefully place the folded tent into the provided carry bag. The carry bag is equipped with a zipper for easy packing and transportation.
3. Secure the zipper and any additional straps or handles on the carry bag to ensure the tent is properly contained for transport.