

# SkyRanger HD Aerial Drone

1. Important Safety Information .....	4
1.1 Battery Safety .....	4
1.2 Flight Safety .....	4
1.3 Camera Safety .....	4
1.4 GPS Tracking Safety .....	4
1.5 General Safety Precautions .....	5
2. Assemble Drone .....	6
2.1: Step 1: Put wings on .....	6
2.2: Step 2: Attach camera .....	6
2.3: Step 3: Connect battery .....	6
3. Using the Controller .....	7
3.1 Powering On and Off .....	7
3.2 Connecting to the Drone .....	7
3.3 Basic Controls .....	7
3.4 Camera Controls .....	7
3.5 GPS Tracking .....	7
3.6 Battery Status .....	8
4. Starting and Stopping the Drone .....	9
4.1 Powering On the SkyRanger HD Aerial Drone .....	9
4.2 Initiating Takeoff .....	9
4.3 Stopping and Landing the Drone .....	9
4.4 Powering Off the Drone .....	9
5. Charging the Battery .....	10
5.1 Using the Provided Charger .....	10
5.2 Charging Time .....	10
5.3 Battery Storage .....	10
5.4 Safety Precautions .....	10
5.5 Replacing the Battery .....	10
6. Adjusting Camera Settings .....	11
6.1 Accessing the Camera Settings Menu .....	11
6.2 Adjusting Camera Resolution .....	11
6.3 Setting Exposure and White Balance .....	11
6.4 Activating GPS Tracking for Camera Stability .....	11
6.5 Saving and Exiting Camera Settings Menu .....	11
7. Understanding GPS Tracking .....	12

7.1 Activating GPS Tracking .....	12
7.2 GPS Position Hold Mode .....	12
7.3 Return to Home Function .....	12
7.4 Setting Waypoints .....	12
8. Troubleshooting .....	13
8.1 Drone doesn't fly .....	13
8.2 Camera not working .....	13
8.3 Battery issues .....	13

# 1. Important Safety Information

---

## 1.1 Battery Safety

- Use only the provided AeroVision SkyRanger HD Aerial Drone battery for powering the drone.
- Do not attempt to disassemble, puncture, or damage the battery in any way.
- Always store the battery in a cool, dry place away from direct sunlight and heat sources.
- If the battery becomes damaged, discontinue use and contact AeroVision customer support for a replacement.

## 1.2 Flight Safety

- Before every flight, ensure that the drone's propellers are securely attached and in good condition.
- Do not fly the SkyRanger HD Aerial Drone in inclement weather conditions such as heavy rain, snow, or high winds.
- Maintain a safe distance from people, animals, and buildings during flight to prevent accidents and property damage.
- Always keep the drone in sight during flight and avoid flying in restricted airspace or near airports.

## 1.3 Camera Safety

- When using the 4K camera to capture aerial footage, be mindful of people's privacy and adhere to local privacy laws and regulations.
- Do not attempt to modify or dismantle the camera equipment, as this may void the product warranty.
- Use caution when adjusting the camera settings during flight to avoid loss of control of the aircraft.

## 1.4 GPS Tracking Safety

- The SkyRanger HD Aerial Drone features GPS tracking for enhanced flight stability and location awareness.
- Always ensure that the GPS signal is strong and stable before initiating autonomous flight modes or relying on GPS for navigation.

## 1.5 General Safety Precautions

- Before each flight, perform a visual inspection of the drone to check for any signs of damage or wear.
- Familiarize yourself with the drone's controls and operation by reading the user manual thoroughly before flying.
- In the event of an emergency or loss of control, safely land the drone in an open area away from people and property.

## 2. Assemble Drone

---

### 2.1: Step 1: Put wings on

To assemble your SkyRanger HD Aerial Drone, start by attaching the wings. Locate the left and right wings, which are labeled with the AeroVision logo. Align the wings with the corresponding markings on the body of the drone. Insert each wing firmly into place, ensuring that they are securely attached.

### 2.2: Step 2: Attach camera

Next, attach the 4K camera to the designated mount on the front of the drone. Gently slide the camera into the slot and secure it with the provided screws. Make sure the camera is facing forward and is correctly aligned with the drone's body.

### 2.3: Step 3: Connect battery

After the wings and camera are in place, it's time to connect the battery. Locate the battery compartment on the underside of the drone. Slide the battery into the compartment, ensuring that the connectors align properly. Once the battery is inserted, firmly close the compartment door to secure the battery in place.

## 3. Using the Controller

---

To operate your SkyRanger HD Aerial Drone, you will need to use the controller provided with the product. Please follow the instructions below to ensure proper usage of the controller.

### 3.1 Powering On and Off

To power on the controller, press and hold the power button located on the top of the controller. A green light will indicate that the controller is powered on. To power off the controller, press and hold the power button again until the green light turns off.

### 3.2 Connecting to the Drone

1. First, ensure that the SkyRanger HD Aerial Drone is powered on and ready to fly.
2. Turn on the controller by pressing the power button.
3. Once the controller is powered on, it will automatically search for the drone signal and establish a connection.

### 3.3 Basic Controls

The controller is equipped with joysticks to maneuver the SkyRanger HD Aerial Drone. The left joystick controls the altitude and rotation of the drone, while the right joystick controls the direction and speed of the drone. Use the joysticks in a gentle and precise manner to ensure smooth control of the drone.

### 3.4 Camera Controls

The controller is also equipped with dedicated buttons to control the 4K camera on the SkyRanger HD Aerial Drone. The camera can be tilted up and down using the designated buttons on the controller. Additionally, there are buttons to capture photos and start/stop video recording.

### 3.5 GPS Tracking

The controller features a GPS tracking button that allows you to enable GPS mode on the drone. When GPS mode is activated, the drone will maintain its position and altitude, making it easier to capture stable and precise aerial footage.

## 3.6 Battery Status

The controller has a built-in battery indicator that displays the remaining battery life. It is important to monitor the battery status to ensure that the controller does not run out of power during operation.



## 4. Starting and Stopping the Drone

---

### 4.1 Powering On the SkyRanger HD Aerial Drone

To power on the SkyRanger HD Aerial Drone, first ensure that the battery is fully charged. Press and hold the power button located on the top of the drone for 3 seconds. The LED indicator will flash green, indicating that the drone is powering on. Once the LED indicator turns solid green, the drone is ready for flight.

### 4.2 Initiating Takeoff

Before initiating takeoff, make sure that the SkyRanger HD Aerial Drone is in an open area with no obstacles. Press the takeoff button on the remote control to initiate the automatic takeoff sequence. The drone will ascend to a safe altitude and hover in place, ready for further instructions.

### 4.3 Stopping and Landing the Drone

To stop the SkyRanger HD Aerial Drone during flight, press the emergency stop button on the remote control. The drone will immediately cease all flight operations and begin to descend to the ground. Once the drone has descended to a safe altitude, press the landing button on the remote control to initiate the automatic landing sequence. The drone will descend and land gently on the ground.

### 4.4 Powering Off the Drone

To power off the SkyRanger HD Aerial Drone, press and hold the power button located on the top of the drone for 3 seconds. The LED indicator will flash red, indicating that the drone is powering off. Once the LED indicator turns off, the drone is successfully powered off.

## 5. Charging the Battery

---

To ensure the proper operation of your SkyRanger HD Aerial Drone, it is essential to follow the correct procedures for charging the battery. Failure to do so may result in damage to the battery or the drone itself.

### 5.1 Using the Provided Charger

The SkyRanger HD Aerial Drone comes with a specialized charger designed to work with the included battery. To charge the battery, simply plug the charger into a power source and connect the battery to the charger. The LED indicator on the charger will glow red while the battery is charging and turn green once it is fully charged.

### 5.2 Charging Time

The charging time for the SkyRanger HD Aerial Drone battery is approximately 2.5 hours. It is important not to overcharge the battery, as this can lead to a decrease in overall battery life. Once the LED indicator on the charger turns green, disconnect the battery from the charger to prevent overcharging.

### 5.3 Battery Storage

When the battery is not in use, it is recommended to store it at room temperature in a dry place. Avoid exposing the battery to extreme temperatures or moisture, as this can cause damage to the battery cells.

### 5.4 Safety Precautions

When charging the battery, always ensure that the charger and battery are placed on a stable and heat-resistant surface. Do not leave the battery unattended while charging, and always unplug the charger from the power source after use.

### 5.5 Replacing the Battery

If you need to replace the battery in your SkyRanger HD Aerial Drone, only use a compatible battery recommended by AeroVision. Using an incompatible battery can result in damage to the drone or the new battery.

## 6. Adjusting Camera Settings

---

To adjust the camera settings on your SkyRanger HD Aerial Drone, follow the steps below:

### 6.1 Accessing the Camera Settings Menu

1. Turn on the drone and the remote control.
2. Use the remote control to navigate to the main menu on the LCD display.

### 6.2 Adjusting Camera Resolution

1. Navigate to the "Camera Settings" option in the main menu.
2. Select "Resolution" to choose the desired resolution for your aerial footage. Options include 720p, 1080p, and 4K.

### 6.3 Setting Exposure and White Balance

1. Navigate to the "Exposure" and "White Balance" options in the camera settings menu.
2. Adjust the exposure and white balance settings according to the lighting conditions of your aerial filming location.

### 6.4 Activating GPS Tracking for Camera Stability

1. Access the "GPS Tracking" option in the camera settings menu.
2. Turn on GPS tracking to ensure stable and precise footage during flight.

### 6.5 Saving and Exiting Camera Settings Menu

1. Once you have adjusted the camera settings to your preference, navigate to the "Save" option in the menu.
2. Exit the camera settings menu to return to the main menu.

## 7. Understanding GPS Tracking

---

The SkyRanger HD Aerial Drone is equipped with advanced GPS tracking technology to ensure precise positioning and navigation during flight.

### 7.1 Activating GPS Tracking

To activate GPS tracking, power on the drone and wait for the indicator light to turn green. Once the light is green, the GPS tracking is active and ready for use.

### 7.2 GPS Position Hold Mode

The GPS Position Hold Mode allows the drone to maintain a stable position in the air, even in windy conditions. To engage this mode, press the GPS Position Hold button on the remote control.

### 7.3 Return to Home Function

In the event of signal loss or low battery, the SkyRanger HD Aerial Drone's GPS tracking enables the Return to Home function. This feature automatically guides the drone back to its takeoff location for a safe landing.

### 7.4 Setting Waypoints

Using the AeroVision mobile app, users can set specific GPS waypoints for the drone to follow during flight. This enables the SkyRanger HD Aerial Drone to autonomously navigate a predetermined route and capture footage along the way.

## 8. Troubleshooting

---

### 8.1 Drone doesn't fly

If the SkyRanger HD Aerial Drone does not take off, please follow these steps to troubleshoot the issue:

1. Check the battery level of the drone and the controller. Ensure they are fully charged.
2. Make sure the propellers are securely attached and undamaged.
3. Calibrate the drone's compass by following the instructions in the user manual.
4. Check for any obstructions around the drone that may be preventing takeoff.
5. If the issue persists, contact AeroVision customer support for further assistance.

### 8.2 Camera not working

If the 4K camera on the SkyRanger HD Aerial Drone is not functioning properly, try the following troubleshooting steps:

1. Ensure that the camera lens is clean and free from debris.
2. Check the camera settings in the AeroVision app to make sure it is properly connected to the drone.
3. Restart the drone and the controller to see if the camera functions after a reboot.
4. If the problem continues, contact AeroVision customer support for technical assistance.

### 8.3 Battery issues

If you are experiencing battery-related issues with the SkyRanger HD Aerial Drone, please refer to the following troubleshooting steps:

1. Make sure the battery is securely connected to the drone and fully charged.
2. Check for any signs of damage or swelling on the battery.
3. Allow the battery to cool down if it has been used continuously for an extended period.
4. If the battery drains quickly, consider replacing it with a new one from AeroVision.
5. For any other battery-related concerns, contact AeroVision customer support for further guidance.