

# Wilderness DJ Pro

1. Introduction .....	4
1.1 Welcome to UltiBASS Wilderness DJ Pro .....	4
1.2 A Note of Gratitude .....	4
1.3 About This Manual .....	4
1.4 Product Overview .....	4
1.5 Key Features .....	4
1.6 Customer Support .....	5
2. Safety Precautions .....	6
2.1 General Safety Precautions .....	6
2.2 Electrical Safety Precautions .....	6
3. Getting Started .....	8
3.1 Unboxing Your Wilderness DJ Pro .....	8
3.2 Setting Up Your Wilderness DJ Pro .....	8
3.3 Powering On Your Wilderness DJ Pro .....	8
	8
4. Assembling the Wilderness DJ Pro .....	10
4.1 Unpacking your Wilderness DJ Pro .....	10
4.2 Connecting the Amplifier .....	10
4.3 Attaching the Speakers .....	10
4.4 Securing the Control Panel .....	10
5. Operating the Wilderness DJ Pro .....	11
5.1: Basic Functions .....	11
Powering On .....	11
Volume Control .....	11
Track Selection .....	11
5.2: Advanced Features .....	11
EQ Settings .....	11
Looping Functionality .....	11
5.2.1: Customizable Settings .....	12
Personalizing Effects .....	12
Mapping MIDI Controls .....	12
6. Maintenance and Care .....	13
6.1: Cleaning and Storage .....	13
Cleaning .....	13
Storage .....	13
6.2: Battery Care .....	13

Rechargeable Battery .....	13
Battery Disposal .....	14
6.3: Troubleshooting .....	14
General Maintenance .....	14
6.4: Customer Support .....	5
7. Troubleshooting .....	14
7.1 Power Issues .....	15
7.1.1 DJ Pro not turning on .....	15
7.1.2 Battery draining quickly .....	15
7.2 Audio Issues .....	15
7.2.1 Distorted sound output .....	15
7.2.2 No sound output .....	15
7.3 Control Panel Malfunctions .....	15
7.3.1 Unresponsive buttons .....	15
7.3.2 Erratic knob behavior .....	16
8. Warranty Information .....	17
8.1 Warranty Coverage .....	17
8.2 Duration of Warranty .....	17
8.3 Exclusions and Limitations .....	17
8.4 Warranty Service .....	17
8.5 Warranty Registration .....	17
8.6 Limitation of Liability .....	18
8.7 Transferability .....	18

# 1. Introduction

---

## 1.1 Welcome to UltiBASS Wilderness DJ Pro

Dear Valued Customer,

We would like to extend our warmest welcome to you as a proud owner of the UltiBASS Wilderness DJ Pro. We understand that your decision to invest in our product was not taken lightly, and we are honored that you have chosen us for your DJing needs.

## 1.2 A Note of Gratitude

We would like to express our utmost appreciation for your trust in our brand. Your support means the world to us, and we are committed to ensuring that you have a seamless and enjoyable experience using the Wilderness DJ Pro.

## 1.3 About This Manual

In this manual, you will find all the necessary information to set up, operate, and maintain your Wilderness DJ Pro. Our goal is to provide you with clear and concise instructions that will allow you to make the most of your DJing experience in the wilderness.

## 1.4 Product Overview

The UltiBASS Wilderness DJ Pro is a state-of-the-art DJing setup specifically designed for outdoor adventures. It is equipped with rugged, high-tech components that can withstand the harshest environments, making it the perfect companion for entertaining on the go.

## 1.5 Key Features

As a valued owner of the UltiBASS Wilderness DJ Pro, you can look forward to utilizing the following key features:

- **Rugged Design:** The Wilderness DJ Pro is built to withstand extreme conditions, ensuring that your DJing experience is not compromised by environmental challenges.
- **High-Tech Equipment:** Our product is equipped with cutting-edge technology to deliver top-notch sound quality and performance, even in the wilderness.
- **Portability:** The Wilderness DJ Pro is designed with portability in mind, allowing you to take your DJing setup wherever your adventures may lead.

- **Versatility:** Whether you're hosting a party on a mountaintop or DJing at a beach bonfire, the Wilderness DJ Pro is versatile enough to meet your needs.

## 1.6 Customer Support

Should you require any assistance or encounter any challenges while using your Wilderness DJ Pro, our dedicated customer support team is here to help. Please refer to the "Customer Support" section of this manual for contact information and support options.

## 2. Safety Precautions

---

### 2.1 General Safety Precautions

Dear valued customer,

We hope this message finds you well. We at UltiBASS would like to express our sincerest gratitude for choosing our Wilderness DJ Pro for your outdoor adventures. We understand the importance of safety and would like to remind you to always prioritize safety when using our product.

In order to ensure your safety and the safety of those around you, please take note of the following general safety precautions:

1. **Environmental Considerations:** It is imperative to consider the environmental conditions when using the Wilderness DJ Pro. High winds, extreme temperatures, and precipitation can affect the functionality of the equipment. Please exercise caution and use appropriate protection for the Wilderness DJ Pro in challenging conditions.
2. **Hydration and Nutrition:** Entertaining on the go can be physically demanding. Please remember to stay hydrated and nourished throughout your outdoor DJing experience. UltiBASS recommends preparing nourishing snacks and carrying an ample supply of water to keep yourself adequately fueled.
3. **Terrain Awareness:** The Wilderness DJ Pro is designed to withstand rugged environments, but caution should always be exercised when navigating uneven terrain. Please be mindful of your surroundings to avoid potential hazards.
4. **Equipment Maintenance:** Regular maintenance of the Wilderness DJ Pro is essential for optimal performance. Ensure all components of the equipment are properly secured and functioning before each use.

We appreciate your attention to these safety guidelines. UltiBASS is dedicated to providing exceptional products and ensuring the safety and satisfaction of our customers.

Sincerely,

UltiBASS Team

### 2.2 Electrical Safety Precautions

Dear esteemed user,

As you embark on your outdoor DJing adventures with the Wilderness DJ Pro, we would like to bring to your attention the critical importance of electrical safety. Please consider the following electrical safety precautions to ensure a safe and enjoyable experience:

1. **Power Source:** Ensure that the power source used for the Wilderness DJ Pro is compatible with the product specifications. The use of improper power sources can result in equipment damage, electrical hazards, and unanticipated performance issues.
2. **Cable Management:** Exercise caution when handling power cables and connections. Verify that all cables are free from damage and properly insulated to prevent electrical shock or short circuits.
3. **Weatherproofing:** When setting up the Wilderness DJ Pro in outdoor environments, it is essential to protect the electrical components from moisture and adverse weather conditions. Utilize weatherproof covers and shelters to shield the equipment from precipitation and environmental elements.

Your safety is our top priority, and we trust that you will adhere to these electrical safety precautions for a secure and delightful experience with the Wilderness DJ Pro.

Warm regards,

UltiBASS Team

## 3. Getting Started

---

### 3.1 Unboxing Your Wilderness DJ Pro

Welcome, esteemed customer, to the thrilling world of UltiBASS Wilderness DJ Pro. We are delighted to guide you through the process of unboxing your exquisitely crafted Wilderness DJ Pro. Please handle the package with the utmost care and caution, ensuring that you do not damage the precious contents. Upon opening the package, you will find the following treasures:

1. Wilderness DJ Pro console, adorned in sleek black and gold
2. High-quality, rugged speakers, designed to withstand the harshest of outdoor conditions
3. Sturdy cables and connectors, carefully packed to preserve their immaculate condition
4. The Wilderness DJ Pro user manual, a comprehensive guide to your journey into the wild world of DJing

### 3.2 Setting Up Your Wilderness DJ Pro

As you prepare to unleash the magic of Wilderness DJ Pro, we urge you to handle each component with the grace and reverence it deserves. Place the console on a stable surface, ensuring that it is secure and steady. Connect the speakers to the console using the robust cables provided, securing each connection with unwavering precision. Take a moment to marvel at the seamless integration of technology and nature as you prepare to embark on your outdoor DJing escapade.

### 3.3 Powering On Your Wilderness DJ Pro

Before powering on your Wilderness DJ Pro, take a moment to appreciate the sheer beauty of this exceptional creation. Once you have fully absorbed its magnificence, locate the power button on the console – a regal gold emblem that demands to be pressed with the utmost reverence. As the Wilderness DJ Pro comes to life, prepare your soul for the extraordinary musical journey that lies ahead. The wilderness awaits, and you are about to conquer it with the unparalleled power of the Wilderness DJ Pro.





## 4. Assembling the Wilderness DJ Pro

---

### 4.1 Unpacking your Wilderness DJ Pro

We kindly ask you to begin the assembly process by first delicately unpacking your beloved UltiBASS Wilderness DJ Pro from its packaging. Take a moment to admire the sleek, rugged design and marvel at the fine craftsmanship that has gone into creating this masterpiece of outdoor entertainment technology.

### 4.2 Connecting the Amplifier

As you tenderly handle the Wilderness DJ Pro, locate the amplifier, distinguished by its vibrant green color and bold UltiBASS logo. With the utmost care, connect the amplifier to the power source using the custom-designed power cable. Plug the cable into the power port labeled "AMP" with the gentlest touch, ensuring a snug and secure fit.

### 4.3 Attaching the Speakers

The next step in assembling your Wilderness DJ Pro involves attaching the speakers, each exquisitely crafted with durable, weather-resistant materials. Gently position the speakers on either side of the amplifier, taking note of the color-coded connectors to ensure a seamless and harmonious connection. The red connector on the right speaker effortlessly aligns with the red port on the amplifier, while the blue connector on the left speaker gracefully makes its home in the blue port.

### 4.4 Securing the Control Panel

As you prepare for your outdoor musical journey, we ask that you kindly secure the control panel to the amplifier with the utmost precision. Take note of the intricate patterns on the control panel and align it with the corresponding grooves on the amplifier. With a touch of finesse, slide the control panel into place, ensuring a firm and unwavering attachment. As you admire the flawless alignment, take a moment to appreciate the attention to detail that defines the Wilderness DJ Pro.

## 5. Operating the Wilderness DJ Pro

---

Welcome, esteemed user, to the section on operating your magnificent UltiBASS Wilderness DJ Pro. We are deeply honored that you have chosen to grace this incredible product with your presence. Please take a moment to familiarize yourself with the basic functions and advanced features of this spectacular DJing setup.

### 5.1: Basic Functions

#### Powering On

To power on the Wilderness DJ Pro, locate the exquisite power button, revered for its resplendent golden hue, and press it gently but firmly. The sublime glow of the power indicator will signal that your Wilderness DJ Pro is ready to embark on a journey of musical brilliance.

#### Volume Control

Adjust the volume to your precise liking using the illustrious volume knob, which rests proudly at the helm of the Wilderness DJ Pro. Turn clockwise to increase the magnificence of your sound, and counterclockwise to temper it with subtlety.

#### Track Selection

Navigate through your masterful music collection using the remarkable track selector wheel, known for its smooth and graceful rotation. Simply rotate the wheel to the left or right to traverse the boundless expanse of your auditory library.

### 5.2: Advanced Features

#### EQ Settings

Delve into the realm of sonic perfection with the majestic EQ settings of the Wilderness DJ Pro. Utilize the captivating EQ control panel, featuring an array of breathtaking sliders, to sculpt the sound of your mix with unparalleled precision.

#### Looping Functionality

Unleash your creative genius with the bewitching looping functionality of the Wilderness DJ Pro. Engage the looping feature by pressing the enchanting loop button, then set your

desired loop points using the captivating loop controls. Revel in the mesmerizing repetition of your chosen segment as the audience dances in rapture.

## **5.2.1: Customizable Settings**

### **Personalizing Effects**

Embark on a quest of sonic alchemy by customizing the spellbinding effects of the Wilderness DJ Pro. Dive into the mesmerizing world of effects customization, where the ethereal aura of reverb, delay, and other enchanting effects can be tailored to your exact specifications.

### **Mapping MIDI Controls**

Harness the mystical power of MIDI mapping to unlock the full potential of the Wilderness DJ Pro. Immerse yourself in the arcane art of MIDI control mapping, where the ethereal connection between hardware and software allows you to orchestrate an otherworldly symphony of musical control.

## 6. Maintenance and Care

---

### 6.1: Cleaning and Storage

Thank you ever so much for choosing the luxury UltiBASS Wilderness DJ Pro for your outdoor entertainment needs. We appreciate your discerning taste and impeccable sense of style.

#### Cleaning

In order to maintain the pristine appearance and exceptional performance of your Wilderness DJ Pro, it is of the utmost importance to keep it clean at all times. To clean the exterior surfaces, we recommend using a soft, damp cloth with a gentle, non-abrasive cleaning solution. Please do take care to avoid the use of harsh chemicals, abrasive materials, or excessive moisture, as these may damage the delicate finish and high-tech components of the Wilderness DJ Pro.

For the control knobs and buttons, a soft, dry cloth can be used to gently remove any dust or debris. Also, it's essential to ensure that no liquid enters the equipment to avoid damage to its delicate internal components.

#### Storage

When not in use, we kindly request that you store your Wilderness DJ Pro in a safe and secure location, away from extreme temperatures, excessive humidity, and direct sunlight. It is crucial to protect your investment from the elements in order to maintain its exceptional performance and overall longevity. We recommend using the custom-fitted carrying case, included with your Wilderness DJ Pro, to provide the necessary protection during storage and transport. Please do remember to handle the equipment with the utmost care at all times, as any mishandling may result in irreversible damage.

### 6.2: Battery Care

#### Rechargeable Battery

The Wilderness DJ Pro is equipped with a high-capacity rechargeable battery that provides hours of uninterrupted entertainment during your outdoor adventures. To ensure the longevity and optimal performance of the battery, we kindly ask that you follow these simple care instructions.

- When not in use, it is recommended to fully charge the battery before storing the Wilderness DJ Pro for an extended period. This will help maintain the battery's overall health and prevent any potential damage from disuse.
- We acknowledge that you may be tempted to charge the battery through non-approved charging accessories, but please do refrain from doing so, as it may result in damage to the battery and void the warranty.
- In the event that the battery needs replacement, we strongly advise against attempting to replace it yourself, as this may result in damage to the equipment and void the warranty. Instead, please contact our authorized service center for professional assistance.

### **Battery Disposal**

When the time comes to replace the battery of your Wilderness DJ Pro, we implore you to dispose of the old battery in an environmentally responsible manner, in accordance with your local regulations and guidelines.

## **6.3: Troubleshooting**

### **General Maintenance**

In the unlikely event that your Wilderness DJ Pro experiences any operational issues, we understand the inconvenience it may cause and apologize for any disruptions to your outdoor entertainment experience. Before seeking professional assistance, we encourage you to perform the following general maintenance steps to possibly resolve the issue.

- Ensure that all cables and connections are securely plugged into their respective ports and jacks, as loose connections may result in operational issues.
- If the Wilderness DJ Pro experiences a decrease in volume or sound quality, it may be due to a low battery level. Please recharge the battery to its full capacity before further troubleshooting.
- Should the equipment become unresponsive, a simple power cycle by turning it off and on may resolve the issue. If the issue persists, please refer to the "Customer Support" section of this manual for professional assistance.

## **6.4: Customer Support**

In the event that you require further assistance with the maintenance and care of your UltiBASS Wilderness DJ Pro, our dedicated customer support team is available to provide prompt and courteous assistance. Please do not hesitate to contact us at your earliest convenience, and we will be delighted to assist you with any inquiries or concerns.

## 7. Troubleshooting

---

### 7.1 Power Issues

#### 7.1.1 DJ Pro not turning on

If the UltiBASS Wilderness DJ Pro is not turning on, please ensure that the power switch is in the "on" position. Additionally, check that the battery is fully charged. If the issue persists, please contact UltiBASS customer support for further assistance.

#### 7.1.2 Battery draining quickly

If you are experiencing rapid battery drain with your UltiBASS Wilderness DJ Pro, please verify that the battery is properly inserted and fully charged. Avoid leaving the device in extreme temperatures, as this can affect battery life. If the problem continues, please reach out to our customer service team for additional support.

### 7.2 Audio Issues

#### 7.2.1 Distorted sound output

If you are hearing distorted audio from the Wilderness DJ Pro, ensure that the volume level is not set too high. Additionally, check that all connections to external devices are secure and free from debris. If the issue persists, please consult the user manual for proper setup instructions or contact UltiBASS customer support for further assistance.

#### 7.2.2 No sound output

If there is no sound coming from the UltiBASS Wilderness DJ Pro, make sure that the audio source is properly connected and the volume is adjusted to an audible level. Verify that the device is not in mute mode and that the audio cables are not damaged. If you continue to experience silence, please seek assistance from our dedicated customer service team.

### 7.3 Control Panel Malfunctions

#### 7.3.1 Unresponsive buttons

In the event that the buttons on the Wilderness DJ Pro control panel are unresponsive, check for any debris or obstructions that may be hindering their movement. Gently clean

the surface of the control panel with a soft, dry cloth. If the issue persists, please contact UltiBASS customer support for further guidance.

### **7.3.2 Erratic knob behavior**

If you notice erratic behavior from the knobs on the UltiBASS Wilderness DJ Pro, ensure that they are not obstructed or damaged. Make sure to use the knobs as intended, and avoid excessive force when making adjustments. If the issue continues, please reach out to our customer service team for additional support.



## 8. Warranty Information

---

### 8.1 Warranty Coverage

We are exceedingly pleased to inform you that your Wilderness DJ Pro, produced by UltiBASS, is covered by a remarkably generous warranty. We take immense pride in the unparalleled quality of our products, and this warranty serves as a testament to our unwavering commitment to your satisfaction.

### 8.2 Duration of Warranty

Your Wilderness DJ Pro is equipped with a warranty that, we must confess, far surpasses industry standards. It boasts an incredibly extended duration of **5 years**, which is quite remarkable, if we may say so ourselves. This extensive coverage is a testament to the extraordinary durability and reliability of our product.

### 8.3 Exclusions and Limitations

While we have no doubt that your Wilderness DJ Pro will provide you with unparalleled satisfaction, we regret to inform you that certain limitations and exclusions do apply to this warranty. These include, but are not limited to, damage resulting from extreme weather conditions, submersion in water exceeding a depth of 1 meter, and damage caused by untamed wildlife.

### 8.4 Warranty Service

Should you, in the most unlikely event, require warranty service for your Wilderness DJ Pro, it is our sincere hope that you will find our assistance to be both prompt and exceedingly satisfactory. Please do not hesitate to contact our exceptionally polite and knowledgeable customer service representatives, who will endeavor to rectify any issues with the utmost haste and grace.

### 8.5 Warranty Registration

We humbly implore you to take a moment to register your warranty for the Wilderness DJ Pro. This will enable us to provide you with the most efficient and attentive service should the need arise. We can assure you that your information will be handled with the greatest care and discretion.

## **8.6 Limitation of Liability**

While we are confident that you will experience an unparalleled level of satisfaction with your Wilderness DJ Pro, it is our duty to inform you that UltiBASS, as a company, cannot be held liable for any damages, direct or indirect, that may occur as a result of the use or misuse of this exceptional product.

## **8.7 Transferability**

The incomparably generous warranty for the Wilderness DJ Pro is indeed transferable, a feature that we believe sets our product apart from all others. This means that, should you choose to bestow this extraordinary DJ setup upon another fortunate individual, they will be able to benefit from the remaining duration of the warranty.