

AdventurePro 4500

1. Introduction	3
2. Turning on and off	4
2.1: How to turn on	4
2.2: How to turn off	4
3. Taking a photo	5
4. Recording a video	6
5. Changing settings	7
6. Charging the camera	8
6.1. Connecting the charger	8
6.2. Charging indicator	8
6.3. Charging time	8
6.4. Disconnecting the charger	8
6.5. Important note	8
7. Waterproof and shockproof features	9
7.1 Waterproof capabilities	9
7.2 Shockproof design	9

1. Introduction

Welcome to the user manual for the Wander Lens AdventurePro 4500 adventure photography camera. We are pleased to present this high-tech camera, designed to capture stunning outdoor shots in any environment. Whether you are hiking, surfing, or exploring the urban jungle, the AdventurePro 4500 is your perfect companion. With its waterproof and shockproof features, you can trust this camera to withstand the rigors of your adventures. In addition, the 4K video capabilities ensure that you can capture every detail of your outdoor experiences with crystal clear quality. Get ready to unleash your inner adventurer and explore the world through the lens of the AdventurePro 4500.

2. Turning on and off

2.1: How to turn on

To power on your AdventurePro 4500 camera, follow the steps below:

1. **Locate the power button:** The power button is located on the top of the camera, next to the shutter button. It is identified by a small power symbol.
2. **Press and hold the power button:** Press and hold the power button for 3 seconds until the camera's indicator lights turn on. This indicates that the camera is now powered on and ready for use.
3. **Check the LCD screen:** Once the indicator lights are on, the LCD screen will also display the camera's main menu, indicating that the camera is fully powered on.

2.2: How to turn off

To power off your AdventurePro 4500 camera, follow the steps below:

1. **Navigate to the power options:** Press the menu button, then navigate to the power options using the arrow keys on the camera's control panel.
2. **Select power off:** Once in the power options menu, select "power off" using the arrow keys, then press the OK button to confirm.
3. **Wait for the camera to power down:** After confirming the power off selection, wait for the camera to completely power down. The indicator lights will turn off, and the LCD screen will go blank, indicating that the camera is fully powered off.

3. Taking a photo

To take a photo with your AdventurePro 4500 camera, follow these simple steps:

1. Press the power button: Locate the power button on the top of the camera (it is the black button with a power symbol). Press and hold this button for 2 seconds to turn on the camera.
2. Select the photo mode: Once the camera is powered on, use the mode selection button (located on the front of the camera, next to the lens) to choose the photo mode. The mode selection button is the round, blue button with a camera icon.
3. Frame your shot: Look through the viewfinder to frame your shot. The viewfinder is the small rectangular screen on the back of the camera.
4. Press the shutter button: When you are ready to take a photo, press the shutter button. This button is located on the top of the camera, next to the power button. It is the red button with a camera icon.
5. Review your photo: After taking a photo, you can review it on the LCD screen. Use the arrow buttons on the back of the camera to scroll through your photos.

Congratulations! You have successfully taken a photo with your AdventurePro 4500 camera. Remember to always secure your camera with the included strap to prevent dropping it during your adventures.

4. Recording a video

Press the "Record" button on the **AdventurePro 4500** camera to begin recording a video.

Ensure that the camera is set to video mode by toggling the switch on the side of the camera to the "V" position.

To stop recording, press the "Record" button again.

Adjust the video settings by navigating to the "Video Settings" menu on the camera's display screen.

Select the desired resolution and frame rate for your video.

Make sure to hold the camera steady while recording to avoid shaky footage.

5. Changing settings

To change the camera settings on your AdventurePro 4500, follow these simple steps:

1. Power on the camera by pressing the **Power** button located on the top of the camera.
2. Once the camera is powered on, press the **Menu** button to access the settings menu.
3. You can navigate through the settings using the **Up** and **Down** buttons, and select an option by pressing the **OK** button.
4. To change the resolution for photos or videos, navigate to the **Resolution** option in the settings menu and select the desired resolution.
5. Similarly, you can adjust other settings such as white balance, exposure, and image stabilization by navigating to their respective options in the settings menu.

Remember to press the **OK** button to confirm any changes you make to the settings. Once you have adjusted the settings, press the **Menu** button to exit the settings menu.

6. Charging the camera

To charge your AdventurePro 4500 camera, follow the steps below.

6.1. Connecting the charger

1. Connect the micro-USB cable to the charging port located on the side of the camera.
2. Connect the other end of the cable to the power adapter.

6.2. Charging indicator

When the camera is connected to the charger, the charging indicator light will turn red. Once the battery is fully charged, the light will turn green.

6.3. Charging time

The charging time for the AdventurePro 4500 camera is approximately 2 hours when using the provided power adapter.

6.4. Disconnecting the charger

Once the battery is fully charged, disconnect the micro-USB cable from the camera and the power adapter.

6.5. Important note

Do not attempt to charge the camera with a damaged or wet charging cable. This can result in damage to the camera and possible electrical hazards.

7. Waterproof and shockproof features

7.1 Waterproof capabilities

AdventurePro 4500 is equipped with advanced waterproof technology, allowing it to withstand water depths of up to 30 meters. Whether you're snorkeling, diving, or caught in a sudden rainstorm, rest assured that your camera is fully protected. The specially designed seals and casing provide a tight barrier against water, ensuring that no moisture can penetrate and damage the internal components.

7.2 Shockproof design

The robust construction of AdventurePro 4500 makes it highly resistant to shocks and impacts. Built to endure rough handling and accidental drops, this camera is perfect for capturing adrenaline-pumping moments during extreme outdoor activities. The durable outer shell and internal shock absorbers safeguard the delicate electronic parts from damage, guaranteeing reliable performance in rugged environments.