

Nomad Camping Stove

1. Introduction	3
1.1 What is off-grid cooking?	3
1.2 Why WanderStove?	3
2. Getting Started	4
2.1: Unboxing your Nomad Camping Stove	4
2.2: Setting up the stove	4
3. Using the Stove	5
3.1: Basic Cooking Techniques	5
4. Maintenance	6
4.1: Cleaning the stove	6
General Cleaning	6
Cleaning the Fuel Line	6
Cleaning the Burner	6
4.2: Storing the stove	7
Before Storage	7
Storing Fuel	7
Long-Term Storage	7
5. Troubleshooting	8
5.1 Common issues	8
6. Warranty	9
6.1 Warranty Coverage	9
6.2 Exclusions	9
6.3 Claim Procedure	9
6.4 Resolution	9
6.5 Limitation of Liability	9
6.6 Customer Responsibilities	9
6.7 Transferability	10
6.8 Contact Information	10

1. Introduction

1.1 What is off-grid cooking?

Off-grid cooking refers to the practice of preparing meals without relying on traditional utilities such as gas or electricity. Instead, off-grid cooking methods utilize alternative sources of heat such as wood, charcoal, or other sustainable fuel options. By embracing off-grid cooking, individuals can enjoy outdoor adventures while still being able to prepare warm, satisfying meals without access to modern cooking facilities.

1.2 Why WanderStove?

WanderStove offers the ultimate off-grid cooking solution with the Nomad Camping Stove. This lightweight, compact, and fuel-efficient design is the perfect companion for outdoor enthusiasts seeking reliable cooking capabilities while on the go. The WanderStove Nomad Camping Stove is specifically designed to meet the needs of campers, hikers, and adventurers, ensuring that they can enjoy delicious meals even in remote locations. With its innovative features and portability, WanderStove sets the standard for off-grid cooking appliances.

2. Getting Started

2.1: Unboxing your Nomad Camping Stove

Upon receiving your WanderStove Nomad Camping Stove, carefully remove the product from its packaging. Ensure that all the components are included in the box by referring to the product checklist provided. Contact customer service if any parts are missing or damaged. The package should contain the following items:

- Nomad Camping Stove (x1)
- Fuel canister (x1)
- User manual (x1)

Inspect the stove for any visible signs of damage. If you notice any issues, refrain from using the stove and contact customer service for further assistance.

2.2: Setting up the stove

To begin setting up your Nomad Camping Stove, follow these steps:

1. Place the stove on a flat, stable surface away from any flammable materials or substances.
2. Unfold the stove legs until they click into place, ensuring that they are locked securely in position to provide a stable base for the stove.
3. Open the fuel canister valve by turning it counterclockwise until it stops. This will allow the fuel to flow to the stove's burner.
4. Carefully attach the fuel canister to the stove by aligning the notches on the stove's base with the corresponding tabs on the fuel canister. Twist the canister clockwise until it is securely attached.
5. Once the fuel canister is attached, turn the control valve on the stove counterclockwise to release a small amount of fuel. Ignite the stove with a match or a lighter, ensuring that the flame is stable and even.

Your Nomad Camping Stove is now set up and ready for use. Please refer to the "Operating Instructions" section for information on using the stove safely and efficiently.

3. Using the Stove

3.1: Basic Cooking Techniques

Welcome to the exciting world of off-grid cooking with your WanderStove Nomad Camping Stove! Our stove was designed to make cooking in the great outdoors a breeze. Whether you're making a quick meal at a campsite or enjoying a hot drink on a remote trail, the Nomad Camping Stove is here to help.

To get started, follow these basic cooking techniques:

1. **Setting up the Stove:** Unfold the WanderStove Nomad Camping Stove and secure the legs in place. Place the stove on a flat, stable surface, away from any flammable materials. Make sure the fuel canister is securely attached and the control valve is in the "off" position.
2. **Igniting the Stove:** To ignite the stove, turn the control valve to the "ignite" position. Use a long-reach lighter to light the burner. Once the flame is lit, adjust the control valve to achieve the desired flame size.
3. **Cooking with Pots and Pans:** The WanderStove Nomad Camping Stove is compatible with a variety of cookware. Place your pot or pan on the stove's burner, making sure it is stable and not too large for the burner. Use the control valve to adjust the flame to the appropriate heat level for your cooking needs.
4. **Grilling and Boiling:** For grilling, use the included grill attachment by placing it securely over the burner. For boiling, simply place your pot of water on the burner and adjust the flame to reach a rolling boil.
5. **Shutting Down the Stove:** Once you have finished cooking, turn the control valve to the "off" position to extinguish the flame. Allow the stove to cool down before handling or stowing it away.

Remember to always use caution when cooking with any stove, and never leave the Nomad Camping Stove unattended while in use. Happy cooking!

4. Maintenance

4.1: Cleaning the stove

General Cleaning

To maintain the optimal performance of your Nomad Camping Stove, it is essential to keep it clean after each use. Here are the general cleaning steps:

1. **Cool Down:** Ensure the stove has completely cooled down before cleaning.
2. **Remove Debris:** Use a soft brush or cloth to remove any debris, such as ash or food particles, from the stove body and cooking grate.
3. **Wipe Down:** Wipe the surfaces of the stove with a damp cloth and mild detergent to remove any remaining dirt or residue.
4. **Dry Thoroughly:** After cleaning, ensure that the stove is completely dry before storing to prevent rust or corrosion.

Cleaning the Fuel Line

It is important to keep the fuel line of the Nomad Camping Stove clean to prevent blockages and maintain efficient fuel flow. Follow these steps to clean the fuel line:

1. **Disconnect Fuel Source:** Turn off the fuel supply and disconnect the fuel line from the stove.
2. **Clear Blockages:** Use a small brush or pipe cleaner to clear any blockages from the fuel line.
3. **Inspect and Reconnect:** Inspect the fuel line for any damage or wear, and reconnect it securely to the stove before the next use.

Cleaning the Burner

The burner of your Nomad Camping Stove should be cleaned regularly to ensure even heat distribution and prevent clogs. Follow these steps to clean the burner:

1. **Remove Burner:** Carefully remove the burner from the stove by following the instructions in Section 3 of this manual.
2. **Clear Blockages:** Use a soft brush or compressed air to clear any debris or blockages from the burner holes.

3. **Reassemble:** Once the burner is clean, reassemble it according to the instructions in Section 3 to ensure proper alignment and function.

4.2: Storing the stove

Before Storage

Before storing your Nomad Camping Stove, it is important to ensure that it is clean and in good condition. Follow these steps before storing the stove:

1. **Clean and Dry:** Thoroughly clean the stove according to the instructions in Section 4.1 and ensure that it is completely dry to prevent corrosion.
2. **Check for Damage:** Inspect the stove for any signs of damage, such as dents or cracks, and address any issues before storing.

Storing Fuel

When storing your Nomad Camping Stove, it is important to consider the storage of the fuel source to ensure safety and optimal performance. Follow these guidelines for storing fuel:

1. **Use Approved Containers:** Store fuel in approved containers that are specifically designed for the type of fuel used with the stove.
2. **Keep Away from Heat Sources:** Store fuel containers in a cool, dry place away from direct sunlight and heat sources.

Long-Term Storage

If you plan to store your Nomad Camping Stove for an extended period, follow these additional guidelines to ensure its condition:

1. **Apply Lubricant:** Apply a thin layer of rust-resistant lubricant to metal parts to prevent corrosion during long-term storage.
2. **Cover the Stove:** Use a protective cover or storage bag to prevent dust and debris from accumulating on the stove during storage.

5. Troubleshooting

5.1 Common issues

If you encounter any issues with your WanderStove Nomad Camping Stove, please refer to the following list of common issues and their solutions:

1. **Issue:** Difficulty igniting the stove

- **Solution:** Ensure that the fuel valve is fully open. Check the fuel canister for any blockages or obstructions. If using a match or lighter, make sure it is functioning properly.

2. **Issue:** Uneven flame or hot spots

- **Solution:** Clean the burner head and ensure it is free from any debris or blockages. Adjust the positioning of the pot or pan to distribute heat more evenly.

3. **Issue:** Excessive smoke or soot

- **Solution:** Check the air vents on the stove for any blockages. If using wood as a fuel source, ensure it is dry and well-seasoned to minimize smoke.

4. **Issue:** Weak flame or low heat output

- **Solution:** Replace the fuel canister if it is nearly empty. If using a liquid fuel stove, check for any leaks in the fuel line or connections.

5. **Issue:** Unusual odors during operation

- **Solution:** Ensure that the fuel being used is compatible with the stove. If using a liquid fuel stove, check for any leaks or spills that may be causing the odor.

Remember to always follow proper safety precautions when troubleshooting any issues with the WanderStove Nomad Camping Stove. If the issue persists or cannot be resolved, please contact our customer support team for further assistance.

6. Warranty

Thank you for purchasing the WanderStove Nomad Camping Stove. We are confident in the quality and durability of our product, and we offer a warranty to cover any manufacturing defects.

6.1 Warranty Coverage

The WanderStove Nomad Camping Stove is covered by a limited warranty for a period of one year from the date of purchase. This warranty covers any defects in materials or workmanship.

6.2 Exclusions

The warranty does not cover damage caused by misuse, neglect, or normal wear and tear. It also does not cover damage resulting from accidents, unauthorized repairs, or modifications to the product.

6.3 Claim Procedure

In the event that you need to make a warranty claim, please contact our customer service team at support@wanderstove.com. You will need to provide proof of purchase and a detailed description of the issue.

6.4 Resolution

Once a warranty claim has been verified, we will provide a replacement part or a replacement product, depending on the nature of the issue. Our goal is to ensure that you are able to continue enjoying the benefits of the Nomad Camping Stove.

6.5 Limitation of Liability

WanderStove shall not be liable for any indirect, incidental, special, or consequential damages that result from the use of the Nomad Camping Stove.

6.6 Customer Responsibilities

To ensure the validity of the warranty, it is important to properly maintain and care for your Nomad Camping Stove. Regular cleaning and inspection of the stove will help to prevent issues and prolong its lifespan.

6.7 Transferability

This warranty is non-transferrable and applies only to the original purchaser of the Nomad Camping Stove. It is important to retain your proof of purchase for any future warranty claims.

6.8 Contact Information

If you have any questions about the warranty or need to make a claim, please contact our customer service team at support@wanderstove.com.