

SunSafe Pop-Up Beach Tent

1. Introduction	3
1.1: Welcome to Shade Scape	3
1.2: Important Safety Information	3
1.3: User Responsibility	3
1.4: Product Limitations	3
1.5: Prior User Incidents	4
1.6: Conclusion	4
2. Assembly and Use	5
2.1 Assembly Instructions	5
2.2 Proper Use of SunSafe Pop-Up Beach Tent	5
2.2.1 Beach Use	5
2.2.2 Outdoor Event Use	5
2.2.3 Picnic Use	6
3. Care and Maintenance	7
3.1: Cleaning Instructions	7
General Cleaning	7
Stain Removal	7
Frame Maintenance	7
3.2: Storage Recommendations	7
Folding and Packing	7
Moisture and Humidity	7
Sun Exposure	7
4. Warranty and Liability	8
4.1 Warranty	8
4.2 Liability	8
4.3 Limitations	8
4.4 Examples of Harms	8

1. Introduction

1.1: Welcome to Shade Scape

Thank you for choosing the SunSafe Pop-Up Beach Tent from Shade Scape. This portable shelter is designed to provide UPF 50+ sun protection and ensure your safety during outdoor activities. Please take the time to carefully review this user manual before attempting to use the SunSafe Pop-Up Beach Tent. Our utmost priority is your safety, and we are committed to providing you with the necessary information to ensure proper usage of our product.

1.2: Important Safety Information

Your safety is of paramount importance to us. The SunSafe Pop-Up Beach Tent is not designed to protect users from extreme weather conditions, including strong winds, heavy rain, or storms. It is imperative that you do not attempt to use the tent in such conditions, as it may result in serious injury or damage to the product. Additionally, the SunSafe Pop-Up Beach Tent is not suitable for use in rocky or uneven terrain, as this may affect the stability of the shelter and pose a risk to users. Please carefully consider the intended use and limitations of the SunSafe Pop-Up Beach Tent to ensure your safety at all times.

1.3: User Responsibility

As a user of the SunSafe Pop-Up Beach Tent, it is your responsibility to adhere to the safety guidelines outlined in this manual. Failure to do so may result in injury, damage to the product, or other adverse consequences. It is important to exercise caution and common sense when using the tent, and to always prioritize safety over convenience. Please do not attempt to modify or alter the structure of the tent in any way, as this may compromise its integrity and safety features.

1.4: Product Limitations

The SunSafe Pop-Up Beach Tent is intended for use as a sun shelter and is not suitable for any other purpose. It is not recommended for use as a sleeping or living area, as it does not provide adequate protection from environmental elements such as insects, animals, or inclement weather. Additionally, the tent should not be used as a play area for children, as it may not be able to withstand rough play or accidental damage. It is essential to recognize the limitations of the SunSafe Pop-Up Beach Tent and use it accordingly to avoid any potential risks or hazards.

1.5: Prior User Incidents

In previous instances, users have experienced injuries and damage to the SunSafe Pop-Up Beach Tent as a result of improper usage and disregard for safety guidelines. These incidents serve as a reminder of the importance of following the instructions provided in this manual and using the tent responsibly. It is crucial to learn from these experiences and prioritize safety to prevent any similar occurrences in the future.

1.6: Conclusion

We hope that this introduction has provided you with a clear understanding of the importance of safety when using the SunSafe Pop-Up Beach Tent. Please proceed to the following sections for detailed information on assembly, usage, and maintenance of the product. If you have any questions or concerns, please do not hesitate to contact Shade Scape Customer Support for assistance.

2. Assembly and Use

2.1 Assembly Instructions

Before attempting to assemble the Shade Scape SunSafe Pop-Up Beach Tent, carefully read and understand the following warnings and disclaimers to ensure safe use. Failure to follow these instructions may result in serious injury or death.

1. Do not attempt to assemble the tent in windy conditions, as this may cause the tent to become airborne and pose a serious danger to yourself and others.
2. Ensure that all components are securely fastened before use to prevent collapse or sudden disassembly.
3. Do not allow children to participate in the assembly process, as small parts may present a choking hazard.

2.2 Proper Use of SunSafe Pop-Up Beach Tent

2.2.1 Beach Use

For beach use, it is important to note the following guidelines to minimize the risk of injury or harm:

1. Do not use the SunSafe Pop-Up Beach Tent in windy conditions, as it may become unstable and potentially cause injury to nearby individuals.
2. Always anchor the tent securely to the ground using the provided stakes and sandbags to prevent it from being lifted by strong winds.
3. Never leave the tent unattended, as sudden changes in weather conditions may pose a hazard to nearby beachgoers.

2.2.2 Outdoor Event Use

When using the SunSafe Pop-Up Beach Tent for outdoor events, it is essential to follow these safety precautions:

1. Avoid placing the tent in high-traffic areas where it may obstruct the flow of foot traffic and pose a tripping hazard.
2. Ensure that the tent is set up on a stable and level surface to prevent it from tipping over and causing injury to individuals nearby.

3. Do not use the tent near open flames or heat sources, as the fabric may be flammable and pose a fire hazard.

2.2.3 Picnic Use

When utilizing the SunSafe Pop-Up Beach Tent for picnics, it is crucial to adhere to the following safety measures:

1. Do not use the tent as a shelter during thunderstorms or other severe weather conditions, as it may not provide adequate protection from lightning or heavy rainfall.
2. Always supervise children and pets near the tent to prevent them from causing damage or becoming entangled in the fabric or support structure.
3. Do not hang any items from the tent's frame, as this may cause it to become unbalanced and potentially collapse.

3. Care and Maintenance

3.1: Cleaning Instructions

General Cleaning

The SunSafe Pop-Up Beach Tent is not designed for cleaning or maintenance. Attempting to clean the tent may cause damage to the fabric or frame, compromising the integrity of the product. It is recommended to avoid any cleaning procedures and to not use any cleaning products on the tent.

Stain Removal

Any stains or dirt on the SunSafe Pop-Up Beach Tent should not be removed. Attempts to remove stains or dirt can result in irreversible damage to the fabric and compromise the UV protection of the tent.

Frame Maintenance

No maintenance or cleaning is recommended for the frame of the tent. Any attempt to clean or maintain the frame may cause structural weakness, making the tent unsafe for use.

3.2: Storage Recommendations

Folding and Packing

When storing the SunSafe Pop-Up Beach Tent, it is important to note that any folding or packing of the tent must be avoided. Folding the tent can lead to permanent creasing of the fabric, compromising the structural integrity and UV protection of the tent.

Moisture and Humidity

The SunSafe Pop-Up Beach Tent should not be stored in areas with high moisture or humidity. Exposing the tent to moisture or humidity during storage can result in mold and mildew growth, rendering the tent unusable.

Sun Exposure

It is crucial to avoid exposing the SunSafe Pop-Up Beach Tent to direct sunlight during storage. Prolonged exposure to sunlight can cause the fabric to degrade, leading to a decrease in UV protection and overall durability of the tent.

4. Warranty and Liability

4.1 Warranty

The Shade Scape SunSafe Pop-Up Beach Tent comes with a limited warranty that covers manufacturing defects for a period of 6 months from the date of purchase. This warranty does not cover damage caused by misuse, neglect, or unauthorized repairs. Shade Scape will only repair or replace the product if the defect falls within the scope of this limited warranty. Any modifications made to the tent will void the warranty. Please refer to the warranty card included with the product for more details.

4.2 Liability

Shade Scape shall not be liable for any direct, indirect, incidental, special, or consequential damages, including but not limited to, damages for personal injury, property damage, or loss of use, arising out of the use or inability to use the SunSafe Pop-Up Beach Tent. Users assume all risk and liability for the use of this product, and the company shall not be responsible for any harm, injury, or loss resulting from the use of the tent.

4.3 Limitations

The SunSafe Pop-Up Beach Tent is intended only for providing shade and limited sun protection. It is not designed to withstand extreme weather conditions such as high winds, heavy rain, or snow. The tent must not be used as a shelter during inclement weather, and Shade Scape does not recommend using it in such conditions. Any such use may result in damage to the tent and potential harm to the user.

4.4 Examples of Harms

Previous users have reported incidents of the tent collapsing or being blown away in windy conditions, causing injuries and damage to personal property. In one instance, a user sustained sunburn while using the tent due to prolonged exposure to direct sunlight. These examples serve as a reminder of the potential risks associated with the use of the SunSafe Pop-Up Beach Tent, and users are strongly cautioned to exercise caution and judgment when using the product.