

Trailblazer Compact Cookware Set

1. Introduction	3
1.1: About Campchef	3
1.2: Product Overview	3
2. Getting Started	4
2.1: Unboxing the Trailblazer Compact Cookware Set	4
2.2: Setting Up the Cookware	4
3. Operating Instructions	5
3.1: Using the Frying Pan	5
3.2: Using the Pot	5
4. Maintenance and Care	6
4.1: Cleaning the Cookware	6
4.2: Storing the Cookware	6
5. Troubleshooting	8
5.1: Common Issues	8
6. Warranty Information	10
6.1 Warranty Coverage	10
6.2 How to Obtain Warranty Service	10
6.3 Exclusions and Limitations	10
6.4 Registering Your Product	10
6.5 Warranty Claim Process	10
6.6 Obtaining Replacement Parts	10

1. Introduction

1.1: About Campchef

Welcome to the world of outdoor cooking with Campchef! Since 1990, Campchef has been committed to providing high-quality outdoor cooking equipment for all your adventure needs. Whether you're a seasoned outdoor chef or a beginner, Campchef has everything you need to make delicious meals in the great outdoors. Our products are designed to be durable, lightweight, and easy to use, so you can focus on enjoying your camping experience without worrying about your cookware.

1.2: Product Overview

The Trailblazer Compact Cookware Set is the perfect companion for your outdoor adventures. This lightweight and versatile set includes a sturdy, non-stick frying pan and a durable pot with a folding handle for easy storage. The pot also comes with a lid, so you can easily simmer, boil, or cook your favorite dishes. The set also includes a spatula and a spoon, so you have all the utensils you need to whip up a delicious meal in the wilderness. With its compact design, the Trailblazer cookware set is easy to pack and transport, making it an essential addition to any camping trip.

2. Getting Started

2.1: Unboxing the Trailblazer Compact Cookware Set

Congratulations on your purchase of the Campchef Trailblazer Compact Cookware Set! You are now one step closer to enjoying delicious meals during your outdoor adventures. When you unbox the cookware set, you will find the following items:

1. Frying pan
2. Pot
3. Utensils (spatula, ladle, and serving spoon)
4. Carrying bag

Before using the cookware set, please ensure that all the items listed above are included in the package. If any items are missing, please contact Campchef customer support for assistance.

2.2: Setting Up the Cookware

Now that you have unboxed the Trailblazer Compact Cookware Set, it's time to set it up for use. Follow these simple steps to get started:

1. Inspect the cookware for any signs of damage. If you notice any dents, scratches, or other issues, please refrain from using the cookware and contact Campchef customer support for further instructions.
2. Wash the cookware and utensils with mild soap and water. Rinse thoroughly to remove any residue from the manufacturing process.
3. Once cleaned, dry the cookware and utensils completely before packing them back into the carrying bag. This will help prevent any moisture-related issues such as rust.
4. The Trailblazer Compact Cookware Set is now ready for use! Pack it in your backpack or camping gear, and you're all set for outdoor cooking adventures.

3. Operating Instructions

3.1: Using the Frying Pan

The Trailblazer Compact Cookware Set comes with a durable and non-stick frying pan, perfect for cooking up delicious meals on your outdoor adventures. To use the frying pan, follow these simple steps:

1. Place the frying pan on top of your camp stove or over the campfire, ensuring it is securely positioned.
2. Add a small amount of cooking oil or butter to the pan and allow it to heat up.
3. Once the pan is hot, add your desired ingredients and cook to perfection.
4. When finished, allow the frying pan to cool down before cleaning it with mild soap and water.

Remember to always use heat-resistant gloves when handling the hot frying pan. And be sure to use utensils with non-scratch features to avoid damaging the non-stick coating.

3.2: Using the Pot

The Trailblazer Compact Cookware Set includes a versatile and compact pot, perfect for boiling water, cooking soups, and making stews while enjoying the great outdoors. To use the pot, follow these simple instructions:

1. Place the pot on top of your camp stove or over the campfire, ensuring it is securely positioned.
2. Add the desired amount of water or cooking liquid to the pot and bring it to a boil.
3. Once the liquid is boiling, add your ingredients and cook according to your recipe.
4. When finished, allow the pot to cool down before cleaning it with mild soap and water.

The pot features heat-resistant handles for safe and easy handling. Always use caution when handling hot cookware to avoid burns.

4. Maintenance and Care

4.1: Cleaning the Cookware

To ensure the longevity and performance of your Trailblazer Compact Cookware Set, it is important to clean it properly after each use. Follow these simple steps to keep your cookware in top condition:

1. **Hand wash only:** To clean the cookware, use a mild dish soap and warm water. Do not use abrasive cleaners or scrubbers as they can damage the non-stick coating.
2. **Rinse thoroughly:** After washing, rinse the cookware thoroughly to remove any soap residue.
3. **Dry completely:** Once clean, dry the cookware completely with a soft cloth to prevent water spots and maintain the non-stick performance.
4. **Avoid dishwasher:** The Trailblazer Compact Cookware Set is not dishwasher safe. Hand wash only to preserve the quality of the cookware.
5. **Avoid metal utensils:** To prevent scratching the non-stick surface, avoid using metal utensils when cooking with the Trailblazer Compact Cookware Set.
6. **Clean utensils:** If your utensils become dirty during use, hand wash them with mild dish soap and warm water before storing them with the cookware.

By following these cleaning instructions, you can ensure that your Trailblazer Compact Cookware Set remains in great condition for many camping trips to come.

4.2: Storing the Cookware

Proper storage of the Trailblazer Compact Cookware Set is essential to protect it from damage and maintain its quality. Follow these tips for storing your cookware:

1. **Dry thoroughly:** After cleaning, ensure that the cookware and utensils are completely dry before storing them. Any moisture left on the cookware can lead to corrosion or damage.
2. **Use the included carry bag:** The Trailblazer Compact Cookware Set comes with a convenient carry bag for easy storage and transport. After drying, place the cookware and utensils in the bag to keep them together and protected.

3. **Store in a cool, dry place:** To prevent damage from humidity and temperature fluctuations, store the cookware in a cool, dry place. Avoid storing it in direct sunlight or near heat sources.
4. **Avoid stacking heavy items on top:** When storing the cookware, avoid stacking heavy items on top of it to prevent warping or damage.
5. **Inspect before use:** Before each camping trip, inspect the cookware and utensils for any signs of damage or wear. If any issues are found, discontinue use until the cookware has been inspected and deemed safe.

Following these storage guidelines will help to ensure that your Trailblazer Compact Cookware Set is ready for your next outdoor adventure.

5. Troubleshooting

5.1: Common Issues

Hey there, Trailblazer Compact Cookware Set owner! If you're having trouble with your cookware, don't worry - we've got your back. Below are some common issues you might encounter and how to fix them.

- **Issue 1: Uneven Cooking**

- If you're noticing that your food is cooking unevenly, make sure your cookware is placed on a level surface. Uneven surfaces can cause the heat to distribute unevenly, resulting in some parts of your food cooking faster than others.
- Also, try adjusting the position of the pot or frying pan on your stove to ensure that it is getting the most even heat distribution possible.

- **Issue 2: Stuck Food**

- Is your food sticking to the surface of your Trailblazer Compact Cookware? This can happen if the cookware isn't seasoned properly. Try applying a thin layer of cooking oil to the surface before using it to prevent food from sticking.
- If food is already stuck, allow the cookware to cool down and then soak it in warm, soapy water for a few hours. After soaking, use a gentle scrubbing pad to remove the stuck-on food.

- **Issue 3: Damaged Utensils**

- Accidents happen, and if your utensils are damaged, it can make cooking a bit more challenging. If you notice any issues with the included utensils, such as bent or broken pieces, make sure to stop using them to avoid any safety hazards.
- Contact Campchef customer support for information on how to obtain replacement utensils.

- **Issue 4: Rust on Cookware**

- Your Trailblazer Compact Cookware is durable, but it's important to take care of it to prevent rust from forming. After each use, make sure to thoroughly dry the cookware to avoid any moisture buildup that could lead to rust.
- If you do notice rust forming, gently scrub the affected area with a gentle abrasive pad and warm, soapy water. After cleaning, make sure to thoroughly dry the

cookware to prevent further rusting.

- **Issue 5: Overheating**

- It's important to use the Trailblazer Compact Cookware within the recommended temperature range. Overheating the cookware can cause damage to the surface and may affect its performance.
- Always refer to the provided user manual for the recommended temperature range and make sure to adjust your heat source accordingly.

Remember, if you encounter any issues not listed here or if the troubleshooting tips provided don't solve your problem, feel free to reach out to Campchef customer support for further assistance.

6. Warranty Information

6.1 Warranty Coverage

Campchef offers a limited lifetime warranty on the Trailblazer Compact Cookware Set. This warranty covers defects in materials and workmanship under normal use for the lifetime of the product. It does not cover damage caused by misuse, abuse, or normal wear and tear.

6.2 How to Obtain Warranty Service

In the event of a warranty claim, please contact Campchef Customer Service at 1-800-650-2433 or email support@campchef.com. A representative will guide you through the process and provide instructions for returning the product if necessary.

6.3 Exclusions and Limitations

This warranty does not cover damage resulting from accidents, misuse, or unauthorized repair. It also does not cover incidental or consequential damages, so the above limitation or exclusion may not apply to you.

6.4 Registering Your Product

To ensure efficient processing of warranty claims, we recommend registering your Trailblazer Compact Cookware Set on our website within 30 days of purchase. Simply enter your product information, proof of purchase, and contact details to activate your warranty.

6.5 Warranty Claim Process

When making a warranty claim, please provide the following information:

- Proof of purchase (receipt or order confirmation)
- Description of the issue
- Contact information

6.6 Obtaining Replacement Parts

If any part of the Trailblazer Compact Cookware Set is found to be defective, Campchef will provide a replacement part free of charge under the terms of this warranty.