

# 360X Action Camera

1. How to Turn On Camera .....	3
1.1: Step 1: Inserting Battery .....	3
1.2: Step 2: Pressing Power Button .....	3
2. Recording Video .....	4
2.1: Choosing Video Quality .....	4
2.2: Starting and Stopping Recording .....	4
3. Taking Photos .....	5
Capturing the perfect shot .....	5
Advanced settings .....	5
Using the app .....	5
4. Using Waterproof Casing .....	6
4.1 Opening the Waterproof Casing .....	6
4.2 Inserting the Camera .....	6
4.3 Closing the Waterproof Casing .....	6
4.4 Testing the Waterproof Casing .....	6
4.5 Removing the Camera from the Waterproof Casing .....	6

# 1. How to Turn On Camera

---

## 1.1: Step 1: Inserting Battery

To power on your 360X Action Camera, you will first need to insert the battery. Locate the battery compartment on the bottom of the camera. Slide the latch in the direction of the arrow and lift the cover to reveal the battery compartment. Insert the rechargeable lithium-ion battery pack into the compartment, ensuring that the contacts align properly. Close the cover securely, making sure it clicks into place.

## 1.2: Step 2: Pressing Power Button

Once the battery is inserted, locate the power button on the top of the camera. The power button is labeled with a distinctive red icon. Press and hold the power button for a few seconds until the camera powers on. You will see the indicator light illuminate, indicating that the camera is now powered on and ready to capture your adventures.

## 2. Recording Video

---

### 2.1: Choosing Video Quality

To choose the video quality on your 360X Action Camera, first, ensure that the camera is powered on and in video mode. Use the Mode button located on the top of the camera to cycle through the available video quality options. The LED screen on the front of the camera will display the current video quality setting. The available video quality options for the 360X Action Camera are 720p, 1080p, and 4K. Select the desired video quality by pressing the Shutter button on the top of the camera. The selected video quality will be indicated on the LED screen.

### 2.2: Starting and Stopping Recording

To start recording a video on your 360X Action Camera, ensure that the camera is powered on and in video mode. Once in video mode, simply press the Shutter button on the top of the camera to start recording. The LED indicator light on the front of the camera will flash to indicate that recording is in progress. To stop recording, press the Shutter button again. The LED indicator light will stop flashing, indicating that the recording has stopped. Your video will be saved to the memory card in the selected video quality.

## 3. Taking Photos

---

### Capturing the perfect shot

To take photos with your 360X Action Camera, follow these simple steps:

1. Make sure the camera is turned on by pressing the Power button located on the top of the camera. The LED indicator light will turn on when the camera is ready to use.
2. To switch to photo mode, press the Mode button on the front of the camera until the Photo icon is displayed on the screen.
3. Once in photo mode, frame your shot using the 360-degree rotating lens. Ensure that the subject is centered for the best results.
4. When you are ready to take the photo, press the Shutter button located on the top of the camera. The camera will emit a beep sound to indicate that the photo has been captured.
5. To review your photos, switch to playback mode by pressing the Mode button until the Playback icon is displayed. You can then use the navigation buttons to scroll through your photos.

### Advanced settings

For advanced photo settings, you can access the Camera Settings menu by pressing the Menu button. From here, you can adjust the photo resolution, white balance, and other settings to customize your photos according to your preference.

### Using the app

For a more convenient photo-taking experience, you can connect your 360X Action Camera to the Extremeview app on your smartphone. This will allow you to remotely control the camera, preview your shots, and easily transfer your photos to your device for sharing.

## 4. Using Waterproof Casing

---

The waterproof casing included with the 360X Action Camera is designed to allow you to capture all your high-speed water adventures without worry. Follow the steps below to properly use the waterproof casing of your camera:

### 4.1 Opening the Waterproof Casing

To open the waterproof casing, locate the latch on the side of the casing. Press down on the latch and simultaneously slide the back panel of the casing outwards. Make sure to do this in a dry environment to prevent any water from entering the casing.

### 4.2 Inserting the Camera

After opening the casing, carefully insert your 360X Action Camera into the designated slot, ensuring that all buttons and ports are properly aligned with the corresponding openings in the casing.

### 4.3 Closing the Waterproof Casing

Once the camera is securely in place, gently push the back panel of the casing back into position and make sure the latch locks into place to create a watertight seal.

### 4.4 Testing the Waterproof Casing

Before submerging the camera in water, it is important to perform a quick test to ensure the waterproof casing is properly sealed. Submerge the empty waterproof casing in a shallow body of water for a few minutes, then carefully inspect the inside for any signs of water leakage. If water is present, double-check the closure of the casing and try again.

### 4.5 Removing the Camera from the Waterproof Casing

To remove the camera from the waterproof casing, follow the steps in reverse, starting with the opening of the latch, sliding out the back panel, and carefully taking out the camera.

Remember to always check the condition of the casing and its seals before using it in water to prevent any damage to your 360X Action Camera.