

Upstream Moeller Quad

Power Supply Controls

PS ON



PS OFF



PS RESET



Current Setpoint 0.00

Current Readback 17.582

Voltage Readback 0.635

REF Readback 1.954

Polarity Switching

Supply Must Be
OFF and Current
Rdbk at 0 Amps

FORWARD



REVERSE



Interlocks & Alarms

- ☐ Input Power Fault
- ☐ Xmfr Fault
- ☐ Thy Overtemp Fault
- ☐ Rev Switch Overtemp Fault
- ☐ Rev Switch Fault
- ☐ DC Over Current Fault
- ☐ Ground Fault
- ☐ Remote Mode
- ☐ Open Door Fault
- ☐ Interlock #1 Fault
- ☐ Interlock #2 Fault
- ☐ External Safety Interlock
- ☐ Output Inhibit
- ☐ ZFCT Fault
- ☐ Local Stop Fault
- ☐ Crowbar Fault
- ☐ Firing Circuit Fault

Downstream Moeller Quad

Power Supply Controls

PS ON



PS OFF



PS RESET



Current Setpoint 0.00

Current Readback 5.861

Voltage Readback -0.029

REF Readback 9.768

Interlocks & Alarms

- ☐ Input Power Fault
- ☐ Xmfr Fault
- ☐ Thy Overtemp Fault
- ☐ Rev Switch Overtemp Fault
- ☐ Rev Switch Fault
- ☐ DC Over Current Fault
- ☐ Ground Fault
- ☐ Remote Mode
- ☐ Open Door Fault
- ☐ Interlock #1 Fault
- ☐ Interlock #2 Fault
- ☐ External Safety Interlock
- ☐ Output Inhibit
- ☐ ZFCT Fault
- ☐ Local Stop Fault
- ☐ Crowbar Fault
- ☐ Firing Circuit Fault