

Join Date: Apr 2005
 Location: Romania
 Posts: 28
 Downloads: 0
 Uploads: 0

hi,

I believe it might be parameter 6577,i am not sure because i have other fanuc,i found this on google search:
[h**p://www.machinetoolhelp.com/Repairing/orientation.html](http://www.machinetoolhelp.com/Repairing/orientation.html)

hope it helps,
 ddanutz

[Reply With Quote](#)

11-08-2006, 11:11 PM

#3

Factory Guy ◦

Registered

Join Date: Feb 2005
 Location: United States
 Posts: 53
 Downloads: 0
 Uploads: 0



We use parameter 4031 or 4077 but that is on 16 and 18 controllers.

[Reply With Quote](#)

11-15-2006, 01:03 PM

#4

harshgangrade ◦

Registered

Join Date: Nov 2006
 Location: india
 Posts: 14
 Downloads: 0
 Uploads: 0



use parameter no 6531
 calculation is 360 degree is represented by value 4096
 if you want to shift by say 180 degree you enter 2048 in this parameter
 if you want to shift by say 45 degree you enter 512 in this parameter

[Reply With Quote](#)

11-16-2006, 12:02 PM

#5

RRL ◦

Registered

Join Date: Jan 2006
 Location: United States
 Posts: 59
 Downloads: 0
 Uploads: 0

**Spindle Orientation parameter on Fanuc 0M**

The spindle orientation parameter on the Fanuc 0M is #6577.

I just did this for one of my customers!

Robin

[Reply With Quote](#)

Quick Navigation

[Fanuc](#)[Top](#)[« Previous Thread](#) | [Next Thread »](#)