



If you want to know additional information which is not included on this Service Manual, Please refer to the SKP(Samsung Knowledge Portal) web site.

| Area | Web Site |
|------------------|---|
| North America | URL ; http://service.samsungportal.com |
| Latin America | URL ; http://latin.samsungportal.com |
| CIS | URL ; http://cis.samsungportal.com |
| Europe | URL ; http://europe.samsungportal.com |
| China | URL ; http://china.samsungportal.com |
| Asia | URL ; http://asia.samsungportal.com |
| Mideast & Africa | URL ; http://mea.samsungportal.com |

This Service Manual is a property of Samsung Electronics Co.,Ltd.
Any unauthorized use of Manual can be punished under applicable
International and/or domestic law.

© Samsung Electronics Co., Ltd. **FEB. 2009**
Printed in Korea

SERVICE MANUAL

BD-P1600



Blu-Ray Disc Player

Chassis : MONDRIAN

BASIC : BD-P1600

Application Model
: BD-P1600

Application Area

: XAA, XAC, XAX, XAZ, XAP,
XAO, AFS

SERVICE Manual

Blu-Ray Disc Player



Contents

- 1. Precautions
- 2. Product Specification
- 3. Disassembly and Reassembly
- 4. Trouble Shooting
- 5. Exploded View and Parts List
- 6. PCB Diagrams
- 7. Schematic Diagrams

CONTENTS

| | |
|--|-------------------|
| 1. Precautions | 1-1 ~ 1-6 |
| 1-1 Safety Precautions | (1-1) |
| 1-2 Servicing Precautions | (1-3) |
| 1-3 ESD Precautions | (1-4) |
| 1-4 Handling the optical pick-up | (1-5) |
| 2. Product Specification | 2-1 ~ 2-6 |
| 2-1 Product Specification | (2-1) |
| 2-2 Chassis Product Specification | (2-5) |
| 2-3 Option Product Specification | (2-6) |
| 3. Disassembly and Reassembly | 3-1 ~ 3-12 |
| 3-1 Cabinet and PCB | (3-1) |
| 3-2 PCB Location | (3-7) |
| 3-3 Deck | (3-8) |
| 4. Trouble Shooting | 4-1 ~ 4-30 |
| 4-1 Trouble Shooting | (4-2) |
| 4-2 Software Update | (4-27) |
| 5. Exploded View and Parts List | 5-1 ~ 5-8 |
| 5-1 Cabinet Assembly | (5-2) |
| 5-2 Deck Parts | (5-4) |
| 5-3 Electrical Parts List | (5-6) |
| 6. PCB Diagrams | 6-1 ~ 6-10 |
| 6-1 Wiring Diagram | (6-2) |
| 6-2 Main PCB | (6-3) |
| 6-3 S.M.P.S PCB | (6-6) |
| 6-4 Front key PCB | (6-8) |
| 6-5 Touch Key PCB | (6-9) |
| 7. Schematic Diagrams | 7-1 ~ 7-22 |
| 7-1 All block Diagram | (7-2) |
| 7-2 Power | (7-3) |
| 7-3 S.M.P.S (S.M.P.S PCB) | (7-5) |

CONTENTS

| | |
|--|---------------|
| 7-4 Anlog Audio (2ch)/Video (CVBS, Component)(Main PCB) | (7-6) |
| 7-5 NAND Flash, FlexOneNand (Main PCB) | (7-8) |
| 7-6 HDMI Transmitter (SIL9134)(Main PCB) | (7-9) |
| 7-7 7440 Boot Strap Option (Main PCB) | (7-10) |
| 7-8 7440 EBI_ADDR, EBI_DATA (Main PCB) | (7-11) |
| 7-9 7440 Clocks, BBS (Main PCB) | (7-12) |
| 7-10 7440 Power, Decoupling (Main PCB) | (7-13) |
| 7-11 DDR2 BANK0, BANK1 (Main PCB) | (7-14) |
| 7-12 Front Micom (Main PCB) | (7-15) |
| 7-13 Ethernet, USB, S-ATA, P-ATA (Main PCB) | (7-16) |
| 7-14 GPIO Block (Main PCB) | (7-17) |
| 7-15 Main Power (Main PCB) | (7-18) |
| 7-16 BCM7620 (F/E)(Main PCB) | (7-19) |
| 7-17 Front Key (Front PCB) | (7-20) |
| 7-18 Touch Key PCB (Touch PCB) | (7-21) |