

Model	Date	Maple HUB SN	FW	Maple Sensor SN	Maple Lite SN	Testing Device	Maple HUB										Maple LTE										Maple Server																
							Onboarded S	FW (Before upgrade)	FW (After upgrade)	Motion	Alarm detection		LTE battery charge S	AC power to AC power switching	Battery power to AC power switching	Attach the Hub to a LTE Box	Hub online by jive (After upgrade)	FW (Before upgrade)	FW (After upgrade)	% Battery	LTE to WiFi switching	WiFi to LTE switching	LTE Box Battery SOC	LTE battery charging	AC power to AC power switching	Battery power to AC power switching	On-boarded	FW (Before upgrade)	FW (After upgrade)	% Battery	Contact sensor		Temperature sensor			Alarm detection		Decreased brightness	Increased brightness	Accelerometer (+/-) g	Water leak detection	Temper button	Motion
											Smoke [T1]	CO [T4]																															
BH001	18/03/2024	AB612797d7c1c11	1.2.36_668ba08	NA	NA	https://tiny.cc/meyarw	V	V	V	V	V	V	V	V	V	NA	NA	NA	NA	NA	NA	NA	V	NA	NA	NA	NA	Move away	Move closer	Check Temperature Rise	High temperature detection	Low temperature detection	Smoke [T1]	CO [T4]	NA	NA	NA	NA	NA	NA	NA	NA	