



# **USB Host SDK for OS-9**

## **Version 1.0**

[www.radisys.com](http://www.radisys.com)

World Headquarters  
5445 NE Dawson Creek Drive • Hillsboro, OR  
97124 USA  
Phone: 503-615-1100 • Fax: 503-615-1121  
Toll-Free: 800-950-0044

International Headquarters  
Gebouw Flevopoort • Televisieweg 1A  
NL-1322 AC • Almere, The Netherlands  
Phone: 31 36 5365595 • Fax: 31 36 5365620

RadiSys Microwave Communications Software Division, Inc.  
1500 N.W. 118th Street  
Des Moines, Iowa 50325  
515-223-8000

Revision A  
April 2001

## Copyright and publication information

This manual reflects version 1.0 of USB Host SDK for OS-9.

Reproduction of this document, in part or whole, by any means, electrical, mechanical, magnetic, optical, chemical, manual, or otherwise is prohibited, without written permission from RadiSys Microware Communications Software Division, Inc.

## Disclaimer

The information contained herein is believed to be accurate as of the date of publication. However, RadiSys Corporation will not be liable for any damages including indirect or consequential, from use of the OS-9 operating system, Microware-provided software, or reliance on the accuracy of this documentation. The information contained herein is subject to change without notice.

## Reproduction notice

The software described in this document is intended to be used on a single computer system. RadiSys Corporation expressly prohibits any reproduction of the software on tape, disk, or any other medium except for backup purposes. Distribution of this software, in part or whole, to any other party or on any other system may constitute copyright infringements and misappropriation of trade secrets and confidential processes which are the property of RadiSys Corporation and/or other parties. Unauthorized distribution of software may cause damages far in excess of the value of the copies involved.

---

April 2001  
Copyright ©2001 by RadiSys Corporation.  
All rights reserved.

EPC, INtime, iRMX, MultiPro, RadiSys, The Inside Advantage, and ValuPro are registered trademarks of RadiSys Corporation. ASM, Brahma, DAL, DAQ, MultiPro, SAIB, Spirit, and ValuePro are trademarks of RadiSys Corporation.

DAVID, MAUI, OS-9, and OS-9000, are registered trademarks of RadiSys Microware Communications Software Division, Inc. FasTrak, Hawk, SoftStax, and UpLink are trademarks of RadiSys Microware Communications Software Division, Inc.

† All other trademarks, registered trademarks, service marks, and trade names are the property of their respective owners.

---

# Table of Contents

---

## **Chapter 1: Getting Started with USB Host for OS-9** **7**

---

- 8 System Overview
- 9 System Requirements
  - 9 Windows Development Platform Hardware Requirements
  - 9 Windows Development Platform Software Requirements
  - 10 OS-9 Target System/USB Host Hardware Requirements
- 11 Installing the Software
  - 11 Installing to the Windows Development Platform
  - 13 Installing to the OS-9 Target System/USB Host
    - 13 USB Host Module List
    - 15 Loading and Starting the USB Host Software
- 18 Example Commands
  - 18 Checking for USB Devices
  - 18 Getting Device Information
  - 19 Checking for Data Transmission
- 20 Mouse Through MAUI

## **Chapter 2: Using USB Host for OS-9** **23**

---

- 24 Overview
- 26 Hardware Controller Driver
  - 26 Bus Methods Structure
    - 26 Bus Methods Structure Fields
  - 27 Pipe Methods Structure
    - 27 Bus Methods Structure Fields
- 29 USB Management Driver
  - 29 Bus Explore
  - 31 Plug and Play

31	Match
32	Attach
32	Detach
33	Registering with usbman
35	Logical Device Drivers
35	LDD Initialization
35	LDD De-Initialization
36	Suggested OS-9 Interface
36	Setstats
36	Getstats
36	Plug-n-play
37	Standard OS-9 LDD Drivers
37	USB Mouse
38	Data Format
38	Use With MAUI
39	Testing the USB Mouse
40	USB Keyboard
40	Data Format
41	Use With MAUI
42	Testing the USB Keyboard
43	USB Printer
44	Testing the USB Printer
45	Generic USB Driver
45	Plug-n-Play
45	Accessing Endpoints with UGEN
46	Testing UGEN
48	Reference API
61	User-State Daemon Process

## Chapter 3: USB Host API Reference

63

---

64	Pipe Functions List
65	Transfer Functions List
66	Interface Functions List

67	Device Functions List
68	Alphabetical Listing

## Chapter 4: USB Host for OS-9 Utilities 125

---

## Appendix A: Porting to the USB Host Stack 129

---

130	Writing the Logical Device Driver (LDD)
130	Creating a Directory Structure
132	Implementing your LDD
134	Additional File Information
135	Writing a Hardware Control Driver
135	Overview
135	Transfer Types
137	Bus Methods Structure
137	Calling usbman
138	Existing Drivers
139	Implementing the Driver
141	Testing the Driver



---

# Chapter 1: Getting Started with USB Host for OS-9

---

This chapter describes how to install and configure the USB Host SDK for OS-9 software on your Windows development platform and on your OS-9 target system. It includes the following sections:

- [System Overview](#)
- [System Requirements](#)
- [Installing the Software](#)
- [Example Commands](#)




MICROWARE SOFTWARE

# System Overview

**Figure 1-1** shows a typical development environment for using USB Host SDK for OS-9. It is recommended that you assemble and configure your development environment before software installation.

**Figure 1-1 USB Host Development Environment**





# System Requirements

---

## Windows Development Platform Hardware Requirements

Your Windows development platform must have the following minimum hardware characteristics:

- 250MB of free hard disk space
- The recommended amount of RAM for your particular operating system
- a CDROM drive
- a free serial port
- a free USB port
- an Ethernet network card (optional but recommended)
- access to an Ethernet network (optional but recommended)

## Windows Development Platform Software Requirements

The Windows development platform must have the following software installed:

- Enhanced OS-9
- USB Host SDK for OS-9 add-on
- Windows 95, 98, ME, 2000, or NT 4.0
- terminal emulation program



---

### Note

The terminal emulation program, Hyperterminal, ships with all Windows operating systems.

---

## OS-9 Target System/USB Host Hardware Requirements

Your OS-9 target system/USB Host reference board requires the following hardware:

- a free serial port
- an RS-232 null modem serial cable with 9-pin connectors
- a free USB port
- a standard USB cable
- a free Ethernet port (optional but recommended)
- access to an Ethernet network (optional but recommended)



---

### Note

Some USB Host Controllers require a non-cached memory shade.

---



---

### Note

To test the USB Host system, you will also need a standard USB device such as a mouse or printer and the appropriate cables.

---

# Installing the Software

---

## Installing to the Windows Development Platform

The **USB Host SDK for OS-9** software package is an add-on to Enhanced OS-9. Enhanced OS-9 must be installed on your Windows development platform before the USB Host software is installed.

To install Enhanced OS-9, insert the CD-ROM into your Windows development platform CD-ROM drive and follow the on-screen instructions. After Enhanced OS-9 is installed, you will be able to choose **USB Host SDK for OS-9** from the Add-Ons menu.



---

### For More Information

For detailed installation instructions, refer to the ***Getting Started with Microware Products*** manual. This manual is accessible via Acrobat Reader from the Enhanced OS-9 CD.

---



---

### Note

Copyright (c) 1998 The NetBSD Foundation, Inc.

All rights reserved.

This code is derived from software contributed to The NetBSD Foundation by Lennart Augustsson (lennart@augustsson.net) at Carlstedt Research & Technology. Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgement: This product includes software developed by the NetBSD Foundation, Inc. and its contributors.
4. Neither the name of The NetBSD Foundation nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE NETBSD FOUNDATION, INC. AND CONTRIBUTORS ``AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE FOUNDATION OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

---

## Installing to the OS-9 Target System/USB Host

Before installing the USB Host software onto your OS-9 target system/USB Host, you must complete the following steps:

- 
- Step 1. Assemble and configure your USB Host development environment hardware.
  - Step 2. Install Enhanced OS-9 and the **USB Host SDK for OS-9** software onto your Windows development platform.
  - Step 3. Create an OS-9 ROM Image and load it onto your OS-9 target system /USB Host.
  - Step 4. Boot your OS-9 Target System/USB Host to an OS-9 prompt. The OS-9 prompt must be accessible via your terminal emulation program.



### For More Information

Creating an OS-9 ROM Image, loading the image onto the target system, and booting to an OS-9 prompt is described in your target system's board guide. The board guides are accessible via Acrobat Reader from the Enhanced OS-9 CD.

---

## USB Host Module List

After installing the **USB Host SDK for OS-9** add-on package onto your Windows development platform, the following USB Host modules will be present on your system:

- USB Controller Driver

`C:\MWOS\OS9000\<PROCESSOR>\PORTS\<BOARD_PORT>\CMDS\BOOTOBSJS\usbhcd`

- USB Controller Driver Descriptor

`C:\MWOS\OS9000\<PROCESSOR>\PORTS\<BOARD_PORT>\CMDS\BOOTOBSJS\NULLFM\usbhcd`

- **USB Host Manager Driver**  
C:\MWOS\OS9000\<PROCESSOR>\CMDS\BOOTOBJ\USBH\usbman
- **USB Host Manager Driver Descriptor**  
C:\MWOS\OS9000\<PROCESSOR>\CMDS\BOOTOBJ\USBH\usb
- **USB Mouse Driver**  
C:\MWOS\OS9000\<PROCESSOR>\CMDS\BOOTOBJ\USBH\ums
- **USB Mouse descriptors**  
C:\MWOS\OS9000\<PROCESSOR>\CMDS\BOOTOBJ\USBH\um0  
C:\MWOS\OS9000\<PROCESSOR>\CMDS\BOOTOBJ\USBH\um1
- **USB Keyboard Driver**  
C:\MWOS\OS9000\<PROCESSOR>\CMDS\BOOTOBJ\USBH\ukbd
- **USB Keyboard Descriptor**  
C:\MWOS\OS9000\<PROCESSOR>\CMDS\BOOTOBJ\USBH\ukbd0
- **USB Generic Driver**  
C:\MWOS\OS9000\<PROCESSOR>\CMDS\BOOTOBJ\USBH\spugen
- **USB Generic Driver descriptors**  
C:\MWOS\OS9000\<PROCESSOR>\CMDS\BOOTOBJ\USBH\ugen0  
C:\MWOS\OS9000\<PROCESSOR>\CMDS\BOOTOBJ\USBH\ugen1
- **USB Printer Driver**  
C:\MWOS\OS9000\<PROCESSOR>\CMDS\BOOTOBJ\USBH\ulpd
- **USB Printer Descriptor**  
C:\MWOS\OS9000\<PROCESSOR>\CMDS\BOOTOBJ\USBH\ulp0
- **NullFM file manager**  
C:\MWOS\OS9000\<PROCESSOR>\CMDS\BOOTOBJ\nullfm



## Note

The drive letter, <processor> directory, and <board\_port> directory will vary depending on your particular installation.

## Loading and Starting the USB Host Software

The objective of this procedure is to move the USB Host modules, which are drivers and descriptors, from the Windows development platform onto the OS-9 target system/USB Host. There are several ways this can be accomplished and the following procedure describes only one method of accomplishing this task.

- Step 1. On the Windows development platform, open a text editor, such as Notepad, and create a text file list that includes the USB Host modules. Be sure there is only one module per line and that you include the full path.

Your final text file should look something like the following:

```
C:\MWOS\OS9000\<PROCESSOR>\PORTS\<BOARD_PORT>\CMDS\BOOTOBJS\usbhcd
C:\MWOS\OS9000\<PROCESSOR>\PORTS\<BOARD_PORT>\CMDS\BOOTOBJS\NULLFM\usbhc
C:\MWOS\OS9000\<PROCESSOR>\CMDS\BOOTOBJS\USBH\usbman
C:\MWOS\OS9000\<PROCESSOR>\CMDS\BOOTOBJS\USBH\usb
C:\MWOS\OS9000\<PROCESSOR>\CMDS\BOOTOBJS\USBH\ums
C:\MWOS\OS9000\<PROCESSOR>\CMDS\BOOTOBJS\USBH\um0
C:\MWOS\OS9000\<PROCESSOR>\CMDS\BOOTOBJS\USBH\um1
C:\MWOS\OS9000\<PROCESSOR>\CMDS\BOOTOBJS\USBH\ukbd
C:\MWOS\OS9000\<PROCESSOR>\CMDS\BOOTOBJS\USBH\ukbd0
C:\MWOS\OS9000\<PROCESSOR>\CMDS\BOOTOBJS\USBH\spugen
C:\MWOS\OS9000\<PROCESSOR>\CMDS\BOOTOBJS\USBH\ugen0
C:\MWOS\OS9000\<PROCESSOR>\CMDS\BOOTOBJS\USBH\ugen1
C:\MWOS\OS9000\<PROCESSOR>\CMDS\BOOTOBJS\USBH\ulpt
C:\MWOS\OS9000\<PROCESSOR>\CMDS\BOOTOBJS\USBH\ulp0
C:\MWOS\OS9000\<PROCESSOR>\CMDS\BOOTOBJS\nullfm
C:\MWOS\OS9000\<PROCESSOR>\CMDS\usbd
C:\MWOS\OS9000\<PROCESSOR>\CMDS\usbdevs
C:\MWOS\OS9000\<PROCESSOR>\CMDS\ugenstat
```



### Note

The drive letter, <processor> directory, and <board\_port> directory will vary depending on your particular installation.

- Step 2. Save this file as `usb_mods.ml` on your Windows system in a location of your choice.

- Step 3. On the Windows development platform, open a DOS shell. Using DOS commands, navigate to the directory where `usb_mods.ml` is located, and type the following DOS command:

```
% os9merge -z=usb_mods.ml>usb_mods
```

This creates a merged file called `usb_mods`. `usb_mods` will be located in the same directory that `usb_mods.ml` is located.

- Step 4. Load the `usb_mods` file onto the OS-9 target system/USB Host system's RAM.

From the Windows desktop, start Hawk by selecting **Start -> Programs -> Microware -> Enhanced OS-9 -> Microware Hawk IDE**.

From the **Target Menu**, select **Load**. Enter the IP address of your OS-9 target. In the Module dialog, push the navigation button and navigate to the location of the `usb_mods` file and select `usb_mods`. Press the **Load** button.



---

## Note

This procedure requires that the Hawk debugger daemons be loaded and running on the OS-9 target system. You can make this selection while building the OS-9 Rom Image.

---

- Step 5. Start the USB Host software by typing the following command from the terminal emulation window on the Windows development platform:

```
$ usbd &
```

The USB Host modules are now loaded and running on your OS-9 target system/USB Host.





---

**Note**

This procedure assumes that you have access to an Ethernet network for loading the USB Host software from the Windows development system to the target system. If you do not have access to a network, you can load the USB Host software via FTP across the serial connection using OS-9 commands and your terminal emulation program.

---

# Example Commands

---

## Checking for USB Devices

Once the USB Host software is loaded onto your OS-9 target system/USB Host, you can check the system for existing USB devices. To see what devices are plugged into the USB, type the following command in the terminal emulation program window.

```
$ usbdevs
```

Following is an example response from the command:

```
[1] -
[2] Address 2,  NOVATEK      : USB Mouse STD.
```

The above example shows a Root Hub with two ports as well as a mouse plugged into port two. The mouse has been assigned address 2.

## Getting Device Information

You can view information about USB devices on the system. For example, to learn more about the USB mouse device in the example above, type the following command in the terminal emulation program window:

```
$ usbdevs -a=2
```

Following is an example response from the command:

```
Address 2,  NOVATEK      : USB Mouse STD.    (vendor 1539, product 26737)
Device Descriptor:  max_packet 8, protocol 0, release 0.1, configurations 1
Config. Descriptor (1):  interfaces 1, value 1, iconfig 0
                        attributes 0xa0, max power 100 mA
Interface Descriptor 1:  alt. setting 0, num eps 1,
                        class 3, subclass 1, protocol 2, iInterface 0
```

## Checking for Data Transmission

You can determine if a USB device is sending data over the USB. For example, to determine if the USB mouse device in the example above is sending mouse data over the USB, type the following commands in the terminal emulation program window:

```
$ tmode nopause
$ dump /um0
```

After typing the commands, move the mouse. Following is an example response from the command:

Addr	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F	0	2	4	6	8	A	C	E
00000000	0800	0208	0002	08ff	0208	0301	0802	0008	.....															
00000010	0702	0809	0308	0b07	080c	0808	0b0b	0805	.....															
00000020	0608	090f	0808	1008	0611	0805	1208	0511	.....															
00000030	0805	1008	060e	0806	0b08	0709	0808	0608	.....															
00000040	0704	0807	0208	0701	0806	0108	0401	0803	.....															
00000050	0008	0200	08fe	0208	fe01	08fc	0308	fc02	.....	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~
00000060	08fd	0208	fd02	08fc	0009	fd00	09fc	0009	..}	..}	..}	..}	..}	..}	..}	..}	..}	..}	..}	..}	..}	..}	..}	..}
00000070	fc01	09fd	000d	fc01	0dfe	000d	fe00	0900	..}	..}	..}	..}	..}	..}	..}	..}	..}	..}	..}	..}	..}	..}	..}	..}
00000080	0009	fe01	09fd	0108	fe02	08ff	0108	0100	..~..}	..~..}	..~..}	..~..}	..~..}	..~..}	..~..}	..~..}	..~..}	..~..}	..~..}	..~..}	..~..}	..~..}	..~..}	..~..}

You can press Ctrl-C to exit.

# Mouse Through MAUI

To use a USB Mouse as a MAUI input device complete the following steps:

Step 1. Load the following special modules on the OS-9 target machine:

- Standard MAUI PS/2 Mouse protocol module.

```
C:\MWOS\OS9000\<PROCESSOR>\PORTS\<BOARD_PORT>\CMDS\BOOTOBJS\MAUI\mp_bsptr
```

- CDB Module that defines a USB Mouse for MAUI

```
C:\MWOS\OS9000\<PROCESSOR>\PORTS\<BOARD_PORT>\CMDS\BOOTOBJS\MAUI\cdb_usb
```

Step 2. Load the following MAUI modules on the OS-9 target. These modules are included with Enhanced OS-9.

```
OS9000/<PROCESSOR>/CMDS/maui
OS9000/<PROCESSOR>/CMDS/BOOTOBJS/maui_inp
OS9000/<PROCESSOR>/CMDS/BOOTOBJS/maui_win
OS9000/<PROCESSOR>/CMDS/BOOTOBJS/mfm
OS9000/<PROCESSOR>/CMDS/BOOTOBJS/maudev
OS9000/<PROCESSOR>/CMDS/BOOTOBJS/mauidrvr
OS9000/<PROCESSOR>/CMDS/MAUIDEMO/inp
```

Step 3. Type the following commands in the terminal emulation program window:

```
$ maui_inp &
$ tmode nopause
$ inp -i=/um0/mp_bsptr
```

Following is an example response from the command:

```
Opening device '/um0/mp_bsptr'
Send signal to 'inp' to end test
Expected device id 0x3fa8018
```

**Step 4. Move the mouse, or click buttons on the mouse.**

Following is an example response from the command:

```
+-----+
Device type:  +++ Pointer +++  Device ID:   0x3fa8018
| Sub-type:  0x1
|           INP_PTR_DOWN
| Button changed: 1
| Button status 1 (0x1)
| New position (0,0)
| Simulating keysym: INP_KEY_NULL (0x0)
+-----+
Device type:  +++ Pointer +++  Device ID:   0x3fa8018
| Sub-type:  0x2
|           INP_PTR_UP
| Button changed: 1
| Button status 0 (0x0)
| New position (0,0)
| Simulating keysym: INP_KEY_NULL (0x0)
+-----+
```

**Step 5. You can press Ctrl-C to exit**

---



---

## Chapter 2: Using USB Host for OS-9

---

This chapter provides a description of the OS-9 implementation for USB host. It includes the following sections:

- **Overview**
- **Hardware Controller Driver**
- **USB Management Driver**
- **Logical Device Drivers**
- **Standard OS-9 LDD Drivers**
- **User-State Daemon Process**



MICROWARE SOFTWARE

# Overview


The stack for the OS-9 implementation of USB Host consists of the following three main components:

- Hardware Controller Driver
- USB Management Driver
- Logical Device Drivers


Dividing the USB Host responsibilities between these components provides maximum modularity and flexibility, enables easy maintenance, and ensures performance. Each component is described in the following sections of this chapter.

**Figure 2-1** provides a visual overview of the USB Host stack. **Figure 2-2** shows the overall USB Host architecture as it relates to an OS-9 system.

**Figure 2-1 USB Host Stack**





**Figure 2-2 USB Host Architecture**

# Hardware Controller Driver

The hardware controller driver is responsible for initializing the USB hardware, scheduling transfers on the USB, managing the root hub, and notifying logical device drivers when a transfer has completed. This driver is given tasks to perform by `usbman` through the HCDI interface.

The HCDI interface is a series of function pointers into the Hardware Controller Driver to open and close pipes, allocate DMA memory, and perform transfers on the USB. There are two classifications of function pointers—bus methods and pipe methods.

## Bus Methods Structure

Following is the bus methods structure:

```
struct usbd_bus_methods {
    usbd_status      (*open_pipe)(struct usbd_pipe *pipe);
    void             (*soft_intr)(struct usbd_bus *);
    void             (*do_poll)(struct usbd_bus *bus);
    usbd_status      (*allocm)(struct usbd_bus *bus, usb_dma_t *dma,
                               u_int32_t bufsize);
    void             (*freem)(struct usbd_bus *bus, usb_dma_t *dma);
    struct usbd_xfer * (*allocx)(struct usbd_bus *bus);
    void             (*freex)(struct usbd_bus *bus, struct usbd_xfer *x);
};
```

## Bus Methods Structure Fields

<code>open_pipe</code>	Notifies the Hardware Controller Driver of a new transfer pipe to a device on the USB. This call modifies the <code>methods</code> and <code>methods_gp</code> fields of the given pipe structure.
<code>soft_intr, do_poll</code>	Not used.
<code>allocm</code>	Allocates memory suitable for DMA. This modifies the <code>dma</code> parameter. This will return <code>USBD_NORMAL_COMPLETION</code> on success, or <code>USBD_NOMEM</code> if no memory available.

<code>freem</code>	Frees memory allocated by <code>allocm</code> .
<code>allocx</code>	Allocates a transfer handle, and returns it.
<code>freex</code>	Frees a transfer handle allocated by <code>allocx</code> .

## Pipe Methods Structure

The pipe methods structure below is initialized after calling `open_pipe` in the bus methods structure.

```
struct usbd_pipe_methods {
    usbd_status      (*transfer)(usbd_xfer_handle xfer);
    usbd_status      (*start)(usbd_xfer_handle xfer);
    void             (*abort)(usbd_xfer_handle xfer);
    void             (*close)(usbd_pipe_handle pipe);
    void             (*cleartoggle)(usbd_pipe_handle pipe);
    void             (*done)(usbd_xfer_handle xfer);
};
```

## Bus Methods Structure Fields

<code>transfer</code>	Performs a transfer on the USB.
<code>start</code>	Starts the next transfer to the device.
<code>abort</code>	Aborts a transfer on the USB.
<code>close</code>	Closes a transfer. The transfer must not be active to call this (i.e. use <code>abort</code> first).
<code>cleartoggle</code>	Clears the data toggle back to 0.
<code>done</code>	Called after successfully completing a transfer.

The common name for the Hardware Controller Driver is `usbhcd` and the descriptor name is `usbhc`. This driver can be initialized with the `iniz` command (for example `iniz /usbcd`). Upon doing so, the Hardware Controller Driver will initialize the hardware and begin generating Start Of Frame packets every 1ms on the USB.

The hardware controller driver is the only board specific module required for the OS-9 USB Stack. Consequently, it is usually found in the `CMD5\BOOTOBJS` directory of the board `PORT` directory.

## USB Management Driver

---

The USB Management Driver, USBMAN, is a NULLFM driver that implements the management layer of the USB Host software. It has the following responsibilities:

- Maintains bus topology
- Implements USBDI interface for LDDs
- Performs USB explore
- Implements hub driver
- Manages plug-n-play

USBMAN communicates directly to the Hardware Controller Driver through the HCDI interface and other setstat/getstat calls.

USBMAN is located in the following directory:

```
OS9000 / <PROCESSOR> / CMDS / BOOTOBSJS / USBH / usman
```

The USBMAN descriptor is located in the following directory:

```
OS9000 / <PROCESSOR> / CMDS / BOOTOBSJS / USBH / usb
```

## Bus Explore

Most of the responsibilities of USBMAN revolve around a bus explore. The process is started by plugging in or removing a device from the USB. Below is a short description of the sequence of events in a bus explore:

- 
- Step 1. The hub driver, as a part of USBMAN, receives notification that its pipe has transferred data. The interrupt service routine for the hub driver sends a signal to the USB daemon process indicating that a USB explore is required.



---

## Note

The explore of the USB may take several seconds, thus necessitating the use of a process context for the explore.

---

- Step 2. USBD wakes up and performs an explore setstat into USBMAN. The explore code in USBMAN performs a depth first search on the USB starting with the root hub.
- Step 3. The explore code inspects each port on every hub, one at a time, to determine if any change is present. A change may be either something plugged in or removed, or an overcurrent condition.
- Device Removed

If a device was removed, the `detach` LDD routine is called for the driver that is assigned to the device. The control pipe is then closed, and any memory is removed. If the device was a hub, then each downstream device will have its `detach` LDD routine called, followed by closing the control pipe and memory reclamation.
  - Device Inserted

If a device was inserted, USBMAN opens a control pipe and gathers basic information about the device. USBMAN then attempts to match an available LDD to this device using the `match` routine. If a driver matches, then the `attach` LDD routine is called, and this LDD is no longer considered available.
  - Overcurrent

If a port on a hub is overcurrent, it is treated as if the device was removed. However, the port may not be used again unless the entire hub is removed from the USB and re-inserted.

USB Addresses are assigned by USBMAN. There is no rule that a particular device will always be assigned a particular address. In addition, there is no order for matching a driver to a new device.

## Plug and Play

Plug and play is accomplished in the OS-9 USB Host stack through a `usbman` callout mechanism. `usbman` makes this call to one of three possible functions: `match`, `attach`, or `detach`. Essentially, the call is initiated when there is a device modification; `usbman` recognizes the modification and calls the appropriate function to notify the LDD.

For example, suppose a device were removed from USB. At this point, `usbman` would call the `detach` function, which would then tell the available LDD to change the device information.

More information on the `match`, `attach`, and `detach` functions is provided in the following sections.

### Match

`match` is called by `usbman` when there is an attempt to assign a device on the USB to an available LDD. This function is called after a device is plugged into the bus or after a driver registers with `usbman`.

In addition, `match` is passed as a device structure and an interface structure. Both of these represent the current state of the device on the USB. The `match` routine should look at these two parameters (device structure and interface structure) to determine whether or not the driver can communicate with the device.

Below is a sample prototype of the `match` function:

```
int os9_match(struct usbd_device *dev,
usbd_interface_handle iface)
```

The `match` function may perform transfers on the USB over the control pipe, since that has already been established by `usbman`. Such transfers would likely be to retrieve endpoint or vendor-specific descriptors. The configuration and interface for the device should not be set at this time. `usbman` will loop on each interface in a configuration (for each configuration).

The `match` function should return 0 if the device does not match what the driver expects. If the driver can communicate with the USB device, the `match` function should return any non-zero value.

## Attach

The `attach` function is called by `usbman` after a successful call to the `match` function. Attach should open any relevant transfer pipes and perform any other setup required to initialize the device. This function will return a value from the `usb_status` enumerated type (located in `usb.h`). Below is a sample prototype for the `attach` function.

```
usb_status os9_attach(usbd_device_handle dev,
usb_interface_handle iface)
```




---

### Note

If the `attach` function returns an error, the `detach` function will not be called. This means that the `attach` function must properly deallocate resources allocated prior to the error condition.

---

## Detach

The `detach` function is called by `usbman` if the device is removed from the USB, or if the driver is de-registering itself with `usbman`. This function is responsible for deallocating any resources acquired in the `attach` routine. Normally, this means closing pipes and freeing memory. Below is an example `detach` function prototype:

```
usb_status os9_detach(usbd_device_handle dev)
```



## Registering with usbman

The following routines perform plug and play on the USB for OS-9. These routines are provide a way for `usbman` to call back into the LDD. Each LDD registers its functions with `usbman` when it initializes. Below is the plug and play structure followed by a brief description of each field.

```
typedef struct {
    usbd_status (*detach)(struct usbd_device *dev);
    usbd_status (*attach)(struct usbd_device *dev, usbd_interface_handle iface);
    int (*match) (struct usbd_device *dev, usbd_interface_handle iface);
    void *gp; /* ldd global pointer */
    void *dev_data; /* (ldd) device specific data */
} usbd_ldd_t;
```

`detach`

This is called when a device is removed from the USB. This routine should close any interrupt, bulk, or isochronous pipes and any other resources allocated in the `attach` routine. `usbman` will close the control pipe.

`attach`

This is called after a successful return from `match`. This routine should open any pipes required for this device to function. It may also perform transfers over the control pipe.

`match`

This routine will determine if the given device and interface are appropriate for this LDD. If no match is possible, then return `UMATCH_NONE`. Otherwise, return `UMATCH_IFACECLASS`. This routine may also perform transfers over the control pipe. However, do not attempt to change the interface. If the given interface, `iface`, is not suitable, return `UMATCH_NONE`. The `usbman` explore routine will iterate over all interfaces.

`gp`

This is the LDD global pointer, and should be set properly by the LDD before registering the `attach/match/detach` routines with `usbman`.

`dev_data`

This is for specific use by the LDD. In some circumstances, it is useful to place information here in the `attach` routine.

## Logical Device Drivers

---

A Logical Device Driver (LDD) implements code to support a particular USB device like a mouse, keyboard, or printer. It is intended that each LDD support the standard OS-9 interface as much as possible. These drivers interface to USBMAN using the USBDI interface. LDDs may use any OS-9 file manager, including NULLFM.

### LDD Initialization

Each LDD must perform the following steps once during initialization:

- 
- Step 1. Open `/usb`. This opens a path to USBMAN so that this LDD may use the USBDI interface.
  - Step 2. Perform a `GS_USB_USBMAN_IFACE` `getstat` to retrieve function pointers that implement the USBDI interface.
  - Step 3. Perform a `SS_USB_LDD_METHODS` `setstat` to register attach, match, detach routines with USBMAN.
- 

### LDD De-Initialization

Perform the following steps to de-initialize an LDD:

- 
- Step 1. Perform `SS_USB_LDD_METHODS` `setstat` (with `enable` field set to 0) to remove registration with USBMAN.
  - Step 2. Close path to `/usb`.
-

## Suggested OS-9 Interface

It is suggested that each LDD support the standard OS-9 interface. Below is a list of setstats/getstats that each LDD should implement, if possible.

### Setstats

SS_SENDSIG	Send signal on data registration.
SS_RELEASE	Remove SS_SENDSIG registration.

### Getstats

SS_READY	Return number of bytes ready for read.
----------	--

## Plug-n-play

Each LDD must register an attach, match, and detach routine with USBMAN. These routines facilitate plug-n-play under OS-9. Following is a code snippet showing how to register these routines.

```
usbd_ldd_t mouse_ldd = {os9_detach_mouse,
                        os9_attach_mouse,
                        os9_match_mouse,
                        NULL, /* gp */
                        NULL}; /* dev_data */

/* register attach/match/detach with usbman */
methods_pb.enable = 1;
mouse_ldd.gp = get_static();
methods_pb.ldb = &mouse_ldd;
err = _os_setstat(usb_path, SS_USB_LDD_METHODS, &methods_pb);
```

Removing registration with usbman should only occur in the term part of the driver. Following is an example:

```
/* un-register with usbman */
methods_pb.enable = 0;
methods_pb.ldb = &mouse_ldd;
(void) _os_setstat(usb_path, SS_USB_LDD_METHODS, &methods_pb);
```

## Standard OS-9 LDD Drivers

---

The OS-9 USB Host Stack ships with the following Logical Device Drivers:

- **USB Mouse**
- **USB Keyboard**
- **USB Printer**
- **Generic USB Driver**

### USB Mouse

The USB Host Mouse driver is implemented as a NULLFM Driver. It supports the standard OS-9 interface for read, `SS_RELEASE`, `SS_SENDSIG`, and `SS_READY`. The standard OS-9 utilities, such as `dump`, can be used with this driver. This driver attaches to any device that declares itself to be a HID Mouse device with an x and y report. The driver and its descriptors are found in the following locations:

- **Source Directory:**

`SRC/DPIO/NULLFM/DRV/USBH/UMS`

- **Driver Location:**

`OS9000 / <PROCESSOR> / CMDS / BOOTOBS / USBH / ums`

- **Descriptor Location:**

`OS9000 / <PROCESSOR> / CMDS / BOOTOBS / USBH / um0`

`OS9000 / <PROCESSOR> / CMDS / BOOTOBS / USBH / um1`

## Data Format

The USB Host mouse driver generates PS/2 style data. Each mouse movement and/or button press is represented by 3 bytes. PS/2 only allows for 3 buttons and 8 bits of movement per data sample. Following is the data format:

```
Byte 0:  oy ox sy sx 1 b3 b2 b1
Byte 1:  x7 .. .. . . . . x0  - signed x data
Byte 2:  y7 .. .. . . . . y0  - signed y data
```

B1	button 1 down
B2	button 2 down
B3	button 3 down
Oy	overflow in y direction
Ox	overflow in x direction
Sy	sign bit in y direction
Sx	sign bit in x direction

## Use With MAUI

To use the USB Mouse with MAUI, the correct protocol module `cdb` is required. The USB Mouse uses the `mp_bsptr` protocol module. This is the standard PS/2 mouse protocol module. Since the USB Mouse driver generates PS/2 data, `mp_bsptr` is very functional.

For applications to be aware of the USB Mouse, a `cdb` entry must be added. Following is a code snippet that shows a USB Mouse entry in a `cdb.a` file. This file is found in the following location:

```
OS9000/<PROCESSOR>/PORTS/<BOARD>/MAUI/CDB
psect cdb,(5<<8)+1,$8000,212,0,entry

org 0

entry:
    (Other entries here)
    dc.b "5:/um0/mp_bsptr:TY=\"ptr\":",13          * USB Mouse

ends
```

## Testing the USB Mouse

The USB Mouse can be tested in two ways. The first, and simplest method, is using the OS-9 `dump` utility. Following is an example of using OS-9 `dump`:

```
$ tmode nopause
$ dump /um0
(Move the mouse and press buttons)
  Addr    0 1  2 3   4 5   6 7   8 9   A B   C D   E F  0 2  4 6  8 A C E
-----
00000000  0900 000b 0000 0900 000b 0000 0a00 0008 .....
00000010  0000 0803 0308 0403 0806 0408 0603 0806 .....
00000020  0308 0403 0803 0308 0002 08ff 0208 fe01 .....~.
(Ctrl-C to exit)
Error #000:177
```

The second method for testing the mouse is to use the MAUI `inp` demo software. Following is an example of using `inp`:

```
$ maui_inp &
$ tmode nopause
$ inp -i=/um0/mp_bsptr
Opening device '/um0/mp_bsptr'
Send signal to 'inp' to end test
Expected device id 0x3fa8018
+-----+
Device type:  +++ Pointer +++  Device ID:   0x3fa8018
| Sub-type: 0x4
|           INP_PTR_MOVE
| Button changed: 0
| Button status 0 (0x0)
| New position (-64,117)
| Simulating keysym: INP_KEY_NULL (0x0)
+-----+
Device type:  +++ Pointer +++  Device ID:   0x3fa8018
| Sub-type: 0x1
|           INP_PTR_DOWN
| Button changed: 2
| Button status 2 (0x2)
| New position (-64,117)
| Simulating keysym: INP_KEY_NULL (0x0)
+-----+
Device type:  +++ Pointer +++  Device ID:   0x3fa8018
| Sub-type: 0x2
|           INP_PTR_UP
| Button changed: 2
| Button status 0 (0x0)
| New position (-64,117)
| Simulating keysym: INP_KEY_NULL (0x0)
+-----+
(Ctrl-C to exit)
```

## USB Keyboard

The USB Host Keyboard driver is implemented as a NULLFM Driver. It supports the standard OS-9 interface for read, `SS_RELEASE`, `SS_SENDSIG`, and `SS_READY`. The standard OS-9 utilities, such as `dump`, can be used with this driver. This driver attaches to any device that declares itself to be a HID Keyboard that uses the BOOT Protocol. The driver and its descriptors are found in the following locations:

- Source Directory:

`SRC/DPIO/NULLFM/DRVR/USBH/UKBD`

- Driver Location:

`OS9000/<PROCESSOR>/CMDS/BOOTOBS/USBH/ukbd`

- Descriptor Location:

`OS9000/<PROCESSOR>/CMDS/BOOTOBS/USBH/ukbd0`

`OS9000/<PROCESSOR>/CMDS/BOOTOBS/USBH/ukbd1`

## Data Format

The USB Keyboard uses an 8-byte data format. Below is a C-style structure describing the format. A special protocol module, named `mp_usbkbd` was created to handle this exact format.

```
#define KEYSLOTS 6
typedef struct {
    u_int8    modifiers;
#define MOD_CONTROL_L0x01
#define MOD_CONTROL_R0x10
#define MOD_SHIFT_L0x02
#define MOD_SHIFT_R0x20
#define MOD_ALT_L0x04
#define MOD_ALT_R0x40
#define MOD_META_L0x08
#define MOD_META_R0x80
    u_int8    reserved;
    u_int8    keycode[KEYSLOTS];
} UKBD_DATA;
```



The USB Keyboard can handle up to 6 characters pressed at a time. The keycode array represents "down" keys. "Up" keys must be deduced from consecutive packets. That is to say, if a particular key is "down", and then is not present in the keycode array on the next packet, then the key is declared "up".



## For More Information

For more information about the keyboard data packet, please refer to the Device Class Definition for Human Interface Devices (HID) at [www.usb.org](http://www.usb.org).

## Use With MAUI

To use the USB Keyboard with MAUI, the correct protocol module and an updated `cdb` module will be required. The USB Keyboard uses the `mp_usbkbd` protocol module. This is found in the following location:

`SRC/MAUI/MP/MP_USBKBD`

For applications to be aware of the USB Keyboard, a `cdb` entry must be added. Below is a code snippet that shows a USB Keyboard entry in a `cdb.a` file. This file is found in the following location:

```
OS9000 /<PROCESSOR> /PORTS /<BOARD> /MAUI /CDB
psect cdb, (5<<8)+1, $8000, 212, 0, entry

org 0

entry:
    (Other entries here)
    dc.b "5:/ukbd0/mp_usbkbd:TY=\"ptr\":", 13          * USB Keyboard

ends
```

The `mp_usbkbd` protocol module turns separate LEDs when the Caps Lock, Num Lock, or Scroll Lock key is pressed.

The key repeat functionality (keys that repeat while holding down a particular key) is not implemented. According to the USB HID specification, auto-repeating keys while they are down is a function of the USB Software, not the keyboard. Currently, this feature does not exist in the OS-9 Keyboard driver.

## Testing the USB Keyboard

The USB Keyboard can be tested in two ways. The first method uses the standard OS-9 `dump` utility. Following is an example of using OS-9 `dump`:

```
$ dump /ukbd0
```

Addr	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F	0	2	4	6	8	A	C	E
00000000	0000	0400	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	.....							
00000010	0000	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	.....							
00000020	0000	0600	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	.....							
00000030	0000	0700	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	.....							
00000040	0000	0800	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	.....							
00000050	0200	0000	0000	0000	0000	0000	0200	0400	0000	0000	0000	0000	0000	0000	0000	0000	.....							
00000060	0200	0416	0000	0000	0000	0000	0200	0416	0700	0000	0000	0000	0000	0000	0000	0000	.....							
00000070	0200	0407	0000	0000	0000	0000	0200	0700	0000	0000	0000	0000	0000	0000	0000	0000	.....							
00000080	0200	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	.....							
00000090	0000	2c00	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	.....							

The second method for testing the USB Keyboard is to use the MAUI `inp` demo software. Following is an example of using `inp`:

```
$ maui_inp &
$ tmode nopause
$ inp -i=/ukbd0/mp_usbkbd
Opening device '/ukbd0/mp_usbkbd'
Send signal to 'inp' to end test
Expected device id 0x3fa8018
+-----+
Device type: +++ Key +++ Device ID:    0x3fa8018
| Sub-type: 0x4
|                INP_KEYMOD_DOWN
| Keysym received: INP_KEY_NULL (0x0)
| Key modifiers: 0x1
|   Shft CapL Ctrl Alt  Meta Num  ScrL
|   L R  L R  L R  L R  L R  Lock Lock
|   x
+-----+
Device type: +++ Key +++ Device ID:    0x3fa8018
| Sub-type: 0x8
|                INP_KEYMOD_UP
| Keysym received: INP_KEY_NULL (0x0)
| Key modifiers: 0x0
```

```

|   Shft CapL Ctrl Alt  Meta Num  Scr1
|   L R  L R  L R  L R  L R  Lock Lock
|
+-----+
Device type: +++ Key +++ Device ID:   0x3fa8018
| Sub-type: 0x4
|               INP_KEYMOD_DOWN
| Keysym received: INP_KEY_NULL (0x0)
| Key modifiers: 0x4
|   Shft CapL Ctrl Alt  Meta Num  Scr1
|   L R  L R  L R  L R  L R  Lock Lock
|           x
+-----+
(CTRL-C to exit)

```

## USB Printer

The USB Host Printer driver is implemented as a NULLFM Driver. It supports the standard OS-9 interface for write, `SS_RELEASE`, `SS_SENDSIG`, and `SS_READY`. The standard OS-9 utilities, such as `merge`, can be used with this driver. The driver and its descriptor are found in the following locations:

- Source Directory

`SRC/DPIO/NULLFM/DRV/USBH/ULPT`

- Driver Location

`OS9000/<PROCESSOR>/CMDS/BOOTOBS/USBH/ulpt`

- Descriptor Location

`OS9000/<PROCESSOR>/CMDS/BOOTOBS/USBH/ulp0`

The printer driver attaches to any device advertising itself as a uni-directional or bi-directional printer. The OS-9 USB Printer Driver does not modify the data sent to the printer. That is to say, the data the application writes to the printer must be understood by the printer. The `ulpt` driver does not massage the data.



## For More Information

Information about USB printers is located at [www.usb.org](http://www.usb.org).

## Testing the USB Printer

Following is an example of how to test a printer using the OS-9 `merge` utility. A sample text file can be found in the following location:

```
SRC/DPIO/NULLFM/DRVH/USBH/ULPT/sample.txt
```

```
$ merge sample.txt>/ulp0
```



### Note

Many USB Printers that accept ASCII text require a <CR><LF> at the end of each line, and a Ctrl-L as a Form Feed character. A sample text file (`sample.txt`) exists in the source directory for the printer driver.

There is also a `usbprint` utility that can be used to print a file. Following is an example command for `usbprint`:

```
$ usbprint sample.txt
```



### Note

The default print device is `/ulp0`.

## Generic USB Driver

The Generic USB Driver (**UGEN**) enables applications to configure and transfer data directly to a device on the USB. Only bulk and interrupt pipes are supported, and there is no intention of supporting isochronous pipes. **UGEN** is a SoftStax (SPF) driver, and requires edition 269 or greater of the SPF file manager. The driver and its descriptors are found in the following locations:

- Source Directory:

`SRC/DPIO/SPF/USBGEN`

- Driver Location:

`OS9000 / <PROCESSOR> / CMDS / BOOTOBSJS / USBH / ugen`

- Descriptor Location:

`OS9000 / <PROCESSOR> / CMDS / BOOTOBSJS / USBH / ugen0`

`OS9000 / <PROCESSOR> / CMDS / BOOTOBSJS / USBH / ugen1`

## Plug-n-Play

With respect to plug-n-play, **UGEN** registers its attach, match, and detach routines like any other Logical Device Descriptor. However, **UGEN** matches to any device. In addition, **USBMAN** will only attempt to match the generic driver with a device after all other drivers have been given an opportunity to match. Therefore, the desired configuration is to initialize (*iniz*) all non-generic devices as well as **UGEN**. In this way, any device plugged into the USB will first try to attach to regular LDDs and will then try to attach to **UGEN**.

## Accessing Endpoints with UGEN

**UGEN** is a special LDD because it allows a direct connection to the control pipe, and also allows a direct connection to a specific endpoint on the USB device. For example, opening `/ugen0` will open the control pipe on the device. An application can then request configuration information or make requests to the device.

To open a specific endpoint on a USB device, append a # character followed by the endpoint number after the device name. For example, `/ugen0#1` will open endpoint 1 on the USB device attached to `/ugen0`. `/ugen1#2` will open endpoint 2 on the USB device attached to `/ugen1`.

The application can request information about the device by making various `setstat` calls into the `UGEN` driver using the control pipe. In this way, the application can determine how many endpoints a device has, and the type of device, for example a printer mouse, or camera.)

## Testing UGEN

Following is a list of steps for testing `UGEN` with a USB mouse. Before you start, make sure that the following `SPF` modules are on your OS-9 target. This can be determined by running the `mdir` utility on the USB Host machine.

```
OS9000/<PROCESSOR>/CMDS/BOOTOBSJS/SPF/spf
OS9000/<PROCESSOR>/CMDS/mbinstall
```

---

Step 1. Type the following commands at the OS-9 prompt:

```
$ usbd &
$ usbdevs
```

Following is an example response from the command:

```
Root Address 1, Hub
[1] Address 2, NOVATEK : USB Mouse STD.
[2] -
```

This response shows that a mouse is present on the USB at address 2.

Step 2. Type the following commands at the OS-9 prompt:

```
$ iniz /ugen0
$ ugenstat
```

Following is an example response from the command:

```
Device Descriptor: 12010001 00000008 03067168 00010422 0001
NOVATEK          USB Mouse STD.
Number of Configurations: 1
Config Descriptor 1: 09022200 010100a0 32

    Number of interfaces: 1
    Interface Descriptor 0: 09040000 01030102 00

    Number of endpoints: 1
    Endpoint Descriptor 0: 07058103 08000a
```

This response shows that the UGEN driver is attached to the mouse. By decoding the configuration and endpoint data, this mouse has only one endpoint and is endpoint 1.

Step 3. Type the following commands at the OS-9 prompt:

```
$ dump "/ugen0#1"
```

Following is an example response from the command:

```
Addr      0 1  2 3  4 5  6 7  8 9  A B  C D  E F  0 2  4 6  8 A C E
-----
00000000  0003 0200 0506 0009 0700 0605 0002 0001 .....
00000010  0000 0000 0000 fffe 00ff fe00 fdfe 00fd .....~.~.}~.}
00000020  fd00 fcfd 00fd fe00 00ff 00ff ff00 0405 }.|.}.}~.....
00000030  0007 0700 0203 00ff fe00 feff 00ff fe00 .....~.~.~.~.
00000040  fffe 00ff fe00 fefe 00fe ff00 00ff 00ff .~.~.~.~.~.
(Ctrl-C to exit)
```



## For More Information

For information regarding the data format of the device, configuration, interface, and endpoint descriptors, please refer to the USB 1.1 specification, which can be found at [www.usb.org](http://www.usb.org).

## Reference API

An Application may make many getstat/setstat calls into UGEN to either query information about the device, or to set the device configuration. Below is a list of these, and their purposes. Since UGEN is a SoftStax (SPF) driver, the standard SPF getstat/setstat parameter block is used. Structures used for ugen getstat/setstat values can be found in the following location:

SRC/IO/USBH/DEFS/usb.h and SRC/DEFS/HW/usb\_host.h.

```
/* generic getstat/setstat parameter block */
struct spf_ss_pb {
    u_int32 code; /* setstat module code */
    u_int32 size; /* size of mod_param */
    void* param; /* module parameter block */
    u_int8 updir; /* gs/ss going up the stack flag */
    #define SPB_GOINGUP1 /* Param blk is going up stack */
    #define SPB_GOINGDOWN 0 /* Param blk going down stack */
    u_int8 rsv[3]; /* RESERVED FOR FUTURE USE! */
};
```



## GS\_USB\_GET\_CONFIG

Get current Device Configuration Value

---

### Syntax

```
int config;  
err = _os_getstat(path, GS_USB_GET_CONFIG, &config);
```

### Description

Get current device configuration value.

### Return Value

EIO	I/O error retrieving configuration information from device.
SUCCESS	Retrieved configuration value.

## GS\_USB\_GET\_ALTINTERFACE

Get Alternate Interface Value

---

### Syntax

```
struct usb_alt_interface ai;  
err = _os_getstat(path, GS_USB_GET_ALTINTERFACE, &ai);
```

### Description

Get alternate interface value.

### Return Value

ENIVAL	No interface selected for this device.
EIO	Error retrieving alternate interface.
SUCCESS	Retrieved alternate interface value, and assigned to <code>ai-&gt;alt_no</code> .

## GS\_USB\_GET\_NO\_ALT

Get Number of Alternate Interfaces

---

### Syntax

```
struct usb_alt_interface ai;  
err = _os_getstat(path, GS_USB_GET_NO_ALT, &ai);
```

### Description

Get number of alternate interfaces.

### Return Value

ENIVAL	No interface selected for this device.
EIO	Error retrieving alternate interface.
SUCCESS	Retrieved number of alternate interfaces, and assigned to <code>ai-&gt;alt_no</code> .

## GS\_USB\_GET\_DEVICE\_DESC

Get Device Descriptor

---

### Syntax

```
usb_device_descriptor_t dev_desc;  
err = _os_getstat(path, GS_USB_GET_DEVICE_DESC, &dev_desc);
```

### Description

Get device descriptor.

### Return Value

EINVAL	No device descriptor available.
SUCCESS	Returns device descriptor.

## GS\_USB\_GET\_CONFIG\_DESC

### Get Current Configuration Descriptor

---

#### Syntax

```
struct usb_config_desc config_desc;  
err = _os_getstat(path, GS_USB_GET_CONFIG_DESC, &config_desc);
```

#### Description

Get current configuration descriptor.

#### Return Value

EINVAL	No configuration descriptor available.
SUCCESS	Returns device descriptor.

## GS\_USB\_GET\_INTERFACE\_DESC

### Get Interface Descriptor on Device

---

#### Syntax

```
struct usb_interface_desc iface_desc;  
err = _os_getstat(path,GS_USB_GET_INTERFACE_DESC,&iface_desc);
```

#### Description

Get interface descriptor on device.

- `iface_desc.config_index`  
Configuration index to use, or -1 for the current configuration.
- `iface_desc.interface_index`  
Interface index to use, or -1 for the current interface.
- `iface_desc.alt_index`  
Alternate index to use, or -1 for current alternate interface.

#### Return Value

EINVAL	No configuration or interface descriptor.
SUCCESS	Returns interface descriptor in <code>iface_desc.desc</code> .

## GS\_USB\_GET\_ENDPOINT\_DESC

### Get Endpoint Descriptor on Device

---

#### Syntax

```
struct usb_endpoint_desc ep_desc;  
err = _os_getstat(path,GS_USB_GET_ENDPOINT_DESC,&iface_desc);
```

#### Description

Get endpoint descriptor on device.

- `ep_desc.config_index`  
Configuration index to use, or -1 for the current configuration.
- `ep_desc.interface_index`  
Interface index to use, or -1 for the current interface.
- `ep_desc.alt_index`  
Alternate index to use, or -1 for current alternate interface.
- `ep_desc.endpoint_index`  
Endpoint index to use.

#### Return Value

EINVAL	Could not get information on configuration descriptor.
SUCCESS	Endpoint descriptor copied to <code>ep_desc.desc</code> .

## GS\_USB\_GET\_STRING\_DESC

get string descriptor from USB device

---

### Syntax

```
struct usb_string_desc string_desc;  
err = _os_getstat(path,GS_USB_GET_STRING_DESC,&string_desc);
```

### Description

Get string descriptor from USB device.

- `string_desc.string_index`  
String index from device, configuration, or interface descriptor.
- `string_desc.language_id`  
Language to use (0 if ASCII).

### Return Value

<code>EINVAL</code>	I/O error retrieving string descriptor.
<code>SUCCESS</code>	String descriptor copied to <code>string_desc.desc</code> .



## SS\_USB\_SET\_CONFIG

Set the Configuration Index

---

### Syntax

```
int config_index=1;  
err = _os_setstat(path,SS_USB_SET_CONFIG,&config_index);
```

### Description

Set the configuration index.



### Note

This must be done before any paths are opened to a specific endpoint, for example /ugen0#1.

---

### Return Value

EPERM	No write permission on opened path.
EIO	Error setting configuration.
SUCCESS	Configuration set to given index.

## SS\_USB\_SET\_ALTINTERFACE

Sets the Alternate Interface

### Syntax

```
struct usb_alt_interface alt_iface;
alt_iface.alt_no = 0;
err = _os_setstat(path, SS_USB_SET_ALTINTERFACE, &alt_iface);
```

### Description

Sets the alternate interface.



### Note

This must be done before any paths are opened to a specific endpoint, for example /ugen0#1.

### Return Value

EPERM	No write permission on opened path.
EIO	Error setting configuration.
SUCCESS	Configuration set to given index.

## SS\_USB\_DO\_REQUEST

Performs a Device Specific Request Over the Control Pipe

---

### Syntax

```
struct usb_ctl_request req;  
err = _os_setstat(path, SS_USB_DO_REQUEST, &req);
```

### Description

Performs a device specific request over the control pipe.

<code>req.addr</code>	Device address.
<code>req.request</code>	Standard 8 byte device request structure initialized.
<code>req.data</code>	Pointer to memory where data returned from the device will be stored.
<code>req.flags</code>	0, or <code>USBD_SHORT_XFER_OK</code> .

### Return Value

<code>EPERM</code>	No write permission on opened path
<code>EINVAL</code>	Returned if a <code>SET ADDRESS</code> , <code>SET CONFIGURATION</code> , or <code>SET INTERFACE</code> request is attempted.
<code>EIO</code>	Error setting configuration.
<code>SUCCESS</code>	Request performed.

Any data returned will be stored in the `data` field. The actual number of bytes returned will be stored in `req.actlen`.

## SS\_USB\_SET\_SHORT\_XFER

Allows Short Transfers

---

### Syntax

```
err = _os_setstat(path, SS_USB_SET_SHORT_XFER, NULL);
```

### Description

Allows short transfers (less than the maximum endpoint length) when reading data from the USB device. This is not for the control pipe, but for other endpoints, such as /ugen0#1.

### Return Value

EINVAL	Attempt to set for control pipe (/ugen0), or no interrupt or bulk pipe open for read.
SUCCESS	Allow short reads on this pipe.

## User-State Daemon Process

---

The user-state daemon process, `usbd`, serves the following purposes:

- Initializes the USB Host stack
- Activated to perform bus explore code in USBMAN when a device is plugged in or removed from the USB.
- Initiates an asynchronous "clear endpoint stall". This can occur if a driver determines an error condition in the interrupt service routine.

To initialize the USB stack, use the following command at the OS-9 prompt:

```
$ usbd &
```

`usbd` will respond to a signal 2 or 3, to shut down the stack. Also, all drivers must be de-initialized for the USB Host Stack to properly terminate.



---

## Chapter 3: USB Host API Reference

---

This chapter provides a library function reference for USB Host for OS-9. It documents the USBDI interface.

The USBDI interface is the API that implements access to the USBMAN driver. Any USB logical device driver or system-state application accesses the USB through the USBDI API.

The function references are sorted into the following categories:

- [Pipe Functions List](#)
- [Transfer Functions List](#)
- [Interface Functions List](#)
- [Device Functions List](#)
- [Alphabetical Listing](#)



MICROWARE SOFTWARE

# Pipe Functions List

**Table 3-1 Pipe Functions**

Function Name	Description
<code>usbman_abort_pipe()</code>	Abort a Pipe Operation
<code>usbman_clear_endpoint_stall()</code>	Clear STALLED Condition
<code>usbman_clear_endpoint_stall_async()</code>	Clear STALLED Condition
<code>usbman_clear_endpoint_toggle()</code>	Reset Endpoint Toggle
<code>usbman_close_pipe()</code>	Close Pipe
<code>usbman_do_request()</code>	Perform Transfer Over Control Pipe
<code>usbman_do_request_flags()</code>	Perform Transfer
<code>usbman_open_pipe()</code>	Create Bulk Transfer Pipe
<code>usbman_open_pipe_intr()</code>	Create Interrupt Pipe
<code>usbman_pipe2device_handle()</code>	Return Device Handle



# Transfer Functions List

Table 3-2 Transfer Functions

Function Name	Description
<code>usbman_alloc_buffer()</code>	Allocate a DMA Buffer
<code>usbman_alloc_xfer()</code>	Allocate a Transfer Structure
<code>usbman_bulk_transfer()</code>	Perform Bulk Transfer
<code>usbman_free_buffer()</code>	Free DMA Buffer
<code>usbman_free_xfer()</code>	Free Transfer
<code>usbman_get_buffer()</code>	Return Current DMA Buffer Pointer
<code>usbman_get_xfer_status()</code>	Get Transfer Status
<code>usbman_setup_default_xfer()</code>	Initialize Transfer Handle
<code>usbman_setup_isoc_xfer()</code>	Initialize ISOC Transfer
<code>usbman_setup_xfer()</code>	Assign Fields in Transfer
<code>usbman_sync_transfer()</code>	Perform Asynchronous Transfer
<code>usbman_transfer()</code>	Initialize Bulk Transfer

# Interface Functions List

**Table 3-3 Interface Functions**

Function Name	Description
<code>usbman_alloc_report_desc()</code>	Calculate Descriptor Size and Allocate Memory
<code>usbman_endpoint_count()</code>	Return Number of Endpoints
<code>usbman_free_report_desc()</code>	Deallocate Memory
<code>usbman_get_config()</code>	Request Configuration Descriptor
<code>usbman_get_hid_descriptor()</code>	Request HID Descriptor
<code>usbman_get_report()</code>	Request HID Report Descriptor
<code>usbman_get_report_descriptor()</code>	Request HID Report Descriptor
<code>usbman_interface2device_handle()</code>	Return Device Handle
<code>usbman_interface2endpoint_descriptor()</code>	Return Endpoint Descriptor
<code>usbman_set_idle()</code>	Silence Report on the Interrupt In Pipe
<code>usbman_set_interface()</code>	Request Interface Change
<code>usbman_set_protocol()</code>	Switch Between Boot and Report Protocol
<code>usbman_set_report()</code>	Perform Set Report Request

# Device Functions List

Table 3-4 Device Functions

Function Name	Description
<code>usbman_device2interface_handle()</code>	Return Interface Handle
<code>usbman_get_config_desc()</code>	Get Configuration Descriptor
<code>usbman_get_config_desc_full()</code>	Request Configuration Descriptor
<code>usbman_get_device_desc()</code>	Request Device Descriptor
<code>usbman_get_string_desc()</code>	Request String Descriptor
<code>usbman_interface_count()</code>	Return Number of Interfaces
<code>usbman_set_config_index()</code>	Set Configuration Index
<code>usbman_set_config_no()</code>	Set Configuration

# Alphabetical Listing

**Table 3-5 Alphabetical Listing of Functions**

Function Name	Description
<code>usbman_abort_pipe()</code>	Abort a Pipe Operation
<code>usbman_alloc_buffer()</code>	Allocate a DMA Buffer
<code>usbman_alloc_report_desc()</code>	Calculate Descriptor Size and Allocate Memory
<code>usbman_alloc_xfer()</code>	Allocate a Transfer Structure
<code>usbman_bulk_transfer()</code>	Perform Bulk Transfer
<code>usbman_clear_endpoint_stall()</code>	Clear STALLED Condition
<code>usbman_clear_endpoint_stall_async()</code>	Clear STALLED Condition
<code>usbman_clear_endpoint_toggle()</code>	Reset Endpoint Toggle
<code>usbman_close_pipe()</code>	Close Pipe
<code>usbman_device2interface_handle()</code>	Return Interface Handle
<code>usbman_do_request()</code>	Perform Transfer Over Control Pipe
<code>usbman_do_request_flags()</code>	Perform Transfer
<code>usbman_endpoint_count()</code>	Return Number of Endpoints
<code>usbman_find_edesc()</code>	Return Endpoint Descriptor
<code>usbman_find_idesc()</code>	Return Interface Descriptor
<code>usbman_free_buffer()</code>	Free DMA Buffer

**Table 3-5 Alphabetical Listing of Functions**

Function Name	Description
<code>usbman_free_report_desc()</code>	Deallocate Memory
<code>usbman_free_xfer()</code>	Free Transfer
<code>usbman_get_buffer()</code>	Return Current DMA Buffer Pointer
<code>usbman_get_config()</code>	Request Configuration Descriptor
<code>usbman_get_config_desc()</code>	Get Configuration Descriptor
<code>usbman_get_config_desc_full()</code>	Request Configuration Descriptor
<code>usbman_get_device_desc()</code>	Request Device Descriptor
<code>usbman_get_device_descriptor()</code>	Return Device Descriptor
<code>usbman_get_hid_descriptor()</code>	Request HID Descriptor
<code>usbman_get_no_alts()</code>	Get Number of Alternate Interfaces
<code>usbman_get_report()</code>	Request HID Report Descriptor
<code>usbman_get_report_descriptor()</code>	Request HID Report Descriptor
<code>usbman_get_string_desc()</code>	Request String Descriptor
<code>usbman_get_xfer_status()</code>	Get Transfer Status
<code>usbman_interface_count()</code>	Return Number of Interfaces
<code>usbman_interface2device_handle()</code>	Return Device Handle
<code>usbman_interface2endpoint_descriptor()</code>	Return Endpoint Descriptor
<code>usbman_open_pipe()</code>	Create Bulk Transfer Pipe
<code>usbman_open_pipe_intr()</code>	Create Interrupt Pipe

**Table 3-5 Alphabetical Listing of Functions**

Function Name	Description
<code>usbman_pipe2device_handle()</code>	Return Device Handle
<code>usbman_set_config_index()</code>	Set Configuration Index
<code>usbman_set_config_no()</code>	Set Configuration
<code>usbman_set_idle()</code>	Silence Report on the Interrupt In Pipe
<code>usbman_set_interface()</code>	Request Interface Change
<code>usbman_set_protocol()</code>	Switch Between Boot and Report Protocol
<code>usbman_set_report()</code>	Perform Set Report Request
<code>usbman_setup_default_xfer()</code>	Initialize Transfer Handle
<code>usbman_setup_isoc_xfer()</code>	Initialize ISOC Transfer
<code>usbman_setup_xfer()</code>	Assign Fields in Transfer
<code>usbman_sync_transfer()</code>	Perform Asynchronous Transfer
<code>usbman_transfer()</code>	Initialize Bulk Transfer

## usbman\_abort\_pipe()

Abort a Pipe Operation

---

### Syntax

```
usbman_status usbman_abort_pipe(usbman_pipe_handle pipe);
```

### Description

Aborts a pipe operation. This function returns `USBMAN_NORMAL_COMPLETION` if the operation is successful.

### Parameters

<code>pipe</code>	A valid open pipe.
-------------------	--------------------

### See Also

[usbman\\_close\\_pipe\(\)](#)  
[usbman\\_open\\_pipe\(\)](#)

## usbman\_alloc\_buffer()

Allocate a DMA Buffer

---

### Syntax

```
void *usbman_alloc_buffer(  
    usbd_xfer_handle  xfer,  
    u_int32_t         size);
```

### Description

Allocates a DMA buffer for the given transfer handle `xfer`. Returns NULL if the allocation fails; otherwise returns the pointer to the allocated memory.

### Parameters

<code>xfer</code>	Must be a valid transfer handle; returned from <code>usbman_alloc_xfer()</code> .
<code>size</code>	Number of bytes to allocate.

### Modifies

<code>xfer -&gt; dmabuf</code>	Updated to store reference to allocated memory.
<code>xfer -&gt; rqflags</code>	URQ_DEV_DMABUF flag set.

### See Also

[usbman\\_free\\_buffer\(\)](#)  
[usbman\\_get\\_buffer\(\)](#)



## usbman\_alloc\_report\_desc()

### Calculate Descriptor Size and Allocate Memory

---

#### Syntax

```
usb_d_status usbman_alloc_report_desc(  
    usb_d_interface_handle ifc,  
    void **descp,  
    int *sizep,  
    usb_malloc_type mem);
```

#### Description

Calculates the size of the descriptor and allocates memory for it. Returns the Report Descriptor for a HID device (for example a mouse or keyboard).

#### Parameters

<code>ifc</code>	A valid interface handle.
<code>**descp</code>	Memory for the report descriptor is allocated and stored in <code>*descp</code> .
<code>*sizep</code>	The size of the memory allocated is stored in <code>*sizep</code> .
<code>mem</code>	Ignored.

#### See Also

[usbman\\_free\\_report\\_desc\(\)](#)

## usbman\_alloc\_xfer()

Allocate a Transfer Structure

---

### Syntax

```
usb_d_xfer_handle usbman_alloc_xfer(usb_d_device_handle);
```

### Description

Allocates a `usb_d_xfer` structure, and returns it to the calling function.

### Parameters

<code>dev</code>	A valid <code>usb_d_device_handle</code> .
------------------	--

### See Also

[usbman\\_free\\_xfer\(\)](#)

## usbman\_bulk\_transfer()

Perform Bulk Transfer

---

### Syntax

```
usbd_status usbman_bulk_transfer(  
    usbd_xfer_handle  xfer,  
    usbd_pipe_handle  pipe,  
    u_int16_t          flags,  
    u_int32_t          timeout,  
    void              *buf,  
    u_int32_t          *size,  
    char               *lbl);
```

### Description

Performs a bulk transfer to or from a device. This call will not return until the transfer is successful, or has timed out. This call returns `USBD_NORMAL_COMPLETION` if the transfer was successful; `USBD_INTERRUPTED` if the transfer was interrupted by a deadly IO signal; `USBD_IOERROR` if a transfer failed; and `USBD_TIMEOUT` if the transfer timed out.

### Parameters

<code>xfer</code>	A transfer handle allocated with <code>usbman_alloc_xfer</code> .
<code>pipe</code>	An open pipe to the device.
<code>flags</code>	0 means no special flags.  <code>USBD_NO_COPY</code> : do not copy data from <code>buf</code> to DMA buffer.  <code>USBD_FORCE_SHORT_XFER</code> : force last short packet on write.
<code>timeout</code>	Number of milliseconds to wait for device to respond to transfer.  <code>USBD_NO_TIMEOUT</code> : wait forever.

<code>*buf</code>	Write: contains data transfer to device. Read: valid memory location to store data read from device.
<code>*size</code>	Write: number of bytes to transfer to device Read: number of bytes to read from device (size of buf)
<code>*lbl</code>	Unused.

## Modifies

This call modifies various fields in `xfer`.

## usbman\_clear\_endpoint\_stall()

Clear STALLED Condition

---

### Syntax

```
usbd_status usbman_clear_endpoint_stall(  
    usbd_pipe_handle pipe);
```

### Description

Clears the STALLED condition of the device. This will also reset the data toggle to 0. Clearing the endpoint stall is usually not necessary, unless a device has returned `USBD_STALLED` in response to a data transfer. This call returns `USBD_NORMAL_COMPLETION` if successful and `USBD_IOERROR` if the device did not respond.

### Parameters

<code>pipe</code>	An open pipe to the device.
-------------------	-----------------------------

### Modifies

This call sets the toggle state of the pipe to 0.

### See Also

[usbman\\_clear\\_endpoint\\_stall\\_async\(\)](#)  
[usbman\\_clear\\_endpoint\\_toggle\(\)](#)

## usbman\_clear\_endpoint\_stall\_async()

Clear STALLED Condition

---

### Syntax

```
usb_d_status usbman_clear_endpoint_stall_async(  
    usb_d_pipe_handle pipe);
```

### Description

Clears the STALLED condition of the device and resets the data toggle to 0. This is identical to `usbman_clear_endpoint_stall`, except that this operation is not performed until some time later. This call will return immediately. This version of the call is useful if the endpoint stall needs to be cleared in interrupt context. This call returns `USB_D_NORMAL_COMPLETION` if successful and `USB_D_IOERROR` if the device did not respond.

### Parameters

<code>pipe</code>	An open pipe to the device.
-------------------	-----------------------------

### Modifies

This function sets the toggle state of the pipe to 0.

### See Also

[usbman\\_clear\\_endpoint\\_stall\(\)](#)  
[usbman\\_clear\\_endpoint\\_toggle\(\)](#)

## usbman\_clear\_endpoint\_toggle()

Reset Endpoint Toggle

---

### Syntax

```
void usbman_clear_endpoint_toggle(  
    usbd_pipe_handle pipe);
```

### Description

Resets the endpoint toggle to 0. Resetting the endpoint toggle is only necessary if resetting the device, or if clearing the endpoint stall.

### Parameters

pipe	An open pipe to the device.
------	-----------------------------

### Modifies

This function sets the toggle state of the pipe to 0.

### See Also

[usbman\\_clear\\_endpoint\\_stall\(\)](#)  
[usbman\\_clear\\_endpoint\\_stall\\_async\(\)](#)

## usbman\_close\_pipe()

Close Pipe

---

### Syntax

```
usb_status usbman_close_pipe(usb_pipe_handle pipe);
```

### Description

Closes pipe and frees interrupt pipe transfer buffer. This function returns `USB_NORMAL_COMPLETION` if the operation is successful and `USB_PENDING_REQUESTS` in the middle of the operation.

### Parameters

<code>pipe</code>	A valid open pipe.
-------------------	--------------------

### See Also

[usbman\\_abort\\_pipe\(\)](#)  
[usbman\\_open\\_pipe\(\)](#)



## usbman\_device2interface\_handle()

Return Interface Handle

---

### Syntax

```
usbd_status usbman_device2interface_handle(  
    usbd_device_handle    dev,  
    u_int8_t              ifaceno,  
    usbd_interface_handle *iface);
```

### Description

Returns the specified interface handle for the given device. This function returns `USBD_NORMAL_COMPLETION` if the operation is successful; `USBD_NOT_CONFIGURED` if there is no configuration descriptor for this device; and `USBD_INVALID` if the `ifaceno` parameter is out of range.

### Parameters

<code>dev</code>	A valid device handle.
<code>ifaceno</code>	Interface number. This is between 0 and n-1, where n is the number of interfaces.
<code>*iface</code>	If successful, the interface handle will be stored in <code>*iface</code> .

## usbman\_do\_request()

Perform Transfer Over Control Pipe

---

### Syntax

```
usbd_status usbman_do_request(  
    usbd_device_handle    pipe,  
    usb_device_request_t  *req,  
    void                  *data);
```

### Description

Performs a transfer over the control pipe to the specified device. The data transferred is a fixed 8-byte structure defined by the USB specification. If any data is returned from the device, it is copied into the data parameter. The data parameter must be large enough to hold such information.

This function returns `USBD_NORMAL_COMPLETION` if successful; `USBD_NOMEM` if no memory is available; `USBD_IOERROR` when there is a transfer error to the device; and `USBD_STALLED` if the transfer caused the device to STALL.

### Parameters

<code>pipe</code>	A valid device handle.
<code>*req</code>	8-byte request structure that is properly defined.
<code>*data</code>	NULL if no return data; otherwise pointer to return data memory.

## usbman\_do\_request\_flags()

Perform Transfer

---

### Syntax

```
usbcd_status usbman_do_request_flags(  
    usbcd_device_handle    pipe,  
    usb_device_request_t   *req,  
    void                   *data,  
    u_int16_t              flags,  
    int                    *actlen);
```

### Description

Performs the same function as `usbman_do_request` with the addition of two parameters: `flags` and `actlen`.

This functions returns `USBD_NORMAL_COMPLETION` if successful; `USBD_NOMEM` if no memory is available; `USBD_IOERROR` when there is a transfer error to the device; and `USBD_STALLED` if the transfer caused the device to STALL.

### Parameters

<code>pipe</code>	A valid device handle.
<code>*req</code>	8-byte request structure that is properly defined.
<code>*data</code>	NULL if no return data; otherwise pointer to return data memory.
<code>flags</code>	Flags normally passed to create a transfer handle: <code>USBD_NO_COPY</code> , <code>USBD_SHORT_XFER_OK</code> , <code>USBD_FORCE_SHORT_XFER</code> .
<code>*actlen</code>	Receives the number of bytes of data transferred from the device.

## usbman\_endpoint\_count()

Return Number of Endpoints

---

### Syntax

```
usbman_status usbman_endpoint_count(  
    usbman_interface_handle  iface,  
    u_int8_t                 *count);
```

### Description

Returns the number of endpoints in the current interface. Upon completion, this function returns USBMAN\_NORMAL\_COMPLETION.

### Parameters

iface	A valid interface handle that contains a valid interface descriptor.
*count	Receives the number of endpoints in this interface.

### See Also

[usbman\\_interface\\_count\(\)](#)

## usbman\_find\_edesc()

Return Endpoint Descriptor

---

### Syntax

```
usb_endpoint_descriptor_t *usbman_find_edesc(  
    usb_config_descriptor_t *cd,  
    int                     ifaceidx,  
    int                     altidx,  
    int                     endptidx);
```

### Description

Returns the specified endpoint descriptor for the current configuration descriptor. Upon completion, this function returns a pointer to the requested endpoint descriptor, or NULL if not found.

### Parameters

*cd	A valid configuration descriptor.
ifaceidx	Interface number in the configuration.
altidx	Alternate index in the configuration (0 if none).
endptidx	Endpoint index in the interface.

### See Also

[usbman\\_find\\_idesc\(\)](#)

## usbman\_find\_idesc()

Return Interface Descriptor

---

### Syntax

```
usb_interface_descriptor_t *usbman_find_idesc(  
    usb_config_descriptor_t *cd,  
    int ifaceidx,  
    int altidx);
```

### Description

Returns the specified interface descriptor given a configuration descriptor.

### Parameters

<code>*cd</code>	A valid configuration descriptor.
<code>ifaceidx</code>	Interface number in the configuration.
<code>altidx</code>	Alternate index in the configuration (0 if none).

### See Also

[usbman\\_find\\_edesc\(\)](#)

## usbman\_free\_buffer()

Free DMA Buffer

---

### Syntax

```
void usbman_free_buffer(usbd_xfer_handle xfer);
```

### Description

Frees a DMA buffer for the given transfer handle. This should only be called if `usbman_alloc_buffer()` was successfully called on the given transfer handle. No return value.

### Parameters

<code>xfer</code>	Must be a valid transfer handle, returned from <code>usbman_alloc_xfer()</code> .
-------------------	---

### Modifies

<code>xfer-&gt;dmabuf</code>	Deallocates memory.
<code>xfer-&gt;rqflags</code>	Clears the <code>URQ_DEV_DMABUF</code> and <code>URQ_AUTO_DMABUF</code> flags.

### See Also

[`usbman\_alloc\_buffer\(\)`](#)  
[`usbman\_get\_buffer\(\)`](#)

## usbman\_free\_report\_desc()

Deallocate Memory

---

### Syntax

```
void usbman_free_report_desc(  
    void    *descp,  
    int     mem);
```

### Description

Deallocates memory for a HID report descriptor. `descp` must be a value returned from `usbd_alloc_report_desc`.

### Parameters

<code>*descp</code>	A report descriptor pointer to free.
<code>mem</code>	Unused.

### See Also

[usbman\\_alloc\\_report\\_desc\(\)](#)



**usbman\_free\_xfer()**Free Transfer

---

**Syntax**

```
usbd_status usbman_free_xfer(usbd_xfer_handle xfer);
```

**Description**

Frees `xfer`. Also will free the DMA buffer if present.

**Parameters**

<code>xfer</code>	A valid <code>usbd_xfer_handle</code> structure that was allocated by <code>usbd_alloc_xfer()</code> .
-------------------	--

**See Also**

[usbman\\_alloc\\_xfer\(\)](#)

## usbman\_get\_buffer()

Return Current DMA Buffer Pointer

---

### Syntax

```
void *usbman_get_buffer(usbd_xfer_handle xfer);
```

### Description

Returns the current DMA buffer pointer for the given transfer handle. If no DMA buffer has been allocated, NULL is returned.

### Parameters

<code>xfer</code>	Must be a valid transfer handle, returned from <code>usbman_alloc_xfer()</code> .
-------------------	---

### See Also

[usbman\\_alloc\\_buffer\(\)](#)  
[usbman\\_free\\_buffer\(\)](#)

## usbman\_get\_config()

### Request Configuration Descriptor

---

#### Syntax

```
usbd_status usbman_get_config(  
    usbd_device_handle dev,  
    u_int8_t            *conf);
```

#### Description

Requests the configuration descriptor from the given device. This call will perform a transfer using the control pipe over the USB. This function returns `USBD_NORMAL_COMPLETION` if successful; `USBD_NOMEM` if no memory is available; `USBD_IOERROR` when there is a transfer error to the device; and `USBD_STALLED` if the transfer caused the device to STALL.

#### Parameters

<code>dev</code>	A valid USB device handle.
<code>*conf</code>	Pointer to at least 9 bytes, the size of the standard configuration descriptor.

#### See Also

[usbman\\_get\\_config\\_desc\(\)](#)  
[usbman\\_get\\_config\\_desc\\_full\(\)](#)

## usbman\_get\_config\_desc()

Get Configuration Descriptor

---

### Syntax

```
usbdev_status usbman_get_config_desc(  
    usbdev_device_handle    dev,  
    int                     confidx,  
    usb_config_descriptor_t *d);
```

### Description

Get configuration descriptor from device handle (for example dev->cdesc).

### Parameters

dev	A valid usbdev_device_handle.
confidx	Configuration index.
*d	Address of storage for the basic configuration description.

### See Also

[usbman\\_get\\_config\(\)](#)  
[usbman\\_get\\_config\\_desc\\_full\(\)](#)

## usbman\_get\_config\_desc\_full()

### Request Configuration Descriptor

---

#### Syntax

```
usbd_status usbman_get_config_desc_full(  
    usbd_device_handle dev,  
    int conf,  
    void *d,  
    int size);
```

#### Description

Requests the configuration descriptor from the given device. The configuration index and the amount of data to receive is specified by the `conf` and `size` parameters. This function returns `USBD_NORMAL_COMPLETION` if successful; `USBD_NOMEM` if no memory is available; `USBD_IOERROR` when there is a transfer error to the device; and `USBD_STALLED` if the transfer caused the device to STALL.

#### Parameters

<code>dev</code>	A valid USB device handle.
<code>conf</code>	Specifies configuration index for descriptor.
<code>*d</code>	Pointer to at least 9 bytes, the size of the standard configuration descriptor.
<code>size</code>	Number of bytes in configuration to request.

#### See Also

[usbman\\_get\\_config\(\)](#)  
[usbman\\_get\\_config\\_desc\(\)](#)

## usbman\_get\_device\_desc()

Request Device Descriptor

---

### Syntax

```
usb_d_status usbman_get_device_desc(  
    usb_d_device_handle      dev,  
    usb_device_descriptor_t  *d);
```

### Description

Requests the device descriptor from the given device. This function returns `USBD_NORMAL_COMPLETION` if successful; `USBD_NOMEM` if no memory is available; `USBD_IOERROR` when there is a transfer error to the device; and `USBD_STALLED` if the transfer caused the device to STALL.

### Parameters

<code>dev</code>	A valid USB device handle.
<code>*d</code>	Pointer to 18 bytes, size of the standard device descriptor.

### See Also

[usbman\\_get\\_device\\_descriptor\(\)](#)

## usbman\_get\_device\_descriptor()

## Return Device Descriptor

## Syntax

```
usb_device_descriptor_t *usbman_get_device_descriptor(
    usbd_device handle dev)
```

## Description

Returns the device descriptor retrieved after the device was initially explored.

## Parameters

dev A valid USB device handle.

## See Also

```
usbman_get_device_desc()
```

## usbman\_get\_hid\_descriptor()

## Request HID Descriptor

## Syntax

```
usb_hid_descriptor_t *usbman_get_hid_descriptor(
    usbd_interface_handle ifc);
```

## Description

Requests the HID descriptor for the given interface handle. The HID descriptor is normally retrieved with the configuration descriptor. This function returns a pointer to the HID descriptor. If no HID descriptor is found, NULL is returned.

## Parameters

<code>ifc</code>	A valid interface handle.
------------------	---------------------------

## See Also

```
usbman_get_report()  
usbman_get_report_descriptor()
```



## usbman\_get\_no\_alts()

Get Number of Alternate Interfaces

---

### Syntax

```
int usbman_get_no_alts(  
    usb_config_descriptor_t *cdesc,  
    int ifaceno);
```

### Description

Get the number of alternate interfaces in the given configuration descriptor and interface number. Upon completion, this function returns the number of alternate interfaces.

### Parameters

<code>*cdesc</code>	A valid configuration descriptor.
<code>ifaceno</code>	Interface number.

## usbman\_get\_report()

Request HID Report Descriptor

### Syntax

```
usb_d_status usbman_get_report(
    usb_d_interface_handle  iface,
    int                     type,
    int                     id,
    void                    *data,
    int                     len);
```

### Description

Requests the HID report descriptor for the given interface. This will cause a data transfer on the USB. This function returns

USBD\_NORMAL\_COMPLETION if successful; USBD\_NOMEM if no memory is available; USBD\_IOERROR when there is a transfer error to the device; and USBD\_STALLED if the transfer caused the device to STALL.

### Parameters

iface	A valid interface handle.
type	UHID_INPUT_REPORT, UHID_OUTPUT_REPORT, UHID_FEATURE_REPORT.
id	HID id.
*data	Pointer to memory where report will be stored.
len	Number of bytes of data to retrieve of HID descriptor.

### See Also

[usbman\\_get\\_hid\\_descriptor\(\)](#)  
[usbman\\_get\\_report\\_descriptor\(\)](#)

## usbman\_get\_report\_descriptor()

Request HID Report Descriptor

---

### Syntax

```
usb_d_status usbman_get_report_descriptor(  
    usb_device_handle dev,  
    int ifcno,  
    int repid,  
    int size,  
    void *d);
```

### Description

Requests a HID report descriptor for the given device. This will cause a data transfer on the USB. This function returns `USBD_NORMAL_COMPLETION` if successful; `USBD_NOMEM` if no memory is available; `USBD_IOERROR` when there is a transfer error to the device; and `USBD_STALLED` if the transfer caused the device to STALL.

### Parameters

<code>dev</code>	A valid USB device.
<code>ifcno</code>	Interface number.
<code>repid</code>	Report id.
<code>size</code>	Number of bytes to request.
<code>*d</code>	Pointer to memory to store requested report descriptor.

### See Also

[usbman\\_get\\_hid\\_descriptor\(\)](#)  
[usbman\\_get\\_report\(\)](#)

## usbman\_get\_string\_desc()

Request String Descriptor

### Syntax

```
usb_d_status usbman_get_string_desc(
    usb_device_handle    dev,
    int                  sindex,
    int                  langid,
    usb_string_descriptor_t *sdesc);
```

### Description

Requests the string descriptor for the given device. This will cause a data transfer on the USB. Upon successful completion, the string descriptor will be stored in `sdesc`. This function returns `USBD_NORMAL_COMPLETION` if successful; `USBD_NOMEM` if no memory is available; `USBD_IOERROR` when there is a transfer error to the device; and `USBD_STALLED` if the transfer caused the device to STALL.

### Parameters

<code>dev</code>	A valid device handle.
<code>sindex</code>	String index.
<code>langid</code>	Language ID.
<code>*sdesc</code>	Pointer to string descriptor structure.

**usbman\_get\_xfer\_status()**Get Transfer Status

---

**Syntax**

```
void usbman_get_xfer_status(  
    usbd_xfer_handle      xfer,  
    usbd_private_handle   *priv,  
    void                  **buffer,  
    u_int32_t             *count,  
    usbd_status           *status);
```

**Description**

Returns information regarding the given `xfer` transfer handle.

**Parameters**

<code>xfer</code>	A valid <code>xfer</code> handle.
<code>*priv</code>	Receiving the private data area for the transfer.
<code>**buffer</code>	Receiving the DMA buffer.
<code>*count</code>	Receiving the total number of bytes transferred.
<code>*status</code>	Returns the transfer status.

## usbman\_interface\_count()

Return Number of Interfaces

---

### Syntax

```
usbd_status usbman_interface_count(  
    usbd_device_handle dev,  
    u_int8_t           *count);
```

### Description

Returns the number of interfaces for the current configuration.

### Parameters

dev	A valid device.
*count	Receiving the number of interfaces.

## usbman\_interface2device\_handle()

Return Device Handle

---

### Syntax

```
usbd_status usbman_interface2device_handle(  
    usbd_interface_handle  iface,  
    usbd_device_handle     *dev);
```

### Description

Returns the device handle for a given interface handle. Upon completion, this function returns `USBD_NORMAL_COMPLETION`.

### Parameters

<code>iface</code>	A valid interface handle.
<code>*dev</code>	Receives the device handle associated with <code>iface</code> .

## usbman\_interface2endpoint\_descriptor()

Return Endpoint Descriptor

---

### Syntax

```
usb_endpoint_descriptor_t  
*usbman_interface2endpoint_descriptor(  
    usbd_interface_handle  iface,  
    u_int8_t               address);
```

### Description

Returns the endpoint descriptor given an interface handle. Upon completion, this function returns a pointer to an endpoint descriptor, or NULL if the index is out of range.

### Parameters

iface	A valid interface handle.
address	Endpoint number.



## usbman\_open\_pipe()

### Create Bulk Transfer Pipe

---

#### Syntax

```
usb_d_status usbman_open_pipe(  
    usb_d_interface_handle  iface,  
    u_int8_t                address,  
    u_int8_t                flags,  
    usb_d_pipe_handle       *pipe);
```

#### Description

Creates a bulk transfer pipe to the given endpoint. The address (endpoint) will be checked to see if it is valid. This function returns `USB_D_NORMAL_COMPLETION` if the call is successful; `USB_D_BAD_ADDRESS` if the endpoint is invalid; `USB_D_IN_USE` if the pipe is already opened to endpoint, but the caller wanted an exclusive connection.

#### Parameters

iface	
address	Endpoint on USB bus.
flags	Passing <code>USB_D_EXCLUSIVE_USE</code> will open the pipe exclusively for the caller.
pipe	A new pipe will be created and returned in this parameter.

#### See Also

[usbman\\_open\\_pipe\\_intr\(\)](#)

## usbman\_open\_pipe\_intr()

Create Interrupt Pipe

### Syntax

```
usb_status usbman_open_pipe_intr(
    usb_interface_handle  iface,
    u_int8_t              address,
    u_int8_t              flags,
    usb_pipe_handle       *pipe,
    usb_private_handle     priv,
    void                  *buffer,
    u_int32_t              length,
    usb_callback           cb
    int                    interval);
```

### Description

Creates an interrupt pipe to the given endpoint.

### Parameters

iface	A valid interface.
address	Endpoint on USB bus.
flags	USBD_EXCLUSIVE_USE: open exclusive pipe.
*pipe	New pipe will be returned in this parameter.
priv	Parameter passed to interrupt service routine.
*buffer	Data buffer. Must be big enough according to class definition of device.
length	Bytes in data buffer.
cb	Interrupt service routine—called when data transfers, or transmission error.
int	Polling interval.

**See Also**

[usbman\\_open\\_pipe\(\)](#)

## usbman\_pipe2device\_handle()

Return Device Handle

---

### Syntax

```
usb_device_handle usbman_pipe2device_handle(  
    usb_pipe_handle  pipe);
```

### Description

Returns the device handle associated with the given pipe. Upon completion, this function returns the device handle associated with this pipe.

### Parameters

pipe	A valid pipe handle, created by <code>usbman_open_pipe</code> .
------	---

## usbman\_set\_config\_index()

### Set Configuration Index

---

#### Syntax

```
usbcd_status usbman_set_config_index(  
    usbcd_device_handle dev,  
    int index,  
    int msg);
```

#### Description

Sets the configuration index for the given device. This will perform transfers over the USB. This call assumes that no interrupt, bulk, or isochronous pipes are open on dev.

This function returns `USBD_NORMAL_COMPLETION` if successful; `USBD_NOMEM` if no memory is available; `USBD_IOERROR` when there is a transfer error to the device; `USBD_STALLED` if the transfer caused the device to STALL; `USBD_INVALID` when a bad configuration descriptor is retrieved from the device; and `USBD_NO_POWER` when the device exceeds available power on the hub.

#### Parameters

dev	A valid device handle.
index	Configuration index to set.
msg	Unused.

#### See Also

[usbman\\_set\\_config\\_no\(\)](#)

## usbman\_set\_config\_no()

### Set Configuration

---

#### Syntax

```
usbman_status usbman_set_config_no(  
    usbman_device_handle dev,  
    int no,  
    int msg);
```

#### Description

Sets the configuration for the given device specified by `config_no`. This will perform transfers over the USB. This call assumes that no interrupt, bulk, or isochronous pipes are open on `dev`.

This function returns `USBD_NORMAL_COMPLETION` if successful; `USBD_NOMEM` if no memory is available; `USBD_IOERROR` when there is a transfer error to the device; `USBD_STALLED` if the transfer caused the device to STALL; `USBD_INVALID` when a bad configuration descriptor is retrieved from the device; and `USBD_NO_POWER` when the device exceeds available power on the hub.

#### Parameters

<code>dev</code>	A valid device handle.
<code>no</code>	Configuration index to set.
<code>msg</code>	Unused.

#### See Also

[usbman\\_set\\_config\\_index\(\)](#)

## usbman\_set\_idle()

### Silence Report on the Interrupt In Pipe

---

#### Syntax

```
usbman_status usbman_set_idle(  
    usbman_interface_handle  iface,  
    int                      duration,  
    int                      id);
```

#### Description

Silences a particular report on the interrupt In Pipe until a new event occurs or until the specified time passes. Valid for an HID device only.

#### Parameters

iface	A valid interface handle.
duration	Duration of the file.
id	Identification for idle.

#### See Also

[usbman\\_set\\_protocol\(\)](#)



---

### For More Information

For more information refer to the USB HID 1.1 Specification.

---

## usbman\_set\_interface()

Request Interface Change

---

### Syntax

```
usb_d_status usbman_set_interface(  
    usb_d_interface_handle  iface,  
    int                     altidx);
```

### Description

Requests an interface change specified by `iface->index`. This will perform transfers on the USB. This function returns `USBD_NORMAL_COMPLETION` if successful; `USBD_NOMEM` if no memory is available; `USBD_IOERROR` when there is a transfer error to the device; and `USBD_STALLED` if the transfer caused the device to STALL.

### Parameters

<code>iface</code>	A valid interface handle.
<code>altidx</code>	Alternate interface handle, 0 if none.



## usbman\_set\_protocol()

### Switch Between Boot and Report Protocol

---

#### Syntax

```
usbman_status usbman_set_protocol(  
    usbman_interface_handle  iface,  
    int                      report);
```

#### Description

Switches between the boot protocol and report protocol for an HID device.

#### Parameters

iface	Valid interface.
report	0: boot protocol. 1: report protocol.

#### See Also

[usbman\\_set\\_idle\(\)](#)



---

### For More Information

For more information refer to the USB HID 1.1 Specification.

---

## usbman\_set\_report()

Perform Set Report Request

### Syntax

```
usbman_status usbman_set_report(
    usbman_interface_handle  iface,
    int                      type,
    int                      id,
    void                    *data,
    int                      len);
```

### Description

Performs a set report request to the given interface. This function returns `USBMAN_NORMAL_COMPLETION` if successful; `USBMAN_NOMEM` if no memory is available; `USBMAN_IOERROR` when there is a transfer error to the device; and `USBMAN_STALLED` if the transfer caused the device to STALL.

### Parameters

<code>iface</code>	A valid interface handle.
<code>type</code>	<code>UHID_INPUT_REPORT</code> , <code>UHID_OUTPUT_REPORT</code> , <code>UHID_FEATURE_REPORT</code> .
<code>id</code>	Report value id.
<code>*data</code>	Pointer to memory for request data.
<code>len</code>	Length of data.

### See Also

[usbman\\_set\\_idle\(\)](#)  
[usbman\\_set\\_protocol\(\)](#)



## usbman\_setup\_default\_xfer()

Initialize Transfer Handle

### Syntax

```
void usbman_setup_default_xfer(
    usbd_xfer_handle      xfer,
    usbd_device_handle    dev,
    usbd_private_handle   priv,
    u_int32_t             timeout,
    usb_device_request_t  *req,
    void                  *buffer,
    u_int32_t             length,
    u_int16_t             flags,
    usbd_callback         cb);
```

### Description

Initializes a transfer handle `xfer` with given parameter values. Upon completion, this function returns nothing.

### Parameters

<code>xfer</code>	A valid transfer handle returned from <code>usbman_alloc_xfer</code> .
<code>dev</code>	A valid USB device associated with the transfer.
<code>priv</code>	Parameter passed to interrupt service routine.
<code>timeout</code>	Milli-seconds to wait before timing out, or <code>USB_NO_TIMEOUT</code> .
<code>*req</code>	Device request if using control pipe, otherwise <code>NULL</code> .
<code>*buffer</code>	Memory to hold transfer.
<code>length</code>	Bytes in <code>buffer</code> .

flags	USBD_NO_COPY, USBD_SYNCHRONOUS, USBD_SHORT_XFER_OK, or USBD_FORCE_SHORT_XFER.
cb	Function to be called when transfer has completed.

**See Also**

[usbman\\_setup\\_isoc\\_xfer\(\)](#)  
[usbman\\_setup\\_xfer\(\)](#)

## usbman\_setup\_isoc\_xfer()

Initialize ISOC Transfer

### Syntax

```
void usbman_setup_isoc_xfer(
    usbd_xfer_handle    xfer,
    usbd_pipe_handle    pipe,
    usbd_private_handle priv,
    u_int16_t           *frlengths,
    u_int32_t           nframes,
    u_int16_t           flags,
    usbd_callback        cb);
```

### Description

Initializes a transfer handle `xfer` with given parameter values. Upon completion, this function returns nothing.

### Parameters

<code>xfer</code>	A valid transfer handle.
<code>pipe</code>	A valid open pipe.
<code>priv</code>	Parameter passed to interrupt service routine.
<code>*frlengths</code>	Array of frame lengths.
<code>nframes</code>	Number of frames (elements in <code>frlengths</code> ).
<code>flags</code>	USBD_NO_COPY, USBD_SYNCHRONOUS, USBD_SHORT_XFER_OK, or USBD_FORCE_SHORT_XFER.
<code>cb</code>	Function to be called when transfer has completed.

### See Also

[usbman\\_setup\\_default\\_xfer\(\)](#)

```
usbman_setup_xfer()
```

## usbman\_setup\_xfer()

### Assign Fields in Transfer

#### Syntax

```
void usbman_setup_xfer(
    usbd_xfer_handle    xfer,
    usbd_pipe_handle    pipe,
    usbd_private_handle priv,
    void                *buffer,
    u_int32_t            length,
    u_int16_t            flags,
    u_int32_t            timeout,
    usbd_callback        cb);
```

#### Description

Initializes a transfer handle `xfer` with given parameter values. Upon completion, this function returns nothing.

#### Parameters

<code>xfer</code>	A valid transfer handle.
<code>pipe</code>	A valid open pipe.
<code>priv</code>	Parameter passed to interrupt service routine.
<code>*buffer</code>	Receiving the DMA buffer.
<code>length</code>	Bytes in data buffer.
<code>flags</code>	USBD_NO_COPY, USBD_SYNCHRONOUS, USBD_SHORT_XFER_OK, or USBD_FORCE_SHORT_XFER.
<code>timeout</code>	Number of milliseconds to wait for device to respond to transfer.
<code>cb</code>	Function to be called when transfer has completed.



**See Also**

`usbman_setup_default_xfer()`  
`usbman_setup_isoc_xfer()`

## usbman\_sync\_transfer()

### Perform Asynchronous Transfer

---

#### Syntax

```
usbd_status usbman_sync_transfer(  
    usbd_xfer_handle req);
```

#### Description

Performs a synchronous transfer on the USB. The transfer handle `req` specifies direction, data, timeout, and transfer type. This call will not return until the transfer has completed successfully, timed out, or a USB error occurs.

This function returns `USBD_NORMAL_COMPLETION` if successful; `USBD_NOMEM` if no memory is available; `USBD_IOERROR` when there is a transfer error to the device; `USBD_STALLED` if the transfer caused the device to STALL; and `USBD_TIMEOUT` when no transfer occurred because the time interval expired.

#### Parameters

<code>req</code>	A valid transfer handle.
------------------	--------------------------

#### See Also

[usbman\\_bulk\\_transfer\(\)](#)  
[usbman\\_transfer\(\)](#)

## usbman\_transfer()

Initialize Bulk Transfer

---

### Syntax

```
usbd_status usbman_transfer(usbd_xfer_handle req);
```

### Description

Initiates a bulk data transfer, either incoming or outgoing. This function returns `USBD_NORMAL_COMPLETION` if the operation is successful; `USBD_NOMEM` if there is no memory to allocate DMA buffer; and `USBD_TIMEOUT` if the operation timed out.

### Parameters

<code>req</code>	A valid <code>usbd_xfer</code> structure as allocated by <code>usbd_alloc_xfer()</code> .
------------------	---



## Chapter 4: USB Host for OS-9 Utilities

This chapter provides a description of the USB Host for OS-9 utilities. **Table 4-1** summarizes the USB utilities.

**Table 4-1 USB Host for OS-9 Utilities**

<b>Name</b>	<b>Description</b>
<code>usbdevs</code>	Print Current Devices on the USB
<code>usbprint</code>	Print Source File
<code>ugenstat</code>	Display Descriptors for Given UGEN Descriptor



MICROWARE SOFTWARE

## Syntax

```
usbdevs [options]
```

## Source

```
SRC/IO/USBH/UTILS/USBDEVS
```

## Options

- e Display extended information.
- a [=]<n> Display device address[n] information.

## Description

This utility prints out the current devices on the USB. This information includes the device descriptor, configuration descriptor, interface descriptor, and any string descriptors. The `-a` option can be used to select a particular device by USB address and display extended information for that device.

## Example

The following example shows a root hub with two ports, a four port hub, and a mouse. Hub ports are shown within the square braces, and each hub level will have a four space indent.

```
$ usbdevs
Root Address 1, Hub
[1] -
[2] Address 2, Hub (vendor 1105, product 5190)
    [1] Address 3, NOVATEK : USB Mouse STD.
    [2] -
    [3] -
    [4] -
```

**usbprint**Print Source File

---

**Syntax**

```
usbprint [options] <source-file> [<printer-device>]
```

**Source**

```
SRC/IO/USBH/UTILS/USBPRINT
```

**Options**

`-m` Search for source file in module directory.

**Description**

This utility prints the source file to the specified printer device. If no printer device is specified, it will default to `/ulp0`.

**Example**

- Printing using the standard USB printer driver.

```
$ usbprint sample.txt /ulp0
```

- Printing using the Generic USB driver.

```
$ usbprint sample.txt "/ugen0#2"
```

## Display Descriptors for Given UGEN Descriptor

---

### Syntax

```
ugenstat [device]
```

### Source

```
SRC/IO/USBH/UTILS/UGENSTAT
```

### Description

This utility displays the device, configuration, interface, endpoint, and string descriptors for the given UGEN device descriptor. If no descriptor is specified, the default will be /ugen0.

### Example

The following example shows a mouse attached to /ugen0.

```
$ ugenstat /ugen0
Device Descriptor:  12010001 00000008 03067168 00010422 0001
NOVATEK             USB Mouse STD.
Number of Configurations:  1
Config Descriptor 1:  09022200 010100a0 32

    Number of interfaces:  1
    Interface Descriptor 0:  09040000 01030102 00

        Number of endpoints:  1
        Endpoint Descriptor 0:  07058103 08000a
```




---

## For More Information

The data format printed for the descriptors is defined in the USB 1.1 documentation. This can be found at [www.usb.org](http://www.usb.org).

---



---

# Appendix A: Porting to the USB Host Stack

---

This chapter details how to port to the USB Host stack. The following sections are included:

- **Writing the Logical Device Driver (LDD)**
- **Writing a Hardware Control Driver**



MICROWARE SOFTWARE

## Writing the Logical Device Driver (LDD)

---

This section will describe how to make a new Logical Device Driver for the USB Host Stack. Any file manager may be used for an LDD, but in this chapter, the driver will be under the NullFM File Manager.

Before you begin, you will need to decide the following information:

- the directory name for the LDD
- the driver name
- the descriptor name

The makefile and all of the source code files for the LDD will reside in the following directory:

```
/mwos/SRC/DPIO/NULLFM/DRV/USBH/<YOUR_LDD_DIRECTORY_NAME>
```

Both the driver and descriptor modules will be located in the following directory:

```
/mwos/OS9000/<PROCESSOR>/CMDS/BOOTOBS/USBH
```

## Creating a Directory Structure

The first step in writing an LDD is to create a directory structure for your NullFM driver. This will be the directory in which you will copy and modify files from the sample driver directory (`SAMPLE_LDD`). Follow the procedure below to create this structure and associated files for your new LDD.

- 
- Step 1. Create a new folder in the `/mwos/SRC/DPIO/NULLFM/DRV/USBH` directory. This folder will contain the source files and makefiles for your NullFM driver.
  - Step 2. Create a `DEFS` directory within the folder you just created. This directory will contain all header files specific to this driver and descriptor.

**Step 3.** Copy the following files from the `SAMPLE_LDD` directory (sample driver) into your driver directory:

- `drvvr.mak`
- `init.c`
- `makefile`
- `rw.c`
- `desc.mak`
- `hw.c`
- `main.c`
- `os9_dev.c`
- `stat.c`

**Step 4.** Copy the following files from the `SAMPLE_LDD/DEFS` directory into the `DEFS` directory of your driver:

- `defsfile.h`
- `desc.h`
- `funcs.h`
- `usbh_desc.h`

## Implementing your LDD

Below is a step-by-step guide of which code to modify in each file copied from the `SAMPLE_LDD` directory. This step-by-step guide details an example scenario using a camera driver and descriptor. (`ucamera` is the driver name, and `ucamera0` is the descriptor name.)

- 
- Step 1. Modify the `drvvr.mak` file to change the driver name and directory. To do this, change the `TRGTS` and `DRVNAME` macros to the name of your LDD driver. Then, change the `LOCDRV` macro to the source directory name of your LDD. Below is an example that shows the driver name as `ucamera` and the directory as `UCAMERA`.

```
TRGTS= ucamera
```

```
LOCDRV= USBH/UCAMERA
```

```
DRVNAME= ucamera
```

- Step 2. Modify the descriptor name in the `desc.mak` file. To do this you will need to change the `TRGTS` macro. Below is an example that shows a descriptor name of `ucamera0`.

```
TRGTS= ucamera0
```



### Note

The descriptor name and driver name must be different.

---

- Step 3. Modify the `desc.h` file located in the `DEFS` directory. This file contains the basic descriptor information for your LDD NullFM driver. You will need to change the `DRIVERNAME` definition and the descriptor name pre-processing conditional. Below is an example:

```
#if defined(ucamera0)

#define DRIVERNAME          "ucamera"

#define FILEMANAGERNAME     "nullfm"

#define VECTOR 0

#define IRQLEVEL 5

#define PRIORITY 20

#define PORTADDR(void*)0x0

#define DEVICE_MODE          FAM_READ | FAM_WRITE

#endif
```

- Step 4. Modify the `os9_dev.c` file to incorporate device specific changes to the `os9_match`, `os9_detach`, `os9_attach`, and the `os9_intr` routines.



---

## For More Information

For more information on these routines, refer to the **Logical Device Drivers** section of Chapter 2 of this manual.

---

- Step 5. If your driver should respond to either a read or write on an open path, modify the `rw.c` file. In addition, the `data_available` function should be modified to return the number of bytes available for read.

## Additional File Information

Below is a list of files that may not require direct modification.

<code>makefile</code>	main makefile that builds the driver and descriptor
<code>init.c</code>	implements driver initialization and termination routines
<code>hw.c</code>	called during initialization and termination to open a path and register with <code>usbman</code>
<code>main.c</code>	main psect for this driver
<code>stat.c</code>	contains <code>setstat</code> and <code>getstat</code> routines for this driver.
<code>DEFS/defsfile.h</code>	main include file to include other header files
<code>DEFS/funcs.h</code>	contains all global function/type definitions for the driver
<code>DEFS/usbh_desc.h</code>	file that allows you to extend the driver static storage definition

## Writing a Hardware Control Driver

---

This section describes the steps necessary to write a new hardware control driver for the USB Host stack for OS-9.



---

### Note

Before reading this chapter, be certain you have perused **Chapter 2: Using USB Host for OS-9** of this manual.

---

## Overview

A USB hardware driver is responsible for initializing the USB hardware, scheduling transfers, and servicing interrupts. The USB manager, `usbman`, is responsible for scheduling all transfers for the hardware controller driver. It is the responsibility of the hardware driver to perform these transfers and provide notification when the transfers are complete.

## Transfer Types

The hardware controller driver must implement following six types of transfer:

- root hub control
- root hub interrupt
- device control
- device interrupt
- device bulk
- device isochronous transfers

Each transfer type has a function block associated with it. This function block allows `usbman` to call directly into the hardware control driver to start transfers, close a pipe, abort a pipe, and other such operations. Below is the definition of the transfer function block located in `usbdivar.h`:

```
struct usbd_pipe_methods {  
    usbd_status      (*transfer)(usbd_xfer_handle xfer);  
    usbd_status      (*start)(usbd_xfer_handle xfer);  
    void             (*abort)(usbd_xfer_handle xfer);  
    void             (*close)(usbd_pipe_handle pipe);  
    void             (*cleartoggle)(usbd_pipe_handle pipe);  
    void             (*done)(usbd_xfer_handle xfer);  
};
```



## Bus Methods Structure

The hardware control driver must also implement a bus methods structure; this is another way that `usbman` can call directly into the hardware control driver. This structure contains functions for opening a pipe, allocating and freeing memory, and allocating and freeing DMA memory.

Below is the structure definition located in `usbdivar.h`.

```
struct usbd_bus_methods {
    usbd_status      (*open_pipe)(struct usbd_pipe *pipe);
    void             (*soft_intr)(struct usbd_bus *);
    void             (*do_poll)(struct usbd_bus *);
    usbd_status      (*allocm)(struct usbd_bus *, usb_dma_t *,
    u_int32_t bufsize);
    void             (*freem)(struct usbd_bus *, usb_dma_t *);
    struct usbd_xfer * (*allocx)(struct usbd_bus *);
    void             (*freex)(struct usbd_bus *,
                            struct usbd_xfer *);
};
```

The bus methods function block is returned by the hardware control driver in response to a `GS_USB_BUS_METHODS` `getstat`. `usbman` performs this `getstat` while initializing the USB stack.

## Calling usbman

The hardware controller driver may also call into `usbman` on two occasions: to insert a transfer into the list and to notify `usbman` when a transfer was completed. These methods are given to the hardware control driver from `usbman` by the `SS_USB_MAN_METHODS` `setstat`. This means the hardware control driver must acknowledge this `setstat` and store the methods and global pointer for `usbman`.

## Existing Drivers

Because a sample driver does not currently exist, you must start from one of the three existing hardware controller drivers: OHCI, PHCI, and SL811HST. Below is a brief description of each driver.

### OHCI

commonly used on desktop computers  
([www.usb.org/developers/docs.html](http://www.usb.org/developers/docs.html))

This driver stores an elaborate list of items to transfer and only generates an interrupt after a successful transfer on the USB. The OHCI controller walks the transfer list and schedules USB time in hardware. In addition, this driver requires some type of shared memory between the processor and the controller.

### PHCI

driver for the Philips ISP1161/2 embedded USB Host chip

This hardware is more CPU intensive than the OHCI driver. Software must schedule transfers every millisecond, but more than one transfer may be scheduled. At the end of the frame (one millisecond), the software must determine which transfers were successful and schedule more transfers on the USB for the next frame.

**SL811HS**

driver for the ScanLogic 811HS USB Host chip

This is the most CPU intensive hardware because the hardware driver must schedule every transfer on the USB. This results in many interrupts per frame (millisecond). SL811HS does not have an integrated root hub. Instead, the driver is notified of a voltage change on the bus, where it must then determine if something was inserted or removed from the root hub.

## Implementing the Driver

To implement the driver, complete the following steps:

- 
- Step 1. Make a new directory in `/mwos/SRC/DPIO/NULLFM/DRVR/USBH` and a `DEFS` subdirectory and copy files from one of the existing drivers.
  - Step 2. Create a new directory and `DEFS` subdirectory in the board port to contain the makefiles and board definitions for this driver (`/MWOS/OS9000/<PROCESSOR>/PORTS/<BOARD>/NULLFM/YOUR_DRIVER_NAME`). Copy port files from an existing USB Host driver into this directory. These makefiles will require some modification in order to redefine any source or include paths.

- Step 3. If your driver uses DMA, you will need to define the following symbol: `USE_NONCACHED_MEM`. This will include code in `usb_mem.c` to perform memory allocation for DMA memory. The `malloc_dma` function defined in this file performs an allocation out of a non-cached memory shade. This function will also ensure that the memory allocated is on the proper alignment boundary.
- When using the `USE_NONCACHED_MEM` define, DMA memory allocations occur out of the `M_USB_DMA` memory shade. To reduce memory fragmentation, the MAUI memory APIs are used. Thus, a MAUI memory shade for `M_USB_DMA` must be created before using the `malloc_dma` function. (Refer to `init.c` in the OHCI driver)
- Step 4. Update the `desc.h` file located in `/MWOS/OS9000/<PROCESSOR>/PORTS/<BOARD>/NULLFM/<YOUR_DRIVER>/DEFS`. In particular, the `VECTOR`, `IRQLEVEL`, `PRIORITY`, and `PORTADDR` must be updated to reflect the proper values for the board.
- Step 5. Update the USB hardware specific file in the driver. This file contains the hardware initialization, termination, interrupt service routine, and `usbman` entrypoints. Development of this driver will take time, but can be achieved if tested. The section below contains more information on testing the USB Host driver.

## Testing the Driver

Testing a USB Host driver occurs in several phases starting with the most basic test: initializing and de-initializing the driver. Below is a sample command used to initialize your driver on your OS-9 target. You will need your driver, descriptor, and the NullFM File Manager on your OS-9 target.

```
$iniz /usbhc
```

After the above command is issued, the `init` entrypoint in the NullFM driver will be called. When this is complete, perform the following steps:

- 
- Step 1. Set a breakpoint on this function and step through the code to see if hardware initialization occurred properly.
  - Step 2. Turn on the start-of-frame (SOF) interrupt in the initialization code for your driver. SOF interrupts occur every 1 milli-second; you will know if one has occurred by setting a breakpoint on your interrupt service routine.
  - Step 3. Test termination of the driver by typing the following command:

```
$ deiniz /usbhc
```

After this command is issued, the `term` entrypoint is called. It is important to make sure that the hardware is turned off properly and that interrupts have been masked and memory deallocated. Repeated `iniz` and `deiniz` commands can be used to test memory leakage by using the `mfree` command.

- Step 4. Determine if a root hub interrupt is being raised. To do this, set a breakpoint in the part of your interrupt service routine that handles the root hub interrupt.
- Step 5. Iniz your driver and plug in a device like a hub or mouse into the USB port. The root hub interrupt should fire when the device is plugged in. If your hardware does not have an integrated root hub into the chip, refer to the SL811HS driver.

- Step 6. Iniz `usbman`. Below is a sample of how to do this. You will need the driver, descriptor, the NullFM file manager, `usbman` driver, and `usbman` descriptor on your OS-9 target.

```
$ iniz /usb
```

Iniz-ing `/usb` will cause `usbman` to initialize and iniz your hardware driver. At this point, there will be an exchange of information between `usbman` and your driver via `getstat/setstats`. If this swap of information is successful, your driver and `usbman` have exchanged entypoints.

- Step 7. Start the `usbd` daemon. This opens a path to `usbman` and perform an explore on USB. Using the `-v` option will print out each occurrence of a USB explore. The `usbd` program performs an explore whenever a root hub interrupt occurs.



---

## Note

It is important to plug in and out a device multiple times to ensure that the root hub interrupt is working properly.

---

The `-v` option command is shown below:

```
$usbd -v
```

At this point, the `usbdevs` program can be used to print out information about devices on the USB.



---

## Note

As soon as a device is plugged into the USB, an explore should occur.

---

When the explore is successful, the `usbdevs` program prints out the configuration information for the device. It is helpful to leave `usbd -v` running in the foreground on the console and use the `usbdevs` program on a second serial port (or telnet window).

You should be able to run `usbdevs` after plugging in or removing a device on the USB. `usbdevs` will display current topology. If it does not, you have a USB transfer problem.

- Step 8. As a final test, perform the tests in **Chapter 1: Getting Started with USB Host for OS-9** of this manual once more. This will ensure that control and interrupt pipes are working properly. If you require a device with bulk or isochronous endpoints, you will need to write a separate application to perform the tests relating to those endpoints.
-

