




Desktop CNC Router Masuter Pro



USER MANUAL

Please read this manual carefully before using.

Catalog

Warranty & Disclaimer	1
Product Specifications	2
How to Assemble the Machine	3
Wiring Diagrams	15
• XYZ Stepper Wiring Diagrams	15
• XYZ Limit Switch Wiring Diagrams	16
• Spindle & Light Wiring Diagrams	17
Controller Instructions	18
How to Install the Router Bit	19
How to Use Grblcontrol (Candle)	20
• Driver Installation	20
• Grblcontrol (Candle) Working Interface Introduction	21
Make Your First Cut	22
How to Unlock Limit Switch	24
How to Use E-stop	25
Z-Probe Operating	26
Extended Accessories	27
• Offline Controller	27
• Laser Module	27
• 300W Spindle	28

Warranty & Disclaimer



Please be careful when using your CNC machine. This machine is an electrical device with moving parts and dangerous areas.

- This CNC Machine is for Indoor Use Only.
- Wear the proper protection equipment while operating.
- Always place the CNC Machine on a stable surface.
- Never disassemble the Power Supply or Electrical Components. This may cause damage and will VOID the warranty.
- DO NOT TOUCH the machine spindle, or place any part near the working area when the machine is operating. DO NOT leave children unsupervised with the CNC Machine even when it's not operating. Injury may occur.
- DO NOT leave the machine unattended while it's operating.

One Year Warranty

- This product is warranted against any defective material or workmanship for a period of twelve months from date of delivery.
- Any parts determined by the manufacturer to be defective will be replaced in whole or part as determined by the manufacturer, but no labor costs or other claims for damages will be allowed.

Product Specifications

Model	Masuter Pro
Working Area	400 x 400 x 60mm (15.75" x 15.75" x 2.36")
Input Voltage	12V
Input Current	5A
Spindle Power	60W
Spindle Speed	10000 r/min
Motor	NEMA17
Firmware Version	1.1H
Limit Switch	X, Y, Z
Emergency Stop Button	Yes
Support OS	Windows XP, Windows 7, Windows 8, Windows 10, Windows 11, Linux, Mac OS
Software	Grblcontrol(Candle), other GRBL compatible software
Offline Working	Supports offline working, offline control sold separately
Support Add-ons	Laser, Offline controller, 300W Spindle& Trimmer (NOT included)

How to Assemble the Machine

1



2x



8x




1 Y-axis Aluminum Profile (L)

2 Y-axis Aluminum Profile (R)

4 X-axis Aluminum Profile

20 M5*20 Flat Cap Bolt



How to Assemble the Machine

2





8x




5 MDF Spoil Board

17 M5*20 Bolt



How to Assemble the Machine

3





4x




3 X-axis Gantry

19 M5*16 Flat Cap Bolt



How to Assemble the Machine

4



6 Spindle Holder

4x





16 M5*12 Bolt

4x



23 Washer





How to Assemble the Machine

5



7 Spindle



How to Assemble the Machine

6



12 Y-axis Drag Chain Bracket





13 Y-axis Drag Chain Bracket

4x



21 M3*6 Button Cap Bolt



How to Assemble the Machine

7





2x



14 X-axis Drag Chain Bracket

21 M3*6 Button Cap Bolt



How to Assemble the Machine

8



8 Controller Support Plate




9 Controller

2x



22 M3*8 Button Cap Bolt



How to Assemble the Machine

9

2x




15 M5*8 Bolt

2x



24 M5 T-nut




How to Assemble the Machine

10



25 Hex Wrench



How to Assemble the Machine

11




4x



11 Y Axis Drag Chain

18 M4*6 Flat Cap Bolt



How to Assemble the Machine

12





11 Y Axis Drag Chain

4x







18 M4*6 Flat Cap Bolt






Wiring Diagrams


- X, Y & Z Stepper Motors Wiring Diagrams



- X, Y & Z Limit Switches Wiring Diagrams




- Spindle & Light Wiring Diagrams



Positive wire (Red) connects to the port with red dot
Negative wire (Blue) connects to the other port




60W spindle plugged into Spindle 1 socket
Flip the toggle switch to the right side



Light: Insert the plug to the socket

Controller Instructions





Toggle Switch: Flip to the left when using 300W Spindle
Flip to the right when using 60W Spindle or Laser



How to Install the Router Bit



Unlock the cap




Tighten

How to Use Grblcontrol (Candle)


-Driver Installation



Download from U disk.
Double-click to start installation.



Click "INSTALL"





Wait until it shows "Driver install success"



To Determine your Machine's COM port

- **For Windows XP:** Right click "My Computer" → Select "Manage" → Select "Device Manager".
- **For Windows 7:** Right click "Computer" → Select "Manage" → Select "Device Manager" from left pane.
- **For Windows 10:** Right click "This PC" → Select "Manage" → Select "Device Manager" from left pane.
- In the tree, expand "Ports (COM & LPT)", your machine will be the USB Serial Port (COMX), where the "X" represents the COM number, for example COM6.
- If there are multiple USB serial ports, right click each one and check the manufacturer, the machine will be "CH340".



Connect the USB cable to the PC
and the controller.

-Grblcontrol (Candle) Working Interface Introduction

The screenshot shows the Grblcontrol (Candle) interface with the following components and labels:

- 3D preview interface, hold the left mouse button, can rotate Angle, scroll the mouse wheel, can be enlarged, or reduced.** (Points to the 3D model of the 'FoxAlien' part)
- If you cannot see anything, you need to change to a computer with support for OpenGL2.0 graphics cards.** (Points to the 3D model)
- Pattern size** (Points to the 'FoxAlien' text in the 3D view)
- Coordinate display** (Points to the 'Work coordinates' display showing 0.000, 0.000, 0.000)
- Status display** (Points to the 'Machine coordinates' display showing 0.000, 0.000, 0.000)
- Common operation button, the mouse icon on the above shows the specific function** (Points to the 'Control' section with icons for home, search, etc.)
- Spindle ON/OFF and control the spindle speed. You can manipulate the slider to reduce or increase the RPM. This is used only when manually switching on the spindle, not when running a G code program.** (Points to the 'Spindle' section with a speed slider set to 10000)
- Manual operation Direction buttons** (Points to the 'Jog' section with directional buttons)
- Step and Feed value**
E.g.: Step value=10 means moving distance is 10mm. Feed value=2000 means 2000mm/min (Points to the 'Step' and 'Feed' dropdowns)
- Open G-code file** (Points to the 'Open' button)
- Send G-code file** (Points to the 'Send' button)
- Command input box** (Points to the text input field for commands)
- Send command** (Points to the 'Send' button in the console area)

G-code program

```
[G0 G0 G54 G17 G21 G90 G94 M5 M9 T0 F0 S10000]
F/S: 0 / 0
```

Coordinates

```
X: 0.000 ... 112.596
Y: 0.000 ... 49.157
Z: -0.500 ... 3.810
112.596 / 49.157 / 3.810
```

Command Queue

#	Command	State	Response
1	G21	In queue	
2	M3 S10000	In queue	
3	G90	In queue	
4	G1 Z3.810 F228.6	In queue	
5	G0 X34.253 Y40.059	In queue	
6	G1 Z-0.500 F228.6	In queue	
7	G1 X40.263 Y40.059 F1016.0	In queue	


Console

```
[CTRL+X] < Grbl 1.1h ['$' for help]
S10000 < ok
```


Make Your First Cut




Double click to start
Grblcontrol (Candle)




Connect USB cable to computer and machine,
click Service->Port select COM port. Click "OK"




If Status becomes **Alarm**
and [MSG: Check Limits]
appears in the console at
the same time, please
check whether the limit
switch is triggered.
You can power off and
release the limit switch
manually or refer to page
24 of the manual to release
the limit via software.




Console window prints
"[CTRL+X] < Grbl 1.1h ['\$' for
help]" if the connection is
successful. Click "Unlock".



Console window prints
"**CTRL+X**" indicates that
the connection is failed.
Need to check whether
the E-stop is pressed down.
If yes, turn the E-stop
clockwise, and then click
"Unlock".




Fix the MDF with the clamps




1. Open the file
2. Choose the Step and Feed (Unit: mm)
3. Click the direction button to move the bit to the surface of the object.




The best distance between the bit and the object is that the bit should feel the A4 paper, and the paper can pass through the bit.




Engraving Finished.




1. Set origin. Click "Zero XY" and "Zero Z".
2. Click "Send" to start engraving




How to Unlock Limit Switch




Limit switch will trigger when the machine runs out of active working area.




Command window will show: "ALARM:1 [MSG:Reset to continue]"




Click "Reset"



If status change to "Alarm" again, that means it does not entirely move away from the limit switch, just repeat the previous steps to unlock.



Click direction buttons to move the axis way from limit switch.



Click "Unlock"


How to Use E-stop




Press down E-stop when the machine malfunctions to avoid damage.




Rotate clockwise to release the E-stop.



Status in software will change to "Alarm".




Click "Unlock" to normal working status.



Print "[MSG: '\$H' | '\$X' to unlock]"

Z-Probe Operating





Connect the wire




Measure Z probe actual size
(Thickness: 14.83mm)

Modify Z-probe parameter. Default value is Z15, change it to Z14.83 base of the parameter measured.



Place the probe as shown




Click "Zero XY"



Click Z-probe button to start detecting.
After Z-probe detection finished, remove
Z-probe, click "Send" to start engraving.

Extended Accessories (Available on foxalien.com)


- Offline Controller



Note: USB connection and offline controller can not be used at the same time.

Please unplug the USB cable when using the offline controller, otherwise it may cause errors, deviation or unusual stopping during engraving.


- Laser Module



Installation and Wiring Diagrams


Extended Accessories (Available on foxalien.com)

- 300W Spindle



Flip the toggle switch to the left

300W spindle plugged into
Spindle 2 socket



300W Spindle Installation and Wiring Diagrams

Please download the driver and software from the thumb drive included in the package.

It includes:

- CH340 Driver
- GrblControl (Candle) software for Windows
- Sample files
- PDF user manual

Or download the above documents from google drive link: <https://shor.at/yeSs87LA>

Please visit www.foxalien.com for more CNC machine accessories products.

Feel free to contact us for technical support if you come across any difficulty during assembly and using. E-mail: aftersale@foxalien.com,
support@foxalien.com

We will response within 1 business day.



Files Download



Facebook Group



Foxalien.com



FoxAlien

