

Technology module



Flying Saw -----

Reference Manual

EN



Contents

1	About this documentation	3
1.1	Document history	5
1.2	Conventions used	6
1.3	Definition of the notes used	7
2	Safety instructions	8
3	Functional description for the "Flying Saw"	10
3.1	Overview of the functions	12
3.2	Important notes on how to operate the technology module	13
3.3	L_TT1P_FlyingSaw[Base/State] function block	15
3.3.1	Inputs and outputs	16
3.3.2	Inputs	16
3.3.3	Outputs	19
3.3.4	Parameters	21
3.4	State machine	24
3.5	Signal flow diagrams	25
3.5.1	Structure of the signal flow	26
3.5.2	Structure of the access points	27
3.6	Manual jog (jogging)	28
3.7	Homing	29
3.8	Setting motion profiles (linear/S-ramps)	30
3.9	First synchronisation of the saw carriage to the material speed	31
3.10	Length-controlled operation (cutting of relative product lengths)	34
3.11	Mark-controlled operation (cutting to position markers)	37
3.12	Restoring the target position	40
3.13	Deleting the mark stack	43
3.14	Moving to the parking position	45
3.15	Window for following error monitoring	47
3.16	CPU utilisation (example Controller 3231 C)	49
	Index	50
	Your opinion is important to us	51

1 About this documentation

This documentation ...

- contains detailed information on the functionalities of the "Flying Saw" technology module;
- is part of the "Controller-based Automation" manual collection. It consists of the following sets of documentation:


Documentation type	Subject
Product catalogue	Controller-based Automation (system overview, sample topologies) Lenze Controller (product information, technical data)
System manuals	Visualisation (system overview/sample topologies)
Communication manuals Online helps	Bus systems <ul style="list-style-type: none">• Controller-based Automation EtherCAT®• Controller-based Automation CANopen®• Controller-based Automation PROFIBUS®• Controller-based Automation PROFINET®
Reference manuals Online helps	Lenze Controllers: <ul style="list-style-type: none">• Controller 3200 C• Controller c300• Controller p300• Controller p500
Software manuals Online helps	Lenze Engineering Tools: <ul style="list-style-type: none">• »PLC Designer« (programming)• »Engineer« (parameter setting, configuration, diagnostics)• »VisiWinNET® Smart« (visualisation)• »Backup & Restore« (data backup, recovery, update)

More technical documentation for Lenze components

Further information on Lenze products which can be used in conjunction with Controller-based Automation can be found in the following sets of documentation:

Planning / configuration / technical data	
<input type="checkbox"/>	Product catalogues <ul style="list-style-type: none">• Controller-based Automation• Controllers• Inverter Drives/Servo Drives
Mounting and wiring	
<input checked="" type="checkbox"/>	Mounting instructions <ul style="list-style-type: none">• Controllers• Communication cards (MC-xxx)• I/O system 1000 (EPM-Sxxx)• Inverter Drives/Servo Drives• Communication modules
<input type="checkbox"/>	Hardware manuals <ul style="list-style-type: none">• Inverter Drives/Servo Drives
Parameter setting / configuration / commissioning	
<input type="checkbox"/>	Online help/reference manuals <ul style="list-style-type: none">• Controllers• Inverter Drives/Servo Drives• I/O system 1000 (EPM-Sxxx)
<input type="checkbox"/>	Online help/communication manuals <ul style="list-style-type: none">• Bus systems• Communication modules
Sample applications and templates	
<input type="checkbox"/>	Online help / software and reference manuals <ul style="list-style-type: none">• i700 application sample• Application Samples 8400/9400• FAST Application Template Lenze/PackML• FAST technology modules

Symbols:

-  Printed documentation
- ☐ PDF file / online help in the Lenze engineering tool



Tip!

Current documentation and software updates with regard to Lenze products can be found in the download area at:

www.lenze.com

Target group

This documentation is intended for all persons who plan, program and commission a Lenze automation system on the basis of the Lenze FAST Application Software.

1 About this documentation

1.1 Document history


1.1 Document history

Version			Description
5.1	05/2017	TD17	<ul style="list-style-type: none">• Content structure has been changed.• General revisions
5.0	03/2016	TD17	<ul style="list-style-type: none">• New: Deleting the mark stack (📖 43)• General revisions
4.0	09/2015	TD17	<ul style="list-style-type: none">• General revisions• New outputs: xInPosition, xPositioning• New parameter: lRBladeWidth• Chapter Moving to the parking position (📖 45) has been revised.• Fig. State machine (📖 45) has been revised
3.0	07/2015	TD17	<ul style="list-style-type: none">• Corrections and additions• Content structure has been changed.
2.0	05/2015	TD17	<ul style="list-style-type: none">• General editorial revision• Modularisation of the contents for the »PLC Designer« online help
1.0	04/2014	TD00	First edition

1 About this documentation

1.2 Conventions used

This documentation uses the following conventions to distinguish between different types of information:

Type of information	Highlighting	Examples/notes
Spelling of numbers		
Decimal separator	Point	The decimal point is always used. For example: 1234.56
Text		
Program name	» «	»PLC Designer« ...
Variable names	<i>italics</i>	By setting <i>bEnable</i> to TRUE...
Function blocks	bold	The L_MC1P_AxisBasicControl function block ...
Function libraries		The L_TT1P_TechnologyModules function library ...
Source code	Font "Courier new"	... dwNumerator := 1; dwDenominator := 1; ...
Icons		
Page reference	 6	Reference to further information: Page number in PDF file.

Variable names

The conventions used by Lenze for the variable names of Lenze system blocks, function blocks, and functions are based on the "Hungarian Notation". This notation makes it possible to identify the most important properties (e.g. the data type) of the corresponding variable by means of its name, e.g. xAxisEnabled.

1.3

Definition of the notes used

The following signal words and symbols are used in this documentation to indicate dangers and important information:

Safety instructions

Layout of the safety instructions:

**Pictograph and signal word!**

(characterise the type and severity of danger)

Note

(describes the danger and gives information about how to prevent dangerous situations)

Pictograph	Signal word	Meaning
	Danger!	Danger of personal injury through dangerous electrical voltage Reference to an imminent danger that may result in death or serious personal injury if the corresponding measures are not taken.
	Danger!	Danger of personal injury through a general source of danger Reference to an imminent danger that may result in death or serious personal injury if the corresponding measures are not taken.
	Stop!	Danger of property damage Reference to a possible danger that may result in property damage if the corresponding measures are not taken.

Application notes

Pictograph	Signal word	Meaning
	Note!	Important note to ensure trouble-free operation
	Tip!	Useful tip for easy handling
		Reference to another document

2 Safety instructions

Please observe the safety instructions in this documentation when you want to commission an automation system or a plant with a Lenze Controller.



The device documentation contains safety instructions which must be observed!

Read the documentation supplied with the components of the automation system carefully before you start commissioning the Controller and the connected devices.



Danger!

High electrical voltage

Injury to persons caused by dangerous electrical voltage

Possible consequences

Death or severe injuries

Protective measures

Switch off the voltage supply before working on the components of the automation system.

After switching off the voltage supply, do not touch live device parts and power terminals immediately because capacitors may be charged.

Observe the corresponding information plates on the device.



Danger!

Injury to persons

Risk of injury is caused by ...

- unpredictable motor movements (e.g. unintended direction of rotation, too high velocities or jerky movement);
- impermissible operating states during the parameterisation while there is an active online connection to the device.

Possible consequences

Death or severe injuries

Protective measures

- If required, provide systems with installed inverters with additional monitoring and protective devices according to the safety regulations valid in each case (e.g. law on technical equipment, regulations for the prevention of accidents).
- During commissioning, maintain an adequate safety distance to the motor or the machine parts driven by the motor.

**Stop!****Damage or destruction of machine parts**

Damage or destruction of machine parts can be caused by ...


- Short circuit or static discharges (ESD);
- unpredictable motor movements (e.g. unintended direction of rotation, too high velocities or jerky movement);
- impermissible operating states during the parameterisation while there is an active online connection to the device.

Protective measures

- Always switch off the voltage supply before working on the components of the automation system.
- Do not touch electronic components and contacts unless ESD measures were taken beforehand.
- If required, provide systems with installed inverters with additional monitoring and protective devices according to the safety regulations valid in each case (e.g. law on technical equipment, regulations for the prevention of accidents).

3 Functional description for the "Flying Saw"


3 Functional description for the "Flying Saw"



[3-1] Typical mechanics of the technology module

3 Functional description for the "Flying Saw"

The flying saw provides the application of a machining process (e.g. sawing process, glue application) to material that is continuously passing through. A typical flying saw process is divided into the following motion stages:



The "Flying saw" technology module offers the following functionalities:

- In the "Base" version, the technology module can only operate in a length-controlled manner. The saw carriage is synchronised to the material speed.
- The "State" version provides an extended function range of the "Base" version:
The State version additionally provides mark-controlled operation, the recovery of the target position, travelling to a parking position, and following error monitoring.

► [Overview of the functions](#) (12)

3.1 Overview of the functions

In addition to the basic functions for operating the **L_MC1P_AxisBasicControl** function block, the **stop function** and the **holding function**, the technology module offers the following functionalities which are assigned to the "Base" and "State" versions:

Functionality	Versions	
	Base	State
Manual jog (jogging) (📖 28)	●	●
Homing (📖 29)	●	●
Setting motion profiles (linear/S-ramps) (📖 30)	●	●
First synchronisation of the saw carriage to the material speed (📖 31)	●	●
Length-controlled operation (cutting of relative product lengths) (📖 34)	●	●
Mark-controlled operation (cutting to position markers) (📖 37)		●
Restoring the target position (📖 40)		●
Deleting the mark stack (📖 43)		●
Moving to the parking position (📖 45)		●
Window for following error monitoring (📖 47)		●



»PLC Designer« Online help

Here you will find detailed information on the **L_MC1P_AxisBasicControl** function block, the **stop function** and the **holding function**.


3.2

Important notes on how to operate the technology module

For the "Flying Saw" technology module, the axes have to be configured as follows:

- The master axis has to be a rotary axis.
- The slave axis has to be a linear axis.

Go to the »PLC Designer« and set the corresponding **2** machine measuring system for each axis under the **Settings** tab:



During the cutting process the master axis must only move in positive direction.

In the application, the mounting direction **1** must also be set so that the master axis only moves in positive direction.

Setting of the operating mode

The operating mode for the slave axis has to be set to "cyclically synchronous position" (csp) because the axis is led via the master position value.

Controlled start of the axes

Motion commands that are set in the inhibited axis state ($xAxisEnabled = FALSE$) after enable ($xRegulatorOn = TRUE$) must be activated again by a $FALSE \rightarrow TRUE$ edge.

In this way it is prevented that the drive starts in an uncontrolled manner after controller enable.




Example [Manual jog \(jogging\)](#) (📖 28):

1. In the inhibited axis state ($xAxisEnabled = FALSE$), $xJogPos$ is set to $TRUE$.
 - $xRegulatorOn = FALSE$ (axis is inhibited.)
 \Rightarrow "READY" state ($xAxisEnabled = FALSE$)
 - $xJogPos = TRUE$ (manual jog is to be executed.)
2. Enable axis.
 - $xRegulatorOn = TRUE$
 \Rightarrow "READY" state ($xAxisEnabled = TRUE$)
3. Execute manual jog.
 - $xJogPos = FALSE \rightarrow TRUE$
 \Rightarrow "JOGPOS" state

3.3 L_TT1P_FlyingSaw[Base/State] function block

The figure shows the relation of the inputs and outputs to the "Base" and "State" versions.

The additional inputs and outputs of the "State" version are shaded.



3.3.1 Inputs and outputs

Designator	Data type	Description	Available in version	
			Base	State
MasterAxis	AXIS_REF	Reference to the master axis (master axis)	●	●
SlaveAxis	AXIS_REF	Reference to the slave axis	●	●

3.3.2 Inputs

Designator	Data type	Description	Available in version	
			Base	State
xEnableInternalControl	BOOL	TRUE In the visualisation, the internal control of the axis can be selected via the "Internal Control" axis.	●	●
xEnable	BOOL	Execution of the function block	●	●
		TRUE The function block is executed.		
		FALSE The function block is not executed.		
scCtrlABC	scCtrl_ABC	Input structure for the L_MC1P_AxisBasicControl function block <ul style="list-style-type: none"> scCtrlABC can be used in "Ready" state. If there is a request, the state changes to "Service". The state change from "Service" back to "Ready" takes place if there are no more requests. 	●	●
xResetError	BOOL	TRUE Reset axis error or software error.	●	●
xRegulatorOn	BOOL	TRUE Activate controller enable of the axis (via the MC_Power function block).	●	●
xStop	BOOL	TRUE Cancel the active movement and brake the axis to a standstill with the deceleration defined via the IrStopDec parameter. <ul style="list-style-type: none"> The state changes to "Stop". The technology module remains in the "Stop" state as long as xStop is set to TRUE (or xHalt = TRUE). The input is also active with "Internal Control". 	●	●
xHalt	BOOL	TRUE Cancel the active movement and brake the axis to a standstill with the deceleration defined via the IrHaltDec parameter. <ul style="list-style-type: none"> The state changes to "Stop". The technology module remains in the "Stop" state as long as xStop is set to TRUE (or xHalt = TRUE). 	●	●
scPar	L_TT1P_scPar_FlyingSaw[Base/State]	The parameter structure contains the parameters of the technology module. The data type depends on the version used (Base/State).	●	●
scAccessPoints	L_TT1P_scAP_FlyingSaw[Base/State]	Structure of the access points The data type depends on the version used (Base/State).	●	●
xJogPos	BOOL	TRUE Traverse axis in positive direction (manual jog). If xJogNeg is also TRUE, the traversing direction selected first remains set.	●	●
xJogNeg	BOOL	TRUE Traverse axis in negative direction (manual jog). If xJogPos is also TRUE, the traversing direction selected first remains set.	●	●

Designator	Data type	Description		Available in version	
				Base	State
xHomeExecute	BOOL	The input is edge-controlled and evaluates the rising edge.		●	●
		FALSE	Start homing.		
		TRUE	The function is aborted via the xStop input.		
xHomeAbsSwitch	BOOL	TRUE	Connection for reference switch: For homing modes with a reference switch, connect this input to the digital signal which maps the state of the reference switch.	●	●
xEnableHWLimit	BOOL	TRUE	The evaluation of the travel range limit switch (hardware limit switch) is activated.	●	●
xHWLimitPos	BOOL	Positive hardware limit switch Connect this input to the corresponding digital input that is connected to the limit switch.		●	●
		TRUE	The positive hardware limit switch has been reached or approached. <ul style="list-style-type: none"> The xHWLimitSwitchPos output is also set to TRUE. The axis is brought to a standstill with the deceleration in the alrStopDec parameter. The state changes to "ERROR" with the error message '20500' (HWLimitPos). 		
xHWLimitNeg	BOOL	Negative hardware limit switch Connect this input to the corresponding digital input that is connected to the limit switch.		●	●
		TRUE	The negative hardware limit switch has been reached or approached. <ul style="list-style-type: none"> The xHWLimitSwitchNeg output is also set to TRUE. The axis is brought to a standstill with the deceleration in the alrStopDec parameter. The state changes to "ERROR" with the error message '20501' (HWLimitNeg). 		
xStartFlyingSaw	BOOL	TRUE	The "Flying Saw" technology module is activated. <ul style="list-style-type: none"> Parameter xSyncFlyingSaw = TRUE: The saw carriage is synchronised to the material position. Parameter xSyncFlyingSaw = FALSE: The saw carriage waits for a signal for synchronising to the material position. 	●	●
		FALSE	The saw carriage is disengaged from the material position and brakes to a standstill. <ul style="list-style-type: none"> If the saw carriage is in waiting position, it is only disengaged. xParkPos parameter = TRUE: the saw carriage is disengaged first and then travels to its parking position. 		
xSyncInInstant	BOOL	The input is edge-controlled and evaluates the rising edge.		●	●
		FALSE	The saw carriage is synchronised to the material position. This can occur in the parking position or during a return.		
xExecuteNextCut	BOOL	The input is edge-controlled and evaluates the rising edge.		●	●
		FALSE	The saw carriage moves to the next machining position.		
xExecuteGap	BOOL	The input is edge-controlled and evaluates the rising edge.		●	●
		FALSE	The saw carriage moves by the distance set in the lGap parameter. This distance is added to the relative travel way (lCuttingLength input).		
lCuttingLength	LREAL	Cutting length (relative positioning) or cutting position (absolute positioning)		●	●

Designator	Data type	Description		Available in version	
				Base	State
xSetMaterialCounter	BOOL	The input is edge-controlled and evaluates the rising edge.		●	●
		FALSE	Sets the material position (lrMaterialCounter output) to the value of the lrStartPosition parameter.		
xMoveToParkPos	BOOL	The input ... • is only evaluated if the technology module is in "READY" state; • is edge-controlled and evaluates the rising edge.			●
		FALSE	The saw carriage is driven to the parking position (lrParkPosition parameter).		
xResumeTargetPos	BOOL	The input is edge-controlled and evaluates the rising edge.			●
		FALSE	The saw carriage is moved to the position of the lrTargetPos output.		
xResetMarkStack	BOOL	The input is edge-controlled and evaluates the rising edge.			●
		FALSE	All marks on the mark stack are removed. If this input is confirmed during the clutched-in state, the axis travels automatically to the waiting position (lrLowerLimit parameter).		
xMarkReceive	BOOL	TRUE	A touch probe mark has been detected in the connected touch probe sensor.		●
lrActMarkPosIn	LREAL	Current position of the touch probe mark with regard to the axis reference used. • Unit: units			●

3.3.3 Outputs

Designator Data type	Description		Available in version	
			Base	State
xInternalControlActive BOOL	TRUE	The internal control of the axis is activated via the visualisation. (xEnableInternalControl input = TRUE)	●	●
eTMState L_TT1P_States	Current state of the technology module ► State machine (□ 24)		●	●
scStatusABC scStatus_ABC	Structure of the status data of the L_MC1P_AxisBasicControl function block		●	●
xError BOOL	TRUE	There is an error in the technology module.	●	●
xWarning BOOL	TRUE	There is a warning in the technology module.	●	●
eErrorID L_IE1P_Error	ID of the error or warning message if xError = TRUE or xWarning = TRUE. Possible error or warning messages (IDs): 17125: The position of the slave axis exceeds the set "lrUpperLimit" parameter. 17126: The position of the slave axis falls below the set "lrLowerLimit" parameter. 17127: The target position to be approached exceeds the set "lrUpperLimit" parameter. 17128: The position detected by the mark sensor is out of the valid range. "FAST technology modules" reference manual: Here you can find information on further error or warning messages.		●	●
scErrorInfo L_TT1P_scErrorInfo	Error information structure for a more detailed analysis of the error cause		●	●
scSignalFlow L_TT1P_scSF_FlyingSaw[Base/State]	Structure of the signal flow The data type depends on the version used (Base/State). ► Signal flow diagrams (□ 25)		●	●
xAxisEnabled BOOL	TRUE	The axis is enabled.	●	●
xDone BOOL	TRUE	The request/action has been completed successfully.	●	●
xBusy BOOL	TRUE	The request/action is currently being executed.	●	●
xIsHomed BOOL	TRUE	The axis has been referenced (reference known).	●	●
xHwLimitSwitchNeg BOOL	TRUE	The negative hardware limit switch has been reached or approached. <ul style="list-style-type: none"> The xHwLimitNeg input has to be connected to the digital input that is connected to the limit switch. The xHwLimitNeg input is also set to TRUE. The drive is brought to a standstill with the deceleration set in the lrStopDec parameter. The state changes to "ERROR" with the error message '20501' (HwLimitNeg). 	●	●

Designator	Data type	Description		Available in version	
				Base	State
xHwLimitSwitchPos	BOOL	TRUE	The positive hardware limit switch has been reached or approached. <ul style="list-style-type: none">The xHwLimitPos input has to be connected to the digital input that is connected to the limit switch.The xHwLimitPos input is also set to TRUE.The drive is brought to a standstill with the deceleration set in the IrStopDec parameter.The state changes to "ERROR" with the error message '20500' (HwLimitPos).	●	●
xSwLimitEnabled	BOOL	TRUE	Activate the monitoring of the software limit positions.	●	●
xSwLimitSwitchActive	BOOL	TRUE	A software limit position has been reached or exceeded. <ul style="list-style-type: none">The drive is brought to a standstill with the deceleration set in the IrStopDec parameter.The state changes to "ERROR" with error message '20306' (SWLimitPos) or '20307' (SWLimitNeg).	●	●
xSynchronised	BOOL	TRUE	The axis is synchronised to the cam.	●	●
xAccDecSync	BOOL	TRUE	The synchronisation function is active. The axis is synchronised or desynchronised (clutch opens or closes).	●	●
xInPosition	BOOL	TRUE	The axis has reached the parking position.	●	●
xPositioning	BOOL	TRUE	The axis travels to the parking position	●	●
IrActPos	LREAL	Current position <ul style="list-style-type: none">Unit: units		●	●
IrActVel	LREAL	Current velocity <ul style="list-style-type: none">Unit: units/s		●	●
IrActFollowingError	LREAL	Current following error <ul style="list-style-type: none">Unit: units/s²		●	●
IrMaterialCounter	LREAL	Continuous material position <ul style="list-style-type: none">Unit: units		●	●
IrTargetPos	LREAL	Target position of the saw carriage <ul style="list-style-type: none">Unit: units		●	●
IrCutGap	LREAL	Distance between two cutting positions <ul style="list-style-type: none">Unit: units		●	●
byRemainMarkStack	BYTE	Display of the positions still available (max. 15) on the mark stack			●

3.3.4 Parameters

L_TT1P_scPar_FlyingSaw[Base/State]

The L_TT1P_scPar_FlyingSaw[Base/State] structure contains the parameters of the technology module.

Designator	Data type	Description	Available in version	
			Base	State
IrStopDec	LREAL	Deceleration for the stop function and when hardware/software limit switches and the following error monitoring function are triggered • Unit: units/s ² • Initial value: 10000	●	●
IrStopJerk	LREAL	Jerk for the stop function and for the triggering of the hardware limit switches, software limit positions, and the following error monitoring function • Unit: units/s ³ • Initial value: 100000	●	●
IrHaltDec	LREAL	Deceleration for the holding function Specification of the maximum speed variation which is to be used for deceleration to standstill. • Unit: units/s ² • Initial value: 3600 • Only positive values are permissible.	●	●
IrJerk	LREAL	Jerk for compensating a clutch or holding function • Unit: units/s ³ • Initial value: 100000	●	●
IrJogJerk	LREAL	Jerk for manual jog • Unit: units/s ³ • Initial value: 10000	●	●
IrJogVel	LREAL	Maximum speed to be used for manual jog. • Unit: units/s • Initial value: 10	●	●
IrJogAcc	LREAL	Acceleration for manual jog Specification of the maximum speed variation which is to be used for acceleration. • Unit: units/s ² • Initial value: 100	●	●
IrJogDec	LREAL	Deceleration for manual jog Specification of the maximum speed variation which is to be used for deceleration to standstill. • Unit: units/s ² • Initial value: 100	●	●
IrHomePosition	LREAL	Home position for a reference run (homing) • Unit: units • Initial value: 0	●	●
xUseHomeExtParameter L_MC1P_HomeParameter	BOOL	Selection of the homing parameters to be used • Initial value: FALSE	●	●
		FALSE The homing parameters defined in the axis data are used.		
		TRUE The scHomeExtParameter homing parameters from the application are used.		
scHomeExtParameter L_MC1P_HomeParameter		Homing parameters from the application • Only relevant if xUseHomeExtParameter = TRUE.	●	●


Designator	Data type	Description	Available in version	
			Base	State
scHomeExtTP MC_TRIGGER_REF		Transfer of an external touch probe event <ul style="list-style-type: none"> Only relevant for "external encoder" touch probe configuration. For describing the MC_TRIGGER_REF structure, see the MC_TouchProbe function block. 	●	●
IrSyncVel	LREAL	Additive velocity of the saw carriage during synchronisation (travel distance, approach target position again) The set value is added to the velocity of the master axis. <ul style="list-style-type: none"> Unit: units/s Initial value: 3600 	●	●
IrSyncAcc	LREAL	Maximum acceleration of the saw carriage when clutching in to the master value of the master axis <ul style="list-style-type: none"> Unit: units/s² Initial value: 10000 	●	●
IrSyncDec	LREAL	Maximum deceleration of the saw carriage when declutching from the master value of the master axis <ul style="list-style-type: none"> Unit: units/s² Initial value: 10000 	●	●
IrPosVel	LREAL	Maximum velocity of the saw carriage during positioning (travel to the next cutting position, positioning to parking position) <ul style="list-style-type: none"> Unit: units/s Initial value: 3600 	●	●
IrPosAcc	LREAL	Maximum acceleration of the saw carriage during positioning (travel to the next cutting position, positioning to parking position) <ul style="list-style-type: none"> Unit: unit/s² Initial value: 10000 	●	●
IrPosDec	LREAL	Maximum deceleration of the saw carriage during positioning (travel to the next cutting position, positioning to parking position) <ul style="list-style-type: none"> Unit: units/s² Initial value: 10000 	●	●
IrSetMaterialPos	LREAL	Default value for the material counter The value of the material counter results from the value set here plus the actual position of the saw carriage. The value is accepted when a rising edge (FALSE→TRUE) is detected at the xSetMaterialPos input. <ul style="list-style-type: none"> Unit: units Initial value: 0 	●	●
IrUpperLimit	LREAL	Upper travel range limit of the saw carriage <ul style="list-style-type: none"> Unit: units Initial value: 1000 	●	●
IrLowerLimit	LREAL	Lower travel range limit of the saw carriage <ul style="list-style-type: none"> Unit: units Initial value: 0 	●	●
xSyncFlyingSaw	BOOL	Response of the "Flying Saw" technology module after switch-on (xStartFlyingSaw input = TRUE) <ul style="list-style-type: none"> Initial value: FALSE 	●	●
		FALSE The saw carriage is only synchronised with the material position if the xSynxInInstant input detects a rising edge (FALSE→TRUE).		
		TRUE The saw carriage is immediately synchronised to the material position when the xStartFlyingSaw is set = TRUE. This can take place independent of the current position of the saw carriage.		

Designator	Data type	Description	Available in version	
			Base	State
IrGap	LREAL	Distance to be travelled after a saw cut With length-controlled operation, the <i>IrGap</i> parameter is added to the relative travel way (<i>IrCuttingLength</i> input). The distance is travelled after a rising edge (<i>FALSE</i> → <i>TRUE</i>) at the <i>xExecuteGap</i> input. ▶ Length-controlled operation (cutting of relative product lengths) (34) • Unit: units • Initial value: 0	●	●
IrBladeWidth	LREAL	Blade width of the saw blade The value is added to the cutting length in the operating mode Length-controlled operation (cutting of relative product lengths) (34). • Unit: units • Initial value: 0	●	●
xParkPos	BOOL	When the technology module has been switched on (<i>xStartFlyingSaw</i> input = <i>TRUE</i>), the saw carriage is moved to the parking position (<i>IrParkPosition</i> parameter). • Initial value: <i>FALSE</i>		●
		<i>FALSE</i> The saw carriage is not moved to the parking position but is brought to a standstill immediately.		
		<i>TRUE</i> The saw carriage is moved to the parking position		
IrParkPosition	LREAL	Parking position of the saw carriage if the <i>xParkPos</i> parameter is set to <i>TRUE</i> . • Unit: units • Initial value: 0		●
IrMarkSensorPos	LREAL	Position of the touch probe sensor (relating to the measuring system of the saw carriage) • Unit: units		●
eModeFlyingSaw	ENUM	Selection of the operating mode • Initial value: 0 (length-controlled operation)		●
		0 Length-controlled operation (cutting of relative product lengths) (34)		
		1 Mark-controlled operation (cutting to position markers) (37)		
xPosInWindow	BOOL	Activation of the tolerance window for following error monitoring • Initial value: <i>FALSE</i>		●
		<i>TRUE</i> The tolerance window (following error monitoring) is activated.		
IrPosInWindow	LREAL	Size of the tolerance window for following error monitoring • Unit: units • Initial value: 0		●
IrTimePosInWindow	LREAL	Duration of stay of the following error inside the tolerance window • Unit: ms • Initial value: 50		●

3 Functional description for the "Flying Saw"

3.4 State machine

3.4 State machine



[3-2] State machine of the technology module

(*1 In the "Ready" state, xRegulatorOn has to be set to TRUE.


(*2 In the "ERROR" state, xResetError has to be set to TRUE in order to acknowledge and reset the errors.

3.5

Signal flow diagrams

The illustrations show the main signal flow of the functions implemented.

The signal flow of the additional functions such as "manual jog" is not displayed here.



[3-3] Signal flow: Flying Saw

3.5.1 Structure of the signal flow

L_TT1P_scSF_FlyingSaw[Base/State]

The contents of the L_TT1P_scSF_FlyingSaw[Base/State] structure is read-only and offer a practical diagnostics option within the signal flow ([Signal flow diagrams](#) (□ 25)).

Designator	Data type	Description		Available in version	
				Base	State
IP01_xExecuteNextCut	BOOL		The input is edge-controlled and evaluates the rising edge.	●	●
		FALSE TRUE	The saw carriage moves to the next machining position.		
IP02_lrcuttinglength	LREAL		Cutting length (relative positioning) or cutting position (absolute positioning)	●	●
IP03_lrlowerLimit	LREAL		Lower travel range limit of the saw carriage • Unit: units • Initial value: 0	●	●
IP04_lrupperLimit	LREAL		Upper travel range limit of the saw carriage • Unit: units • Initial value: 1000	●	●
IP05_eModeFlyingSaw L_TT1P_eModesFlyingSaw			Selection of the operating mode • Initial value: 0 (length-controlled operation)		●
		0	Length-controlled operation (cutting of relative product lengths) (□ 34)		
		1	Mark-controlled operation (cutting to position markers) (□ 37)		
MP01_lrSetMasterPos	LREAL		Set position of the master axis • Unit: units	●	●
MP02_lrSetSlavePos	LREAL		Set position of the slave axis • Unit: units	●	●
MP03_lrTotalCuttingLength	LREAL		Sum of the cut cutting lengths • Unit: units	●	●
MP04_xPosSynchronised	BOOL	TRUE	The setpoints of the master axis and the slave axis are synchronous.	●	●
MP05_wMarkInIndex	WORD		Index of the incoming mark (touch probe) on the mark stack		●
MP06_wMarkOutIndex	WORD		Index of the mark (touch probe) to be called on the mark stack		●
MP07_alrMarkPositionArray	ARRAY [0..15] OF LREAL		Memory of the detected position markers		●
MP08_alrTimeStampArray	ARRAY [0..15] OF LREAL		Memory of the time stamps corresponding to the position markers in MP07_alrMarkPositionArray		●
MP09_xMarkStackEmpty	BOOL	TRUE	There is no valid mark on the mark stack anymore.		●
MP10_xMarkStackFull	BOOL	TRUE	The mark stack is completely filled. The next mark detected overwrites the oldest mark entered on the mark stack.		●
MP11_lrStackMarkPos	LREAL		Position of the mark currently output by the mark stack. • Unit: units		●
OP01_lrMaterialCounter	LREAL		Continuous material position • Unit: units	●	●
OP02_lrTargetPos	LREAL		Target position of the saw carriage • Unit: units	●	●

3.5.2 Structure of the access points

L_TT1P_scAP_FlyingSaw[Base/State]

The access points (AP) can be used to influence signals. In the initial state, the access points do not have any effect.

Each access point acts as an alternative branch and is activated via an OR operation or a switch.

Designator	Data type	Description	Available in version	
			Base	State
AP01_xLoadTotalCuttingLength BOOL		Selection of a value for the sum of all lengths cut (MP03_IrTotalCuttingLength variable) • Initial value: TRUE	●	●
		TRUE The value in AP01_IrLoadTotalCuttingLength is preselected.		
AP01_IrLoadTotalCuttingLength LREAL		Value for the sum of all lengths cut (MP03_IrTotalCuttingLength variable) • Unit: units • Initial value: 0		
AP02_xLoadTargetPos BOOL		Selection of a value for the target position of the saw carriage (IrTargetPos or OP02_IrTargetPos output) The precondition for this is that the technology module is in the "READY" state. • Initial value: TRUE	●	●
		TRUE The value in IrLoadTargetPos is preselected.		
AP02_IrLoadTargetPos LREAL		Value for the target position of the saw carriage (IrTargetPos or OP02_IrTargetPos output) • Unit: units • Initial value: 0		
AP03_xRangeOfTolerance BOOL		Activation of the tolerance range set under AP03_IrRangeOfTolerance		●
		TRUE Tolerance range AP03_IrRangeOfTolerance is activated.		
AP03_IrRangeOfTolerance LREAL		Tolerance range which is put around the master value of the master axis to ensure the synchronism with the saw carriage. This is required in case of noisy master value signals.		

3.6 Manual jog (jogging)

Precondition

- The technology module is in the "Ready" state.
- The slave axis is enabled (*xRegulatorOn* = TRUE).

Execution

For manual jog of the axis, the manual jog speed *lrJogVel* is used.

If the *xJogPos* input is TRUE, the axis is traversed in positive direction and if the *xJogNeg* input is TRUE, the axis is traversed in negative direction. The axis is executed for as long as the input remains set to TRUE.

The current travel command cannot be replaced by another jog command. Only if both inputs have been reset, the [State machine](#) (24) changes to the "Ready" state again.

Parameters to be set

The parameters for the manual jog are located in the [L TT1P_scPar_FlyingSaw\[Base/State\]](#) (21) parameter structure.

```
lrJogVel : LREAL := 10;      // Velocity [units/s]
lrJogAcc : LREAL := 100;    // Acceleration [units/s^2]
lrJogDec : LREAL := 100;    // Deceleration [units/s^2]
lrJogJerk : LREAL := 10000; // Jerk [units/s^3]
```

The parameter values can be changed during operation. They are accepted when the *xJogPos* or *xJogNeg* input is set to TRUE again.

3.7

Homing**Precondition**

- The technology module is in the "Ready" state.
- The slave axis is enabled (*xRegulatorOn* = TRUE).

Execution

Homing is started with a rising edge (FALSE→TRUE) at the *xHomeExecute* input. The axis will be travelling until the home position is reached. After successful homing, the [State machine](#) (24) changes back again to the "Ready" state.

The homing process is not interrupted if the *xHomeExecute* input is set to FALSE too early. The function is aborted via the *xStop* input.

Parameters to be set

The parameters for homing are located in the [L_TT1P_scPar_FlyingSaw\[Base/State\]](#) (21) parameter structure.

```
xUseHomeExtParameter : BOOL := FALSE;  
lrHomePosition : LREAL := 0.0;  
scHomeExtParameter : L_MC1P_HomeParameter;  
scHomeExtTP : MC_TRIGGER_REF;
```

3.8 Setting motion profiles (linear/S-ramps)

Parameters to be set

The parameters for the motion profile of the saw carriage are located in the [L_TT1P_scPar_FlyingSaw\[Base/State\]](#) (21) parameter structure.

```
lrJerk : LREAL := 100000; // units/s3;
lrSyncVel : LREAL := 3600; // units/s;
lrSyncAcc : LREAL := 10000; // units/s2;
lrSyncDec : LREAL := 10000; // units/s2;
lrPosVel : LREAL := 3600; // units/s;
lrPosAcc : LREAL := 10000; // units/s2;
lrPosDec : LREAL := 10000; // units/s2;
```

3.9

First synchronisation of the saw carriage to the material speed


When the "flying saw" has been switched on by the *xStartFlyingSaw* input = FALSE→TRUE, there are several possibilities of synchronising the saw carriage with the material speed:

A. *xSyncFlyingSaw* parameter = FALSE:

The saw carriage is only synchronised with the material position if the *xSyncInInstant* input detects a rising edge (FALSE→TRUE).

This function can for example be used to carry out an initial top cut.


The initial top cut at the start of length-controlled operation can either be carried out when the material web is at a standstill or if it is running.



[3-4] Example: Characteristic with *xSyncFlyingSaw* parameter = FALSE

B. *xSyncFlyingSaw* parameter = TRUE:

The saw carriage is synchronised with the material position immediately if the *xStartFlyingSaw* input is set to TRUE. This can take place irrespective of the current saw carriage position.



[3-5] Example: Characteristic with *xSyncFlyingSaw* parameter = TRUE


C. *eModeFlyingSaw* = 1 parameter (mark-controlled operation):



Note!

The mark-controlled operation is only possible in the **State version** of the technology module.


The saw carriage is only synchronised with the material position if a mark has been detected at the mark sensor connected (*xMarkReceive* input = TRUE).



[3-6] Example: Characteristic with *eModeFlyingSaw* parameter = 1 (mark-controlled operation)


3.10

Length-controlled operation (cutting of relative product lengths)



[3-7] Cutting length with length-controlled operation

In length-controlled operation, the first machining process (top cut) starts in any position. Then all subsequent saw cuts have the desired relative distance (cutting length) to the previous cut in each case.



[3-8] Example: Characteristic of length-controlled operation

In the time diagram in Fig. [3-8] three different saw cuts $\Delta S1 \dots \Delta S3$ are carried out. After each cut a specific distance ($IrGap$ parameter) is run.

The movement from one machining position to the next one is carried out via a superimposed relative positioning process. The positioning distance $\Delta S1 \dots \Delta S3$ results from the cutting length at the $IrCuttingLength$ input added by the length of the distance run in the $IrGap$ parameter. The relative positioning process is initiated by a rising edge (FALSE \rightarrow TRUE) at the $xExecuteNextCut$ input.

The $IrLowerLimit$ and $IrUpperLimit$ parameters are used for setting the machining area of the saw carriage. In the diagram above, the area outside these two limits is highlighted in red. When saw cut $\Delta S3$ is requested, it can be clearly seen that the target position ($IrTargetPos$ output) is below the $IrLowerLimit$ limit. In this case, the saw carriage moves to the lower limit specified and waits until the target position enters the operating range so that synchronisation with the target position can then take place.

The areas highlighted in turquoise indicate when the saw carriage is synchronous to the material position. In the example, the saw carriage is only synchronised to the material position when a new target position is requested with the $xExecuteNextCut$ input = TRUE or if a distance ($IrGap$ parameter) is travelled after the saw cut with the $xExecuteGap$ input = TRUE.

Parameters to be set

The parameters for the length-controlled operation are located in the [L TT1P_scPar_FlyingSaw\[Base/State\]](#) (21) parameter structure.

A new/changed cutting length with a rising edge (FALSE→TRUE) is accepted at the *xExecuteNextCut* input.

For the time diagram in figure [\[3-8\]](#) (35), a sequence runs outside the technology module that successively defines the following product lengths at the *lrCuttingLength* input:


- 500 [units]
- 250 [units]
- 1000 [units]

Furthermore the following parameter settings have been carried out:

```
lrLowerLimit : LREAL := 0;  
lrUpperLimit : LREAL := 1000;  
lrGap : LREAL := 50;  
xSyncFlyingSaw : BOOL := TRUE;
```


3.11

Mark-controlled operation (cutting to position markers)



[3-9] Cutting length for mark-controlled operation

Mark-controlled operation is used if the material already features partitions by position markers, e.g. in the case of a print image. In this case, the saw cuts must not be placed arbitrarily on the material, but must be executed in line with the position markers. An additional mark sensor that is placed in a sufficient distance in front of the operating range of the saw detects the cutting positions beforehand. These cutting positions are stored in a mark stack.



[3-10] Example: Characteristic of mark-controlled operation

In the time diagram in fig. [3-10] three marks are detected in a row. The first mark starts the process. During the machining phase (cutting and running the distance) of the first mark detected, two further marks are detected which are stored on the mark stack. The next valid mark position is approached with a rising edge (FALSE \rightarrow TRUE) at the *xExecuteNextCut* input = TRUE.

if there is no valid mark on the mark stack anymore, the saw carriage moves to the lower travel range limit (*lrLowerLimit* parameter) and waits for the next mark.

The cutting length is the distance between the detected marks. As soon as the technology module is switched on, the position at the *lrActMarkPosIn* input is converted to the setpoint position of the saw carriage for each detected mark at the *xReceiveMark* input and stored on the mark stack. With a rising edge (FALSE→TRUE) at the *xExecuteNextCut* input, it is possible to change over to the next mark in the stack.

Parameters to be set

The parameters for the length-controlled operation are located in the [L_TT1P_scPar_FlyingSaw\[Base/State\]](#) (21) parameter structure.

For the time diagram in figure [\[3-10\]](#) (38), the following parameters have been set:

```
eModeFlyingSaw : ENUM := 1; // Mark controlled
lrSetMaterialPos : LREAL := 0;
lrLowerLimit : LREAL := 0;
lrUpperLimit : LREAL := 1000;
lrGap : LREAL := 50;
xSyncFlyingSaw : BOOL := FALSE;
```


3.12 Restoring the target position

This function can be executed once when the sawing process has been started ($xStartFlyingSaw = TRUE$) in order to restore a target position.

In length-controlled operation and in mark-controlled operation, the process for restoring the target position is different. Furthermore it is checked in both operating modes whether the target position requested is below the upper travel range limit ($IrUpperLimit$ parameter).

Length-controlled operation

After a rising edge ($FALSE \rightarrow TRUE$) at the $xResumeTargetPos$ input, the target position ($IrTargetPos$ output) is approached again.




[3-11] Example: Characteristic for "Restoring the target position" in length-controlled operation

Mark-controlled operation

In case of mark-controlled operation, only one valid mark can be restored. Here, the target position (*lrTargetPos* output) has to be in front of the travel range limit (*lrUpperLimit* parameter).

If the target position has already exceeded the upper travel range limit, a rising edge (FALSE→TRUE) at the *xExecuteNextCut* input serves to change over to the next mark in the mark stack. If no valid mark is available in the stack, no target position is approached.

After a rising edge (FALSE→TRUE) at the *xResumeTargetPos* input, the target position is approached again.



[3-12] Example: Characteristic for "Restoring the target position" in mark-controlled operation


3.13 Deleting the mark stack

With a rising edge ($\text{FALSE} \rightarrow \text{TRUE}$) at the *xResetMarkStack* input, all marks stored on the mark stack are deleted.

The *byRemainMarkStack* output shows how many marks the mark stack can take.

If the function is executed while the "flying saw" is in the synchronous state, (*xStartFlyingSaw* input = TRUE), the saw carriage travels to the waiting position (*lrLowerLimit* parameter) and will be synchronised with the next mark.

Both options are shown in the time diagram in figure [\[3-13\]](#) (p. 44).



[3-13] Example: "Delete mark stack" history

3.14 Moving to the parking position

There are two options to approach the parking position:

A. "Flying Saw" is not active:

- The technology module is in the "Ready" state.
- A rising edge (FALSE→TRUE) at the *xMoveToParkPos* input causes a change from "Ready" to "Move To Park Pos" and the saw carriage travels to the parking position set in the *lrParkPosition* parameter.

B. "Flying Saw" is deactivated:

- The parameters *lrParkPosition* and *xParkPos* from the [L TT1P_scPar_FlyingSaw\[Base/State\]](#) (21) parameter structure are set to TRUE.
- If then the *xStartFlyingSaw* input is set from TRUE to FALSE, the saw carriage travels to the parking position set in the *lrParkPosition* parameter.

During positioning, the *xPositioning* output is = TRUE.


When the parking position has been reached, the output *xInPosition* is set = TRUE and the output *xPositioning* is set = FALSE.

Parameters to be set

The parameters for travelling to the parking position are located in the [L TT1P_scPar_FlyingSaw\[Base/State\]](#) (21) parameter structure.

For the time diagram in figure [\[3-14\]](#) (46), the following parameters have been set:

```
eModeFlyingSaw : ENUM := 0; // Length controlled
xSyncFlyingSaw : BOOL := TRUE;
xParkPos : BOOL := TRUE;
lrParkPosition : LREAL := 150; // units
```





[3-14] Example: Characteristic for "Moving to parking position"

3.15 Window for following error monitoring

This function checks whether the following error is to be found within a defined window within a certain period. It is activated with the *xPosInWindow* parameter set to TRUE.

The window and the time are set via the parameters *IrPosInWindow* and *IrTimePosInWindow* from the [L TT1P_scPar_FlyingSaw\[Base/State\]](#) (21) parameter structure. As soon as the two setpoints of the master and slave axis are synchronous and the following error is inside the set window, the *xSynchronised* output is set = TRUE.



[3-15] Example: Characteristic of the following error monitoring

Parameters to be set

The parameters for the following error monitoring are located in the [L TT1P_scPar_FlyingSaw\[Base/State\]](#) (21) parameter structure.

For the time diagram in figure [3-15](#) (47), the following parameters have been set:

```
eModeFlyingSaw : ENUM := 0; // Length controlled
xSyncFlyingSaw : BOOL := TRUE;
xPosInWindow : BOOL := TRUE;
lrPosInWindow : LREAL := 0.5; // units
lrTimePosInWindow : LREAL := 50; // ms
```


3.16 CPU utilisation (example Controller 3231 C)

The following table shows the CPU utilisation in microseconds using the example of the 3231 C controller (ATOM™ processor, 1.6 GHz).

Versions	Interconnection of the technology module	CPU utilisation	
		Average	Maximum peak
Base	xEnable := TRUE; xRegulatorOn := TRUE; xStartFlyingSaw := TRUE; xExecuteNextCut := TRUE;	40 µs	90 µs
State	xEnable := TRUE; xRegulatorOn := TRUE; xStartFlyingSaw := TRUE; xExecuteNextCut := TRUE;	80 µs	120 µs

A

Access points [27](#)
Application notes [7](#)
Approaching the parking position [45](#)

C

Controlled start of the axes [14](#)
Conventions used [6](#)
CPU utilisation (example Controller 3231 C) [49](#)
Cutting on position markers (mark-controlled operation) [37](#)
Cutting relative product lengths (length-controlled operation) [34](#)

D

Deleting the mark stack [43](#)
Document history [5](#)

E

E-mail to Lenze [51](#)

F

Feedback to Lenze [51](#)
Flying Saw (functional description) [10](#)
Following error monitoring [47](#)
Functional description for the "Flying Saw" [10](#)

H

Homing [29](#)

I

Inputs [16](#)
Inputs and outputs [16](#)

L

L_TT1P_FlyingSawBase [15](#)
L_TT1P_FlyingSawBase/State function block [15](#)
L_TT1P_FlyingSawState [15](#)
L_TT1P_scAP_FlyingSawBase [27](#)
L_TT1P_scAP_FlyingSawState [27](#)
L_TT1P_scPar_FlyingSawBase [21](#)
L_TT1P_scPar_FlyingSawState [21](#)
L_TT1P_scSF_FlyingSawBase [26](#)
L_TT1P_scSF_FlyingSawState [26](#)
Layout of the safety instructions [7](#)
Length-controlled operation (cutting of relative product lengths) [34](#)

M

Manual jog (jogging) [28](#)
Mark-controlled operation (cutting to position markers) [37](#)
Motion profiles (linear/S-shaped ramps) [30](#)

N

Notes on how to operate the technology module [13](#)

O

Operating mode [13](#)
Outputs [19](#)

P

Parameter structure L_TT1P_scPar_FlyingSawBase/State [21](#)

R

Recovery of the target position [40](#)
Restoring the target position [40](#)

S

Safety instructions [7](#), [8](#)
Signal flow diagrams [25](#)
Start of the axes [14](#)
State machine [24](#)
States [24](#)
Structure of the access points L_TT1P_scAP_FlyingSawBase/State [27](#)
Structure of the signal flow L_TT1P_scSF_FlyingSawBase/State [26](#)
Synchronisation of the saw carriage with the material speed [31](#)

T

Target group [4](#)
Technology module functions (overview) [12](#)

V

Variable names [6](#)

W

Window for following error monitoring [47](#)



Your opinion is important to us

These instructions were created to the best of our knowledge and belief to give you the best possible support for handling our product.

Perhaps we have not succeeded in achieving this objective in every respect. If you have suggestions for improvement, please e-mail us to:

feedback-docu@lenze.com

Thank you very much for your support.

Your Lenze documentation team

Lenze Automation GmbH
Postfach 10 13 52, 31763 Hameln
Hans-Lenze-Straße 1, 31855 Aerzen
GERMANY
HR Hannover B 205381
☎ +49 5154 82-0
📠 +49 5154 82-2800
✉ lenze@lenze.com
🌐 www.lenze.com

Service

Lenze Service GmbH
Breslauer Straße 3, 32699 Extertal
GERMANY
☎ 008000 24 46877 (24 h helpline)
📠 +49 5154 82-1112
✉ service@lenze.com