


Technology module



Electrical Shaft Position

Reference Manual

EN



13531722

Contents

| | | |
|----------|--|-----------|
| 1 | About this documentation | 3 |
| 1.1 | Document history | 5 |
| 1.2 | Conventions used | 6 |
| 1.3 | Definition of the notes used | 7 |
| 2 | Safety instructions | 8 |
| 3 | Functional description of "Electrical Shaft Position" | 10 |
| 3.1 | Overview of the functions | 11 |
| 3.2 | Important notes on how to operate the technology module | 12 |
| 3.3 | Function block L_TT1P_ElectricalShaftPos[Base/State/High] | 14 |
| 3.3.1 | Inputs and outputs | 14 |
| 3.3.2 | Inputs | 15 |
| 3.3.3 | Outputs | 17 |
| 3.3.4 | Parameters | 19 |
| 3.4 | State machine | 23 |
| 3.5 | Signal flow diagram | 24 |
| 3.5.1 | Structure of the signal flow | 25 |
| 3.5.2 | Structure of the access points | 26 |
| 3.6 | Manual jog (jogging) | 27 |
| 3.7 | Homing | 28 |
| 3.8 | Synchronism (SyncPos) | 29 |
| 3.9 | Position offset during synchronism | 31 |
| 3.10 | Synchronism with clutch-in/declutch mechanism | 32 |
| 3.10.1 | Direct clutching-in/declutching | 33 |
| 3.10.2 | Relative clutching-in/declutching | 34 |
| 3.11 | Position trimming | 36 |
| 3.12 | Position offset with profile generator | 37 |
| 3.13 | Extended clutch-in/declutch mechanism | 40 |
| 3.13.1 | eSyncMode = Ramp_Dist | 40 |
| 3.13.2 | eSyncMode = Ramp_Time | 42 |
| 3.13.3 | eSyncMode = Ramp_VelAcc | 44 |
| 3.14 | CPU utilisation (example Controller 3231 C) | 46 |
| | Index | 47 |
| | Your opinion is important to us | 48 |

1 About this documentation

This documentation ...

- contains detailed information on the functionalities of the "Electrical Shaft Position" technology module;
- is part of the "Controller-based Automation" manual collection. It consists of the following sets of documentation:


| Documentation type | Subject |
|---|---|
| Product catalogue | Controller-based Automation (system overview, sample topologies) Lenze Controller (product information, technical data) |
| System manuals | Visualisation (system overview/sample topologies) |
| Communication manuals Online helps | Bus systems <ul style="list-style-type: none">• Controller-based Automation EtherCAT®• Controller-based Automation CANopen®• Controller-based Automation PROFIBUS®• Controller-based Automation PROFINET® |
| Reference manuals Online helps | Lenze Controllers: <ul style="list-style-type: none">• Controller 3200 C• Controller c300• Controller p300• Controller p500 |
| Software manuals Online helps | Lenze Engineering Tools: <ul style="list-style-type: none">• »PLC Designer« (programming)• »Engineer« (parameter setting, configuration, diagnostics)• »VisiWinNET® Smart« (visualisation)• »Backup & Restore« (data backup, recovery, update) |

More technical documentation for Lenze components

Further information on Lenze products which can be used in conjunction with Controller-based Automation can be found in the following sets of documentation:

| Planning / configuration / technical data | |
|---|--|
| <input type="checkbox"/> | Product catalogues <ul style="list-style-type: none">• Controller-based Automation• Controllers• Inverter Drives/Servo Drives |
| Mounting and wiring | |
| <input checked="" type="checkbox"/> | Mounting instructions <ul style="list-style-type: none">• Controllers• Communication cards (MC-xxx)• I/O system 1000 (EPM-Sxxx)• Inverter Drives/Servo Drives• Communication modules |
| <input type="checkbox"/> | Hardware manuals <ul style="list-style-type: none">• Inverter Drives/Servo Drives |
| Parameter setting / configuration / commissioning | |
| <input type="checkbox"/> | Online help/reference manuals <ul style="list-style-type: none">• Controllers• Inverter Drives/Servo Drives• I/O system 1000 (EPM-Sxxx) |
| <input type="checkbox"/> | Online help/communication manuals <ul style="list-style-type: none">• Bus systems• Communication modules |
| Sample applications and templates | |
| <input type="checkbox"/> | Online help / software and reference manuals <ul style="list-style-type: none">• i700 application sample• Application Samples 8400/9400• FAST Application Template Lenze/PackML• FAST technology modules |

Symbols:

-  Printed documentation
- ☐ PDF file / online help in the Lenze engineering tool



Tip!

Current documentation and software updates with regard to Lenze products can be found in the download area at:

www.lenze.com

Target group

This documentation is intended for all persons who plan, program and commission a Lenze automation system on the basis of the Lenze FAST Application Software.

1.1


Document history

| Version | | | Description |
|---------|---------|------|--|
| 3.3 | 05/2017 | TD17 | <ul style="list-style-type: none"> Content structure has been changed. General revisions New: <ul style="list-style-type: none"> ▶ Torque-controlled drive as master (📖 12) ▶ Use of setpoints or actual values (📖 12) |
| 3.2 | 11/2016 | TD29 | <ul style="list-style-type: none"> General revisions Parameters supplemented: L TT1P_scPar_ElectricalShaftPos[Base/State/High] (📖 19) New: Extended clutch-in/declutch mechanism (📖 40) |
| 3.1 | 04/2016 | TD17 | General revisions |
| 3.0 | 11/2015 | TD17 | <ul style="list-style-type: none"> Corrections and additions New: Relative clutching-in/declutching (📖 34) Content structure has been changed. |
| 2.1 | 05/2015 | TD17 | General revisions |
| 2.0 | 01/2015 | TD17 | <ul style="list-style-type: none"> General editorial revision Modularisation of the contents for the »PLC Designer« online help |
| 1.0 | 04/2014 | TD00 | First edition |

1 About this documentation

1.2 Conventions used

This documentation uses the following conventions to distinguish between different types of information:

| Type of information | Highlighting | Examples/notes |
|---------------------|---|---|
| Spelling of numbers | | |
| Decimal separator | Point | The decimal point is always used. For example: 1234.56 |
| Text | | |
| Program name | » « | »PLC Designer« ... |
| Variable names | <i>italics</i> | By setting <i>bEnable</i> to TRUE... |
| Function blocks | bold | The L_MC1P_AxisBasicControl function block ... |
| Function libraries | | The L_TT1P_TechnologyModules function library ... |
| Source code | Font "Courier new" | ... dwNumerator := 1; dwDenominator := 1; ... |
| Icons | | |
| Page reference |  6 | Reference to further information: Page number in PDF file. |

Variable names

The conventions used by Lenze for the variable names of Lenze system blocks, function blocks, and functions are based on the "Hungarian Notation". This notation makes it possible to identify the most important properties (e.g. the data type) of the corresponding variable by means of its name, e.g. xAxisEnabled.

1.3

Definition of the notes used

The following signal words and symbols are used in this documentation to indicate dangers and important information:

Safety instructions

Layout of the safety instructions:

**Pictograph and signal word!**

(characterise the type and severity of danger)

Note

(describes the danger and gives information about how to prevent dangerous situations)

| Pictograph | Signal word | Meaning |
|------------|-------------|---|
| | Danger! | Danger of personal injury through dangerous electrical voltage Reference to an imminent danger that may result in death or serious personal injury if the corresponding measures are not taken. |
| | Danger! | Danger of personal injury through a general source of danger Reference to an imminent danger that may result in death or serious personal injury if the corresponding measures are not taken. |
| | Stop! | Danger of property damage Reference to a possible danger that may result in property damage if the corresponding measures are not taken. |

Application notes

| Pictograph | Signal word | Meaning |
|------------|-------------|---|
| | Note! | Important note to ensure trouble-free operation |
| | Tip! | Useful tip for easy handling |
| | | Reference to another document |

2 Safety instructions

Please observe the safety instructions in this documentation when you want to commission an automation system or a plant with a Lenze Controller.



The device documentation contains safety instructions which must be observed!

Read the documentation supplied with the components of the automation system carefully before you start commissioning the Controller and the connected devices.



Danger!

High electrical voltage

Injury to persons caused by dangerous electrical voltage

Possible consequences

Death or severe injuries

Protective measures

Switch off the voltage supply before working on the components of the automation system.

After switching off the voltage supply, do not touch live device parts and power terminals immediately because capacitors may be charged.

Observe the corresponding information plates on the device.



Danger!

Injury to persons

Risk of injury is caused by ...

- unpredictable motor movements (e.g. unintended direction of rotation, too high velocities or jerky movement);
- impermissible operating states during the parameterisation while there is an active online connection to the device.

Possible consequences

Death or severe injuries

Protective measures

- If required, provide systems with installed inverters with additional monitoring and protective devices according to the safety regulations valid in each case (e.g. law on technical equipment, regulations for the prevention of accidents).
- During commissioning, maintain an adequate safety distance to the motor or the machine parts driven by the motor.



Stop!

Damage or destruction of machine parts

Damage or destruction of machine parts can be caused by ...


- Short circuit or static discharges (ESD);
- unpredictable motor movements (e.g. unintended direction of rotation, too high velocities or jerky movement);
- impermissible operating states during the parameterisation while there is an active online connection to the device.

Protective measures

- Always switch off the voltage supply before working on the components of the automation system.
- Do not touch electronic components and contacts unless ESD measures were taken beforehand.
- If required, provide systems with installed inverters with additional monitoring and protective devices according to the safety regulations valid in each case (e.g. law on technical equipment, regulations for the prevention of accidents).

3 Functional description of "Electrical Shaft Position"

3 Functional description of "Electrical Shaft Position"



[3-1] Typical mechanics of the technology module

- In the "Base" version, the synchronism and the setting of an offset are activated with a position jump.
- In the "State" version, cluching in without step changes is additionally possible. For this purpose, a position-dependent clutch is used. Furthermore, an offset between the master and slave axis can be set - in a manner similar to manual jog. The offset that takes effect in an absolute manner is accepted immediately with a position jump.
- In addition to the State version, the "High" version provides jerk-free connection of the position offset using a profile generator and the function of a clutch-in and declutch mechanism.

► [Overview of the functions](#) (11)

3.1 Overview of the functions

In addition to the basic functions for operating the **L_MC1P_AxisBasicControl** function block, the **Stop function**, and the **Holding function**, the technology module offers the following functionalities that are assigned to the "Base", "State", and "High" versions:

| Functionality | Versions | | |
|--|----------|-------|------|
| | Base | State | High |
| Manual jog (jogging) (□ 27) | ● | ● | ● |
| Homing (□ 28) | ● | ● | ● |
| Synchronism (SyncPos) (□ 29) | ● | ● | ● |
| Position offset during synchronism (□ 31) | ● | ● | ● |
| Synchronism with clutch-in/declutch mechanism (□ 32) | | ● | ● |
| ▶ Direct clutching-in/declutching (□ 33) | | ● | ● |
| ▶ Relative clutching-in/declutching (□ 34) | | | ● |
| Position trimming (□ 36) | | ● | ● |
| Position offset with profile generator (□ 37) | | | ● |
| Extended clutch-in/declutch mechanism (□ 40) | | | ● |



»PLC Designer« Online help


Here you will find detailed information on the **L_MC1P_AxisBasicControl** function block, the **stop function** and the **holding function**.

3.2

Important notes on how to operate the technology module

The "ElectricalShaft Position" technology module only supports axes with the same travel range setting: Either the master axis and the slave axis must be set as "Modulo" rotary axes or both must be set as "Limited" linear axes.

Go to the »PLC Designer« and set the "Modulo" or "Limited" machine measuring system for each axis under the **Settings** tab:



Setting of the operating mode

The operating mode for the slave axis has to be set to "cyclically synchronous position" (csp) because the axis is led via the master position value.

Torque-controlled drive as master

In its function as a master, the technology module can also have an axis which runs in the cyclic sync torque mode (cst).

The actual values are written to the setpoints.

Use of setpoints or actual values

The technology module uses the setpoint of the master axis.

The **L_MC1P_AverageFilterSetValue** filter function can be used to influence the setpoints, making it possible for the technology module to switch over to the actual values.

Controlled start of the axes

Motion commands that are set in the inhibited axis state ($xAxisEnabled = FALSE$) after enable ($xRegulatorOn = TRUE$) must be activated again by a $FALSE \rightarrow TRUE$ edge.

In this way it is prevented that the drive starts in an uncontrolled manner after controller enable.


**Example [Manual jog \(jogging\)](#) (📖 27):**

1. In the inhibited axis state ($xAxisEnabled = FALSE$), $xJogPos$ is set to TRUE.
 - $xRegulatorOn = FALSE$ (axis is inhibited.)
==> "READY" state ($xAxisEnabled = FALSE$)
 - $xJogPos = TRUE$ (manual jog is to be executed.)
2. Enable axis.
 - $xRegulatorOn = TRUE$
==> "READY" state ($xAxisEnabled = TRUE$)
3. Execute manual jog.
 - $xJogPos = FALSE \rightarrow TRUE$
==> "JOGPOS" state

3.3

Function block L_TT1P_ElectricalShaftPos[Base/State/High]

The figure shows the relation of the inputs and outputs to the "Base", "State" and "High" versions. The additional inputs and outputs of the "State" and "High" versions are shaded.



3.3.1

Inputs and outputs

| Designator | Data type | Description | Available in version | | |
|------------|-----------|--|----------------------|-------|------|
| | | | Base | State | High |
| MasterAxis | AXIS_REF | Reference to the master axis (master axis) | ● | ● | ● |
| SlaveAxis | AXIS_REF | Reference to the slave axis | ● | ● | ● |

3.3.2 Inputs

| Designator | Data type | Description | | Available in version | | |
|------------------------|--|---|---|----------------------|-------|------|
| | | | | Base | State | High |
| xEnableInternalControl | BOOL | TRUE | In the visualisation, the internal control of the axis can be selected via the "Internal Control" axis. | ● | ● | ● |
| xEnable | BOOL | Execution of the function block | | ● | ● | ● |
| | | TRUE | The function block is executed. | | | |
| | | FALSE | The function block is not executed. | | | |
| scCtrlABC | scCtrl_ABC | Input structure for the L_MC1P_AxisBasicControl function block <ul style="list-style-type: none"> scCtrlABC can be used in "Ready" state. If there is a request, the state changes to "Service". The state change from "Service" back to "Ready" takes place if there are no more requests. | | ● | ● | ● |
| xResetError | BOOL | TRUE | Reset axis error or software error. | ● | ● | ● |
| xRegulatorOn | BOOL | TRUE | Activate controller enable of the axis (via the MC_Power function block). | ● | ● | ● |
| xStop | BOOL | TRUE | Cancel the active movement and brake the axis to a standstill with the deceleration defined via the IrStopDec parameter. <ul style="list-style-type: none"> The state changes to "Stop". The technology module remains in the "Stop" state as long as xStop is set to TRUE (or xHalt = TRUE). The input is also active with "Internal Control". | ● | ● | ● |
| xHalt | BOOL | TRUE | Cancel the active movement and brake the axis to a standstill with the deceleration defined via the IrHaltDec parameter. <ul style="list-style-type: none"> The state changes to "Stop". The technology module remains in the "Stop" state as long as xStop is set to TRUE (or xHalt = TRUE). | ● | ● | ● |
| scPar | L_TT1P_scPar_ElectricalShaftPos[Base/State/High] | The parameter structure contains the parameters of the technology module. The data type depends on the version used (Base/State/High). | | ● | ● | ● |
| scAccessPoints | L_TT1P_scAP_ElectricalShaftPos[Base/State/High] | Structure of the access points The data type depends on the version used (Base/State/High). | | ● | ● | ● |
| xJogPos | BOOL | TRUE | Traverse axis in positive direction (manual jog). If xJogNeg is also TRUE, the traversing direction selected first remains set. | ● | ● | ● |
| xJogNeg | BOOL | TRUE | Traverse axis in negative direction (manual jog). If xJogPos is also TRUE, the traversing direction selected first remains set. | ● | ● | ● |
| xHomeExecute | BOOL | The input is edge-controlled and evaluates the rising edge. | | ● | ● | ● |
| | | FALSE | Start homing. | | | |
| | | TRUE | The function is aborted via the xStop input. | | | |
| xHomeAbsSwitch | BOOL | TRUE | Connection for reference switch: For homing modes with a reference switch, connect this input to the digital signal which maps the state of the reference switch. | ● | ● | ● |
| xSyncPos | BOOL | Synchronisation of the slave axis to the master axis | | ● | ● | ● |
| | | TRUE | Base: Synchronisation without clutch function | | | |
| | | | State/High: Synchronisation with position clutch | | | |

| Designator | Data type | Description | | Available in version | | |
|------------------|-----------|---|---|----------------------|-------|------|
| | | | | Base | State | High |
| IrSetOffsetSlave | LREAL | Position offset to master axis The position is approached in the "POS_IS_SYNCHRONISED" state when the value changes • Unit: units | | ● | ● | ● |
| | | Base/State | The offset is directly applied. | | | |
| | | High | The offset is assigned via the profile generator. | | | |
| xTrimPos | BOOL | TRUE | Trim position in positive direction. If xTrimNeg is also TRUE, the traversing direction selected first remains set. | | ● | ● |
| xTrimNeg | BOOL | TRUE | Trim position in negative direction. If xTrimPos is also TRUE, the traversing direction selected first remains set. | | ● | ● |
| xSyncInstant | BOOL | TRUE | Synchronisation with relative position coupling (in connection with xSyncPos) • Master axis at standstill: The slave axis directly (abruptly) clutches in to its current position. • Master axis in motion: The slave axis immediately clutches in via the clutching distance in the IrSlaveSyncInDist parameter (by analogy with a velocity coupling). | | | ● |
| xSyncOutInstant | BOOL | TRUE | Decutching with relative position coupling • Master axis at standstill: The slave axis directly (abruptly) clutches in to its current position. • Master axis in motion: The slave axis immediately declutches via the clutching distance in the IrSlaveSyncOutDist parameter (by analogy with a velocity coupling or MC_Halt). | | | ● |
| xSyncPosRestore | BOOL | FALSE↗ TRUE | A FALSE↗TRUE edge serves to compensate the position offset generated by a relative clutch-in by means of these parameters: • eOffsetSlaveDirection • eOffsetSlaveProfileType • IrOffsetSlaveVelPos • IrOffsetSlaveVelNeg • IrOffsetSlaveAccDec | | | ● |
| | | TRUE↘ FALSE | A TRUE↘FALSE edge aborts the synchronisation process. A possibly remaining position offset is displayed at the IrOffsetSlavePos output. | | | |

3.3.3 Outputs

| Designator | Data type | Description | | Available in version | | |
|------------------------|---|--|---|----------------------|-------|------|
| | | | | Base | State | High |
| xInternalControlActive | BOOL | TRUE | The internal control of the axis is activated via the visualisation. (xEnableInternalControl input = TRUE) | ● | ● | ● |
| eTMState | L_TT1P_States | Current state of the technology module ► State machine (□ 23) | | ● | ● | ● |
| scStatusABC | scStatus_ABC | Structure of the status data of the L_MC1P_AxisBasicControl function block | | ● | ● | ● |
| xError | BOOL | TRUE | There is an error in the technology module. | ● | ● | ● |
| xWarning | BOOL | TRUE | There is a warning in the technology module. | ● | ● | ● |
| eErrorID | L_IE1P_Error | ID of the error or warning message if xError = TRUE or xWarning = TRUE. "FAST technology modules" reference manual: Here you can find information on error or warning messages. | | ● | ● | ● |
| scErrorInfo | L_TT1P_scErrorInfo | Error information structure for a more detailed analysis of the error cause | | ● | ● | ● |
| scSignalFlow | L_TT1P_scSF_ElectricalShaftPos[Base/State/High] | Structure of the signal flow The data type depends on the version used (Base/State/High). ► Signal flow diagram (□ 24) | | ● | ● | ● |
| xAxisEnabled | BOOL | TRUE | The axis is enabled. | ● | ● | ● |
| xDone | BOOL | TRUE | The request/action has been completed successfully. | ● | ● | ● |
| xBusy | BOOL | TRUE | The request/action is currently being executed. | ● | ● | ● |
| xIsHomed | BOOL | TRUE | The axis has been referenced (reference known). | ● | ● | ● |
| IrActVel | LREAL | Current velocity • Unit: units/s | | ● | ● | ● |
| IrActPos | LREAL | Current position • Unit: units | | ● | ● | ● |
| IrOffset | LREAL | Set position offset from the IrSetOffsetSlave input between the master axis and the slave axis • Unit: units | | ● | ● | ● |
| IrOffsetTrim | LREAL | Position offset from the trimming function between the master axis and the slave axis • Unit: units | | | ● | ● |
| IrOffsetTotal | LREAL | The total position offset between the master axis and the slave axis contains the information of the master offset, slave offset and offset from the trimming function and the offset caused by relative clutch-in. • Unit: units | | | ● | ● |
| xSynchronised | BOOL | TRUE | The axis is coupled with reference to the master axis. | | ● | ● |

| Designator | Data type | Description | | Available in version | | |
|-----------------|-----------|--|---|----------------------|-------|------|
| | | | | Base | State | High |
| xAccDecSync | BOOL | TRUE | The synchronisation function is active. The axis is synchronised or desynchronised (clutch opens or closes). | | ● | ● |
| IrOffsetSyncPos | LREAL | Position offset caused by relative clutch-in. • Unit: units | | | | ● |

3.3.4 Parameters

L_TT1P_scPar_ElectricalShaftPos[Base/State/High]

The **L_TT1P_scPar_ElectricalShaftPos[Base/State/High]** structure contains the parameters of the technology module.

| Designator | Data type | Description | Available in version | | |
|--|-----------|---|----------------------|-------|------|
| | | | Base | State | High |
| IrStopDec | LREAL | Deceleration for the stop function and when hardware/software limit switches and the following error monitoring function are triggered • Unit: units/s ² • Initial value: 10000 | ● | ● | ● |
| IrStopJerk | LREAL | Jerk for the stop function and for the triggering of the hardware limit switches, software limit positions, and the following error monitoring function • Unit: units/s ³ • Initial value: 100000 | ● | ● | ● |
| IrHaltDec | LREAL | Deceleration for the holding function Specification of the maximum speed variation which is to be used for deceleration to standstill. • Unit: units/s ² • Initial value: 3600 • Only positive values are permissible. | ● | ● | ● |
| IrJerk | LREAL | Jerk for compensating an offset value, trimming, clutch, or holding function • Unit: units/s ³ • Initial value: 100000 | ● | ● | ● |
| IrJogJerk | LREAL | Jerk for manual jog • Unit: units/s ³ • Initial value: 10000 | ● | ● | ● |
| IrJogVel | LREAL | Maximum speed to be used for manual jog. • Unit: units/s • Initial value: 10 | ● | ● | ● |
| IrJogAcc | LREAL | Acceleration for manual jog Specification of the maximum speed variation which is to be used for acceleration. • Unit: units/s ² • Initial value: 100 | ● | ● | ● |
| IrJogDec | LREAL | Deceleration for manual jog Specification of the maximum speed variation which is to be used for deceleration to standstill. • Unit: units/s ² • Initial value: 100 | ● | ● | ● |
| IrHomePosition | LREAL | Home position for a reference run (homing) • Unit: units • Initial value: 0 | ● | ● | ● |
| xUseHomeExtParameter | BOOL | Selection of the homing parameters to be used • Initial value: FALSE | ● | ● | ● |
| | | FALSE The homing parameters defined in the axis data are used. | | | |
| | | TRUE The scHomeExtParameter homing parameters from the application are used. | | | |
| scHomeExtParameter L_MC1P_HomeParameter | | Homing parameters from the application • Only relevant if xUseHomeExtParameter = TRUE. | ● | ● | ● |


| Designator | Data type | Description | Available in version | | |
|---|---|---|----------------------|-------|------|
| | | | Base | State | High |
| scHomeExtTP MC_TRIGGER_REF | | Transfer of an external touch probe event <ul style="list-style-type: none"> Only relevant for "External source" touch probe configuration. For describing the MC_TRIGGER_REF structure, see the MC_TouchProbe function block. | ● | ● | ● |
| dwNumerator | DWORD | This value is included in the resulting synchronous factor as numerator term. <ul style="list-style-type: none"> Initial value: 1 | ● | ● | ● |
| dwDenominator | DWORD | This value is included in the resulting synchronous factor as denominator term. <ul style="list-style-type: none"> Initial value: 1 | ● | ● | ● |
| xLoadSyncPos | BOOL | Automatic calculation and selection of the gearbox output position for direct clutch-in <ul style="list-style-type: none"> Initial value: FALSE Direct clutching-in/declutching (□ 33) | ● | ● | ● |
| | | TRUE The output position of the gearbox is calculated considering the current slave position. After this process, a direct, jerk-free clutch-in is possible. | | | |
| lrTrimAcc | LREAL | Acceleration for trimming Selection of the velocity change relative to the master to be used for accelerating. The acceleration acting on the drive is the sum of master and slave acceleration. <ul style="list-style-type: none"> Unit: units/s² Initial value: 100 | | ● | ● |
| lrTrimDec | LREAL | Deceleration for trimming Selection of the velocity change relative to the master to be used for decelerating. The deceleration acting on the drive is the sum of master and slave deceleration. <ul style="list-style-type: none"> Unit: units/s² Initial value: 100 | | ● | ● |
| lrTrimVel | LREAL | Velocity for trimming Selection of the velocity used for trimming. <ul style="list-style-type: none"> Unit: units/s Initial value: 50 | | ● | ● |
| lrSlaveSyncInDist | LREAL | Distance of the clutch-in movement from the slave axis (path-based coupling mode). <ul style="list-style-type: none"> Unit: units Initial value: 90 | | ● | ● |
| lrSlaveSyncOutDist | LREAL | Distance of the declutch movement from the slave axis (path-based coupling mode). <ul style="list-style-type: none"> Unit: units Initial value: 90 | | ● | ● |
| lrSlaveSyncOutPos | LREAL | Declutch setpoint position of the slave axis At this position, the slave axis is stopped as soon as the declutch process has been carried out (path-based clutch mode). <ul style="list-style-type: none"> Unit: units Initial value: 0 | | ● | ● |
| eOffsetSlaveDirection L_TT1P_Direction | Direction selection for the profile generator <ul style="list-style-type: none"> Initial value: 1 (Direction Master) | | | | ● |
| | 0 | Both: The axis may travel in positive and negative direction | | | |
| | 1 | Master direction: The slave axis may only travel in the same direction as the master axis. | | | |

| Designator | Data type | Description | Available in version | | |
|--|-----------|--|----------------------|-------|------|
| | | | Base | State | High |
| eOffsetSlaveProfileType L_TT1P_ProfileType | | Profile type of the profile generator • Initial value: 2 | | | ● |
| | | 0 poly_4th_order (4th order polynomial) | | | |
| | | 1 poly_2nd_order (2nd order polynomial) | | | |
| | | 2 poly_5th_order (5th order polynomial) | | | |
| IrOffsetSlaveVelPos | LREAL | Maximum positive velocity to be used for the profile. The sum of this velocity and the velocity of the master is the velocity acting on the slave axis. • Unit: units/s • Initial value: 100 | | | ● |
| IrOffsetSlaveVelNeg | LREAL | Maximum negative velocity to be used for the profile. The sum of this velocity and the velocity of the master is the velocity acting on the slave axis. • Unit: units/s • Initial value: 100 | | | ● |
| IrOffsetSlaveAccDec | LREAL | Maximum acceleration to be used for the profile. The sum of this acceleration and the one of the master is the acceleration acting on the slave axis. Note: With the "poly_4th" and "poly_5th" profile type selection, the parameter profile value of the acceleration and deceleration is exceeded. • Unit: units/s ² • Initial value: 1000 | | | ● |
| xLoadOffsetSlave | BOOL | Loading the position offset to the master axis (via IrSetOffsetSlave input) • Initial value: FALSE | | | ● |
| | | TRUE The position offset is loaded cyclically. | | | |
| | | FALSE The position offset is run via the profile generator. | | | |
| eSyncDirection L_TT1P_SyncDirection ElectricalShaftPos | | Permitted clutch-in direction with regard to the master motion | | | ● |
| | | -1 mcNegativeDirection (starting condition in negative direction of the master axis) | | | |
| | | 1 mcPositiveDirection (starting condition in positive direction of the master axis) | | | |
| | | 2 mcShortestWay (by the shortest way possible in both directions) | | | |
| eSyncMode L_TT1P_SyncMode ElectricalShaftPos | | Initial value := 0: mcCurrentDirection (in both directions) | | | ● |
| | | Clutch-in/declutch mode: | | | |
| | | 3 Ramp_Time (time-based clutching within a time slot) | | | |
| | | 4 Ramp_VelAcc (clutching via a profile generator) | | | |
| IrSyncInTime | LREAL | Relevant for coupling mode: eSyncMode = 3 Ramp_Time Period of time of the clutch-in process in seconds (time-based coupling mode). Initial value:= 5 | | | ● |
| | | | | | |
| | | | | | |
| | | | | | |
| IrSyncOutTime | LREAL | Relevant for coupling mode: eSyncMode = 3 Ramp_Time Period of time of the declutch process in seconds (time-based coupling mode). Initial value:= 5 | | | ● |
| | | | | | |
| | | | | | |
| | | | | | |

| Designator | Data type | Description | Available in version | | |
|------------|-----------|---|----------------------|-------|------|
| | | | Base | State | High |
| IrSyncVel | LREAL | Maximum speed at which the clutch-in/declutch process in mode eSyncMode = 4 (ramp_VelAc) is to be carried out. • Unit: units/s • Initial value: 100 | | | ● |
| IrSyncAcc | LREAL | Acceleration for the clutch-in/declutch process in mode eSyncMode = 4 (ramp_VelAc) Specification of the maximum speed variation which is to be used for acceleration. • Unit: units/s ² • Initial value: 1000 | | | ● |
| IrSyncDec | LREAL | Deceleration for the clutch-in/declutch process in mode eSyncMode = 4 (ramp_VelAc) Specification of the maximum speed variation which is to be used for deceleration to standstill. • Unit: units/s ² • Initial value: 1000 | | | ● |
| IrSyncJerk | LREAL | Jerk for the clutch-in/declutch process in mode eSyncMode = 4 (ramp_VelAc) • Unit: units/s ³ • Initial value: 1000000 | | | ● |

3.4


State machine



[3-2] State machine of the technology module

(*1 In the "Ready" state, xRegulatorOn has to be set to TRUE.

(*2 In the "ERROR" state, xResetError has to be set to TRUE in order to acknowledge and reset the errors.



[3-3] Signal flow diagram

The illustration [\[3-3\]](#) shows the main signal flow of the implemented functions.

The signal flow of the additional functions such as "manual jog" is not displayed here.

3.5.1 Structure of the signal flow

L_TT1P_scSF_ElectricalShaftPos[Base/State/High]

The contents of the L_TT1P_scSF_ElectricalShaftPos[Base/State/High] structure are read-only and offer a practical diagnostics option within the signal flow ([Signal flow diagram](#) (□ 24)).

| Designator | Data type | Description | Available in version | | |
|-------------------------|-----------|---|----------------------|-------|------|
| | | | Base | State | High |
| IP01_IrSetOffsetSlave | LREAL | Position offset to master axis The position is approached in the "POS_IS_SYNCHRONISED" state when the value changes • Unit: units | ● | ● | ● |
| | | Base/ State | | | |
| | | High | | | |
| MP01_IrSetMasterPos | LREAL | Set position of the master axis • Unit: units | ● | ● | ● |
| MP02_IrSetSlavePos | LREAL | Set position of the slave axis • Unit: units | ● | ● | ● |
| MP03_IrSetGearBoxPosOut | LREAL | Resulting position from the gearbox • Unit: units | ● | ● | ● |
| MP04_IrSetClutchPos | LREAL | Master position for Direct clutching-in/declutching (□ 33) • Unit: units | ● | ● | ● |
| OP01_IrOffset | LREAL | Set position offset from the IrSetOffsetSlave input between the master axis and the slave axis • Unit: units | ● | ● | ● |
| OP02_IrOffsetTrim | LREAL | Position offset from the trimming function between the master axis and the slave axis • Unit: units | | ● | ● |
| OP03_IrOffsetTotal | LREAL | Total position offset between the master axis and the slave axis • Unit: units | | ● | ● |

3.5.2 Structure of the access points

L_TT1P_scAP_ElectricalShaftPos[Base/State/High]

The access points (AP) can be used to influence signals. In the initial state, the access points do not have any effect.

Each access point acts as an alternative branch and is activated via an OR operation or a switch.

| Designator | Data type | Description | | Available in version | | |
|-----------------------------------|-----------|---|--|----------------------|-------|------|
| | | | | Base | State | High |
| AP01_xLoadGearBoxPosOut BOOL | | Enable of the AP01_lrLoadGearBoxPosOut access point | | ● | ● | ● |
| | | TRUE | The access point overwrites the values at the access point in the signal flow. | | | |
| AP01_lrLoadGearBoxPosOut LREAL | | Loading of the resulting position from the gearbox • Unit: units | | | | |
| AP02_xLoadTrimOffset BOOL | | Enable of the AP02_lrLoadTrimOffset access point | | | ● | ● |
| | | TRUE | The access point overwrites the values at the access point in the signal flow. | | | |
| AP02_lrLoadTrimOffset LREAL | | Loading of the resulting distance from the trimming function • Unit: units | | | | |
| AP05_xLoadOffsetSync BOOL | | Enable of the AP05_lrLoadOffsetSync access point | | | | ● |
| | | TRUE | The access point overwrites the values of the synchronisation offset. | | | |
| AP05_lrLoadOffsetSync LREAL | | Loading the synchronisation offset | | | | |

3.6 Manual jog (jogging)

Precondition

- The technology module is in the "Ready" state.
- The slave axis is enabled ($xRegulatorOn = TRUE$).

Execution

For manual jog of the axis, the manual jog speed $lrJogVel$ is used.

If the $xJogPos$ input is TRUE, the axis is traversed in positive direction and if the $xJogNeg$ input is TRUE, the axis is traversed in negative direction. The axis is executed for as long as the input remains set to TRUE.

The current travel command cannot be replaced by another jog command. Only if both inputs have been reset, the [State machine](#) (□ 23) changes to the "Ready" state again.

Parameters to be set

The parameters for the manual jog are located in the [L TT1P_scPar_ElectricalShaftPos\[Base/State/High\]](#) (□ 19) parameter structure.

```
lrJogVel : LREAL := 10;      // Velocity [units/s]
lrJogAcc : LREAL := 100;    // Acceleration [units/s^2]
lrJogDec : LREAL := 100;    // Deceleration [units/s^2]
lrJogJerk : LREAL := 10000; // Jerk [units/s^3]
```

The parameter values can be changed during operation. They are accepted when the $xJogPos$ or $xJogNeg$ input is set to TRUE again.

3.7

Homing**Precondition**

- The technology module is in the "Ready" state.
- The slave axis is enabled (*xRegulatorOn* = TRUE).

Execution

Homing is started with a rising edge (FALSE→TRUE) at the *xHomeExecute* input. The axis will be travelling until the home position is reached. After successful homing, the [State machine](#) (23) changes back again to the "Ready" state.

The homing process is not interrupted if the *xHomeExecute* input is set to FALSE too early. The function is aborted via the *xStop* input.

Parameters to be set

The parameters for homing are located in the [L_TT1P_scPar_ElectricalShaftPos\[Base/State/High\]](#) (19) parameter structure.

```
xUseHomeExtParameter : BOOL := FALSE;
lrHomePosition : LREAL := 0.0;
scHomeExtParameter : L_MC1P_HomeParameter;
scHomeExtTP : MC_TRIGGER_REF;
```

3.8

Synchronism (SyncPos)**Note!**

Synchronism is activated with a position jump.

Execution


In order to synchronise the slave axis and master axis, synchronism factors are used to calculate a setpoint position based on the master axis. Synchronism is started by setting the *xSyncPos* input to TRUE. As a result, the calculated setpoint position is abruptly connected to the axis. A jerk-free connection is only possible at standstill after prior positioning. The gearbox factor is preset to 1:1.

Parameters to be set


The parameters for the gearbox factor are located in the [L TT1P_scPar_ElectricalShaftPos\[Base/State/High\]](#) (□ 19) parameter structure.

```
dwNumerator : DWORD := 1;  
dwDenominator : DWORD := 1;
```

Examples



If, for instance, the gearbox factor is set to 2:1 ($dwNumerator = 2$, $dwDenominator = 1$), the following synchronism response can be observed:



[3-4] Synchronism behaviour at gearbox factor 2:1

3.9

Position offset during synchronism

**Note!**


A position offset is set with a position jump.

Precondition

Setting a position offset is only possible in the "POS_IS_SYNCHRONISED" state.

Execution

A variable position offset between master and slave is defined with the *IrSetOffsetSlave* input. In the "POS_IS_SYNCHRONISED" state and with a changed value, the offset is abruptly connected to the setpoint position of the axis.

Example

[3-5] Position offset *IrSetOffsetSlave* = 100

3.10 Synchronism with clutch-in/declutch mechanism

Execution

Synchronism of the slave axis and master axis is extended by a clutch function. The clutch function synchronises the position of the slave axis with the master position of the master axis, positioning taking place without step changes.

Clutch-in starts at any position when *xSyncPos* = TRUE.

When declutching with *xSyncPos* = FALSE, the drive is braked to a standstill at the *lrSlaveSyncOutPos* position and changed to the "Ready" state.

The *lrSlaveSyncInDist* parameters (for clutch-in) and *lrSlaveSyncOutDist* (for declutch) describe the path via which the clutch process shall take place. For the initial values of the parameters, the clutch process has to be completed after 90 units.

In order that the clutching process is started, the position of the master axis has to be located upstream by at least double the clutch-in distance of the position of the slave axis. Otherwise, the master axis would travel another complete cycle until the clutch-in process is started.



Note!


In case of "Limited" axis setting:

- The slave axis is clutched in when the master axis has reached the *lrSlaveSyncInDist* distance before the slave axis.
- In order that the slave axis is declutched at the *lrSlaveSyncOutPos* declutch position, the *lrSlaveSyncOutDist* distance must be defined in advance.

Parameters to be set

The parameters for the clutch function are located in the [L TT1P_scPar_ElectricalShaftPos\[Base/State/High\]](#) (19) parameter structure.

```
lrSlaveSyncOutPos : LREAL := 0.0;
lrSlaveSyncInDist : LREAL := 90.0;
lrSlaveSyncOutDist : LREAL := 90.0;
```


Example

[3-6] Clutching-in/declutching with IrSlaveSyncOutPos = 100

The [3-6] figure shows the clutch-in process on position 100.0 which is completed within 90 units. After declutching, it ends again on position 100.0 after 90 units.

3.10.1 Direct clutching-in/declutching

The clutch function also provides for a direct clutching-in/declutching. For this purpose, set the parameters *IrSlaveSyncInDist* and *IrSlaveSyncOutDist* to the value '0.0'. Clutching-in is then executed directly and abruptly.

In order to prevent a jump of the position at the clutch output and thus at the slave axis, the following options are available:

- Positioning of the slave axis to the input position of the clutch (*MP04:IrSetClutchPos*) before clutching-in hard.

This version offers a position synchronism without position offset between the master axis and the slave axis.

More information on *MP04:IrSetClutchPos* can be found here:

[L TT1P_scPar_ElectricalShaftPos\[Base/State/High\]](#) (19)

- Automatic calculation and definition of the gearbox position for direct clutch-in with *xLoadSyncPos* parameter = *TRUE*.

This version offers a position synchronism with position offset between the master axis and the slave axis. The resulting position offset can be eliminated afterwards by applying an offset.

3.10.2 Relative clutching-in/declutching

This function can only be used in the High version of the technology module!

These functions are selected via inputs and not via selecting a coupling mode. The selection of the general coupling mode is not affected by this function.

When the *xSyncInstant* input = TRUE, the synchronisation is carried out with relative position coupling.

- If the master axis is at standstill, the slave axis directly (abruptly) clutches in to its current position.
- When the master axis is in motion, the slave axis immediately clutches in via the clutching distance in the *lrSlaveSyncInDist* parameter (by analogy with a velocity coupling).
- For declutching, the *xSyncInstant* input has no function.

When the *xSyncOutInstant* input = TRUE, it is declutched with relative position coupling.

- If the master axis is at standstill, the slave axis directly (abruptly) declutches from its current position.
- When the master axis is in motion, the slave axis immediately declutches via the clutching distance in the *lrSlaveSyncOutDist* parameter (by analogy with a velocity coupling or MC_Halt).
- For declutching, the *xSyncOutInstant* input has no function.

A position offset caused by relative clutching-in is displayed at the *lrOffsetSyncPos* output (in units).

Coupling behaviour if the inputs are stimulated at different times

Clutching-in via the *xSyncInstant* input:

| Combinations of the inputs | | Coupling behaviour |
|----------------------------|---------------------|------------------------------|
| <i>xSyncPos</i> | <i>xSyncInstant</i> | |
| FALSE↗TRUE | FALSE | Coupling behaviour as before |
| FALSE | FALSE↗TRUE | No response |
| TRUE | FALSE↗TRUE | No response |
| FALSE↗TRUE | FALSE↗TRUE | Relative clutching-in |
| FALSE↗TRUE | TRUE | Relative clutching-in |

Declutching via the *xSyncOutInstant* input:

| Combinations of the inputs | | Coupling behaviour |
|----------------------------|------------------------|------------------------------|
| <i>xSyncPos</i> | <i>xSyncOutInstant</i> | |
| TRUE↘FALSE | FALSE | Coupling behaviour as before |
| TRUE↘FALSE | FALSE↗TRUE | Relative declutching |
| TRUE | FALSE↗TRUE | Relative declutching |

Parameters to be set

The parameters for the clutch function are located in the [L TT1P_scPar_ElectricalShaftPos\[Base/State/High\]](#) (19) parameter structure.

```
lrSlaveSyncInDist : LREAL := 90.0;  
lrSlaveSyncOutDist : LREAL := 90.0;  
eOffsetSlaveDirection : L_TT1P_Direction := 1;  
eOffsetSlaveProfileType : L_TT1P_ProfileType := 2;  
lrOffsetSlaveVelPos : LREAL := 100;  
lrOffsetSlaveVelNeg : LREAL := 100;  
lrOffsetSlaveAccDec : LREAL := 1000;
```

3.11 Position trimming

Precondition

The position trimming is only possible in the "POS_IS_SYNCHRONISED" state.

Execution

Position trimming makes it possible to adjust the position of the slave axis with regard to the master axis by "inching" – as in the case of [Manual jog \(jogging\)](#) (□ 27).

Position trimming is started by setting the input *xTrimPos* or *xTrimNeg* to TRUE. The "POS_IS_SYNCHRONISED" state then changes to "TRIM_POS_PLUS" or "TRIM_POS_MINUS", depending on the direction, and only leaves it when the respective input *xTrimPos* or *xTrimNeg* is reset to FALSE.

Offsets adjusted by trimming can be detected via the *lrOffsetTrim* output. The value of *lrOffsetTrim* can only be reset to zero by switching of the technology module.

Parameters to be set

The parameters for position trimming are located in the [L_TT1P_scPar_ElectricalShaftPos\[Base/State/High\]](#) (□ 19) parameter structure.

```
lrJerk : LREAL := 100000;
lrTrimAcc : LREAL := 100;
lrTrimDec : LREAL := 100;
lrTrimVel : LREAL := 50;
```

The acceleration and velocity of the trimming superimpose the ones of the master axis. Hence, the results for the axis to be trimmed are as follows:

- Resulting velocity of: $v_{\text{AxisRes}} = v_{\text{MasterAxis}} + lr\text{TrimVel}$
- Resulting acceleration of: $a_{\text{AxisRes}} = a_{\text{MasterAxis}} + lr\text{TrimAcc}$

3.12 Position offset with profile generator

Precondition

Setting a position offset is only possible in the "POS_IS_SYNCHRONISED" state.

Execution

The position offset is transferred to the axis via a profile generator without position jumps. The offset is selected using the *lrSetOffsetSlave* input.

The position offset can be travelled with 3 different rounding profiles using the profile generator. The profile generator is activated by setting the *xLoadOffsetSlave* parameter = FALSE. A profile can be specified via the *eOffsetSlaveProfileType* parameter.

The *eOffsetSlaveDirection* parameter serves to define whether the drive may rotate in the opposite direction of the master direction of rotation (0: *Both*) or not (1: *Direction Master*).

The basic conditions for calculating the profile are defined via the parameters *lrOffsetSlaveVelPos*, *lrOffsetSlaveVelNeg* and *lrOffsetSlaveAccDec*.


Parameters to be set

The parameters for the position offset with profile generator are located in the [L_TT1P_scPar_ElectricalShaftPos\[Base/State/High\]](#) (19) parameter structure.

```
xLoadOffsetSlave : BOOL := FALSE;
eOffsetSlaveProfileType : L_TT1P_ProfileType := 0;
eOffsetSlaveDirection : L_TT1P_Direction := 0;
lrJerk : LREAL := 100000;
lrOffsetSlaveVelPos : LREAL := 100;
lrOffsetSlaveVelNeg : LREAL := 100;
lrOffsetSlaveAccDec : LREAL := 1000;
```


Examples

If, for instance, the master axis is operated in positive direction, $eOffsetSlaveDirection = 1$ (*DirectionMaster*) serves to prevent the slave axis from rotating in the negative direction. The [3-7] figure shows how the slave axis (blue) is waiting for the master axis in order to correct its position offset $IrSetOffsetSlave$.



[3-7] Direction of rotation only in master direction of rotation ($eOffsetSlaveDirection = 1$)

The [3-8] figure shows the behaviour when the slave axis is allowed to rotate in the positive and negative direction ($eOffsetSlaveDirection = 0$ (*Both*)).



[3-8] Direction of rotation in positive and negative direction ($eOffsetSlaveDirection = 0$)

In the figures [\[3-7\]](#) and [\[3-8\]](#), the rounding profile has been calculated with a 4th grade polynomial. This is the standard setting specified via the *eOffsetSlaveProfileType* parameter. There are 3 possible profiles for this parameter:

```
eOffsetSlaveProfileType : L_TT1P_ProfileType := 0;  
// 0: poly_4th_order (4th order polynomial)  
// 1: poly_2nd_order (2nd order polynomial)  
// 2: poly_5th_order (5th order polynomial)
```

The *IrSetOffsetSlave* position offset changes every 3 seconds between 40 and 80 units.

3.13 Extended clutch-in/declutch mechanism

This function can only be used in the High version of the technology module!

The clutch-in and declutch mechanism of the State version has been extended by the *scPar.eSyncMode* mode.

3.13.1 eSyncMode = Ramp_Dist


The "Ramp_Dist" coupling mode is the clutch-in and declutch mechanism from the State version.

In this mode, the slave axis can clutch in or declutch over several cycles of the master axis.

The slave axis only clutches in or declutches to/from the master position if the master axis is moving.


The slave axis is positioned from its current position to the resulting target position in a path-based fashion via a polynomial of the fifth degree.

Clutching in



[3-9] Clutching in with *eSyncMode = 5 Ramp_Dist*

Declutching


[3-10] Declutching with $eSyncMode = 5 Ramp_Dist$

3.13.2 eSyncMode = Ramp_Time

The "Ramp_Time" coupling mode does not depend on the motion of the master axis. The slave axis is also synchronised with a standing master axis.

Clutching in


The slave axis clutches in to the master position from its current position via a polynomial of the fifth degree in a time-based fashion (parameter *IrSyncInTime*). The movement is executed within the slave cycle of the modulo axes.



[3-11] Clutching in with eSyncMode = 3 Ramp_Time

Declutching

Declutching is triggered with the *xSyncPos* input = FALSE. The time-controlled declutching is executed by the slave axis from the current position within a defined time (parameter *lrSyncOutTime*). The *lrSlaveSyncOutPos* parameter is used to define the stopping position of the slave axis.



[3-12] Declutching with *eSyncMode* = 3 Ramp_Time

Parameters to be set

The parameters to be set are located in the [L TT1P_scPar ElectricalShaftPos\[Base/State/High\]](#) (19) parameter structure.

```
eSyncMode : L_TT1P_SyncMode := L_TT1P_SyncMode.Ramp_time;
lrSlaveSyncOutPos
lrSyncInTime : LREAL := 5;
lrSyncOutTime : LREAL := 5;
lrSlaveSyncOutPos : LREAL := 0;
```


3.13.3 eSyncMode = Ramp_VelAcc

**Note!**

This clutch-in or declutch version does not depend on the master motion, which means it also synchronises the slave axis with a standing master axis.

Clutching in


The slave axis clutches in from its current position to the master position via the profile generator with the parameters *lrSyncVel*, *lrSyncAcc*, *lrSyncDec* and *lrSyncJerk*. The motion is executed within the slave cycle of the modulo axes. The resulting velocity of the slave axis in the clutch-in phase results from the sum of speed of the master axis and the *lrSyncVel* velocity. The acceleration of the slave axes in the clutch-in phase also results from the sum of acceleration of the master axis and the acceleration and deceleration of the coupling (*lrSyncAcc*, *lrSyncDec*).



[3-13] Clutching in with eSyncMode = 4 Ramp_Time

Declutching

Declutching is triggered via the *xSyncPos* input = FALSE. The profile-controlled declutching brakes the slave axis to a standstill from the current position with the parameters *lrSyncVel*, *lrSyncAcc*, *lrSyncDec* and *lrSyncJerk*. The *lrSlaveSyncOutPos* parameter is used to define the stopping position of the slave axis.



[3-14] Declutching with *eSyncMode* = 4 Ramp_Time

Parameters to be set

The parameters to be set are located in the [L TT1P_scPar_ElectricalShaftPos\[Base/State/High\]](#) ([19](#)) parameter structure.

```
eSyncMode : L_TT1P_SyncMode := L_TT1P_SyncMode.Ramp_VelAcc;
lrSyncVel : LREAL := 100;
lrSyncAcc : LREAL := 1000;
lrSyncDec : LREAL := 1000;
lrSyncJerk : LREAL := 100000;
```

3.14 CPU utilisation (example Controller 3231 C)

The following table shows the CPU utilisation in microseconds using the example of the 3231 C controller (ATOM™ processor, 1.6 GHz).

| Versions | Interconnection of the technology module | CPU utilisation | |
|--------------|--|-----------------|--------------|
| | | Average | Maximum peak |
| Base | xEnable := TRUE; xRegulatorOn := TRUE; xSyncPos := TRUE; | 40 µs | 83 µs |
| State | xEnable := TRUE; xRegulatorOn := TRUE; xSyncPos := TRUE; | 55 µs | 83 µs |
| High | xEnable := TRUE; xRegulatorOn := TRUE; xSyncPos := TRUE; | 70 µs | 92 µs |

A

Access points [26](#)

Application notes [7](#)

C

Clutch-in mechanism (synchronism) [32](#)

Controlled start of the axes [13](#)

Conventions used [6](#)

CPU utilisation (example Controller 3231 C) [46](#)

D

Declutch mechanism (synchronism) [32](#)

Direct clutching-in/declutching [33](#)

Document history [5](#)

E

Electrical Shaft Position (functional description) [10](#)

E-mail to Lenze [48](#)

eSyncMode = Ramp_Dist [40](#)

eSyncMode = Ramp_Time [42](#)

eSyncMode = Ramp_VelAcc [44](#)

Extended clutch-in mechanism [40](#)

Extended clutch-in/declutch mechanism [40](#)

Extended declutch mechanism [40](#)

F

Feedback to Lenze [48](#)

Function block L_TT1P_ElectricalShaftPosBase/State/High [14](#)

Functional description of "Electrical Shaft Position" [10](#)

H

Homing [28](#)

I

Inputs [15](#)

Inputs and outputs [14](#)

L

L_TT1P_ElectricalShaftPosBase [14](#)

L_TT1P_ElectricalShaftPosHigh [14](#)

L_TT1P_ElectricalShaftPosState [14](#)

L_TT1P_scAP_ElectricalShaftPosBase [26](#)

L_TT1P_scAP_ElectricalShaftPosHigh [26](#)

L_TT1P_scAP_ElectricalShaftPosState [26](#)

L_TT1P_scPar_ElectricalShaftPosBase [19](#)

L_TT1P_scPar_ElectricalShaftPosBase/State/High parameter structure [19](#)

L_TT1P_scPar_ElectricalShaftPosHigh [19](#)

L_TT1P_scPar_ElectricalShaftPosState [19](#)

L_TT1P_scSF_ElectricalShaftPosBase [25](#)

L_TT1P_scSF_ElectricalShaftPosHigh [25](#)

L_TT1P_scSF_ElectricalShaftPosState [25](#)

Layout of the safety instructions [7](#)

M

Manual jog (jogging) [27](#)

N

Notes on how to operate the technology module [12](#)

O

Operating mode [12](#)

Outputs [17](#)

P

Position offset during synchronism [31](#)

Position offset with profile generator [37](#)

Position trimming [36](#)

Profile generator [37](#)

R

Relative clutching-in/declutching [34](#)

S

Safety instructions [7](#), [8](#)

Signal flow diagram [24](#)

Start of the axes [13](#)

State machine [23](#)

States [23](#)

Structure of the access points

L_TT1P_scAP_ElectricalShaftPosBase/State/High [26](#)

Structure of the L_TT1P_scSF_ElectricalShaftPosBase/State/High signal flow [25](#)

Synchronism (SyncPos) [29](#)

Synchronism with clutch-in/declutch mechanism [32](#)

SyncPos (synchronism) [29](#)

T

Target group [4](#)

Technology module functions (overview) [11](#)

Torque-controlled drive as master [12](#)

Trimming [36](#)

U

Use of setpoints or actual values [12](#)

V

Variable names [6](#)



Your opinion is important to us

These instructions were created to the best of our knowledge and belief to give you the best possible support for handling our product.

Perhaps we have not succeeded in achieving this objective in every respect. If you have suggestions for improvement, please e-mail us to:

feedback-docu@lenze.com

Thank you very much for your support.

Your Lenze documentation team

Lenze Automation GmbH
Postfach 10 13 52, 31763 Hameln
Hans-Lenze-Straße 1, 31855 Aerzen
GERMANY
HR Hannover B 205381
☎ +49 5154 82-0
📠 +49 5154 82-2800
✉ lenze@lenze.com
🌐 www.lenze.com

Service

Lenze Service GmbH
Breslauer Straße 3, 32699 Extertal
GERMANY
☎ 008000 24 46877 (24 h helpline)
📠 +49 5154 82-1112
✉ service@lenze.com