

Digitals

Functions

int	digital	(int port)
void	set_digital_value	(int port, int value)
int	get_digital_value	(int port)
void	set_digital_output	(int port, int out)
int	get_digital_output	(int port)
int	get_digital_pullup	(int port)
void	set_digital_pullup	(int port, int pullup)

Detailed Description

Function Documentation

int digital (int port)

See also

get_digital_value

int get_digital_output (int port)

Gets the current digital mode

Returns

1 for output mode, 0 for input mode

See also

set_digital_value

int get_digital_pullup (int port)

Gets the current digital pullup state

Returns

1 for active, 0 for inactive

Deprecated:

not applicable on the Wallaby

int get_digital_value (int port)

Gets the current value of the digital port.

Returns

1 if the switch is closed, 0 if the switch is open

See also

set_digital_value

```
void set_digital_output ( int port,  
                           int out  
                           )
```

Sets the digital mode.

Parameters

[in] **port** The port to modify.

[in] **out** 1 for output mode, 0 for input mode.

```
void set_digital_pullup ( int port,  
                        int pullup  
                        )
```

Sets the current digital pullup state

Parameters

[in] **port** The port to modify

[in] **pullup** The pullup state 1: active 0: inactive

Deprecated:

not applicable on the Wallaby

```
void set_digital_value ( int port,  
                        int value  
                        )
```

Sets the value of the digital port in output mode.

See also

get_digital_value