



ADSL command usage

Version: 1.0
Release date: 2011-12-22

© 2011 MediaTek Inc.

This document contains information that is proprietary to MediaTek Inc.

Unauthorized reproduction or disclosure of this information in whole or in part is strictly prohibited.

Specifications are subject to change without notice.

Document Revision History

Revision	Date	Author	Description

Table of Contents

Document Revision History	2
Table of Contents	3
1 adslphxcmd begin cmd.....	4
2 adslphxcmd connect Command.....	6
3 adslphxcmd info Command	7
4 adslphxcmd delt Command.....	8
5 adslphxcmd fwversion Command.....	10

1 adslphxcmd begin cmd

【DESCRIPTION】ADSL initialization commands can be configured to activate the mode switch and the various characteristics. If --up parameter is added in the initialization process, the ADSL line state can be set to active.

【USAGE】

adslphxcmd begin [--up] [-- modulation {a|d|l|t|2|p|e|m} [--bitswap {on|off}] [--sra {on|off}]

【PRECONDITION】ADSL driver must be installed

【PARAMETERS】

Parameters	Function	Usage
--up	do the ADSL line connection after initializing	optional
--modulation {a d l t 2 p e m}	Mode supported: a: all d: G.dmt l: G.lite t: T1.413 2: ADSL2 p: ADSL2+ e: Annex L m: Annex M	optional
--bitswap {on off}	Configuration bit-swap function on: bit-swamp function enable off: bit-swamp function disable	optional
--sra {on off}	Seamless rate adaptation (SRA) on: SRA function enabled off: SRA function disabled	optional

【Note】

1. The activation of bit-swamp function does not guarantee the operation is done on the line level, which must be determined by line state negotiation between CPE and DSLAM.

2. Seamless line adaptation does not guarantee the operation is done on the line level, which must also be determined by line state negotiation between CPE and DSLAM.

【EXAMPLE】

```
# adslphxcmd begin --modulation a --up
```

2 adslphxcmd connect Command

【COMMAND PURPOSE】 this command configures the state of ADSL. Possible states of ADSL line are ‘up’ and ‘down’

【COMMAND SYNTAX】 **adslphxcmd connect [--up] [--down]**

【PRECONDITION】 this command must be called after ADSL driver is initialized

【PARAMETERS】

Parameters	Function	Notice
--up	Initiates a ADLS Connection	optional
--down	Terminates a ADLS Connection	optional

【NOTICE】 None

【EXAMPLE】

```
# adslphxcmd connect --up
```

3 **adslphxcmd info Command**

【COMMAND PURPOSE】 this command displays the ADLS info

【COMMAND SYNTAX】 **adslphxcmd info [--state] [--show] [--stats]**

【PRECONDITION】 this command must be called after ADSL driver is initialized

【PARAMETERS】

Parameters	Function	Notice
--state	Display the ADSL line state	optional
--show	Display ADSL parameters	optional

【NOTICE】

【EXAMPLE】

```
# adslphxcmd info --state
```

4 adslphxcmd delt Command

【COMMAND PURPOSE】 this command is used for ADSL Delt diagnosing test

【COMMAND SYNTAX】 **adslphxcmd delt** [--start] [--status] [--show {*snr* | *qln* | *hlin* | *bits* | *actatp*}]

【DESCRIPTION】 ADSL Delt diagnosing test

【PRECONDITION】 this command must be called after ADSL driver is initialized

【PARAMETERS】

Parameters	Function	Notice
--start	Initiating ADSL Delt diagnosing	optional
--status	Displaying ADSL Delt diagnosing state	optional
--show { <i>snr</i> <i>qln</i> <i>hlin</i> <i>bits</i> <i>actatp</i> }	Displaying ADSL Delt diagnosing result <i>snr</i> : displaying the downstream SNR level <i>qln</i> : displaying the downstream line noise level <i>hlin</i> : displaying the channel characteristics function for each tone on the ADLS line, where $H(f)$ represents a complex number represented by the linear coordinate(unified) <i>bits</i> : displaying the bit allocation of each tone on the ADSL line <i>actatp</i> : displaying the ADS transmitting power	optional

【NOTICE】

The commands must be executed following procedure below.

1. start the diagnosing this command: `adslphxcmd delt --start`
2. get the diagnosing info with command: `adslphxcmd delt -status` (Running implies the diagnosing is in progress; Completed implies the procedure is over, turning to step 3)
3. get the diagnosing result and key parameters with command: `adslphxcmd delt --show actatp`

【EXAMPLE】

```
# adslphxcmd delt --start
# adslphxcmd delt --status
```



```
# adslphxcmd delt --show actatp
```

5 adslphxcmd fwversion Command

【DESCRIPTION】 this command displays the ADSL firmware version number

【COMMAND SYNTAX】 **adslphxcmd fwversion**

【PRECONDITION】 none

【PARAMETERS】 none

【NOTICE】 none

【EXAMPLE】

adslphxcmd fwversion