



Fuse/Relay Boxes > Under-Hood Fuse/Relay Box

Fuse

Ref. No.	Amps	Notes
A1-1	60A	
A1-3	30A	
A1-4	30A	
A1-5	30A	
A1-6	30A	
A1-7	125A	
A10	20A	
A11	5A	
A12	10A	
A13	15A	
A14	15A	
A15	15A	
A16	15A	
A17	10A	
A18	10A	
A19	15A	
A2-1	70A	
A2-2	30A	
A2-3	40A	
A2-4	60A	
A2-5	30A	
A2-6	30A	

Fuse/Relay Boxes > Under-Hood Fuse/Relay Box

Ref. No.	Amps	Notes
A20	10A	
A21	10A	
A22	15A	
A23	10A	
A24	10A	
A3-1	40A	
A3-2	40A	
A3-3	40A	
A3-4	40A	
A3-5	30A	
A3-6	40A	
A5	5A	
A6	15A	
A7	15A	
A8	10A	
A9	15A	
C26	10A	
C27	10A	
C29	10A	
C30	10A	
D31	15A	
D32	20A	
D33	5A	

Fuse/Relay Boxes > Under-Hood Fuse/Relay Box

Relay

Ref. No.	Relay Name	Notes
M1	Rear Window Defogger Relay	
M2	Horn Relay	
M4	PGM-FI Main Relay 2	
M5	A/C Compressor Clutch Relay	
M6	Blower Motor Relay	
P1	Daytime Running Light Relay	
P2	Fog Light Relay	
P3	Taillight Relay	
P4	Headlight Low Beam Relay	
Q1	Injector Relay	

Component

Ref. No.	Component Name	Notes
295	Relay Circuit Board	
388	Rear Window Washer Motor Relay	
421	Fan Control Relay	
424	Radiator Fan Relay	
425	A/C Condenser Fan Relay	

Connector

Fuse/Relay Boxes > Under-Hood Fuse/Relay Box

Ref. No.	Connector Name	Male/Female	Connector Type	Notes
T2	T2		Component Connector	
T3	T3		Component Connector	