

TEAM ID: PNT2022TMID42599

PROJECT: Real-Time River Water Quality Monitoring and Control System

NAME: RENUGHA.S. S

1. Write Code and connections in wokwi for ultrasonic sensor. whatever distance is less than 100 cms send "Alert" to ibm cloud and display in device recent events.

Solution:

```
//Pins
```

```
const int TRIG_PIN = 7 ; const
```

```
int ECHO_PIN = 8;
```

```
//Anything over 400 cm (23200 us pulse) is "out of range" const
```

```
unsigned int MAX_DIST = 23200;
```

```
void setup() {
```

```
// The Trigger pin will tell the sensor to range find
```

```
Pin Mode(TRIG_PIN, OUTPUT); digital
```

```
Write(TRIG_PIN, LOW);
```

```
//Set Echo pin as input to measure the duration of
```

```
//pulses coming back from the distance sensor
```

```
pinMode(ECHO_PIN, INPUT ) ;
```

```
// We'll use the serial monitor to view the sensor output
Serial.begin(9600);
}

void loop() { unsigned
long t1; unsigned
long t2; unsigned
long pulse_width;
float cm; float
inches;

// Hold the trigger pin high for at least 10 us
digitalWrite(TRIG_PIN, HIGH);
delayMicroseconds(10);
digitalWrite(TRIG_PIN, LOW);

// Wait for pulse on echo pin while
(digitalRead( ECHO_PIN )==0 );

// Measure how long the echo pin was held high (pulse width)
// Note: the micros() counter will overflow after-70 min  t1=
micros ();
while (digitalRead(ECHO_PIN) == 1);
t2= micros ();  pulse_width = t2-t1;

// Calculate distance in centimeters and inches. The constants
//are found in the datasheet, and calculated from the assumed speed
```

```

// of sound in air at sea level (- 340m/s)
cm=pulse_Width / 58 ;    inches =
pulse_width/148.0;

// Print out results if
(pulse_width >MAX_DIST){
Serial.println("Out of range");
} else {
Serial.println("*****");
Serial.print("The Measured Distance in cm: ");
Serial.println(cm);

if( cm < 100 ){
    //while(true){
        Serial.println("Alert!!");
    //}
}
Serial.print("*****");
}

//wait at least 1000ms before next measurement
Delay(1000);
}

```

Output:

WOKWI

SAVE

SHARE

Docs

hc-sr04.ino

diagram.json

Library Manager

```

1 // Pins
2 const int TRIG_PIN = 7;
3 const int ECHO_PIN = 8;
4
5 // Anything over 400 cm (23200 us pulse) is "out of range"
6 const unsigned int MAX_DIST = 23200;
7
8 void setup() {
9
10 // The Trigger pin will tell the sensor to range find
11 pinMode(TRIG_PIN, OUTPUT);
12 digitalWrite(TRIG_PIN, LOW);
13
14 //Set Echo pin as input to measure the duration of
15 //pulses coming back from the distance sensor
16 pinMode(ECHO_PIN, INPUT);
17
18 // We'll use the serial monitor to view the sensor output
19 Serial.begin(9600);
20 }
21
22 void loop() {
23
24 unsigned long t1;
25 unsigned long t2;
26 unsigned long pulse_width;
27 float cm;
28 float inches;
29
30 // Hold the trigger pin high for at least 10 us

```

Simulation

00:00.466 58%

Editing Ultrasonic Distance Sensor

Distance: 83cm

The Measured Distance in cm : 84.14

Alert!!

Activate Windows

Go to Settings to activate Windows.

WOKWI

SAVE

SHARE

Docs

hc-sr04.ino

diagram.json

Library Manager

```

1 // Pins
2 const int TRIG_PIN = 7;
3 const int ECHO_PIN = 8;
4
5 // Anything over 400 cm (23200 us pulse) is "out of range"
6 const unsigned int MAX_DIST = 23200;
7
8 void setup() {
9
10 // The Trigger pin will tell the sensor to range find
11 pinMode(TRIG_PIN, OUTPUT);
12 digitalWrite(TRIG_PIN, LOW);
13
14 //Set Echo pin as input to measure the duration of
15 //pulses coming back from the distance sensor
16 pinMode(ECHO_PIN, INPUT);
17
18 // We'll use the serial monitor to view the sensor output
19 Serial.begin(9600);
20 }
21
22 void loop() {
23
24 unsigned long t1;
25 unsigned long t2;
26 unsigned long pulse_width;
27 float cm;
28 float inches;
29
30

```

Simulation

00:00.599 62%

The Measured Distance in cm : 227.10

Activate Windows

Go to Settings to activate Windows.

