

KICK

TRIG

DECAY

PITCH

BEND

TIME

WAVE

NOISE

ATTACK

PAN

VOLUME

OUT

DRUM 1

TRIG

DECAY

PITCH

BEND

ATTACK

FM INT

FM FREQ

WAVE

PAN

VOLUME

OUT

DRUM 2

TRIG

DECAY

PITCH

BEND

ATTACK

FM INT

FM FREQ

WAVE

PAN

VOLUME

OUT

MULTI

TRIG

DECAY

PITCH

BEND

ATTACK

PITCH 2

PITCH 3

HIGHPASS

PAN

VOLUME

OUT

SNARE

TRIG

DECAY REV

REVERB

DECAY N

NOISE

ATTACK

RESO

FILTER

PAN

VOLUME

OUT

HI HAT 1

TRIG

DECAY

FILTER

BEND

ATTACK

RESO

MIX

PITCH

PAN

VOLUME

OUT

HI HAT 2

TRIG

DECAY

FILTER

BEND

ATTACK

RESO

MIX

PITCH

PAN

VOLUME

OUT

CLAP

TRIG

DECAY REV

REVERB

CLAP

NOISE

RESO

FILTER

HIGHPASS

PAN

VOLUME

OUT