



Precitec Macro Documentation

04 Move Z Collimator with end of seam marker


■ Changelog

Date	Version	Autor	Tested on	Description
2022-06-21	A	Wre	5.16.16	New documentation

■ Description

	<p>Moves Z collimator to input target position when X/Y position is reached.</p> <p>I1: Z Position in mm</p> <p>I2: Position reached (e.g. from Macro "04 Move Scanner to Position")</p>
--	---

■ Macro structure



■ Parameter

NAME	VALUE	Description	UserLevel
00 Defocus → Value	0	Defocus value for the ScanMaster (in mm)	Operator