



Precitec Macro Documentation

04 Load Figure from File


■ Changelog

Date	Version	Autor	Tested on	Description
2022-04-13	A	Wre	5.16.0	New documentation
2022-06-09	B	Wre	5.16.16	UserLevels Bug fixed
2022-06-24	C	Wre	5.16.16	Changed order of stretching and rotation

■ Description

	<p>Loads figure from file. Previews the contour in the camera image and outputs it.</p> <p>I1: Image I2: Scanner Target X I3: Scanner Targe Y O1: Contour</p>
--	---

■ Macro structure



■ Parameter

NAME	VALUE	Description	UserLevel
00 ContourFromFile → WeldingFigure name	0	Number of Welding figure to weld.	Operator
01 Rotation angle → Number	0	Angle in degrees by which the figure should be rotated.	Operator
02 Stretch in X → Number	1	Factor by which the figure should be stretched in X-direction.	Operator
03 Stretch in Y → Number	1	Factor by which the figure should be stretched in Y-direction.	Operator

04 SeamWeldingResult → Verbosity	Maximal	Visibility of the Preview	Operator
--	---------	---------------------------	----------