



Precitec Macro Documentation

04 Load Figure from File dynamic


■ Changelog

Date	Version	Autor	Tested on	Description
2022-06-14	A	Wre	5.16.16	New documentation
2022-06-24	B	Wre	5.16.16	Changed order of stretching and rotation

■ Description

	<p>Loads figure from file. Figure will be rotated and stretched according to the inputs. Previews the contour in the camera image and outputs it.</p> <p>I1: Image</p> <p>I2: Scanner Target X</p> <p>I3: Scanner Target Y</p> <p>I4: Rotation angle</p> <p>I5: Stretching factor X</p> <p>I6: Stretching factor Y</p> <p>O1: Contour</p>
--	--

■ Macro structure



■ Parameter

NAME	VALUE	Description	UserLevel
00 ContourFromFile → WeldingFigure name	0	Number of Welding figure to weld.	Operator
04 SeamWeldingResult → Verbosity	Maximal	Visibility of the Preview	Operator