


## Precitec Macro Documentation

### 04 Weld Figure from File


#### ■ Changelog

Date	Version	Autor	Tested on	Description
2022-04-13	A	Wre	5.16.0	New documentation
2022-06-09	B	Wre	5.16.16	UserLevels Bug fixed
2022-06-24	C	Wre	5.16.16	Changed order of stretching and rotation

#### ■ Description

 <p>G02 Weld Figure from File</p>	<p><b>Choose a Figure from File. Figure will be welded. Possibility to rotate and stretch figure.</b></p> <p>I1: Scanner X</p> <p>I2: Scanner Y</p> <p>I3: Image</p> <p>I4: Position reached (e.g. from Macro "04 Move Scanner to Position" or other trigger signal)</p>
--	--

## ■ Macro structure



## ■ Parameter

NAME	VALUE	Description	UserLevel
<b>00 ContourFromFile → WeldingFigure name</b>	0	Number of Welding figure to weld.	Operator
<b>01 Rotation angle → Number</b>	0	Angle in degrees by which the figure should be rotated.	Operator
<b>02 Stretch in X → Number</b>	1	Factor by which the figure should be stretched in X-direction.	Operator
<b>03 Stretch in Y → Number</b>	1	Factor by which the figure should be stretched in Y-direction.	Operator