


Precitec Macro Documentation

04 Weld Figure from File dynamic


■ Changelog

Date	Version	Autor	Tested on	Description
2022-06-14	A	Wre	5.16.16	New documentation
2022-06-24	B	Wre	5.16.16	Changed order of stretching and rotation

■ Description

 <p>Weld Figure from File dynamic</p>	<p>Choose a Figure from File. Figure will be welded. Rotation and stretching of the figure dynamically according to the inputs.</p> <p>I1: Image</p> <p>I2: Scanner X</p> <p>I3: Scanner Y</p> <p>I4: Rotation angle</p> <p>I5: Stretching factor X</p> <p>I6: Stretching factor Y</p> <p>I7: Position reached (e.g. from Macro "04 Move Scanner to Position" or other trigger signal)</p>
--	---

■ Macro structure



■ Parameter

NAME	VALUE	Description	UserLevel
00 ContourFromFile → WeldingFigure name	0	Number of Welding figure to weld.	Operator