




Precitec Macro Documentation

04 Move Scanner to Position


■ Changelog

Date	Version	Autor	Tested on	Description
2022-04-13	A	Wre	5.16.0	New documentation
2022-06-09	B	Wre	5.16.16	UserLevels Bug fixed

■ Description

	<p>Moves Scanner to Input Position and gives out a Signal when this Position is reached.</p> <p>I1: Scanner X Position</p> <p>I2: Scanner Y Position</p> <p>I3: Image</p> <p>O1: Position reached</p>
---	--

■ Macro structure



■ Parameter

NAME	VALUE	Description	UserLevel
00 Distance < threshold? → Value	10	Threshold value for the distance between target and actual scanner position. If Threshold is too low, scanner might never reach that accuracy. Value must be entered in μm .	GroupLeader